 <small>A Phoenix Mecano Company</small>	Issue Department:	Date:	2019.01.07
	System Instruction	Author:	
	Instruction of RF39		
		Edition:	V0.0
Page 1 of 4			


Instruction of RF39

1 Key description


1.1 appearance





Figure 1 button of remote


 <small>A Phoenix Mecano Company</small>	Issue Department:	Date:	2019.01.07
	System Instruction	Author:	
	Instruction of RF39		
		Edition:	V0.0
Page 2 of 4			


2 Key description


 **HEAD UP:** Press and hold head up button, head actuator moves out, stop when released.


 **HEAD DOWN:** Press and hold head down button, head actuator moves out, stop when released.

 **FOOT UP:** Press and hold foot up button, foot actuator moves out, stop when released.

 **FOOT DOWN:** Press and hold foot down button, foot actuator moves out, stop when released.

 **FLAT:** Press and hold flat button, the bed goes flat.

 **ZG:** Click zeroG button, the bed moves to zeroG position, press and hold zeroG button for 5s, until backlight flashes, the control set the current position as zeroG position.

 <small>A Phoenix Mecano Company</small>	Issue Department:	Date:	2019.01.07
	System Instruction	Author:	
	Instruction of RF39		
			Page 3 of 4



M:Click M button, the bed moves to M position, press and hold M button for 5s, until backlight flashes, the control set the current position as M position.



ANTI SNORE:Click antisnore button, the bed moves to antisnore position, press and hold antisnore button for 5s until backlight flashes, the control set the current position as antisnore position.



LIGHT:Click FLASH LIGHT button, open or close flash light.

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ISED RSS Warning:

This device complies with Innovation, Science and Economic Development Canada licence exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED RF exposure statement:

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement.

Le matériel est conforme aux limites de dose d'exposition aux rayonnements énoncés pour un autre environnement. ce dispositif a été évalué à satisfaire l'exigence générale de l'exposition aux rf.



A Phoenix Mecano Company

Issue Department:

System Instruction

Date:

2019.01.07


Author:

Instruction of RF39

Edition:

V0.0

Page 4 of 4



FCC ID: PCU-RF39
IC: 21319-RF39