


# Samsung Bluetooth Keyboard Quick Guide



# Keyboard Hardware



**1) Bluetooth LED**

In Power On/Off, LED lights on , In Paring Mode LED blinks

**2) Caps Lock LED**

Caps Lock key is pressed, this LED toggled.

**3) FN key**

Some keys have blue prined key together. That Blue key is operated, FN key is pressed at the same time

**4) Power button**


Power button have 2 kins of function.

1. Power On/Off – Press Power button for 2 seconds
2. Paring – Press Power Button for 4 seconds

**5) Battery Cover**

Open – slide into left side

Close - slide inti right side



# Pairing flow

## 1) Battery inserting

Remove Battery Cover and then insert Two AAA batteries into the battery compartment. Make sure to properly orient the positive(+) and negativ(-) ends as a specified by the Marks in the battery compartment


## 2) Power ON

Press Power button for 2 seconds, and then see LED lights On.


## 3) Enter Pairing Mode

Press Power button for 4 seconds, and then see LED blinks. Pairing Mode duration Time is 2 mins, if Pairing failed within 2 mins, try again to press Power button for 4 secs.


#### 4) Connecting to DECK TOP PC




1) Control panel-> hardware & sound



2) Add Bluetooth Device



3) Search Bluetooth Device



4) Select Samsung Keyboard and then Next


## 5) DECK TOP PC에 연결하기



5) Input digits and then Type "Enter"



6) Check samusng keyboard device adding



7) Check in Device list.

## ◆ Feature

Frequency	2402MHz ~ 2480 MHz
Temperature	-20℃ ~ +50℃
Voltage	DC 3V ( AAA * 2EA)
PC interface	Bluetooth V2.0
Working distanced	15m Max.
Size	294 x 133 x 15.4 mm

- FCC (Federal Communications Commission)
- 
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
- This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
- However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technical for help.
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technical for help.
  -
- **WARNING:** *This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.*
- This device complies with Part 15 of the FCC's Rules. Operation is subject to the following two Conditions:
  1. This device may not cause harmful interference, and
  2. This device must accept any interference received, including interference that may cause undesirable operation.
- 
- 
- 
- CE
- Hereby, **Oki Electric Technology (Kunshan) Co., Ltd** declares that these models are in compliance with the essential requirements and other relevant provisions of directive 1999/5/EC.