


4180075 MANUAL



1. Antenna Model : 4180075
2. Technology: SST 2-WAY
3. Max Range : 1800M
4. LED : status indication
5. Button: setup key
- 6 Connect to Host (To plug Weblink or RF-Decoder/Antenna)

pin1- Rx (Data from antenna, 0-5 Volts)

pin2- Tx (Data from Host, 0-5 Volts)

pin3- GND (Ground from Host)

pin4- 12V (Power from Host, 12V)

The Control Center, typically located on the upper part of the front windshield. It consists of:

The In-vehicle system antenna.

The Status LED, as a visual indicator of the system's status.

The Control button, for placing the system into Valet Mode and to perform the Emergency Override operation.

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 25cm between the radiator and any part of your body.

FCC Statement

This device complies with FCC Rules part 15. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference that may be received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modification could void the user's authority to use the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.