

## Handset Functions

### Calling Abroad from Japan

Enter number → **[\*]** → **Int'l dial assist**

→ A country/region → Voice Calls: **[☑]** / Video Calls: **[☑]**

- **[☑]** to end call

For more details, visit:

[http://mb.softbank.jp/mb/en/global\\_service/](http://mb.softbank.jp/mb/en/global_service/)

### Global Roaming

Global Roaming Service may require sign up. Details and applications are available online:

[http://mb.softbank.jp/mb/en/global\\_service/](http://mb.softbank.jp/mb/en/global_service/)

### Network Mode

**[●]** → **Settings** → **International Call** →

**Select Network** → **Automatically** or **Manually** (**3G/GSM**, **3G** or **GSM**)

### Calling within the Same Country

Enter number → Voice Calls: **[☑]** / Video Calls: **[☑]**

### Calling Japan

Set **Auto Assist** (**[●]** → **Settings** → **International Call** → **Int'l Dial Assist**) to **ON** and **Japan** beforehand.

Enter number → Voice Calls: **[☑]** / Video Calls: **[☑]** → **Dial**

### Calling Other Countries

Enter number → **[\*]** → **Int'l dial assist**

→ A country/region → Voice Calls: **[☑]** / Video Calls: **[☑]**

- Omit the first **0** from area code, except when calling Italy.

International Code is set to **0046010** by default. The number can be changed if required.

### Answering a Call



- **[☑]** to end call

### Answer Phone

Record messages on handset when unable to answer incoming calls.

### Activating

Press and hold **[CLR]**

- To cancel: Press and hold **[CLR]** again.

### Playing Messages

In Standby, **[☑]** to select indicator → A message

### Deleting Messages

**[●]** → **Tools** → **Sound Recorders** → **Voice Call Data** or **Video Call Data** → Highlight a message → **[\*]**

→ **Erase this** → **YES**

Answer Phone is unavailable when handset is off, out-of-range or in Emission OFF Mode.

### Voice Mail

#### Activating Voice Mail

**[●]** → **Settings** → **Call Settings**

→ **Voice Mail/Call Fwding** → **Voice Mail ON**

→ **Ringer ON** or **Ringer OFF** → Ring time

(for **Ringer ON**) → **YES** → **[●]**

#### Checking Voice Mail Messages

In Standby, **[☑]** to select indicator → **YES**

→ Follow voice guidance

- To switch to English voice guidance, press **[2]** **[1]** **[2]** while Japanese voice guidance is playing.

### Text Entry

#### Toggle Entry Modes

In text entry window, **[☑]** to toggle input modes

(or press **[\*]** → **1byte character** or **2bytes character** to toggle single/double-byte) → Enter text

#### Character Input Mode

漢	Kanji (hiragana) input mode
カ	Katakana input mode
abc	Alphanumerics input mode
123	Number input mode

#### Example: Entering "no"

In text entry window, **[☑]** → **abc½** → **[6]** **[6]** → **[☑]**  
→ **[6]** **[6]** **[6]** → **[●]**

### Phone Book

#### Phone Book Entry Items

##### Phone Number

Save up to four entries in Phone Book; two in USIM Card Phone Book.

##### E-mail Address

Save up to three entries in Phone Book; one in USIM Card Phone Book.

#### Saving to Phone Book

Press and hold **[☑]** → Enter Last name → Enter First name

→ An item → Enter information → **[☑]**

### Save Settings

Select Phone Book memory for new entries.

**[●]** → **Phone Book** → **Settings** → **Save Settings** → **Phone**, **USIM** or **Ask Every Time**

- Select **Ask Every Time** to select target each time you save an entry.

#### Editing Phone Book Entries

**[☑]** → An entry → **[☑]** → An item → Edit → **[☑]** → **YES\***

\* For USIM Card Phone Book, select **Overwrite** or **Add**.

#### Making Calls from Phone Book

**[☑]** → **[☑]** to select a page of the required reading

→ An entry → **[☑]** → A number

### Digital TV

#### Initial Setup

**[●]** → **TV** → **Channel Setting** → **[●]** → **YES**

→ **Select Area** → A region → A prefecture → **YES**

#### Watching TV

**[☑]** → **[●]** → **YES** →

**[0]** - **[9]**, **[\*]**, **[#]** or

**[☑]** to select a channel

• **[☑]** to adjust volume

• To exit: **[☑]** → **YES**



#### Recording Programs

Activate TV → **[●]** → **[●]** to stop recording

- Program is saved to microSD Card.

## Handset Functions

### Camera

#### Capturing Still Images

→ Frame subject → → → Select a folder to save →

#### Recording Videos

Press and hold → Frame subject → → → → Select a folder to save →

### Music Player

#### Playing Music

→ **Music Player** → **Player**  
→ A category → A file  
• To stop playback:



#### Adding Play Lists

→ **Music Player** → **Player** → **Play List** →   
→ **Create play list** → A category → Check files →   
→ Enter a name

#### Using Play Lists

→ **Music Player** → **Player** → **Play List** → A Play List  
→ A file

### Managing Files

#### Opening Files

→ **Data Folder** → A folder → A file

#### Formatting microSD Card

→ **Tools** → **microSD Backup** →   
→ **microSD format** → Enter Phone Password (4 to 8 digits)  
→ **YES**

### Messaging

#### S! Mail/SMS

##### S! Mail

Exchange text messages with e-mail compatible handsets, PCs, etc.; attach image/sound files etc.

##### SMS

Exchange short text messages with SoftBank handsets.

#### Customizing Handset Address

Change your handset mail address (alphanumeric before @) to reduce the risk of receiving spam.

→ **Settings** → **Custom Mail Address**  
→ Follow onscreen instructions

#### Sending S! Mail & SMS

→ **Create New** (**Create New SMS** for SMS)  
→ **<Add Address>** → **Phone Book** → An entry →   
→ A number/mail address → **<Add Subject>** → Enter subject → **<Add Attachment>** → A folder → A file  
→ **<Input Text>** → Enter text →   
• Subject and attachment fields are not available for SMS.

#### Receiving S! Mail & SMS

In Standby, to select indicator → A folder → An unread message

### Yahoo! Keitai

#### Yahoo! Keitai Main Menu

→ **Y! Menu** → **English** → A menu item

#### PC Site Browser

→ **Yahoo! Keitai** → **PC Site Browser**  
→ **Homepage** → → A menu item

### Software Update

#### Precaution

Fully charge battery beforehand.

#### Updating Software

→ **Settings** → **Phone Settings** → **Software Update**  
→ **Software Update** → → Follow onscreen instructions

### Specifications

Weight (including battery)	XXX g*
Dimensions (closed)	XX x XXX x XX.X mm*
Standby Time (closed)	3G: 460 hours* GSM: 240 hours*
Talk Time	3G: 180 minutes* Video Call: 120 minutes* GSM: 180 minutes*
TV Reception Time	Normal Mode: 5.5 hours* ECO Mode: 7.1 hours*
Charging Time	AC Charger: 100 minutes* In-Car Charger: 100 minutes*
Maximum Output	3G: 0.25 W GSM: 2.0 W

\* Approximate value

• Values above were calculated with battery installed.

## General Notes

### Electromagnetic Waves

- **For body worn operation, this mobile phone has been tested and meets RF exposure guidelines when used with an accessory containing no metal and positioning the handset a minimum 15 mm from the body. Use of other accessories may not ensure compliance with RF exposure guidelines.**

### FCC Notice

- **This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:**
  - (1) This device may not cause harmful interference, and
  - (2) this device must accept any interference received, including interference that may cause undesired operation.
- **Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.**

### FCC RF Exposure Information

Your handset is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless handsets employs a unit

of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. The tests are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model handset when tested for use at the ear is 0.648 W/kg and when worn on the body, as described in this First Step Guide, is 0.452 W/kg. Body-worn Operation; This device was tested for typical body-worn operations with the back of the handset kept 1.5 cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5 cm separation distance between the user's body and the back of the handset. The use of beltclips, holsters and similar accessories should not contain metallic components in its assembly.

The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. The FCC has granted an Equipment Authorization for this model handset with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines. SAR information on this model handset is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/ea/> after searching on FCC ID UCE209016A.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) website at <http://www.phonefacts.net>.

### European RF Exposure Information

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg and the highest SAR value for this device when tested at the ear was 0.483 W/kg\*. As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this First Step Guide\*\*. In this case, the highest tested SAR value is 0.467W/kg. As SAR is measured utilizing the devices highest transmitting power the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network. The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a hands-free device to keep the mobile phone away from the head and body.

\*The tests are carried out in accordance with international guidelines for testing.

\*\* Please see Electromagnetic Waves on page 118 for important notes regarding body worn operation.

### Declaration of Conformity

# CE0168

**We, Panasonic Mobile Communications Development of Europe Ltd., declare that SoftBank 832P conforms with the essential and other relevant requirements of the directive 1999/5/EC.**

**A declaration of conformity to this effect can be found at**

**<http://panasonic.net/pmc/support/index.html>**

- **This product is only intended for sale in Japan.**
- **Compliance to the European RTTE directive applies to: SoftBank 832P handset, Battery (PMBAQ1) and AC Charger (SoftBank ZTDAA1).**

# Support

## Customer Service

<b>SoftBank Customer Centers</b> From a SoftBank handset, dial toll free at <b>157</b> (General Information) <b>113</b> (Customer Assistance)	<b>SoftBank Global Call Center</b> From outside Japan, dial <b>+81-3-5351-3491*</b> (International charges will apply.) * Call immediately if handset/USIM is lost or stolen while outside Japan.
--	---

■ Call these numbers toll free from landlines.

Subscription Area	Service Center	Toll Free Number
Hokkaido, Aomori, Akita, Iwate, Yamagata, Miyagi, Fukushima, Niigata, Tokyo, Kanagawa, Chiba, Saitama, Ibaraki, Tochigi, Gunma, Yamanashi, Nagano, Toyama, Ishikawa, Fukui	General Information	0088-240-157
	Customer Assistance	0088-240-113
Aichi, Gifu, Mie, Shizuoka	General Information	0088-241-157
	Customer Assistance	0088-241-113
Osaka, Hyogo, Kyoto, Nara, Shiga, Wakayama	General Information	0088-242-157
	Customer Assistance	0088-242-113
Hiroshima, Okayama, Yamaguchi, Tottori, Shimane, Tokushima, Kagawa, Ehime, Kochi, Fukuoka, Saga, Nagasaki, Oita, Kumamoto, Miyazaki, Kagoshima, Okinawa	General Information	0088-250-157
	Customer Assistance	0088-250-113

## Emergency Numbers

- Police..... **110**
- Fire & Ambulance..... **119**
- Coast Guard..... **118**

## More Information

- **Handset User Support**  
Via Yahoo! Keitai Main Menu: From above search field, select  
**メニューリスト → English → User Support.**
- **Online English Manual**  
<http://mb.softbank.jp/mb/r/support/832p/>  
May be unavailable at purchase. Call Customer Service or try later.

## First Step Guide

## SoftBank 832P 使い方ガイド

2009年5月 第1版

ソフトバンクモバイル株式会社

●  
ご不明な点はお求めになられた  
ソフトバンク携帯電話取扱店にご相談ください。

●  
機種名 : SoftBank 832P

製造元 : パナソニック モバイルコミュニケーションズ株式会社

## ご注意

- 本書の内容の一部でも無断転載することは禁止されております。
- 本書の内容は将来、予告無しに変更することがございます。
- 本書の内容については万全を期しておりますが、万一ご不審な点や記載漏れなどお気づきの点がございましたらお問い合わせ先（P.106）までご連絡ください。
- 乱丁、落丁はお取り替えいたします。

この印刷物は、再生紙を使用しています。