PARKER HANNIFIN CORPORATION QUICK COUPLING DIVISION 8145 LEWIS ROAD MINNEAPOLIS, MN 55427



Parker Sensor Operation and Specification

Operation:

Press button once, sensor powers on into broadcast Mode.

- Green/Red light blinks.
- Sensor advertises for 2 minutes looking for a connection before sensor powers off automatically.

After sensor is connected with App, sensor will then blink solid green light every 5 seconds.

• Sensor starts transmission data to App after connection.

Sensor can be shut down by holding the sensor button for 3 seconds

- Sensor will flash red LED two time upon successful shutdown and power off.
- Sensor will flash green two times and return to the current state if the button is not held for a long enough period of time.

When sensor disconnects with iOS device unexpectedly under below events, sensor will go into broadcast mode for 2 minutes looking to reconnect.

- Turn off the Bluetooth radio for iOS device
- Force shut down app
- Take sensors out of range of iOS device
- Shut off iOS device

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA).

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.