

Automation & Control  
**Modicon® M340™ PLC**  
**Automation Platform**  
*Unity™ Software*

Catalog  
June

07



*Simply Smart !*

[us.telemecanique.com](http://us.telemecanique.com)



This international site ([www.us.telemecanique.com](http://www.us.telemecanique.com)) allows you to access all the Telemecanique products in just 2 clicks via comprehensive range data-sheets, with direct links to:

- Complete library: technical documents, catalogs, certificates, FAQs, brochures...
- Selection guides from the e-catalog.
- Product discovery sites and their Flash animations.

You will also find illustrated overviews, news to which you can subscribe, a discussion forum, the list of country contacts...

To live automation solutions every day!



### Flexibility

- Interchangeable modular functions, to better meet the requirements for extensions
- Software and accessories common to multiple product families



### Compactness

- High functionality in a minimum of space
- Freedom in implementation

### Ingenuity

- Auto-adapts to its environment, "plug & play"
- Application functions, control, communication and diagnostics embedded in the products
- User-friendly operation either directly on the product or remotely



### Openness

- Compliance with field bus, connection, and software standards
- Enabling decentralized or remote surveillance via the web with Transparent Ready® products

### Simplicity

- Cost effective "optimum" offers that make selection easy for most typical applications
- Products that are easy to understand for users, electricians and automation specialists
- User-friendly intuitive programming

---

**Modicon M340 hardware and Unity™ software, a naturally productive pair . . . . . 2****Chapter 1  
Modicon M340 processors, racks & power supplies**

■ Processor modules . . . . .	1/4
■ Power supply modules . . . . .	1/10
■ Single rack configuration . . . . .	1/14

**Chapter 2  
Input/output modules**

■ Discrete I/O modules . . . . .	2/6
■ Analog I/O modules and programmable process control . . . . .	2/24
■ IP 67 and IP 20 distributed I/O modules . . . . .	2/34
■ Counter modules and Motion Function Blocks . . . . .	2/36

**Chapter 3  
Communication**

■ Ethernet TCP/IP network - Transparent Ready® Services . . . . .	3/4
■ CANopen machine and installation bus . . . . .	3/38
■ Modbus® communication system and character mode serial link . . . . .	3/42

**Chapter 4  
Unity™ software**

■ Unity™ software . . . . .	4/4
-----------------------------	-----

**Chapter 5  
Connection interfaces**

■ Advantys™ Telefast® ABE7 pre-wired I/O system . . . . .	5/8
■ Phaseo Universal range of regulated switch mode power supplies . . . . .	5/22
■ HMI Operator dialog terminals . . . . .	5/34

**Chapter 6  
Services**


■ Technical information	
□ Standards, certifications and environment conditions . . . . .	6/2
□ Automation product certifications . . . . .	6/6
□ Power consumption table . . . . .	6/8
■ Index	
□ Product reference index . . . . .	6/9

Advantys™, Altivar®, Atrium™, Concept™, ConneXium™, FactoryCast™, Fipio®, Fipoway®, Lexium®, Magelis®, Modbus®, Modbus Plus™, Modicon®, M340™, Modsoft®, Momentum™, Monitor Pro™ OsiTrack™, Phaseo®, PL7™, PowerSuite™, Premium™, Preventa™, ProWORX™, Quantum™, Tego®, Telefast®, Telemecanique®, TeSys®, Transparent Ready®, Twido®, TwidoSuite™, Unity™, Unity Pro™, and Vijeo™, are trademarks or registered trademarks of Schneider Electric. Other trademarks used herein are the property of their respective owners.

## *A naturally productive pair*

The family of Modicon PLC platforms associated with Unity software offers you ingenuity, flexibility and openness to ever-increasing productivity.

**Modicon® M340™ PLC** concentrates power and innovation, offering the optimum response to the needs of machine manufacturers. It is also the ideal companion for **Modicon® Premium™ PLC** and **Modicon® Quantum™ PLC** to satisfy the need for automation of industrial processes and infrastructures.



## **Modicon® automation platforms**

### *Modicon® M340™ PLC, the ideal solution for machine specialists*

Robust, powerful and compact, the new Modicon M340 PLC is the ideal solution for machine manufacturers in applications such as secondary packaging, materials handling, textiles, printing, food processing, woodworking machines, ceramics, etc. The integration of Altivar® and Lexium® adjustable speed drives, Magelis® display units and Preventa™ safety modules has been enhanced to simplify the setup and use of Telemecanique® solutions.

Modicon M340 PLC is also the ideal companion for Modicon Premium PLC and Modicon Quantum PLC to meet the demand for automation of industrial processes and infrastructures, at the heart of Transparent Ready® architectures.

### *Modicon® Premium™ PLC, the optimum solution for the manufacturing industry and infrastructures*

Modicon Premium PLC stands out as the specialist in complex machines and manufacturing processes. Its level of performance when processing Boolean, numeric instructions and instructions on tables make it the market preference. Thanks to its ability to integrate distributed architectures, Modicon Premium PLC provides ideal solutions for infrastructure projects, particularly in the water and transport sectors.

In addition, Modicon® Atrium™ PLC, the version of Modicon Premium PLC in PCI format, offers a "PC Based" alternative.


### *Modicon® Quantum™ PLC, the specialist in critical systems in the process industries and infrastructures*

Capable of sophisticated distributed architectures, with an extensive catalog of modules complemented by several technological partnerships in the context of the Collaborative Automation program ♦, Modicon Quantum PLC offers a perfect response to the needs of continuous or semi-continuous industrial processes, and control of large infrastructure sites.

Capitalizing on more than 25 years' experience in the field of redundancy, Modicon Quantum PLC is the ideal solution for applications requiring very high levels of availability. The offer is therefore suitable for critical applications such as petrochemicals, metallurgy, cement, energy, tunnels and airports.

( \*) Smarter and more intelligent, yet even easier to use.

♦ A globally run program, to develop and offer solutions to our customers



### Unity™ software

#### *An organizer environment for Modicon® platforms*

Unity Pro™ software is the common programming, debugging and run-time software for Modicon M340, Premium and Quantum PLCs, and Atrium™ slot PLCs.

Meeting the requirements of an IEC 61131-3 program, Unity Pro software is based on the acknowledged standards of PL7™ and Concept™ software. It opens the doors of a complete set of new functions for increased productivity:

- State-of-the-art functionality
- Optimum standardization enabling re-use of developments
- Numerous tools for testing the program and improving system operation
- New integrated diagnostic services

Migration of existing applications is provided for. This maximizes your software investment, reduces training costs, and offers unrivaled potential for development and compatibility.

The Unity software catalog includes specialist software for even better productivity:

- Openness to developments in C language or in VBA (Visual Basic for Applications)
- Design and generation of batch/process applications with PLC/HMI integration



### Transparent Ready® Services

#### *Naturally communicative*

Based on Ethernet TCP/IP and Web technologies, the Modicon Transparent Ready automation platforms offer solutions to optimizing performances in electrical distribution, automation and control.

Modicon controllers offers you the best of Ethernet: Web servers, sending e-mail, direct database access, device synchronization, and I/O distribution.

### Collaborative Automation Partner Program



### Collaborative Automation

#### *The new world of automation*

- Rather than opting for proprietary systems, Telemecanique has adopted market standards such as IEC languages, Ethernet TCP/IP, Modbus IDA, XML, OPC, and IT standards.
- Partnerships with recognized leading hardware and software specialists have been developed within the scope of the Collaborative Automation Partner Program, in an effort to share technology more effectively.
- Offers you the ability to design the best solution without compromising on ease of integration.



Modicon M340 platform

### New Modicon® M340™ platform

Equipped with enhanced memory and functionality, this midrange PLC will give your applications new capabilities. Designed to operate in total synergy with other Telemecanique® devices, the Modicon M340 PLC represents pure concentrated power.

#### Performance

- 7 K instructions/ms
- 4 Mb of program memory
- 256 Kb of data

#### Compact design

- 3 communication ports integrated in the processor
- H x W x D = 100 x 32 x 93 mm.
- High-density discrete I/O modules with 64 channels in a 32 mm wide format.

#### Communication ports are integrated

- CANopen machine and installation bus
- Ethernet TCP/IP network - Transparent Ready® services
- Modbus® serial link or character mode
- Remote access via STN, GSM/GPRS, Radio or ADSL

#### Expert

- Counter modules with ready-to-use functions
- Function block library dedicated to motion control. MFB (*Motion Function Blocks*) to the PLCopen standard
- Advanced library of process control blocks oriented towards control of machinery


#### Innovative

- USB port as standard
- Embedded Web server
- Recipe file management via FTP protocol
- "Plug and Load" SD memory card
- No batteries

#### Ruggedness

- Rack architecture enabling hot swapping of modules during operation (*Hot-Swap*)
- Exceeds the standards in terms of shock, vibration, temperature, altitude and withstand to electrical interference.

As standard, Modicon® M340™ PLC has exclusive services normally reserved for PLCs in a higher category.

**Unity™ software productivity***All-in-one, easy-to-use software*

Unity Pro software fully exploits the advantages of the graphic and contextual interfaces of Windows® XP and Windows® 2000 :

- Direct access to tools and information
- 100% graphics-based configuration
- Customizable toolbar and icons
- Advanced drag & drop and zoom functions
- Integrated diagnostic window

*All the advantages of standardization*

Unity Pro software provides a complete set of functions and tools for applying the application structure to the structure of the process or machine. The program is divided into hierarchically-organized function modules containing:

- Program sections
- Animation tables
- Operator screens
- Hyperlinks

Basic functions that are used repeatedly can be encapsulated in user function blocks (DFBs) in an IEC 61131-3 language.

*Time savings from re-use of modules*

Once they have been tested and qualified, your standardized application code reduce development and installation times on site, thereby optimizing quality and reducing lead times:

- Function modules that can be reused in the application or between projects by XML import/export.
- Function blocks instantiated by dragging and dropping them from the library.
- Instances can be updated automatically to reflect modifications made in the library (if this option is selected by the user)

*Maximum quality assured*

The integrated PLC simulator faithfully reproduces the behavior of the target program on a PC. All the debugging tools can be used during simulation, to enhance quality before installation:

- Step-by-step program execution
- Breakpoint and watchpoint
- Real-time animations for displaying the state of the variables and the logic during operation

*Reduced downtime*

Unity Pro software features a DFB library for application diagnostics. Integrated into the program, these DFBs can be used (depending on their function) to monitor permanent conditions relating to security and the development of a process over time. A display window provides a clear display of all system and application faults in chronological order (date-stamped at source). From this window, you can simply click to access the editor for the program in which the error occurred (search for missing conditions at source).

Online modifications can be grouped consistently in local mode on a PC and transferred directly to the PLC in a single operation in order to take effect in the same scan cycle. A complete range of functions provide the basis for precision control of your operations, to minimize downtime:

- Log of operator actions on Unity Pro software in a protected file
- User profile and password protection
- Integrated graphic runtime screens



## Modicon® M340™ processors

■ Processor modules	
□ Presentation, description	1/4
□ Memory structure	1/6
□ Characteristics	1/8
□ References	1/9
■ Power supply modules	
□ Presentation, description	1/10
□ Functions	1/11
□ Characteristics	1/12
□ References	1/13
■ Single-rack configuration	
□ Presentation, description	1/14
□ Functions	1/14
□ References	1/15
□ Dimensions, mounting	1/15

## Modicon M340 platform for Unity Pro™ software offer

## BMX 34 10 Standard processor



<b>Racks</b>	Number of racks Max. number of slots (excluding power supply module)	1 (4, 6, 8 or 12 slots) 12
<b>Inputs/Outputs</b>	In-rack discrete I/O (1) In-rack analog I/O (1) Distributed I/O	512 channels (modules with 8, 16, 32 or 64 channels) 128/66 channels (2) (modules with 2, 4, 6 or 8 channels) Limited depending on the type of medium: Over Ethernet TCP/IP network via network module (63 devices with I/O Scanning function), over Modbus® serial link (32 devices)
<b>In-rack application-specific channels</b>	Max. number of channels (counter and serial link) Counter (1) Motion control  Process control, programmable loops	20 2-channel (60 kHz) or 8-channel (10 kHz) modules – Process control EFB library
<b>Integrated communication ports</b>	Ethernet TCP/IP network CANopen Master machine and installation bus Serial link USB port	– – 1 in RTU/ASCII Modbus® communication master/slave mode or in character mode (non-isolated RS232/RS485, 0.3...19.2 Kbps) 1 programming port (PC terminal)
<b>Communication modules</b>	Max. number of networks (1) Ethernet TCP/IP network	1 (BMX NOE 0110/0110 network module) 1 x 10BASE-T/100BASE-TX (Modbus TCP/IP, BOOTP/DHCP, FDR, Global Data, I/O Scanning, web server (standard, class B30 or configurable, class C30))
<b>Internal memory capacity</b>	Internal user RAM Program, constants and symbols Located/unlocated data	2,048 Kb 1,792 Kb 128 Kb
<b>Memory card capacity (on processor)</b>	Backup of program, constants and symbols Hosting and display of user web pages File storage	8 Mb as standard – (3) –
<b>Application structure</b>	Master task Fast task Event tasks	1 1 32
<b>No. of instructions executed per ms</b>	100% Boolean 65% Boolean + 35% fixed arithmetic	5.4 K instructions/ms 4.2 K instructions/ms
<b>Rack power supply</b>		24 V $\perp\!\!\!\perp$ isolated, 24...48 V $\perp\!\!\!\perp$ isolated or 100...240 V $\sim$ depending on power supply module
<b>Modicon M340 processor</b>		<b>BMX P34 1000</b>
<b>Page</b>		1/9

(1) The maximum values for the number of discrete I/O, analog I/O and counter channels and the number of networks are not cumulative (they are limited by the number of slots in the single-rack configuration, i.e. 11 maximum).

(2) The first value is applied to a multi-rack configuration (not available). The second value corresponds to the physical limit with a single-rack configuration.

(3) User web pages with FactoryCast™ web server module BMX NOE 0110 (16 Mb available).

## BMX 34 20 Performance processors

1



1 (4, 6, 8 or 12 slots)

12

1,024/704 channels (2) (modules with 8, 16, 32 or 64 channels)

256/66 channels (2) (modules with 2, 4, 6 or 8 channels)

Limited depending on the type of medium: on CANopen bus (63 devices), on Ethernet TCP/IP network via network module (63 devices with I/O Scanning function), on a Modbus® serial link (32 devices)

36

2-channel (60 kHz) or 8-channel (10 kHz) modules

MFB (Motion Function Blocks) library (control of drives or servo drives on the CANopen bus)

–

MFB (Motion Function Blocks) library (control of drives or servo drives on the CANopen bus)

Process control EFB library

–

1 x 10BASE-T/100BASE-TX (Modbus TCP/IP, BOOTP/DHCP, FDR, class B10 standard web server)

1 (63 slaves, 50...1,000 Kbps, class M20)

–

1 (63 slaves, 50...1,000 Kbps, class M20)

1 in RTU/ASCII Modbus master/slave mode or in character mode (non-isolated RS232/RS485, 0.3...19.2 Kbps)

–

1 programming port (PC terminal)

1 (BMX NOE 0100/0110 network module)

1 x 10BASE-T/100BASE-TX [Modbus TCP/IP, BOOTP/DHCP, FDR, Global Data, I/O Scanning, web server (standard, class B30 or configurable, class C30)]

4,096 Kb

3,584 Kb

256 Kb

8 Mb as standard

– (3)

16 Mb (with optional card BMX RMS 008MPF)

1

1

64

8.1 K instructions/ms

6.4 K instructions/ms

24 V ... isolated, 24...48 V ... isolated or 100...240 V ~ power supply module

**BMX P34 2010**

**BMX P34 2020**

**BMX P34 2030**

1/9

Modicon M340 automation platform



### Presentation

Standard and Performance processors from the Modicon M340 automation platform manage an entire PLC single-rack station on which a maximum of 11 slots can be equipped with:

- Discrete I/O modules
- Analog I/O modules
- Application-specific modules (counter, Ethernet TCP/IP communication)

The four processors offered have different memory capacities, processing speeds, number of I/O and number and type of communication ports.

In addition, depending on the model, they offer a maximum (non-cumulative) of:

- 512 to 1024 discrete I/O
- 128 to 256 analog I/O
- 20 to 36 counter channels
- 0 to 2 Ethernet TCP/IP networks (with or without integrated port and network module)

Depending on the model, Modicon M340 processors include:

- A 10BASE-T/100BASE-TX Ethernet TCP/IP port
- A CANopen machine and installation bus
- A Modbus® serial link
- A USB type TER port (for a programming terminal)

Each processor is supplied with a memory card used for:

- Backing up the application (program, symbols and constants)
- Activating a standard web server for Transparent Ready® service — B10 class integrated Ethernet port (depending on the model)

This memory card can be replaced by another type of memory card, to be ordered separately, that supports:

- Backing up the application and activating the standard web server (same as other card)
- A 16 Mb storage area for additional data organized in a file system (directories and sub-directories)


### Programming Modicon® M340™ applications

To set up processors from the Modicon M340 automation platform, you need either:

- Unity Pro™ Small programming software
- Unity Pro™ Medium, Large or Extra Large programming software identical to that used to set up Modicon® Premium™ and Modicon® Quantum™ automation platforms
- With possibly, depending on requirements:
  - Unity™ EFB toolkit software for developing EF and EFB libraries in C language
  - Unity™ SFC View software for viewing and diagnostics of applications written in Sequential Function Chart language (SFC) or Grafcet

The function block software libraries provide Modicon M340 processors with the processing capability required to meet the needs of specialist applications in the following areas:

- Process control via programmable control loops (EF and EFB libraries)
- Motion control with multiple independent axis functions (MFB *Motion Function Blocks*) library. The axes are controlled by Altivar® 31/71 adjustable speed drives or Lexium® 05/15 servo drives connected over the CANopen machine and installation bus.




BMX P34 1000

### Description of BMX P34 1000/2010 processors

BMX P34 1000/2010 Standard and Performance single-format processors have the following on the front panel:

- 1 Securing screw for locking the module in its slot (marked 0) in the rack
- 2 A display block comprising 5 or 7 LEDs, depending on the model:
  - RUN LED (green): Processor running (program executing)
  - ERR LED (red): Processor or system fault
  - I/O LED (red): I/O module fault
  - SER COM LED (yellow): Activity on the Modbus® serial link
  - CARD ERR LED (red): Memory card missing or faulty
- With, in addition, for model **BMX P34 2010**:
  - CAN RUN LED (green): Integrated machine/installation bus operational
  - CAN ERR LED (red): Integrated machine/installation bus fault
  - 3 A mini B USB connector for a programming terminal (or Magelis® XBT GT operator interface)
  - 4 A slot equipped with Flash memory card for backing up the application (an LED, located above this slot, indicates recognition of or access to the memory card)
  - 5 An RJ45 connector for the Modbus® serial link or character mode link (RS 232C/RS-485, 2-wire, non-isolated)
  - With, in addition, for model **BMX P34 2010**:
    - 6 A 9-pin SUB-D connector for the CANopen master machine and installation bus



BMX P34 2010


### Description of BMX P34 2020/2030 processors with integrated Ethernet TCP/IP port

BMX P34 2020/2030 Performance single-format processors have the following on the front panel:


- 1 Securing screw for locking the module in its slot (marked 0) in the rack
- 2 A display block comprising 8 or 10 LEDs, depending on the model:
  - RUN LED (green): Processor running (program executing)
  - ERR LED (red): Processor or system fault
  - I/O LED (red): I/O module fault
  - SER COM LED (yellow): Activity on the Modbus® serial link
  - CARD ERR LED (red): Memory card missing or faulty
  - ETH ACT LED (green): Activity on the Ethernet TCP/IP network
  - ETH STS LED (green): Ethernet TCP/IP network status
  - ETH 100 LED (red): Data rate on the Ethernet TCP/IP network (10 or 100 Mbps)
- With, in addition, for model **BMX P34 2030**:
  - CAN RUN LED (green): Integrated machine/installation bus operational
  - CAN ERR LED (red): Integrated machine/installation bus fault
  - 3 A mini B USB connector for a programming terminal (or Magelis® XBT GT operator interface)
  - 4 A slot equipped with Flash memory card for backing up the application (an LED, located above this slot, indicates recognition of or access to the memory card)
  - 5 An RJ45 connector for connection to the Ethernet TCP/IP 10BASE-T/100BASE-TX network
  - Also included, depending on the model:
    - 6 BMX P 34 2020 processor: An RJ45 connector for the Modbus® serial link or character mode link (RS 232C/RS 485, 2-wire, non-isolated)
    - 7 BMX P 34 2030 processor: A 9-pin SUB-D connector for the CANopen master machine and installation bus

On the back panel there are two rotary switches for assigning the IP address. There are three ways to define this assignment:

- Address set by the position of the two rotary switches
- Address set by the application parameters
- Address set by the Ethernet TCP/IP BOOTP server




BMX P34 2020



BMX P34 2030

### Memory structure

BMX P34 1000/20•0 processor with memory card supplied as standard



#### Application internal RAM

The application memory is divided into memory areas, physically distributed in the Modicon M340 PLCs internal RAM:

- 1 Application data area, which may be one of two possible types:
  - Located data, corresponding to the data defined by an address (for example %MW237) with which a symbol can be associated (for example, Counter\_reject).
  - Unlocated data, corresponding to data defined only by a symbol. The use of unlocated data eliminates the restrictions of managing the memory location since the addresses are assigned automatically and also allows data to be structured and re-used.

This data area is backed up automatically when the PLC is turned off by duplicating its contents in a 256 Kbyte non-volatile internal memory integrated in the processor. It is also possible to back up this memory at any time with a user program.

- 2 Program, symbols and comments area: At program level this area contains the executable binary code and IEC source code.
- 3 Constants area: This area supports the constant located data (%KWi).
- 4 Area for online program modification (see page 1/7)

The user can choose to transfer the source data to the executable program in the PLC. The fact of having the program source in the PLC means that, when an empty programming terminal is connected to the PLC, all the elements needed to debug or upgrade this application can be restored to the terminal. Comments and animation tables can be excluded from the data embedded in the PLC.

#### Memory card

Modicon M340 processors are supplied with an SD (*Secure Digital*) type Flash memory card. This memory card is intended for backing up the program, symbols and comments area 2 and the constants area 3.


Duplication (for areas 22 and 33) and retrieval (on return of power) operations are managed automatically by the system and are therefore transparent to the user.

This card (formatted by Schneider Electric® and supplied with each processor) is referenced as a replacement part **BMX RMS 008MP**.

(1) For the size of the different memory areas, see characteristics, page 1/8.

### Memory structure (continued)

BMX P34 2000 processor with BMX RMS 008MPF memory card



In place of the BMX RMS 008MP memory card (supplied as standard with each processor), **BMX P34 2010/2020/2030** processors can take the **BMX RMS 008MPF** memory card. With the three above-mentioned processors, this card also offers (in addition to the features of the BMX RMS 008MP card supplied as standard described on page 1/6):

- 5 A file storage area (for additional data, such as production data and manufacturing sequences): This area is limited to 16 Mb. These files can be managed from the application program or by any FTP client connected to the Ethernet TCP/IP port integrated in the processor.

For **BMX P34 2020/2030** processors with integrated Ethernet TCP/IP port, the **BMX RMS 008MPF** memory card also offers standard Transparent Ready® web service - class B10).

The Unity Pro™ programming software assists the application designer with managing the structure and memory space occupation of the Modicon M340 automation platform.

### Protecting the application

If necessary, it is possible to prohibit access to the application (in terms of reading or modifying the program) by only loading the executable code to the PLC. Additionally, a memory protection bit, set in configuration mode, is also available to prevent any program modification (via the programming terminal or downloads).

### Modifying the program in online mode

As with Modicon® Premium™ and Quantum™ platforms (with Unity Pro™ software), the online program modification function is available on the Modicon M340 automation platform with the option of adding or modifying the program code and data in different places in the application in a single modification session (thus ensuring modification is homogenous and consistent with the controlled process).

The application internal RAM memory area 4 authorizes these program modification or addition sessions while observing the recommendation to structure the application program in several reasonably sized sections.

Modicon M340 Micro-PLCs have been designed to conform with the main national and international standards relating to electronic devices for industrial control systems (see pages 6/2 to 6/7) "Standards, certifications and environmental conditions".

### Characteristics and performance

Processor		Standard BMX P34 1000	Performance BMX P34 2010	BMX P34 2020	BMX P34 2030
<b>Maximum configuration</b>	No. of racks	4, 6, 8 or 12 slots	1		
	Max. number of slots for processor and modules (excluding power supply module)		12		
<b>Functions</b>	Max. no. (1)				
	Discrete I/O	512	1,024; 704 in single-rack configuration (64 I/O x 11)		
	Analog I/O	128; 66 in single-rack configuration (4I/2Q x 11)	256; 66 in single-rack configuration (4I/2Q x 11)		
	Control channels		Programmable loops (via CONT-CTL process control EFB library)		
	Counter channels	20	36		
	Motion control	–	Independent axes on CANopen bus (via MFB library)	–	Independent axes on CANopen bus (via MFB library)
<b>Integrated connections</b>	Ethernet TCP/IP	–		1 RJ45 port, 10/100 Mbps, with Transparent Ready® web server - class B10 standard	
	CANopen master bus	–	1 (9-pin SUB-D)	–	1 (9-pin SUB-D)
	Serial link		1 RJ45 port, Modbus® communication master/slave RTU/ASCII or character mode (non-isolated RS 232C/RS 485), 0.3...19.2 Kbps	–	–
	USB port		1 port, 12 Mbps		
Communication module	Ethernet TCP/IP		1 RJ45 port, 10/100 Mbps, with: - Transparent Ready® web server - class B30 standard with BMX NOE 0100 module - Transparent Ready® web server - class C30 configurable with BMX NOE 0110 module		
<b>Internal user RAM</b>	Total capacity	<b>Kb</b>	2,048	4,096	
	Program, constants and symbols	<b>Kb</b>	1,792	3,584	
	Data	<b>Kb</b>	128	256	
<b>Memory card</b>	Supplied as standard (reference BMX RMS 008MP)		Backup of program, constants, symbol and data		
			–	Activation of standard web server, class B10	
	To be ordered separately (reference BMX RMS 008MPF)		–	Backup of program, constants, symbol and data	
			–	File storage, 16 Mb	Activation of standard web server, class B10
<b>Maximum size of object areas</b>	Located internal bits	<b>Maximum bits</b>	16,250% Mi	32,464% Mi	
		<b>Default</b>	256% Mi	512% Mi	
	Located internal data	<b>Maximum Bytes</b>	32,464% MWi internal words, 32,760% KWi constant words		
		<b>Default</b>	512% MWi internal words, 128% KWi constant words	1,024% MWi internal words, 256% KWi constant words	
	Max. unlocated internal data	<b>Kb</b>	128 (2)	256 (2)	
<b>Application structure</b>	Master task		1 cyclic or periodic		
	Fast task		1 periodic		
	Auxiliary tasks		–		
	Event tasks		32 (including 2 with priority)	64 (including 2 with priority)	
<b>Execution time for one instruction</b>	Boolean	<b>μs</b>	0.18	0.12	
	On words or fixed point arithmetic	<b>Single-length words</b>	0.38	0.25	
		<b>Double-length words</b>	0.26	0.17	
	On floating points	<b>μs</b>	1.74	1.16	
<b>No. of K instructions executed per ms</b>	100% Boolean	<b>K inst/ms</b>	5.4	8.1	
	65% Boolean and 35% fixed arithmetic	<b>K inst/ms</b>	4.2	6.4	
<b>System overhead</b>	Master task	<b>ms</b>	1.05	0.70	
	Fast task	<b>ms</b>	0.20	0.13	
<b>Power consumption</b>		With 24 V --- voltage	<b>mA</b>	72	90
					95
					135

(1) Only affects in-rack modules. The remote I/O on the CANopen bus are not included in these maximum numbers.

(2) The size of the located data (internal bits and data) and the size of the configuration data should be deducted from this value.

### BMX P34 Modicon® M340™ processors

Modicon M340 processor modules are supplied with the **BMX RMS 008MP** Flash memory card. This card performs the following actions transparently:

- Backing up the application (program, symbols and constants) supported in the processor internal RAM that is not backed up
- Activation of the Transparent Ready® web server - class B10 standard (with **BMX P34 2020/2030** Performance processors)

This card can be replaced by another card featuring a file storage option.



BMX P34 1000



BMX P34 2010/2030



BMX P34 2020



BMX RMS 008MP / MPF



BMX XCA USB H000

I/O capacity (1)	Memory capacity	Max. no. of network modules	Integrated communication ports	Reference (3)	Weight kg
<b>Standard BMX P340 10</b>					
512 discrete I/O 128 analog I/O 20 application-specific channels	2,048 Kb integrated	1 Ethernet TCP/IP network	Modbus® serial link	<b>BMXP341000</b>	0.200
<b>Performance BMX P340 20</b>					
1,024 discrete I/O 256 analog I/O 36 application-specific channels	4,096 Kb integrated	1 Ethernet TCP/IP network	Modbus® serial link CANopen bus	<b>BMXP342010</b>	0.210
			Modbus® serial link Ethernet TCP/IP network	<b>BMXP342020</b>	0.205
			Ethernet TCP/IP network CANopen bus	<b>BMXP342030</b>	0.215

### Memory card

Description	Use	Processor compatibility	Reference	Weight kg
Memory card 16 Mb	As replacement for the memory card supplied as standard with each processor, used for: - Backup of program, constants, symbol and data - File storage, 16 Mb - Activation of class B10 web server	BMX P34 20•0	<b>BMXRMS008MPF</b>	0.002

### Separate parts

Description	Use		Length	Reference	Weight kg
	From	To			
Terminal port/USB cord sets	Mini B USB port on the Modicon M340 processor	PC terminal type A USB port	1.8 m 4.5 m	<b>BMXXCAUSBH018</b> <b>BMXXCAUSBH045</b>	0.065 0.110

### Replacement parts

Description	Use	Processor compatibility	Reference	Weight kg
Memory card 8 Mb	Supplied as standard with each processor, used for: - Backup of program, constants, symbol and data - Activation of class B10 web server	BMX P34 1000 / 20•0	<b>BMXRMS008MP</b>	0.002

(1) For I/O capacity in single-rack configuration, see characteristics, page 1/8.

### Presentation

BMX CPS **●●●0** power supply modules provide the power supply for each BMX XBP **●●00** rack and the modules installed on it.

There are two types of power supply module:

- Power supply modules for AC supplies
- Power supply modules for DC supplies

### Description

The power supply module is selected according to:

- The electrical line supply: 24 V  $\perp\!\!\!\perp$ , 48 V  $\perp\!\!\!\perp$  or 100...240 V  $\sim$
- The required power (see the power consumption table on page 6/8) (1)

BMX CPS **●●●0** power supply modules have the following on the front panel :


- 1 A display block comprising:
  - OK LED (green), lit if rack voltages are present and correct
  - 24 V LED (green), lit when the sensor voltage is present (for BMX CPS 2000/3500 AC power supply modules only)
- 2 A pencil-point RESET push button for a cold restart of the application
- 3 A 2-pin connector that can receive a removable terminal block (screw or spring-type) for connecting the alarm relay
- 4 A 5-pin connector that can receive a removable terminal block (screw or spring-type) for connecting the following:
  - $\perp\!\!\!\perp$  or  $\sim$  line supply
  - Protective earth ground
  - Dedicated 24 V  $\perp\!\!\!\perp$  power supply for the input sensors (for BMX CPS 2000/3500 AC power supply modules only)

#### To be ordered separately:

Pack of two removable terminal blocks, depending on the model:

- Screw clamp **BMX XTS CPS10**
- Spring-type **BMX XTS CPS20**

(1) This power consumption calculation for the rack can also be performed by the Unity Pro™ programming software.



**Functions****Alarm relay**

The alarm relay located in each power supply module has a voltage-free contact accessible from the front of the 2-pin connector.

The operating principle is as follows:

In normal operation, with the PLC in RUN, the alarm relay is activated and its contact is closed (state 1).

The relay de-energizes and its associated contact opens (state 0) whenever the application stops, even partially, due to any of the following:

- Occurrence of a blocking fault
- Incorrect rack output voltages
- Loss of supply voltage

**RESET push button**

The power supply module in each rack has a RESET button on the front panel; when activated, this triggers an initialization sequence for the processor and the rack modules it supplies.

Pressing this push button triggers a sequence of service signals, which is the same as that for:

- A power break when the push button is pressed
- A power-up when the push button is released

These operations represent a cold start (forcing the I/O modules to state 0 and initializing the processor).

**Sensor power supply**

The **BMX CPS 2000/3500** AC power supply modules have an integrated 24 V  $\perp\perp$  voltage supply for powering the input sensors. Connection to this sensor power supply is via the 5-pin connector on the front panel.

The power available on this 24 V  $\perp\perp$  voltage depends on the power supply model (0.45 or 0.9 A) (see characteristics on page 1/12).

### Characteristics

#### --- power supply module

			BMX CPS 2010	BMX CPS 3020
<b>Primary</b>	Voltage	Nominal	V 24 --- isolated	24...48 --- isolated
		Limit (including ripple)	V 18...31.2 ---	18...62.4 ---
Current	Input nominal I rms	A 1 at 24 V ---	1.65 at 24 V ---; 0.83 at 48 V ---	
Initial power-up at 25 °C (1)	I inrush	A 24 ---	24 ---	48 ---
	I <sup>2</sup> t on activation	A <sup>2</sup> s ≤ 0.6	≤ 1	≤ 3
	It on activation	As ≤ 0.15	≤ 0.2	≤ 0.3
Micro-break duration	Line (accepted)	ms ≤ 1		
Integrated protection			With internal fuse (not accessible)	
<b>Secondary</b>	Useful power	Max. W 17	32	
3.3 V --- voltage (2)	Nominal voltage V 3.3			
	Nominal current A 2.5		4.5	
	Typical power W 8.25		14.85	
24 V --- output (3)	Nominal voltage V 24 ---			
	Nominal current A 0.7		1.3	
	Typical power W 16.8		31.2	
Integrated protection on the voltages (4)			Yes, against overloads, short-circuits and overvoltages	
<b>Max. dissipated power</b>	W 8.5			
<b>Max. length of power supply cable</b>	Copper wires with 1.5 mm <sup>2</sup> cross-section m 20		10	
	Copper wires with 2.5 mm <sup>2</sup> cross-section m 30		15	
<b>Insulation</b>	Dielectric strength Primary/secondary and primary/ground	V rms	1,500 - 50 Hz for 1 min at an altitude of 0...4,000 m	
	Insulation resistance Primary/secondary and primary/ground	MΩ	≥ 10	
~ power supply module			BMX CPS 2000	BMX CPS 3500
<b>Primary</b>	Voltages	Nominal V 100...240 ~		
		Limit (including ripple) V 85...264 ~		
Frequencies	Nominal/limit Hz 50-60/47-63			
Power	Apparent VA 70		120	
Current	Input nominal I rms A rms 0.61 at 115 V ~; 0.31 at 240 V ~		1.04 at 115 V ~; 0.52 at 240 V ~	
Initial power-up at 25 °C (1)	I inrush V 120 ~ A ≤ 30	240 ~ ≤ 60	120 ~ ≤ 30	240 ~ ≤ 60
	I <sup>2</sup> t on activation A <sup>2</sup> s ≤ 0.5		≤ 2	≤ 1
	It on activation As 0.03	0.06	≤ 0.05	≤ 0.07
Micro-break duration	Line (accepted) ms ≤ 10			
Integrated protection			With internal fuse (not accessible)	
<b>Secondary</b>	Useful power Max. overall W 20		36	
	Max. on 3.3 V --- and 24 V --- rack output voltages W 16.5		31.2	
3.3 V --- voltage (2)	Nominal voltage V 3.3			
	Nominal current A 2.5		4.5	
	Power (typical) W 8.25		14.85	
24 V rack --- voltage (3)	Nominal voltage V 24 ---			
	Nominal current A 0.7		1.3	
	Typical power W 16.8		31.2	
24 V --- sensor voltage (4)	Nominal voltage V 24 ---			
	Nominal current A 0.45		0.9	
	Typical power W 10.8		21.6	
Integrated protection on the voltages (5)			Yes, against overloads, short-circuits and overvoltages	
<b>Maximum dissipated power</b>	W 8.5			
<b>Insulation</b>	Dielectric strength Primary/secondary (24 V/3.3 V) V rms 1500			
	Primary/secondary (sensor 24 V) V rms 2300			
	Primary/ground V rms 1500			
	24 V sensor output/ground V rms 500			
Insulation resistance Primary/secondary and primary/ground MΩ ≥ 100				

(1) These values should be considered when starting several devices simultaneously and when sizing protection devices.

(2) 3.3 V --- voltage for the I/O module logic power supply

(3) 24 V --- voltage for the I/O module power supply and the processor

(4) 24 V --- sensor output for the sensor power supply

(5) Protected by a fuse that cannot be accessed

### References

Each **BMX XBP 000** rack must be equipped with a power supply module. These modules are inserted into the first two slots of each rack (marked CPS).

The power required to supply each rack depends on the type and number of modules installed in the rack. It is therefore necessary to draw up a power consumption table rack by rack to determine the **BMX CPS 000** power supply module most suitable for each rack (see 6/8).



BMX CPS 2010 / 3020

### Power supply modules

Line supply	Available power (1)			Reference	Weight kg	
	3.3 V (2) 24 V	24 V	Total			
24 V (3) isolated	8.3 W	16.5 W	—	16.5 W	BMXCPS2010	0.290
24...48 V (3) isolated	15 W	31.2 W	—	31.2 W	BMXCPS3020	0.340
100...240 V ~	8.3 W	16.5 W	10.8 W	20 W	BMXCPS2000	0.300
	15 W	31.2 W	21.6 W	36 W	BMXCPS3500	0.360



BMX CPS 2000 / 3500

### Separate parts

Description	Composition	Type	Reference	Weight kg
Pack of 2 removable connectors	One 5-pin terminal block and one 2-pin terminal block	Cage clamp	BMXXTSCPS10	0.020
		Spring-type	BMXXTSCPS20	0.015

(1) The sum of the absorbed power on each voltage (3.3 V and 24 V) should not exceed the total power of the module. See the power consumption table on page 6/8

(2) 3.3 V and 24 V rack voltages for powering Modicon M340 PLC modules

(3) 24 V sensor voltage for powering the input sensors (voltage available via the 2-pin removable connector on the front panel)

### **Presentation**


**BMX XBP 0000** racks are the basic element of the Modicon M340 automation platform in a single-rack configuration.

These racks perform the following functions:

- Mechanical function: They are used to install all the modules in a PLC station (power supply, processor, discrete I/O, analog and application-specific I/O). These racks can be mounted on a panel, plate or DIN rail:
  - Inside enclosures
  - On machine frames, etc.
- Electrical function: The racks incorporate a Bus X. They are used to:
  - Distribute the power supplies required for each module in the same rack
  - Distribute data and service signals for the entire PLC station
  - Hot swap modules during operation

### **Description**

**BMX XBP 0000** racks are available in 4, 6, 8 or 12-slot versions, and comprise:



Rack 6 slots BMX XBP 0600

- 1 A metal frame that performs the following functions:
- Holds the Bus X electronic card and protects it against EMI and ESD type interference
- Holds the modules
- Gives the rack mechanical rigidity
- 2 A ground terminal for grounding the rack
- 3 Holes for mounting the rack on a frame. These holes are big enough for M6 screws.
- 4 Connecting points for the shielding connection bar
- 5 Tapped holes to receive each module locking screw
- 6 A connector for an expansion module. This connector (marked XBE) is not used for this version.
- 7 40-pin female 1/2 DIN connectors forming the connection between the rack and each module. When the rack is delivered, these connectors are protected by covers that should be removed before inserting the modules.
- Slots for anchoring the module pins

#### **To be ordered separately:**

**BMX XSP 0000** cable shielding connection kit, used to protect against electrostatic discharge when connecting the shielding of cord sets for connecting:
 

- Analog modules
- A Magelis® XBT operator interface to the processor (via **BMX XCA USBH000** shielded USB cable)

This kit comprises:

- 8 A metal bar that receives the clamping rings
- 9 Two sub-bases to be mounted on the rack
- 10 A set of spring clamping rings for attaching cables with their shielding to the metal bar.

Packs of 10 **STB XSP 3000** clamping rings can be ordered in addition if required.


### **Function**

#### **Addressing modules in a single-rack configuration**


Each rack must contain a power supply module and a processor module.

#### **Inserting different modules into the rack:**


- The power supply module always occupies the **CPS** slot.
- The processor module must always be installed in slot **00**.
- Its I/O modules and application-specific modules are installed in slot **01** to slot ...
  - **03** with a 4-slot rack
  - **05** with a 6-slot rack
  - **07** with an 8-slot rack
  - **11** with a 12-slot rack




Example of installation with 8-slot rack




BMX XBP 0400



BMX XBP 0800



BMX XBP 1200



BMX XSP 0000


STB XSP 3000

## Dimensions, mounting

### BMX XBP

#### Common side view

#### Front view: BMX XBP example




	a
BMX XBP 0400	242.4
BMX XBP 0600	307.6
BMX XBP 0800	372.8
BMX XBP 1200	503.2

(1) With removable terminal block (cage, screw or spring).

(2) With FCN connector.

#### Mounting the racks


##### On AM1 PA and AM3 PA pre-slotted plate



(1) On AM1 ED rail: 35 mm wide, 15 mm deep Only possible with BMX XBP 0400/0600/0800 rack.

(2) For panel-mounting: The diameter of the mounting holes must be sufficient to accept M4, M5, M6 screws (4.32 to 6.35).

#### Installation rules



a ≥ 3 mm

(1) Equipment or enclosure.  
(2) Cable ducting or clip.

## Racks

Description	Type of module to be inserted	No. of slots (1)	Reference	Weight kg
Racks	BMX CPS power supply, BMX P34 processor, I/O modules and application-specific modules (counter, communication)	4	BMXXBP0400	1.470
		6	BMXXB0600	1.750
		8	BMXXBP0800	2.310
		12	BMXXBP1200	—

## Accessories

Description	For use with	Unit reference	Weight kg
Shielding connection kits comprising: - a metal bar - two sub-bases - one set of spring clamping rings	BMX XBP 0400 rack BMX XBP 0600 rack BMX XBP 0800 rack BMX XBP 1200 rack	BMXXSP0400 BMXXSP0600 BMXXSP0800 BMXXSP1200	0.280 0.310 0.340 0.400
Spring clamping rings	Cables with 1.5...6 mm <sup>2</sup> cross-section (pack of 5)	STBXSP3010	0.050
	Cables with 5...11 mm <sup>2</sup> cross-section (pack of 5)	STBXSP3020	0.070
Protective covers	Unoccupied slots on BMX XBP 0000 rack (pack of 5)	BMXXEM010	0.005

(1) Number of slots receiving the processor module, I/O modules and application-specific modules (excluding power supply module).



---

## Discrete I/O modules

■ Discrete I/O modules	
□ Presentation, description . . . . .	2/6
□ Functions . . . . .	2/8
□ Characteristics . . . . .	2/10
□ References . . . . .	2/16
□ Connections . . . . .	2/18

2

## Analog I/O modules and process control

■ Analog I/O modules	
□ Presentation, description . . . . .	2/24
□ Connections . . . . .	2/25
□ Functions . . . . .	2/26
□ Characteristics . . . . .	2/28
□ References . . . . .	2/31
■ Programmable process control . . . . .	2/32

## Distributed I/O modules

## Counter modules and Motion Function Blocks

■ Counter modules	
□ Presentation, description . . . . .	2/36
□ Functions . . . . .	2/37
□ Characteristics . . . . .	2/40
□ References . . . . .	2/41
□ Connections . . . . .	2/42
■ MFB, Motion Function Blocks . . . . .	2/44

## Applications

## 16-channel input modules

Connection via cage clamp, screw clamp or spring-type removable terminals

2



## Type

## Voltage

—	24 V	—	24 V	—	48 V	—	100...120V
---	------	---	------	---	------	---	------------

Modularity  
(Number of channels)

16 isolated channels

## Connection

Via BMX FTB 2000/2010/2020 20-pin cage clamp, screw clamp or spring-type removable terminals

## Isolated inputs

## IEC 1131-2 conformity

## Logic

Sensor compatibility in accordance with standard IEC 947-5-2

Type 3	Type 1	Type 1 (~)	Type 3
--------	--------	------------	--------

Positive	Pos. or neg.	—	—
----------	--------------	---	---

2-wire —, 3-wire — PNP any type	2-wire —/~, 3-wire — PNP or NPN any type	2-wire —
---------------------------------	--	----------

## Isolated outputs

## Fallback

## IEC 1131-2 conformity

## Protection

## Logic

BMX DDI 1602	BMX DDI 1603 ▲	BMX DAI 1602 ▲	BMX DAI 1603 ▲	BMX DAI 1604
--------------	----------------	----------------	----------------	--------------

1/16

## Page

## Compatibility with installation help system

## Tego® Dial

## TeSys® Quickfit

—

—

## Compatibility with Advantys™ Telefast® ABE7 pre-wired I/O system

## Connection sub-bases

## Input and output adapter sub-bases

—

—

## Passive connection sub-base Optimum "Economy"

## Optimum "Miniature"

## Universal

—

—

—

## Relay adapter sub-base

## Fixed relays

## Plug-in relays

—

—

## Preformed cord sets with 40-pin connector

—

## Pages

—

▲ Available 4<sup>th</sup> quarter 2007

<b>32/64-channel high-density input modules</b>
Connection via 40-pin connectors with preformed cord sets



<b>16/32-channel mixed I/O modules</b>
Connection via cage clamp, screw clamp or spring-type removable terminals



<b>Connection via 40-pin connectors with preformed cord sets</b>
--



—	
24 V	
32 isolated channels	64 isolated channels
Via one 40-pin connector	Via two 40-pin connectors
Type 3	Non-IEC
Positive	
2-wire —, 3-wire — PNP any type	—

—	— and ~ (outputs only)	—
24 V I/O	24 V inputs, relay outputs	24 V I/O
8 isolated inputs and 8 isolated outputs		16 isolated inputs and 16 isolated outputs
Via BMX FTB 2000/2010/2020 20-pin cage clamp, screw clamp or spring-type removable terminals		Via one 40-pin connector
Type 3		Type 3
Positive	—	Positive
Configurable output fallback, continuous monitoring of output control and resetting of outputs in case of internal fault		
Yes		
Protected	Not protected	Protected
Positive	—	Positive

<b>BMX DDI 3202K</b>	<b>BMX DDI 6402K</b>
1/16	1/17

<b>BMX DDM 16022</b>	<b>BMX DDM 16025</b>	<b>BMX DDM 3202K</b>
1/17		
APE 1B24M Dialbase interface with 8I/8Q	—	APE 1B24M Dialbase interface

LU9 G02 splitter boxes (8 motor starters) and BMX FCC ●●1/●●3 preformed cord sets	—	LU9 G02 splitter boxes (8 motor starters) and BMX FCC ●●1/●●3 preformed cord sets
Depending on model, 8- or 16-channel passive sub-bases, with or without LED, with common or 2 terminals per channel		
Depending on model, 16-channel active sub-bases with solid state or electromechanical, fixed or removable relays, 5...48 V —, 24 V —, 24 V...240 V ~ or voltage-free, with common or 2 terminals per channel, screw or spring-type connection		

<b>ABE7H20E●00</b>
<b>ABE7H16C●●</b>
<b>ABE7H08R●●/H08S21, ABE7H16R1●/H16R50, ABE7H16R2●/H16S21, ABE7H16R3●/H16R23, ABE7H16S43,</b>
<b>ABE7S16E2●●</b>
<b>ABE7P16F31●●</b>
<b>BMX FCC ●●1/FCC ●●3</b>
5/10 to 5/16, 2/17

<b>ABE7H20E●00</b>
<b>ABE7H16C●●</b>
<b>ABE7H08R●●/H08S21, ABE7H16R1●/H16R50, ABE7H16R2●/H16S21, ABE7H16R3●/H16R23, ABE7H16S43/H16F43</b>
<b>ABE7S16E2●●</b>
<b>ABE7S16S●●●/H16S</b>
<b>ABE7P16F31●●</b>
<b>ABE7R16T●●●/H16T●●●</b>
<b>BMXFCC ●●3</b>
5/10 to 5/16, 2/17

# Modicon® M340™ Automation Platform

## Discrete I/O modules

### Output modules

## Applications

32/64-channel high-density output modules

Connection via 40-pin connectors with preformed cord sets

2



Type	... solid state	
Voltage	24 V	
Current	0.1 A per channel	
Modularity (Number of channels)	32 protected channels 64 protected channels	
Connection	Via one 40-pin connector	Via two 40-pin connectors
Isolated outputs	Fallback	Configurable output fallback, continuous monitoring of output control and resetting of outputs in case of internal fault
	IEC 1131-2 conformity	Yes
	Protection	Current limiter with electronic tripping
	Logic	Positive -
Discrete output module	BMX DDO 3202K	BMX DDO 6402K
Page	2/16	
Compatibility with installation help system	Tego® Dial	-
	TeSys® Quickfit	-
Compatibility with Advantys™ Telefast® ABE7 pre-wired I/O system	Connection sub-bases	-
	Input adapter sub-bases	-
Passive sub-base	Optimum "Economy"	ABE7H20E•00
	Optimum "Miniature"	ABE7H16C••
	Universal	ABE7H08R••/7H08S21, ABE7H16R1•/7H16R50, ABE7H16R2•/7H16S21, ABE7H16R3• ABE7H16F43
Relay adapter sub-base	Fixed relays	ABE7S16S•• / 7R16S
	Removable relays	ABE7R16T••/7P16T••
Preformed cord sets with 40-pin connector	BMXFCC••1/FCC ••3	
Pages	5/10 to 5/16, 2/17	

**16-channel output modules**

Connection via cage clamp, screw clamp or spring-type removable terminals

**8/16-channel output modules**

2

--- solid state

24 V ---

0.5 A per channel

16 protected channels

~ triac

100...240 V

0.6 A per channel

16 non-protected channels

---/~ relay

24 V ---, 24...240 V ~

3 A (Ith) per channel

2 A (Ith) per channel

8 non-protected channels

16 non-protected channels

Via BMX FTB 2000/2010/2020 20-pin cage clamp, screw clamp or spring-type removable terminals

Configurable output fallback, continuous monitoring of output control and resetting of outputs in case of internal fault

Configurable output fallback

Yes

Yes

Current limiter with electronic tripping

-

Positive

Negative

-

BMX DDO 1602

BMX DDO 1612 ▲

BMX DAO 1605 ▲

BMX DRA 0805

BMX DRA 1605

2/16

-

-

-

-

-

-

-

-

-

-

-

-

-

-

▲ Available 4<sup>th</sup> quarter 2007

### **Presentation**

Discrete I/O modules in the Modicon M340 PLC offer are standard modules occupying a single slot, equipped with either of the following:

- A connector for a screw or spring-type 20-pin removable terminal block
- One or two 40-pin connector(s)

A wide range of discrete inputs and outputs can be used to meet whatever requirements arise in terms of:

- functions: AC or DC I/O, positive or negative logic
- modularity: 8, 16, 32 or 64 channels per module

The inputs receive signals from the sensors and perform the following functions:

- acquisition
- adaptation
- electrical isolation
- filtering
- protection against interference signals

The outputs memorize commands issued by the processor to enable control of the actuators via the decoupling and amplification circuits.

### **Description**


**BMX D<sub>1</sub>/D<sub>2</sub>O/DRA** discrete I/O modules are standard format (1 slot). Their case ensures IP 20 protection of the electronics, and they are locked into position by a captive screw.

#### **I/O modules connected via 20-pin removable terminal block**


- 1 Rigid body providing support and protection for the electronic card
- 2 Module reference marking (a label is also visible on the right-hand side of the module)
- 3 Channel status display block
- 4 Connector accepting the 20-pin removable terminal block for connecting sensors or preactuators

#### **To be ordered separately:**

A **BMX FTB 20•0** 20-pin removable terminal block or a preformed cord set with a 20-pin removable terminal block at one end and wires at the other (see page 2/7).



Module and 20-pin removable terminal block



32- and 64-channel modules with connection via 40-pin connector(s)


#### **I/O modules connected via 40-pin connector**

- 1 Rigid body providing support and protection for the electronic card
- 2 Module reference marking (a label is also visible on the right-hand side of the module)
- 3 Channel status display block
- 4 One or two 40-pin connectors (32 or 64 channels) (1) for connecting sensors or preactuators
- 5 With the 64-channel module, a push button which, with successive presses, displays the state of channels 0...31 or 32...63 on the block 3 (see page 2/9)


#### **To be ordered separately**, depending on the type of module:

One or two preformed cord set(s) with a 40-pin connector (see page 2/7).


(1) Fujitsu FCN 40-pin connector




Preformed cord set with removable terminal block at one end and wires at the other



Preformed cord set with 40-pin connector at one end and 2 wires at the others



Preformed cord set with 40-pin connector and HE 10 connector for Advantys Telefast ABE7 pre-wired I/O system



Example of connection to the Tego Dial installation help system

### Connecting modules with removable terminal blocks

There are three types of 20-pin removable terminal blocks:

- Screw clamp terminal block
- Cage clamp terminal block
- Spring-type terminal block

Each removable terminal block can accept:

- Bare wires
- Wires equipped with DZ5-CE cable ends

One version of the removable terminal block is equipped with **BMX FTW●●1** cord sets with color-coded wires (3, 5 or 10 m long).

2

### Cage clamp terminal blocks

The capacity of each terminal is:

- Minimum: One 0.34 mm<sup>2</sup> wire (22 AWG)
- Maximum: One 1.5 mm<sup>2</sup> wire (14 AWG)

**BMX FTB 2000** cage clamp connectors are equipped with captive screws maximum tightening torque 0.5 N.m (4.4 lb-in).

### Screw clamp terminal blocks

The capacity of each terminal is:

- Minimum: One or two 0.34 mm<sup>2</sup> wires (22 AWG)
- Maximum: Two 1.5 mm<sup>2</sup> wires (14 AWG)

**BMX FTB 2010** screw clamp connectors are equipped with captive screws maximum tightening torque 0.5 N.m (4.4 lb-in).

### Spring-type terminal blocks

The capacity of each terminal in the **BMX FTB 2020** spring-type terminal blocks is:

- Minimum: Two 0.34 mm<sup>2</sup> wires (22 AWG)
- Maximum: Two 1.5 mm<sup>2</sup> wires (14 AWG)

### Connecting modules with 40-pin connectors

#### Preformed cord sets with 40-pin connector at one end and wires at the other

Preformed cord sets can be used for easy direct wire-to-wire connection between the I/O of modules with connectors **1**, and the sensors, preactuators or intermediate terminals.

These preformed cord sets comprise:

- At one end, a 40-pin connector **2**, with either of the following:
  - One sheath **3**, containing 20 wires sized 0.34 mm<sup>2</sup> (22 AWG) (**BMX FCW ●●1**)
  - Two sheaths **4**, each containing 20 wires sized 0.34 mm<sup>2</sup> (22 AWG) (**BMX FCW ●●3**)
- At the other end **5**, color-coded wires conforming to standard DIN 47100 (see page 2/21)

#### Preformed cord sets with 40-pin connector and HE 10 connector(s)

Two types of cord sets can be used for connecting the I/O modules with 40-pin connectors **1**, using the Advantys™ Telefast® ABE7 pre-wired I/O system of rapid wiring connections, and **2**, adaptation interfaces (see page 5/8).

These preformed cord sets comprise:

- At one end, a 40-pin connector **3**, with either of the following:
  - One sheath **4**, containing 20 wires (**BMX FCC ●●1**)
  - Two sheaths **5**, each containing 20 wires (**BMX FCC ●●3**)
- At the other end, one or two HE 10 connectors **6**

### Connection to Tego® Dial and TeSys® Quickfit systems

**BMX DDI 3202K/6402K** input modules and **BMX DDO 3202K/6402K** output modules **1** are designed for use in conjunction with Tego® Dial and TeSys® Quickfit installation help systems.

The modules are easily connected using a connection cable.

### Functions

#### Hot swapping

Due to their integrated devices, I/O modules (including application-specific modules) can be removed and connected while powered up.

*Note : When the PLC is powered up and running, the I/O modules can be removed without any material risk by performing the following sequence **before** removing the module:*

- Disconnect the power voltage on the outputs
- Disconnect the sensor and preactuator power supply
- Remove the terminal block or connector

### I/O module assignment

Discrete I/O modules have different parameters for each channel. The channels are grouped into blocks of 4, 8 or 16 consecutive channels depending on the type of module. Each group of channels can be assigned to a specific application task (master or fast).

### Protection of DC inputs

The 24 and 48 V  $\text{---}$  inputs are constant-current type. This characteristic makes it possible to:

- Ensure minimum current in active state in compliance with the IEC standard
- Limit the current consumption when the input voltage increases, to avoid unwanted temperature rise in the module
- Reduce the current consumption on the sensor power supply provided by the PLC power supply or by a process power supply

### Protection of DC outputs

All protected solid state outputs have a protective device which, when an output is active, can detect the occurrence of:

- An overload or short-circuit: This type of fault deactivates the output (tripping) and indicates a fault on the display located on the module front panel (the faulty channel LED flashes, and the I/O module fault LED lights up).
- Reverse polarity: This type of fault short-circuits the power supply without damaging the module. For this protection to work in optimum conditions, it is essential to place a fast-blow fuse on the power supply upstream of the preactuators.
- Inductive overvoltage: Each output is protected individually against inductive overvoltages and has a fast zener diode demagnetization circuit for electromagnets, which can reduce the output response time for some fast machines.

### Reactivation of DC outputs

If a fault has caused an output to trip, the output can be reactivated using this parameter if no other terminal fault is present.

Reactivation is defined for each group of 8 channels. It has no effect on an inactive channel or one that is not faulty.

The reactivation command can be:

- Programmed: Reactivation is carried out by a command from the PLC application or via the debug screen. To avoid repeated reactivations too close together, the module automatically allows a time delay of 10 s between two reactivations.
- Automatic: Reactivation takes place automatically every 10 s until the fault disappears.

### RUN/STOP command

An input can be configured to control the RUN/STOP mode for the PLC. This takes effect on a rising edge. A STOP command from an input has priority over a RUN command from a programming terminal or via the network.

### Functions (continued)

#### Output fallback

This parameter defines the fallback mode used by the DC solid state outputs when the PLC stops, following a:

- Processor fault
- Rack fault
- Fault on the cable connecting the racks

The outputs must be set to a state that is not harmful to the application. This state, known as the fallback position, is defined for each module when the DC solid state outputs are configured. This configuration offers a choice between:

- Fallback: The channels are set to 0 or 1 according to the fallback value defined for the group of 8 corresponding channels.
- Maintain: The outputs maintain their state from before the stop.

### I/O module diagnostics

Each discrete I/O module is equipped with a display block on the front panel centralizing all the information necessary for module control, diagnostics and maintenance. The display block comprises:

Run	Err	I/O	+32
0	1	2	3
4	5	6	7
8	9	10	11
12	13	14	15
16	17	18	19
20	21	22	23
24	25	26	27
28	29	30	31

2

3

1

- 1 A set of 8, 16 or 32 green LEDs, depending on the module. Each LED is associated with one channel:
  - On: channel in state 1; Off: channel in state 0
  - Flashing: channel faulty, overloaded or short-circuit
- 2 Three LEDs indicating the module status:
  - RUN (green): On: Normal operation
  - ERR (red): On: Internal module fault; Flashing: Exchange fault between the module and the processor
  - I/O (red): On: External fault (sensor/preactuator voltage, overload, short-circuit, etc.); Flashing: Terminal block fault
- 3 A +32 LED (green) indicating, in the case of 64-channel modules, whether the set of 32 LEDs 1 displays the state of channels 0...31 (off) or the state of channels 32...63 (on). This +32 LED is activated or deactivated by a push button located on top of the module.

### Diagnostics via Unity Pro™ software

Using the integrated diagnostics in Unity Pro™ software, the local diagnostics indicators on the modules front panel are complemented by system diagnostics based on predefined screens at the global hardware configuration level, the module level and the channel level (see pages 4/21 and 4/22).

### Remote diagnostics using a web browser on a “Thin Client” PC

In addition, the diagnostics described above can be performed remotely using a simple web browser thanks to the standard web server integrated in the Modicon M340 platform (processor with integrated Ethernet port or Ethernet module), using the ready-to-use Rack Viewer function (see page 3/4).

### Compatibility with 2-wire and 3-wire sensors

Input type	24 V == Non-IEC positive log. (sink)	48 V == type 1 positive log. (sink)	24 V == type 3 positive log. (sink)	24 V ~ type 1	48 V ~ type 3	100...120 V ~ type 3
Any 3-wire == sensor, PNP type						
Any 3-wire == sensor, NPN type				(1)		
Telemecanique® 2-wire == sensor or other brand with the following characteristics: - Residual voltage in closed state $\leq$ 7 V - Minimum switched current $\leq$ 2.5 mA - Residual current in open state $\leq$ 1.5 mA						
Telemecanique® 2-wire == sensor or other brand with the following characteristics: - Residual voltage in closed state $\leq$ 4 V - Minimum switched current $\leq$ 1 mA - Residual current in open state $\leq$ 0.5 mA						
2-wire ==/~ sensor (1)						
2-wire ~ sensor						

 Not compatible

 Compatible

(1) 24 V ~ sensors can be used as negative logic (source) 24 V == inputs compatible with 3-wire == sensor NPN type, but in this case, are not IEC-compliant.

### Common characteristics

#### Environment

#### Conformity to standards

NFC 63 850, IEC 664, IEC 1131 2, UL 508, UL7 46C, CSA 22 no. 142

#### Temperature derating

The characteristics at 60 °C are assured for 60% of inputs and 60% of outputs at state 1

### Characteristics of DC input modules

Module	BMX DDI 1602	BMX DDI 1603	BMX DDI 3202K	BMX DDI 6402K	BMX DAI 1602			
Number of inputs	16	32	64	16				
Connection	Spring or screw-type 20-pin removable terminal block	One 40-pin connector	Two 40-pin connectors	Spring or screw-type 20-pin removable terminal block				
Nominal input values	Voltage Current Logic	V mA Positive ( <i>sink</i> )	24 ... 3.5 -	48 ... 2.5 -	24 ... 1 -			
Input limit values	At state 1 At state 0	Voltage Current	V mA	≥ 11 > 2 (for U ≥ 11 V) < 5 ≤ 1.5	≥ 34 > 2 (for U ≥ 34 V) < 10 ≤ 0.5	≥ 11 > 2 (for U ≥ 11 V) < 5 ≤ 1.5	≥ 15 > 1 (for U ≥ 15 V) -	≥ 14 ≥ 2 -
	Sensor power supply (including ripple)	V	19...30 (possible up to 34 V, limited to 1 hour in every 24 hours)	38...60	19...30 (possible up to 34 V, limited to 1 hour in every 24 hours)			
Input impedance at nominal voltage		kΩ	6.8	19.2	9.6	24	6.4	
Response time (filtering)	Typical Maximum	ms	4			10		20
Reverse polarity			Protected		No	-		
IEC 1131-2 conformity			Type 3	Type 1	Type 3	Non-IEC		
Compatibility with 2-wire/3-wire sensors			IEC 947-5-2		-			
Paralleling of inputs (1)			Yes	No				
Protection of inputs			Use one 0.5 A fast-blow fuse per group of channels					
Insulation resistance		MΩ	>10 at 500 V ...					
Dielectric strength	Primary/Secondary Between groups of channels	Vrms	1,500 - 50/60 Hz for 1 minute (up to 4,000 m)	500 ...		-		
Type of input			Current sink			Resistive		
Sensor voltage control threshold	OK Fault	V	> 18 ... < 14 ...	> 36 ... < 24 ...	> 18 ... < 14 ...			
Reliability	MTBF in hours	At T <sub>ambient</sub> = 30 °C	798,237	696,320	362,681	1,504,958		
Consumption	Typical	mA	See power consumption table page 6/8					
Maximum dissipated power		W	2.5	3.6	3.9	4.3	3	
Temperature derating			None					

(1) This characteristic allows several inputs to be wired in parallel on the same module or on different modules for input redundancy.

### Characteristics of AC input modules

Module		BMX DAI 1602	BMX DAI 1603	BMX DAI 1604
Number of inputs		16		
Connection		Spring or screw-type 20-pin removable terminal block		
Nominal input values	Voltage	V	24 ~	48 ~
	Current	mA	3	5
	Frequency	Hz	50/60	
Input limit values	At state 1	Voltage	$\geq 15$	$\geq 34$
		Current	$\geq 2$	$\geq 2.5$
	At state 0	Voltage	$\leq 5$	$\leq 10$
		Current	$\leq 1$	$\leq 20$
	Frequency	Hz	47...63	
	Sensor power supply (including ripple)	V	20...26	40...52
Current peak	At nominal voltage on activation	mA	5	95
				240
Input impedance at nominal voltage and F = 55 Hz		$\text{k}\Omega$	6	9
Response time (filtering)	Activation	ms	15	10
	Deactivation	ms	20	
IEC 1131-2 conformity		Type 1	Type 3	
Compatibility with 2-wire/3-wire sensors		IEC 947-5-2		
Protection of inputs		Use one 0.5 A fast-blow fuse per group of channels		
Insulation resistance		$\text{M}\Omega$	>10 at 500 V ...	
Dielectric strength		$\text{V}_{\text{rms}}$	1,500 - 50/60 Hz for 1 minute (up to 4,000 m)	
Type of input			Resistive	Capacitive
Sensor voltage control threshold	OK	V	> 18	> 36
	Fault	V	< 14	< 24
Reliability	MTBF in hours	At $T_{\text{ambient}} = 30^\circ\text{C}$	1,504,958	
Consumption	Typical	mA	See power consumption table page 6/8	
Maximum dissipated power		W	3	4
Temperature derating			None	3.8

### Characteristics of triac output module

Module		BMX DAO 1605
Number of inputs		W
Connection		Spring or screw-type 20-pin removable terminal block
Operating voltages	Nominal	V
	Limit	V
Currents	Maximum	A
	Minimum	
Maximum inrush current		A
Leakage current	At state 0	mA
Residual voltage	At state 1	V
Response time	Activation	ms
Nominal resistive load	Deactivation	ms
Type of command		Passage through zero
Built-in protection		Varistor
Protection fuses		None (use an external fast-blow fuse)
Dielectric strength		$\text{V}_{\text{rms}}$
Insulation resistance		$\text{M}\Omega$
Reliability		-
Consumption	Typical	mA
Maximum dissipated power		-

### Characteristics of DC solid state output modules

Module		BMX DDO 1602	BMX DDO 1612	BMX DDO 3202K	BMX DDO 6402K
Number of inputs		16	32	64	
Connection		Spring or screw-type 20-pin removable terminal block	One 40-pin connector	Two 40-pin connectors	
Output nominal values	Voltage	24 ...			
	Current	0.5	0.1		
	Logic	Positive (source)	Negative (sink)	Positive (source)	
Output limit values	Voltage (including ripple)	V	19...30 (possible up to 34 V, limited to 1 hour in every 24 hours)		
	Current per channel	A	0.625	0.125	
	Current per module	A	10	3.2	6.4 if $\theta \leq 40^\circ\text{C}$ 5.1 if $\theta \leq 50^\circ\text{C}$ 3.8 if $\theta \leq 60^\circ\text{C}$
Tungsten filament lamp power	W	6 maximum	1.2 maximum		
Leakage current	At state 0	mA	< 0.5	0.1 (for $U = 30\text{ V}$ )	
Residual voltage	At state 1	V	< 1.2	< 1.5 (for $I = 0.1\text{ A}$ )	
Minimum load impedance	$\Omega$	48	220		
Response time (1)	ms	1.2			
Maximum overload time	ms	—	15		
Compatibility with IEC 1131-2 DC inputs		Yes (type 3, not IEC)	Yes (not IEC)	Yes (type 3, not IEC)	
Paralleling of outputs		Yes (2 max.)	Yes (3 max.)		
Switching frequency on inductive load	Hz	0.5/L <sup>2</sup>			
Built-in protection	Against overvoltages		Yes, by Transil® diode		
	Against reverse polarity		Yes, by reverse-mounted diode. Use a 2 A fuse on the + 24 V of the preactuators.		
	Against short-circuit and overloads		Yes, with current limiter and electronic circuit breaker $1.5\text{ I}_n < \text{I}_d < 2\text{ I}_n$	Yes, with current limiter and electronic circuit breaker $0.125\text{ A} < \text{I}_d < 0.185\text{ A}$	
Preactuator voltage control threshold	At state 0	V	> 18		
	Fault	V	< 14		
Insulation resistance	M $\Omega$	> 10 at 500 V ...			
Dielectric strength	Output/ground or output/internal logic	Vrms	1,500 ~ - 50/60 Hz for 1 minute		
	Between groups of channels	V	—	500 ...	
Reliability	MTBF in hours	At $T_{\text{ambient}} = 30^\circ\text{C}$	409,413	—	360,412
Consumption	Typical	mA	See power consumption table page 6/8		173,792
Maximum dissipated power	W	4	2.26	3.6	6.85
Temperature derating			None		See "Current per module" above

(1) All outputs are equipped with a fast demagnetization circuit for the electromagnets. Discharge time for the electromagnets <  $L/R$ .

(2) Excluding load current.

### Characteristics of relay output modules

Module	BMX DRA 0805				BMX DRA 1605						
Number of inputs	8				16						
Connection	Spring or screw-type 20-pin removable terminal block										
Limit operating voltages	DC	V	10...34 ...				24...125 ... (resistive load)				
	AC	V	10...264 ~				200...264 ~ (Cos φ = 1)				
Thermal current	A	3					2				
Switching load	Minimum	mA	1 at 5 V ...								
Electrical life					24 V	200 V	240 V				
AC load	Power cos φ = 0.7	VA	–				– 300 (1), 80 (2) 240 (1), 72 (2)				
	Power cos φ = 0.35	VA	–				– 200 (1), 60 (2) 120 (1), 36 (2)				
DC load	Power	W	–				24 (1), 7.2 (2) – –				
Voltage			24 V	48 V	110... 120 V	200... 240 V	24 V 200 V 240 V				
AC load	Resistive loads AC-12	Power	VA	50 (3)	50 (4), 110 (5)	110 (4), 220 (5)	220 (4) –				
	Inductive loads AC-15 (cos φ = 0.3)	Power	VA	24 (5)	10 (6), 24 (7)	10 (8), 50 (9), 110 (10)	10 (8), 50 (11), 110 (4), 220 (12) –				
	Inductive loads AC-14 (cos φ = 0.7)	Power	VA	–							
DC load	Resistive loads DC-12	Power	W	24 (4), 40 (13)	–						
	Inductive loads DC-13 (14)	Power	W	10 (7), 24 (4)	– 24 (1), 7.2 (2)						
Response time	Activation	ms	< 10								
	Deactivation	ms	< 8				< 12				
Built-in protection	Against overloads and short-circuits	None. Use a fast-blow fuse per channel or group of channels									
	Against AC inductive overvoltages	None. Use an RC circuit or ZNO surge limiter appropriate to the voltage in parallel on each output									
	Against DC inductive overvoltages	None. Use a discharge diode on each output									
Insulation resistance		MΩ	> 10 at 500 V ...								
Dielectric strength		Vrms	2,000 - 50/60 Hz for 1 minute								
Reliability	MTBF in hours	At T <sub>ambient</sub> = 30 °C	1,573,341				2,463,296				
Consumption	Typical	mA	See power consumption table page 6/8								
Dissipated power		W	2.7 max.				3				
Temperature derating			None								

- (1) For 1 x 10<sup>5</sup> operating cycles
- (2) For 3 x 10<sup>5</sup> operating cycles
- (3) For 0.7 x 10<sup>6</sup> operating cycles
- (4) For 1 x 10<sup>6</sup> operating cycles
- (5) For 0.5 x 10<sup>6</sup> operating cycles
- (6) For 5 x 10<sup>6</sup> operating cycles
- (7) For 2 x 10<sup>6</sup> operating cycles
- (8) For 10 x 10<sup>6</sup> operating cycles
- (9) For 1.5 x 10<sup>6</sup> operating cycles
- (10) For 0.15 x 10<sup>6</sup> operating cycles
- (11) For 3 x 10<sup>6</sup> operating cycles
- (12) For 0.1 x 10<sup>6</sup> operating cycles
- (13) For 0.3 x 10<sup>6</sup> operating cycles
- (14) Where L/R = 60 ms for BMX DRA 0805 module, L/R = 7 ms for BMX DRA 1605 module

Characteristics of mixed I/O relay module			
Module		BMX DDM 16025	
Number of inputs/outputs		24 V $\perp\!\!\!\perp$ inputs	24 V $\perp\!\!\!\perp$ or 24...240 V $\sim$ relay outputs
Connection			
Nominal values	Inputs	Voltage	24 $\perp\!\!\!\perp$ (positive logic)
	Current	mA	3.5
Outputs	DC voltage	V	—
	Direct current	A	—
	AC voltage	V	—
	Alternating current	A	—
Input limit values	At state 1	Voltage	$\geq 11$
	Current	mA	$\geq 2$ (for $U \geq 11$ )
	At state 0	Voltage	5
	Current	mA	$\leq 1.5$
	Sensor power supply (including ripple)	V	19...30 (possible up to 30 V, limited to 1 hour in every 24 hours)
Relay output voltage			
AC load	Inductive loads AC-14 ( $\cos \varphi = 0.7$ )	Power	VA
	Inductive loads AC-15 ( $\cos \varphi = 0.35$ )	Power	VA
DC load	Inductive loads DC-13	Power	W
Maximum switching frequency			—
Input impedance at nominal voltage		K $\Omega$	6.8
Input response time	Typical	ms	4
	Maximum	ms	7
Reverse polarity on inputs			Protected
IEC 1131-2 conformity			Yes, type 3
Compatibility with 2-wire/3-wire sensors			IEC 947-5-2
Paralleling of inputs			No
Input type			Current sink
Output response time	Activation	ms	—
	Deactivation	ms	—
Switching load	Minimum		—
	Maximum	V	—
Mechanical durability	No. of switching operations		—
Fuse protection			Use one 0.5 A fast-blow fuse per group of channels
Sensor voltage control thresholds	OK	V	$> 18$
	Fault	V	$< 14$
Insulation resistance		M $\Omega$	$> 10$ at 500 V $\perp\!\!\!\perp$
Dielectric strength	Primary/secondary	Vrms	1,500 - 50/60 Hz for 1 minute
	Between groups of I/O	V	500 $\perp\!\!\!\perp$
	Max. voltage	Vrms	—
Reliability	MTBF in hours	At $T_{\text{ambient}} = 30^\circ\text{C}$	912,167
Consumption	Typical	mA	See power consumption table page 6/8
Dissipated power		W	3.1 maximum
Temperature derating			None

(1) For  $1 \times 10^5$  operating cycles(2) For  $3 \times 10^5$  operating cycles

(3) Excluding load current

### Characteristics of 24 V --- mixed I/O modules

Module		BMX DDM 16022		BMX DDM 3202K	
		Inputs	Solid state outputs	Inputs	Solid state outputs
Number of inputs/outputs		8	8	16	16
Connection		Spring or screw-type 20-pin removable terminal block		One 40-pin connector	
Nominal values	Voltage	V	24 ---		
	Current	mA	3.5	500	2.5
	Logic		Positive (sink)	Positive (source)	Positive (sink)
Tungsten filament lamp power		W	—	6 maximum	1.2 maximum
Input limit values	At state 1	Voltage	V	≥ 11	≥ 11
		Current	mA	> 3 (for $U \geq 11$ V)	—
	At state 0	Voltage	V	5	5
		Current	mA	≤ 1.5	≤ 1.5
Sensor power supply (including ripple)	Possible up to 30 V, limited to 1 hour in every 24 hours	V	19...30	—	19...30
Output limit values	Voltage (including ripple)	Possible up to 30 V, limited to 1 hour in every 24 hours	V	—	19...30
	Currents	Per channel	mA	625	—
		Per module	A	5	—
Input impedance at nominal voltage		MΩ	6.8	—	9.6
Input response time	Typical	ms	4	—	—
	Maximum	ms	7	—	—
Reverse polarity on inputs			Protected	—	Protected
IEC 1131-2 conformity			Yes, type 3	—	Yes, type 3
Compatibility with 2-wire/3-wire sensors			IEC 947-5-2	—	IEC 947-5-2
Input type			Current sink	—	Current sink
Leakage current	At state 0	mA	—	< 0.5	—
Residual voltage	At state 1	V	—	< 1.2	—
Minimum load impedance		Ω	—	48	—
Output response time (1)		ms	—	1.2	—
Max. overload time before fault state		ms	—	15	—
Compatibility with IEC 1131-2 DC inputs		—	—	Yes (type 3, not IEC)	—
Paralleling of outputs		—	—	Yes (2 maximum)	—
Switching frequency on inductive load		Hz	—	0.5/LI <sup>2</sup>	—
Built-in protection	Against overvoltages		—	Yes, by Transil® diode	—
	Against inversions		—	Yes, by reverse-mounted diode. Use a 2 A fuse on the preactuator + 24 V	—
	Against short-circuits and overloads		Use one 0.5 A fast-blow fuse per group of channels	Yes, by current limiter and electronic circuit breaker 1.5 ln < Id < 2 ln	Use one 0.5 A fast-blow fuse per group of channels
Sensor and preactuator voltage control thresholds	OK	V	> 18	—	Yes, by current limiter and electronic circuit breaker 0.125 A < Id < 0.185 A
	Fault		< 14	—	—
Insulation resistance		MΩ	> 10 at 500 V ---	—	—
Dielectric strength	Primary/secondary	Vrms	1,500 - 50/60 Hz for 1 minute	—	—
	Between groups of inputs and outputs	V	500 ---	—	—
Outputs/ground or outputs/internal logic		—	—	1,500 - 50/60 Hz for 1 minute	—
Reliability	MTBF in hours	At $T_{\text{ambient}} = 30$ °C	447,581	—	432,904
Consumption	3.3 V ---	Typical	mA	79	125
		Maximum	mA	111	166
	24 V ---	Typical	mA	59	69
	preactuators (2)	Maximum	mA	67	104
Maximum dissipated power		W	3.7	—	4
Temperature derating			None	—	—

(1) All outputs are equipped with a fast demagnetization circuit for the electromagnets. Discharge time for the electromagnets < L/R.

(2) Excluding load current.



BMX DDI 1602



BMX DDI 3202K



BMX DDI 6402K

2

### References

#### Discrete input modules

Type of current	Input voltage	Connection by (1)	IEC 1131-2 Modularity conformity	Modularity (no. of channels)	Reference	Weight kg	
==	24 V (positive logic)	Screw or spring-type 20-pin removable terminal block	Type 3	16 isolated inputs	BMXDDI1602	0.115	
		One 40-pin connector	Type 3	32 isolated inputs	BMXDDI3202K	0.112	
		Two 40-pin connectors	Non-IEC	64 isolated inputs	BMXDDI6402K	0.145	
~	24 V (negative logic)	Screw or spring-type 20-pin removable terminal block	Non-IEC	16 isolated inputs	BMXDAI1602 ▲	0.115	
		48 V (positive logic)	Screw or spring-type 20-pin removable terminal block	Type 1	16 isolated inputs	BMXDAI1603 ▲	0.115
		24 V	Screw or spring-type 20-pin removable terminal block	Type 1	16 isolated inputs	BMXDAI1602 ▲	0.115
	48 V	Screw or spring-type 20-pin removable terminal block	Type 3	16 isolated inputs	BMXDAI1603 ▲	0.115	
		100...120 V	Screw or spring-type 20-pin removable terminal block	Type 3	16 isolated inputs	BMXDAI1604	0.115



BMX DDO 1602



BMX DRA 0805/1605



BMX DDO 3202K



BMX DDO 6402K

#### Discrete output modules

Type of current	Output voltage	Connection by (1)	IEC 1131-2 Modularity conformity	Modularity (no. of channels)	Reference	Weight kg
== solid state	24 V/0.5 A (positive logic)	Screw or spring-type 20-pin removable terminal block	Yes	16 protected outputs	BMXDDO1602	0.120
		Screw or spring-type 20-pin removable terminal block	Non-IEC	16 protected outputs	BMXDDO1612 ▲	0.120
	24 V/0.1 A (positive logic)	One 40-pin connector	Yes	32 protected outputs	BMXDDO3202K	0.110
~ triac	24 V/0.1 A (positive logic)	Two 40-pin connectors	Yes	64 protected outputs	BMXDDO6402K	0.150
		100...240	Screw or spring-type 20-pin removable terminal block	–	16 outputs	BMXDAO1605 ▲
	12...24 V ==/3 A, 24...240 V~/3 A	Screw or spring-type 20-pin removable terminal block	Yes	8 non-protected outputs	BMXDRA0805	0.145
== or ~ relay	24 V ==/2 A, 240 V~/2 A	Screw or spring-type 20-pin removable terminal block	Yes	16 non-protected outputs	BMXDRA1605	0.150

(1) By connector, module supplied with cover(s)

▲ Available 4<sup>th</sup> quarter 2007



### References (continued)

#### Discrete mixed I/O modules

Number of I/O	Connection via (1)	No. and type of inputs	No. and type of outputs	IEC 1131-2 conformity	Reference	Weight kg
16	Screw or spring-type 20-pin removable terminal block	8 (positive logic)	8, solid state 24 V $\square$ / 0,5 A	Inputs, type 3	BMXDDM16022	0.115
			8, relay 24 V $\square$ or 24...240 V $\sim$	Inputs, type 3	BMXDDM16025	0.135
32	One 40-pin connector	16 (positive logic)	16, solid state 24 V $\square$ / 0,1 A	Inputs, type 3	BMXDDM3202K	0.110



#### Removable connection blocks

Description	Use	Reference	Weight kg
20-pin removable terminal blocks	Cage clamp	For module with 20-pin removable terminal block	BMXFTB2000
	Screw clamp	For module with 20-pin removable terminal block	BMXFTB2010
	Spring-type	For module with 20-pin removable terminal block	BMXFTB2020

#### Preformed cord sets for I/O modules with removable terminal block

Description	Composition	Length	Reference	Weight kg
Preformed cordsets with one end with wires	One 20-pin terminal block	3 m	BMXFTW301	0.850
	One end with color-coded wires	5 m	BMXFTW501	1.400
		10 m	BMXFTW1001	2.780



#### Preformed cordsets for I/O modules with 40-pin connectors

Description	No. of sheaths	Composition	Cross-section	Length	Reference	Weight kg
Preformed cord sets with one end with wires	1 x 20 wires (16 channels)	One 40-pin connector One end with color-coded wires	0.324 mm <sup>2</sup>	3 m	BMXFCW301	0.820
				5 m	BMXFCW501	1.370
				10 m	BMXFCW1001	2.770



Description	No. of sheaths	Composition	Cross-section	Length	Reference	Weight kg
Preformed cord sets for Telefast® Advantys™ ABE7 sub-bases	2 x 20 wires (32 channels)	One 40-pin connector Two ends with color-coded wires	0.324 mm <sup>2</sup>	3 m	BMXFCW303	0.900
				5 m	BMXFCW503	1.490
				10 m	BMXFCW1003	2.960



Description	No. of sheaths	Composition	Cross-section	Length	Reference	Weight kg
Preformed cord sets for Telefast® Advantys™ ABE7 sub-bases	1 x 20 wires (16 channels)	One 40-pin connector One HE 10 connector	0.324 mm <sup>2</sup>	0.5 m	BMXFCC051	0.140
				1 m	BMXFCC101	0.195
				2 m	BMXFCC201	0.560




Description	No. of sheaths	Composition	Cross-section	Length	Reference	Weight kg
Preformed cord sets for Telefast® Advantys™ ABE7 sub-bases	2 x 20 wires (32 channels)	One 40-pin connector Two HE 10 connectors	0.324 mm <sup>2</sup>	0.5 m	BMXFCC053	0.210
				1 m	BMXFCC103	0.350
				2 m	BMXFCC203	0.630


2

### Input modules


BMX DDI 1602



BMX DDI 1603



BMX DDI 3202K/6402K




BMX DDI 3202K: Connector A (inputs I0...I32)


BMX DDI 6402K: Connector A (inputs I0...I32) and connector B (inputs I33...I63)

For correspondence of the 40-pin connector pins with the wire colors of BMX FCW •01/•03 prewired cord sets, in accordance with DIN 47100, see table on page 2/21

BMX DAI 1602/1603/1604



BMX DAI 1602, use in 24 V ---, negative logic



P-N voltage:

24 V ~: BMX DAI 1602


48 V ~: BMX DAI 1603

100/120 V ~: BMX DAI 1604


Fu: 0.5 A fast-blow fuse

### Output modules


BMX DDO 1602




BMX DDO 1612



BMX DAO 1605



BMX DDO 3202K/6402K




BMX DDO 3202K: Connector A (outputs Q0...Q32)


BMX DDO 6402K: Connector A (outputs Q0...Q32) and connector B (outputs Q33...Q63)

**Note :** For correspondence of the 40-pin connector pins with the wire colors of BMX FCW 001/003 prewired cord sets, in accordance with DIN 47100, see table on page 2/21.

BMX DRA 0805




BMX DRA 1605




2

## Mixed I/O modules


BMX DDM 16025



BMX DDM 16022




BMX DDM 3202K




Fu: 0.5 A fast-blow fuse

## Connection cables with 40-pin connector and end(s) with wires BMX FCW •01/•03

Correspondence of connector pins with the wire colors at the sheath end



Cord set with one sheathed end with wires BMX FCW •01




Cord set with two sheathed ends with wires BMX FCW •03

Connector pin no.	Color at sheath end	32/64-channel inputs	32/64-channel outputs	32-channel I/O
B20	White	Input 0/32	Output 0/32	Input 0
A20	Brown	Input 1/33	Output 1/33	Input 1
B19	Green	Input 2/34	Output 2/34	Input 2
A19	Yellow	Input 3/35	Output 3/35	Input 3
B18	Gray	Input 4/36	Output 4/36	Input 4
A18	Pink	Input 5/37	Output 5/37	Input 5
B17	Blue	Input 6/38	Output 6/38	Input 6
A17	Red	Input 7/39	Output 7/39	Input 7
B16	Black	Input 8/40	Output 8/40	Input 8
A16	Purple	Input 9/41	Output 9/41	Input 9
B15	Gray/pink	Input 10/42	Output 10/42	Input 10
A15	Red/blue	Input 11/43	Output 11/43	Input 11
B14	White/green	Input 12/44	Output 12/44	Input 12
A14	Brown/green	Input 13/45	Output 13/45	Input 13
B13	White/yellow	Input 14/46	Output 14/46	Input 14
A13	Yellow/brown	Input 15/47	Output 15/47	Input 15
B12	White/gray	+ 24 V	+ 24 V	+ 24 V
A12	Gray/brown	- 24 V	- 24 V	- 24 V
B11	White/pink	+ 24 V	+ 24 V	+ 24 V
A11	Pink/brown	- 24 V	- 24 V	- 24 V
B10	White	Input 16/48	Output 16/48	Output 0
A10	Brown	Input 17/49	Output 17/49	Output 1
B9	Green	Input 18/50	Output 18/50	Output 2
A9	Yellow	Input 19/51	Output 19/51	Output 3
B8	Gray	Input 20/52	Output 20/52	Output 4
A8	Pink	Input 21/53	Output 21/53	Output 5
B7	Blue	Input 22/54	Output 22/54	Output 6
A7	Red	Input 23/55	Output 23/55	Output 7
B6	Black	Input 24/56	Output 24/56	Output 8
A6	Purple	Input 25/57	Output 25/57	Output 9
B5	Gray/pink	Input 26/58	Output 26/58	Output 10
A5	Red/blue	Input 27/59	Output 27/59	Output 11
B4	White/green	Input 28/60	Output 28/60	Output 12
A4	Brown/green	Input 29/61	Output 29/61	Output 13
B3	White/yellow	Input 30/62	Output 30/62	Output 14
A3	Yellow/brown	Input 31/63	Output 31/63	Output 15
B2	White/gray	+ 24 V	+ 24 V	+ 24 V
A2	Gray/brown	- 24 V	- 24 V	- 24 V
B1	White/pink	+ 24 V	+ 24 V	+ 24 V
A1	Pink/brown	- 24 V	- 24 V	- 24 V

## Connection cables with 20-pin terminal block at one end and wires at the other BMX FTW •01

Correspondence of 20-pin removable terminal block pins with the wire colors (at sheath end)

Correspondence of terminal block pins with the wire colors at the sheath end



Cord set with 1 sheathed end with wires BMX FTW •01

Terminal block pin no. end	Color at sheath	16-channel inputs	8- or 16-channel outputs	16-channel I/O
1	White	Input 0	See page 2/19	Input 0
2	Brown	Input 1	See page 2/19	Input 1
3	Green	Input 2	See page 2/19	Input 2
4	Yellow	Input 3	See page 2/19	Input 3
5	Gray	Input 4	See page 2/19	Input 4
6	Pink	Input 5	See page 2/19	Input 5
7	Blue	Input 6	See page 2/19	Input 6
8	Red	Input 7	See page 2/19	Input 7
9	Black	Input 8	See page 2/19	Sensor + common power supply
10	Purple	Input 9	See page 2/19	Sensor pwr supply
11	Gray/pink	Input 10	See page 2/19	Output 0
12	Red/blue	Input 11	See page 2/19	Output 1
13	White/green	Input 12	See page 2/19	Output 2
14	Brown/green	Input 13	See page 2/19	Output 3
15	White/yellow	Input 14	See page 2/19	Output 4
16	Yellow/brown	Input 15	See page 2/19	Output 5
17	White/gray	Power supply	See page 2/19	Output 6
18	Gray/brown	+ common pwr sup.	See page 2/19	Output 7
19	White/pink	Power supply	See page 2/19	Pneumatic pwr sup.
20	Pink/brown	Power supply	See page 2/19	Pneumatic pwr sup.

## Applications

## Analog inputs



## Type of I/O

## Type

## Range

## Voltage

## Current

Thermocouple,  
Temperature probe,  
Resistor

## Modularity

## Acquisition period

## Conversion time

## Resolution

## Isolation

## Connection

## Directly to the module

## Via preformed cord sets

## Module

## Page

Isolated low-level voltage inputs, resistors, thermocouples and temperature probes

Multi-range

 $\pm 40 \text{ mV}, \pm 80 \text{ mV}, \pm 160 \text{ mV}, \pm 320 \text{ mV}, \pm 640 \text{ mV}$  and  $\pm 1.28 \text{ V}$ 

–

Thermocouples type B, E, J, K, L, N, R, S, T, U  
Temperature probes type Pt 100, Pt 1000, Ni 100, Ni 1000 and Cu 10, 2-,3- or 4-wire  
Resistors 2-, 3- or 4-wire, 400  $\Omega$  or 4,000  $\Omega$ 

4 channels

8 channels

400 ms for all 4 channels

400 ms for all 8 channels

–

16 bits

Between channels: 750 V  $\text{---}$   
Between channels and bus: 2,000 V  $\text{---}$   
Between channels and ground: 750 V  $\text{---}$ 

Via 40-pin connector

Via two 40-pin connectors

BMX FCW 001S cord sets with one end with color-coded wires (3 or 5 m long)

BMX ART 0414

BMX ART 0814 ▲

2/32



## Compatibility with Advantys™ Telefast® ABE7 pre-wired I/O system

Sub-base with 4 channels for direct connection of 4 thermocouples plus connection and provision of cold-junction compensation

## Type of module

## Connection sub-base

Preformed cord sets  
(1.5, 3 or 5 m long)

ABE7CPA412

BMX FCA002

## Pages

5/16 and 2/32

▲ Available 4<sup>th</sup> quarter 2007

**Analog inputs****Analog outputs****Mixed analog I/O****2****Isolated high-level inputs****Voltage/current** $\pm 10 \text{ V}, 0...10 \text{ V}, 0...5 \text{ V}, 1...5 \text{ V}, \pm 5 \text{ V}$ 0...20 mA, 4...20 mA,  $\pm 20$  mA

–

4 channels

Fast: 1 + (1 x no. of declared channels) ms  
By default, 5 ms for all 4 channels

–

16 bits

Between channels: 300 V  $\text{---}$   
Between channels and bus: 2,000 V  $\text{---}$   
Between channels and ground: 2,000 V  $\text{---}$ 

Via 20-pin removable terminals (screw or spring-type)

BMX FTW 01S cord sets with one end with color-coded wires (3 or 5 m long)

**BMX AMI 0410****Isolated high-level outputs****Voltage/current** $\pm 10 \text{ V}$ 

0...20 mA, 4...20 mA

–

2 channels

–

 $\leq 1 \text{ ms}$ 

16 bits

Between channels: 1,400 V  $\text{---}$   
Between channels and bus: 2,000 V  $\text{---}$   
Between channels and ground: 2,000 V  $\text{---}$ **Non-isolated high-level inputs****Voltage/current** $\pm 10 \text{ V}, 0...10 \text{ V}, 0...5 \text{ V}, 1...5 \text{ V}$ 

0...20 mA, 4...20 mA

–

4 channels

Fast: 1 + (1 x no. of declared channels) ms  
By default, 5 ms for all 4 channels

–

12 bits in 10 V range  
10 bits in 20 mA rangeBetween group of input channels and group of output channels: 1,400 V  $\text{---}$   
Between channels and bus: 2,000 V  $\text{---}$   
Between channels and ground: 2,000 V  $\text{---}$ **Non-isolated high-level outputs****Voltage/current** $\pm 10 \text{ V}$ 

0...20 mA, 4...20 mA

–

2 channels

–

 $\leq 2 \text{ ms}$ **BMX AMM 0600** ▲

2/32



4-channel sub-base for direct connection of 4 inputs, delivers and distributes 4 protected isolated power supplies

**ABE7CPA410****BMX FCA000**

–

5/16 and 2/32

–

## Presentation

The analog I/O module offer consists of:

- Three isolated analog input modules:
  - 4 analog high-speed channels (16 bits), voltage or current, **BMX AMI 0410**
  - 4 and 8 analog channels (15 bits + sign) for thermocouples, Pt, Ni or Cu temperature probes, **BMX ART 0414/0814**
- One analog output module with 2 voltage/current channels, **BMX AMO 0210**
- One mixed module (12 bits) with 4 analog input channels and 2 analog output channels, non-isolated, voltage or current, **BMX AMM 0600**

Analog I/O modules are equipped with a connector for a 20-pin removable terminal block, except for **BMX ART 0414/0814** analog input modules with thermocouples/temperature probes, which are equipped with a 40-pin connector.

All analog modules occupy a single slot in the **BMX XBP** **●●●** racks. These modules can be installed in any slot in the rack, except the first two (PS and 00) reserved for the power supply module in the **BMX CPS** **●●●** rack, and the **BMX P34** **●●●** processor module respectively.

The power supply for the analog functions is supplied by the backplane bus (3.3 V and 24 V). Analog I/O modules are hot-swappable (see page 2/8).

In a Modicon M340 single-rack configuration, the maximum number of analog channels is limited by the number of slots available in the rack (11 slots maximum).

## Description

**BMX AM●/ART** analog I/O modules are standard format (1 slot). Their case ensures IP 20 protection of the electronics, and they are locked into position by a captive screw.

### I/O modules connected via 20-pin removable terminal block

**BMX AM●** analog I/O modules have the following on the front panel:

- 1 A rigid body providing support and protection for the electronic card
- 2 A module reference marking (a label is also visible on the right-hand side of the module).
- 3 A module and channel status display block
- 4 A connector taking the 20-pin removable terminal block, for connecting sensors or preactuators on screw or spring-type terminals

**To be ordered separately:**

- 5 A **BMX FTB 20●0** 20-pin removable terminal block, or preformed cord sets with 20-pin terminal block at one end and wires at the other (**BMX FTW ●01S** or, with 25-pin SUB-D connector, **BMX FCA ●●0**) for direct connection to Advantys™ Telefast® ABE7 sub-bases (see page 2/30).

### I/O modules connected via 40-pin connector

**BMX ART 0●14** analog input modules have the following on the front panel:



- 1 A rigid body providing support and protection for the electronic card
- 2 A module reference marking (a label is also visible on the right-hand side of the module)
- 3 A module and channel status display block
- 4 A 40-pin connector for connecting the sensors


**To be ordered separately:**

- 5 Preformed cord sets with a 40-pin connector at one end and wires at the other (**BMX FCW ●01S** or, with 25-pin SUB-D connector, **BMX FCA ●●2**) for direct connection to Advantys™ Telefast® ABE7 sub-bases (see page 2/31).

**To be ordered separately** regardless of the type of module:

- A shielding connection kit to protect against electrostatic discharge, consisting of a metal bar and two sub-bases for mounting on the rack supporting the analog modules
- A set of **STB XSP 3020** clamping rings for the shielding braids of analog signal cables.





### Connecting modules with removable terminal blocks

#### BMX AMI 0410/AMO 0210/AMM 0600 modules with 20-pin terminal block

These 20-pin removable terminal blocks are the same as those used for discrete I/O modules (screw clamp, cage clamp or spring-type). See page 2/7.

One version of the removable terminal block is equipped with a 3 or 5 m long cord set with color-coded wires (BMX FTW●01S). These preformed cord sets, with reinforced shielding have, at the other end 1, color-coded wires conforming to standard DIN 47100.


2

### Connecting modules with 40-pin connectors

#### BMX ART 0●14 modules with 40-pin connectors

Two types of cord set are available:

- Preformed cord sets with reinforced shielding (BMX FCW●01S) have, at the other end 2, color-coded wires conforming to standard DIN 47100. They are available in 3 or 5 m lengths, and provide easy direct wire-to-wire connection of the analog sensors via terminal blocks.
- Preformed cord sets with reinforced shielding (BMX FCA●02) which have at the other end 3, a 25-pin SUB-D connector. They are available in 1.5, 3 or 5 m lengths, and provide direct connection to the Advantys™ Telefast® ABE7CPA412 sub-base (see below).



### Use with Advantys™ Telefast® ABE7 sub-bases

Using the Advantys Telefast ABE7 pre-wired I/O system makes it easier to install the modules since the inputs (or outputs) can be accessed using screw terminals. Two special sub-bases are available:

#### Advantys™ Telefast® ABE7CPA410 sub-base

The Advantys Telefast ABE7CPA410 sub-base is mainly used in conjunction with the BMX AMI 0410 voltage/current analog 4-input module. It is used to:

- Connect the four sensors directly
- Remotely locate the input terminals in voltage mode
- Power the 4...20 mA conditioners one channel at a time with 24 V voltage-protection, and circuit-limiting to 25 mA, while maintaining isolation between channels
- Protect the current impedance matching resistors integrated in the sub-base against overvoltages

Connection is via the BMX FCA●00 cord set (1.5, 3 or 5 m long).

#### Advantys™ Telefast® ABE7CPA412 sub-base

The Advantys Telefast ABE7CPA412 sub-base is specially designed as a wiring interface for the BMX ART 0414 and BMX ART 0814 thermocouple modules. It is used to:

- Connect the four thermocouple probes
- Provide external cold-junction compensation with a temperature probe integrated in the sub-base
- Ensure continuity of the shielding

The BMX ART 0814 module requires two Advantys Telefast ABE7CPA412 sub-bases. The connection with each sub-base is made via a BMX FCA●02 cord set (1.5, 3 or 5 m long).

### BMX AMI 0410 analog input modules

The **BMX AMI 0410** module is a high-level analog input module with 4 isolated inputs (16 bits).

Used with sensors or transmitters, it performs monitoring, measurement and process control functions for continuous processes.

For each input, the **BMX AMI 0410** module offers the following ranges:

- Voltage  $\pm 10$  V,  $\pm 5$  V, 0...10 V, 0...5 V and 1...5 V
- Current 0...20 mA, 4...20 mA and  $\pm 20$  mA, depending on the choice made during configuration

The module operates with voltage inputs. It includes four reading resistors connected to the terminal block to form the current inputs.

#### Functions

The **BMX AMI 0410** module includes the following functions:

- Adaptation and multiplexing:
- Physical connection to the process
- Protection of the module against overvoltages
- Protection of the current reading resistors
- Adaptation of input signals by analog filtering
- Scanning of input channels by solid state multiplexing, by optical commutator switches
- Adaptation to input signals: Gain selection, drift compensation
- Conversion: 24-bit analog/digital converter
- Conversion of input measurements to a unit that is suitable for the user:
- Taking account of the alignment coefficients to be applied to measurements, as well as the module auto calibration coefficients
- Measurement filtering, depending on the configuration parameters
- Measurement scaling, depending on the configuration parameters
- Interface and communication with the application:
- Receipt of the configuration parameters for the module and its channels
- Transmission of measured values to the application, as well as module status
- Module power supply
- Module monitoring and indication of any faults to the application:
- Conversion circuit test
- Channel range overshoot test and watchdog test.

### BMX ART 0414/0814 analog input modules

**BMX ART 0414/0814** modules are multi range input modules with 4 or 8 low-level isolated inputs (15 bits + sign) respectively.

Depending on the choice made during configuration, the modules offer, for each of the inputs, the following range:

- Temperature probe: Pt100, Pt1000, Cu10, Ni100 or Ni1000, with open-circuit detection
- Thermocouple: B, E, J, K, L, N, R, S, T or U, with broken wire detection
- Resistor: 0...400 or 0...4000  $\Omega$ , 2-, 3- or 4-wire
- Voltage:  $\pm 40$  mV,  $\pm 80$  mV,  $\pm 160$  mV,  $\pm 320$  mV,  $\pm 640$  mV,  $\pm 1.28$  V.

#### Functions

**BMX ART 0414/0814** modules offer the following functions

- Adaptation and current source per channel:
- Accepting an overload of  $\pm 7.5$  V
- Auto calibration of the analog module offset as close as possible to the input terminal
- Selection of the cold-junction compensation sensor included in the Advantys™ Telefast® **ABE7CPA412** sub-base or externally by the Pt 100 probe
- Adaptation to input signals: Based on a low offset amplifier internal to the A/D converter
- Conversion: 16-bit converter
- Conversion of input measurements to a unit that is suitable for the user:
- Taking account of the alignment coefficients to be applied to measurements, as well as the module auto calibration coefficients
- Measurement filtering, depending on the configuration parameters
- Measurement scaling, depending on the configuration parameters
- Interface and communication with the application:
- Receipt of the configuration parameters for the module and its channels
- Transmission of measured values to the application, as well as module status
- Module monitoring and indication of any faults to the application:
- Conversion circuit test
- Channel range overshoot test and watchdog test.

### BMX AMO 0210 analog output module

The **BMX AMO 0210** module has 2 high-level isolated outputs (15 bits + sign). For each of them it offers the ranges:

- Voltage:  $\pm 10$  V
- Current: 0...20 mA and 4...20 mA

The range is selected during configuration.

#### Functions

The **BMX AMO 210** module includes the following functions:

- Physical connection to the processor
- Protection of the module against overvoltages
- Adaptation of the output signals:
  - Voltage or current adaptation by software configuration
  - Protection of the outputs against short-circuits and overloads
- Conversion to 15 bits + sign with redefinition of data
- Conversion of application values into data that can be used by the digital/analog converter:
  - Use of factory calibration parameters
  - Interface and communication with the application:
    - Managing exchanges with the processor
    - Geographical addressing
    - Receipt of the configuration parameters for the module and its channels
    - Transmission of module status to the application
  - Module monitoring and indication of any faults to the application:
    - Output power supply test
    - Channel range overshoot test
    - Output fault presence test
    - Watchdog test.

### BMX AMM 0600 mixed analog I/O module

The **BMX AMM 0600** mixed module is a module with 4 inputs 14/12 bits and 2 outputs 12 bits non-isolated between one another. For each of them it offers the ranges:

- Voltage:  $\pm 10$  V, 0...10 V, 0...5 V and 1...5 V
- Current: 0...20 mA and 4...20 mA.

#### Functions

The **BMX AMM 0600** module has the following functions:

- Protection of the module against overvoltages
- Adaptation to the different actuators: voltage or current output
- Conversion of digital signals (10 bits or 12 bits depending on the range) to analog signals
- Conversion of application data into data that can be used by the digital/analog converter
- Module monitoring and fault indication to the application: Converter test, range overshoot test, watchdog test.

**Characteristics of BMX AMI 0410 analog input modules**

		BMX AMI 0410								
Input module		Isolated high-level inputs								
Input type		4								
Number of channels										
Nature of inputs	Voltage	$\pm 10 \text{ V}, 0...10 \text{ V}, 0...5 \text{ V}, 1...5 \text{ V}, \pm 5 \text{ V}$								
	Current	0...20 mA, 4...20 mA, $\pm 20 \text{ mA}$ (via protected internal 250 $\Omega$ resistors)								
Analog/digital conversion		24 bits								
Voltage/current range		$\pm 10 \text{ V}$	$\pm 5 \text{ V}$	0...5 V	0...10 V	1...5 V	0...20 mA	4...20 mA	$\pm 20 \text{ mA}$	
Maximum conversion value		$\pm 11.4 \text{ V}$								
Resolution		0.35 mV								
Input impedance	Typical	$M\Omega$	10 (regardless of the input level)							
Permitted overload on the inputs	Voltage range	V	$\pm 30 \text{ ---}$							
	Current range	mA	$\pm 90$ of short-circuit to + 24 V ---							
Voltage/current internal conversion resistor		$\Omega$	—							
Precision of internal conversion resistor			—							
			0.1% - 15 ppm/ $^{\circ}\text{C}$							
Filtering			1 <sup>st</sup> order digital filtering							
Read cycle time	Fast	ms	1 + 1 x no. of channels used (periodic reading of no. of declared channels)							
	Default	ms	5 for 4 channels (periodic reading of all channels)							
Measurement errors (1)	At 25 °C	%FS	0.075%							
	Maximum at 0...60 °C	%FS	0.1%							
Temperature drift			15 ppm/ $^{\circ}\text{C}$							
Recalibration			30 ppm/ $^{\circ}\text{C}$							
Common mode between channels		dB	Internal							
Digital value format			120							
Isolation	Between channels	V	$\pm 300 \text{ ---}$							
	Between channels and bus	V	2,000 $\text{---}$							
	Between channels and ground	V	2,000 $\text{---}$							
Consumption	Typical	mA	See power consumption table page 6/8							

**Characteristics of BMX ART 0414/0814 analog input modules**

		BMX ART 0414		BMX ART 0814		
Input module		Isolated inputs, low-level voltage, resistors, temperature probes, thermocouples				
Input type		4		8		
Number of channels						
Nature of inputs		$\pm 40 \text{ mV}; \pm 80 \text{ mV}; \pm 160 \text{ mV}; \pm 320 \text{ mV}; \pm 640 \text{ mV}; \pm 1.28 \text{ V}$				
Analog/digital conversion		$\Sigma \Delta$ 16 bits				
Resolution		mV	15 + sign			
Filtering			1 <sup>st</sup> order digital filtering			
Read cycle time		ms	400 with temperature probes (1...4) 200 with thermocouples (1...4)		400 with temperature probes (1...8) 200 with thermocouples (1...8)	
Permitted overload on the inputs		V	$\pm 7.5 \text{ ---}$			
50/60 Hz rejection	Differential mode	Typical	dB	60		
	Common mode	Typical	dB	120		
Cold junction compensation	External compensation by Pt100 probe		<input type="checkbox"/> Using the dedicated Advantys™ Telefast® ABE7CPA412 sub-base including the probe <input type="checkbox"/> Using a 2-wire temperature probe wired on channel 0 and/or 4 <input type="checkbox"/> Using a 3-wire temperature probe wired on channel 3 and/or 7			
Recalibration			Internal			
Isolation	Between channels	V	750 $\text{---}$			
	Between channels and bus	V	2,000 $\text{---}$			
	Between channels and ground	V	750 $\text{---}$			
Consumption	Typical	mA	See power consumption table page 6/8			

(1) %FS: Error as a% of full scale

(2) Including the conversion resistor error

## Characteristics of BMX ART 0414/0814 analog input modules

Input ranges for BMX ART 0414/0814 modules

Voltage range		± 40 mV	± 80 mV	± 160 mV	± 320 mV	± 640 mV	± 1.28 V
Typical input impedance	MΩ	10					
Maximum conversion value		± 102.5%					
Maximum resolution	mV	40/2 <sup>14</sup>	80/2 <sup>14</sup>	160/2 <sup>14</sup>	320/2 <sup>14</sup>	640/2 <sup>14</sup>	1280/2 <sup>14</sup>
Measurement errors	At 25 °C	%FS	0.05				
(1)	Maximum at 0...60 °C	%FS	0.15				
Temperature drift	ppm/°C	30					
Resistor range		400 Ω		4,000 Ω			
Type		2-, 3- or 4-wire					
Maximum conversion value		± 100%					
Maximum resolution	mV	400/2 <sup>14</sup>		4,000/2 <sup>14</sup>			
Measurement errors	At 25 °C	%FS	0.12				
(1)	Maximum at 0...60 °C	%FS	0.2				
Temperature drift	ppm/°C	25					
Temperature probe ranges		Pt100	Pt1000	Cu10	Ni100	Ni1000	
Measurement range	°C	According to IEC: -200...+850		-100...+260	-60...+180		
Resolution	°C	0.1					
Detection type		Open circuit (detection on each channel)					
Measurement errors	At 25 °C (2)	°C	± 2.1	± 4	± 2.1	0.7	
(1)	Maximum at 0...60 °C	°C	± 2	± 4	± 3.0	1.3	
Max. wiring resistance	4-wire	Ω	50	500	50	500	
	2/3-wire	Ω	20	200	20	200	
Temperature drift		ppm/°C	30 ppm/°C				
Thermocouple ranges		B	E	J	K	L	
Measurement range	°C	+130...+1820	-270...+1000	-200...+760	-270...+1370	-200...+900	
Resolution	°C	0.1					
Detection type		Open circuit (detection on each channel)					
Measurement errors	At 25 °C	°C	± 3.5	± 3.7	± 2.8	± 3.7	± 3.0
(1)	Maximum at 0...60 °C	°C	± 5	± 5	± 4.5	± 5	± 4.5
Temperature drift		ppm/°C	25				
Thermocouple ranges (continued)		N	R	S	T	U	
Measurement range	°C	+270...+1300	-50...+1769	-50...+1769	-270...+400	-200...+600	
Resolution	°C	0.1					
Detection type		Open circuit (detection on each channel)					
Measurement errors	At 25 °C	°C	± 3.7	± 3.2	± 3.2	± 3.7	± 2.7
(1)	Maximum at 0...60 °C	°C	± 5	± 4.5	± 4.5	± 5	± 4.5
Temperature drift		ppm/°C	25				

(1) %FS: Error as a % of full scale. ± 1 °C with Pt100 temperature probe range, - 100...+ 200 °C

(2) Excluding error caused by the wiring

### Characteristics of the BMX AMO 0210 analog output module

Module	BMX AMO 0210	
Output type	Isolated high-level outputs	
Number of channels	2	
Ranges	Voltage	$\pm 10$ V
	Current	0...20 mA and 4...20 mA
Resolution	bits	15 + sign
Conversion time	ms	$\leq 1$
Output power supply		Internal power supply via rack
Output ranges		Voltage      Current
Adjustment range	Nominal	V $\pm 10$ V
	Maximum	V $\pm 11.25$ V
Load impedance	$\Omega$	$\geq 1,000$ $\leq 600$
Detection type		Short-circuit      Open circuit
Measurement errors	At 25 °C	%FS 0.10
(1)	Maximum at 0...60 °C	%FS 0.25
Temperature drift		40 ppm/°C
Recalibration		None, factory-calibrated
Fallback mode (2)		Default or configurable
Isolation	Between channels	V rms 1,400 V ...
	Between channels and bus	V rms 2,000 V ...
	Between channels and ground	V rms 2,000 V ...
Consumption	Typical	mA See power consumption table page 6/8

### Characteristics of BMX AMM 0600 mixed analog I/O module

Module	BMX AMM 0600	
Channel type	Non-isolated high-level inputs	
Number of channels	4	
Ranges	$\pm 10$ V	0...5 V
	0...10 V	1...5 V
Maximum conversion value	V	$\pm 11.25$
	mA	—
Resolution	bits	14      12      13      12      12      12      11
Filtering		1 <sup>st</sup> order digital filtering by firmware
Precision of internal conversion resistor		250 $\Omega$ , 0.2% - 25 ppm/°C
Read cycle time	Fast	ms 1 + 1 x no. of channels used (periodic reading of no. of declared channels)
	Default	ms 5 for 4 channels
Conversion time	ms	—
Permitted overload on the input channels	Voltage	$\pm 30$ — $\pm 11.25$ —
	Current	mA — $\pm 30$ —      0...24 mA
Measurement errors	At 25 °C	%FS 0.25
(1)	Maximum at 0...60 °C	%FS 0.35      0.50      0.60
Temperature drift		30 ppm/°C      50 ppm/°C      100 ppm/°C
Recalibration		Internal      None, factory-calibrated
Fallback mode (2)		—      Default or configurable
Isolation	Between group of input channels and group of output channels	V 1,400 ...
	Between channels and bus	V 2,000 ...
	Between channels and ground	V 2,000 ...
Consumption	Typical	mA See power consumption table page 6/8

(1) %FS: Error as a % of full scale

(2) Default: Output at 0 (V or mA). Configurable: Hold last value or set at predefined value for each channel.



BMX AMI 0000



BMX ART 0414    BMX ART 0814



BMX FTB 2000



BMX FTW 001S



ABE7CPA410



BMX FCA 000



BMX FCA 002

### References

#### Analog input modules

Input type	Input signal range	Resolution	Connection	No. of channels	Reference	Weight kg
Isolated high-level inputs	± 10 V, 0...10 V, 0...5 V, 1...5 V, ± 5 V 0...20 mA, 4...20 mA, ± 20 mA	16 bits	Via cage clamp, screw clamp or spring-type removable terminal block	4 fast channels	BMXAMI0410	–
Isolated low-level inputs	Temperature probe, thermocouple ± 40 mV, ± 80 mV, ± 160 mV, ± 320 mV, ± 640 mV, ± 1.28 V 0...400 Ω, 0...4000 Ω	15 bits + sign	40-pin connector	4 channels BMXART0414 8 channels BMXART0814 ▲		–

2

#### Analog output module

Output type	Output signal range	Resolution	Connection	No. of channels	Reference	Weight kg
Isolated high-level outputs	± 10 V, 0...20 mA, 4...20 mA	16 bits	Via cage clamp, screw clamp or spring-type removable terminal block	2 channels BMXAMO0210		–

#### Mixed analog I/O module

Channel type	Signal range	Resolution	Connection	No. of channels	Reference	Weight kg
Mixed I/O, non-isolated	± 10 V, 0...10 V, 0...5 V, 1...5 V, 0...20 mA, 4...20 mA depending on the range	14 bits or 12 bits	Via cage clamp, screw clamp or cage spring-type removable terminal block	I: 4 channels Q: 2 channels	BMXAMM0600 ▲	–

#### Connection accessories for analog modules (1)

Description	For use with modules	Type, composition	Length	Reference	Weight kg
20-pin removable terminal blocks	BMX AMI 0410 BMX AMO 0210 BMX AMM 0600	Cage clamp Screw clamp Spring-type	–	BMXFTB2000 BMXFTB2010 BMXFTB2020	–
Preformed cord sets	BMX AMI 0410 BMX AMO 0210 BMX AMM 0600	One 20-pin removable terminal block One end with color-coded wires	3 m 5 m	BMXFTW301S BMXFTW501S	–
	BMX ART 0414 BMX ART 0814 (2)	One 40-pin connector One end with color-coded wires	3 m 5 m	BMXFCW301S BMXFCW501S	–


#### Advantys™ Telefast® ABE7 pre-wired I/O system

Advantys Telefast ABE7 sub-bases	BMX AMI 0410	Distribution of isolated power supplies Delivers 4 protected isolated power supplies for 4...20 mA inputs Direct connection of 4 inputs	–	ABE7CPA410	0.180
	BMX ART 0414 BMX ART 0814	Connection and provision of cold junction compensation for thermocouples Direct connection of 4 inputs	–	ABE7CPA412	0.180
Preformed cord sets for ABE7CPA000 sub-bases	BMX AMI 0410	One 20-pin removable terminal block and one 25-pin SUB-D connector for ABE7CPA410 sub-base	1.5 m 3 m 5 m	BMXFCA150 BMXFCA300 BMXFCA500	–
	BMX ART 0414 BMX ART 0814	One 40-pin connector and one 25-pin SUB-D connector for ABE7CPA412 sub-base	1.5 m 3 m 5 m	BMXFCA152 BMXFCA302 BMXFCA502	–

(1) The shielding on the cord sets carrying the analog signals must always be connected to the BMX XSP000 shielding connection kit mounted under the rack holding the analog modules (see page 1/15).

(2) The BMX ART 0814 8-channel module requires two ABE7CPA412 sub-bases and two BMX FCA002 cord sets.

▲ Available 4<sup>th</sup> quarter 2007



CONT\_CTRL, programmable process control integrated in  
Unity Pro

## Process control in machines

Unity Pro™ software contains CONT\_CTRL, a library of 36 function blocks used to create control loops for machine control.

Modicon M340 processors meet the requirements for closed loop control functions in machines are adequately met by Modicon M340 thanks to the wealth of functions in the library and the flexibility with which function blocks can be linked together through programming. This solution therefore eliminates the need for external controllers, and simplifies the overall control architecture of the machine, as well as its design, roll-out and operation.

The function blocks, EF or EFB, can be used in all Unity Pro™ languages, i.e., LD, ST, IL and FBD. FBD is particularly suitable for accessing control processing operations in Unity Pro™ software through its assistant for entering and viewing parameters and function block variables.

## CONT\_CTRL library functions

The library consists of five function families:

- Input data conditioning
- Controllers
- Math functions
- Measurement processing
- Output value processing

### Input data conditioning


DTIME	Pure delay
INTEGRATOR	Integrator with limiting
LAG_FILTER	First order time lag device
LDLG	PD device with smoothing
LEAD	Differentiator with smoothing
MFLOW	Mass flow calculation based on the measurement of differential pressure or flow speed with pressure and temperature compensation
QDTIME	Deadtime device
SCALING	Scaling
TOTALIZER	Integrator (typically of flow) until a limit (typically a volume) is reached, with automatic reset
VEL_LIM	Velocity limiter, with manipulated variable limiting

### Controllers


PI_B	Simple PI controller: PI algorithm with a mixed structure (series/parallel)
PIDFF	Complete PID controller: PID algorithm with a parallel or mixed structure (series/parallel)
AUTOTUNE	Automatic tuner setting for the PIDFF (complete PID) controller or the PI_B (simple PI) controller <ul style="list-style-type: none"> <li>□ Identification using Ziegler Nichols type method</li> <li>□ Modeling based on 1<sup>st</sup> order process</li> <li>□ Building of control parameters with criterion for prioritizing either the reaction time to disturbance (dynamic) or the stability of the process</li> </ul>
IMC	Model corrector. The model is a first order model with delay. This corrector is useful: <ul style="list-style-type: none"> <li>□ When there are serious delays compared with the main time constant of the process; this scenario cannot be satisfactorily resolved by standard PID process control</li> <li>□ For regulating a non-linear process</li> </ul> IMC can handle any stable and aperiodic process of any order.

### Math functions

COMP_DB	Comparison of two values, with dead zone and hysteresis
K_SQRT	Square root, with weighting and threshold, useful for linearization of flow measurements
MULDIV_W	Weighted multiplication/division of 3 numerical values
SUM_W	Weighted summation of 3 numerical values



Example: PID controller with MS manual control



Programming in Unity Pro in offline mode

#### Measurement processing


AVGMV	Moving average with fixed number of samples (50 max.)
AVGMV_K	Moving average with constant correction factor, 10,000 samples max.
DEAD_ZONE	Dead zone
LOOKUP_TABLE1	Linearization of characteristic curves using first-order interpolation
SAH	Detection of a rising edge
HYST_XXX	Detection of high threshold with hysteresis (1)
INDLIM_XXX	Detection of high and low thresholds with hysteresis (1)

#### Output value processing

MS	Manual control of an output
MS_DB	Manual control of an output with dead zone
PWM1	Control via pulse width modulation
SERVO	Control for servo motors
SPLRG	Control of two <i>Split Range</i> actuators

#### Setpoint management

RAMP	Ramp generator, with separate ascending and descending ramps
RATIO	Ratio controller
SP_SEL	Selection of setpoint value: local (operator) or <i>remote</i> (processing)



Programming in online mode

#### Setting up process control function blocks

Based on the sequencing of function blocks, the FBD language integrated into Unity Pro™ programming language is particularly suitable for building control loops. Designers can use FBD to easily associate blocks from the CONT\_CTRL library with their own DFB blocks written in Unity Pro™ software ST, IL, or LD language, or in C language.

#### Debugging, operation

All Unity Pro™ standard debugging services (see page 4/21) are available. In particular, the Modicon M340 processor simulator can be used to check correct execution of processing offline.

#### Compatibility

The CONT\_CTRL control function block library is available in all versions of Unity Pro™ software. It is compatible with all processors in the Modicon® M340™, Premium™, Quantum™, and Atrium™ PLC ranges.

#### Resources

The technical documentation provides many examples of how to set up programmable process control function blocks in FBD, LD, IL and ST languages.

The techniques for adjusting process control loops are described in the document "Process control, Unity™ V3.0" available on the [www.telemecanique.com](http://www.telemecanique.com) website.

(1) XXX depending on the type of variable: DINT, INT, UINT, UDINT, REAL

Splitter box and module type

Monobloc I/O splitter boxes

Advantys™ FTB distributed I/O system

2



Type of communication with Modicon M340 platform

CANopen

Max. number per connection points

1 monobloc splitter

Discrete inputs/outputs Number of channels

Splitter of 16 I, 8 I + 8 O, 12 I + 4 O, 16 I/O or 8 I + 8 I/O

Input voltage

24 V ...

Output voltage

24 V ...

analog inputs/outputs

—

Counting

—

Type of input/output connectors

M12 connectors

Housing type

Plastic and metal

Module type

FTB 1

Pages

Consult our catalog "IP 67 splitter boxes"

**Monobloc IP 20 distributed I/O**

Modicon® Momentum™ PLC

**Optimum IP 20 distributed I/O**

Advantys™ OTB distributed I/O system

**Modular IP 20 distributed I/O**

Advantys™ STB distributed I/O system



2

**Ethernet TCP/IP**

1 base with 1 communicator

Base of 16 I, 32 I, 8 O, 16 O, 32 O, 10 I/8 O, 16 I/8 O, 16 I/12 O and 16 I/16 O

24 V \_\_, 120 V ~, and 230 V ~

24 V \_\_, 120 V ~, 230 V ~, and relay

Bases 8 I, 16 I or 4 O voltage/current  
Base 4 I thermocouple or RTD

Base 2 channels 10 kHz/200 kHz

Base 6 I/3 O 120 V ~ with 1 Modbus port

Screw or spring terminal blocks

Plastic

**170 AD•**

Consult our catalog: Modicon Momentum automation platform

**Ethernet TCP/IP  
CANopen  
Modbus® communication (RS 485)**

1 interface module

12 I/8 O

24 V \_\_

24 V \_\_, and relay

Integrated in interface module:  
- 2 channels 5 kHz/20 kHz  
- 2 PWM function channels

—

Removable screw terminal blocks

**Ethernet TCP/IP  
CANopen**

1 "NIM" interface module + 32 I/O modules

Module of 2 I, 4 I, 6 I, 16 I, 2 O, 4 O, 6 O or 16 O

24 V \_\_, 115 V ~, and 230 V ~

24 V \_\_, 115/230 V ~, and relay

Modules 2 I and 2 O voltage/current  
Module 2 I thermocouple or RTD

Module 1 channel 40 kHz

Parallel interface module for TeSys® Quickfit and TeSys® U motor-starters

Screw or spring connectors

**OTB 1•O DM9LP**

Consult our catalog: Advantys OTB distributed I/O

**STB Dce/Ace**

Consult our catalog: Advantys STB distributed I/O

### Presentation

**BMX EHC 0200** and **BMX EHC 0800** counter modules for the Modicon M340 automation platform are used to count the pulses generated by a sensor or to process the signals from an incremental encoder.

The two modules differ in the number of counter channels, maximum input frequencies, functions and auxiliary input and output interfaces:

Counter module	No. of channels	Maximum frequency	Integrated functions	No. of physical inputs	No. of physical outputs
BMXEHC0200	2	60 kHz	Upcounting Downcounting Period meter Frequency meter Frequency generator Axis control	6	2
BMXEHC0800	8	10 kHz	Upcounting Downcounting Measurement Interface	2	–

The sensors used on each channel can be:

- 2-wire 24 V proximity sensors
- 3-wire 24 V proximity sensors
- 10/30 V output signal incremental encoders with push-pull outputs

**BMX EHC 0200 / 0800** counter modules can be used to meet the demands of applications such as:

- Alarm generation on empty unwinder status using the ratio
- Sorting small parts using the period meter
- Single electronic cam using the dynamic setting thresholds
- Speed control using the period meter

These standard format modules can be installed in any available slot of a Modicon M340 PLC; they can be removed while powered up.

In a Modicon M340 PLC configuration, the number of **BMX EHC 0200 / 0800** counter modules should be added to the number of application-specific modules: communication, motion control and weighing.

The function parameters are set using Unity Pro™ software.

### Description

**BMX EHC 0200 / 0800** analog I/O modules are standard format. They occupy a single slot in **BMX XBP 0000** racks.

They come in a plastic case which ensures IP 20 protection of the electronics, and locks into position with a screw.

#### BMX EHC 0200 module, 2 channels, 60 kHz

The **BMX EHC 0200** counter module has the following on the front panel:

- 1 Module and channel status LED array
- 2 16-pin connector for wiring the sensors of counter 0
- 3 16-pin connector for wiring the sensors of counter 1
- 4 10-pin connector for wiring:
  - the auxiliary outputs
  - the sensor power supplies

#### To be ordered separately:


- A **BMX XTS HSC 20** kit containing:
  - Two 16-pin connectors
  - One 10-pin connector
- A **BMX XSP 010** electromagnetic compatibility kit.

#### BMX EHC 0800 module, 8 channels, 10 kHz


The **BMX EHC 0800** counter module has the following on the front panel:

- 1 Module and channel status LED array
- 2 20-pin connector compatible with discrete I/O

**To be ordered separately:** a **BMX XSP 010** electromagnetic compatibility kit.




BMX EHC 0200



BMX EHC 0800


### Operation

Block diagram of a BMX EHC 0200 module counter channel




Block diagram of a BMX EHC 0800 module counter channel

Used in 16-bit (8 channels)



Used in 32-bit (4 channels)



(1) Optional inputs

(2) Reference: 5 operating modes for SYNC "IN\_SYNC" and Reference "IN\_REF" inputs.  
Functions of inputs: 15 possible types of behavior.

### Functional characteristics of the BMX EHC 0200 module

Configurable functions	<p>Frequency meter</p> <p>This function measures a frequency, speed, data rate or an event stream. As standard, this function measures the frequency received on the IN_A input. This frequency is always expressed in Hz (number of pulses per second), with a precision of 1 Hz. The maximum frequency on the IN_A input is 60 kHz. The maximum cyclic ratio at 60 kHz is 60%.</p>
Count events	<p>This function is used to determine the number of events received intermittently. In this mode, the counter calculates the number of pulses applied to the IN_A input, at time intervals defined by the user. As an option, it is possible to use the IN_SYNC input during a period of time, provided that the enable bit has indeed been configured. The module counts the pulses applied to the IN_A input each time the pulse for this input lasts longer than 5 µs (without anti-bounce filter). IN_A input pulses that have appeared for less than 100 ms after a change of state of the IN_SYNC input are lost.</p>
Measure time periods	<p>This function is used to:</p> <ul style="list-style-type: none"> <li>■ determine how long an event lasts</li> <li>■ determine the time that separates 2 events</li> <li>■ measure the execution time of a process</li> </ul> <p>Measures the elapsed time during an event or between two events (IN_A input) according to a selectable time base of 10 µs, 100 µs or 1 ms. The IN_SYNC input can be used to enable or stop a measurement. The module can carry out a maximum of 1 measurement every 5 ms. The smallest measurable pulse is 100 µs, even if the unit defined by the user is 10 µs. The maximum measurable duration is 4,294,967,295 units (1) (unit to be defined).</p>
Ratio count	<p>The ratio count mode only uses the IN_A and IN_B inputs. This count mode consists of 2 modes:</p> <ul style="list-style-type: none"> <li>■ Ratio 1: used to divide 2 frequencies and useful in applications such as flowmeters and mixers, for example.</li> <li>■ Ratio 2: used to subtract 2 frequencies and useful in the same applications but requiring more precise regulation (more similar frequencies).</li> </ul> <p>Ratio 1 mode presents the results in thousandths in order to have better accuracy (a display of 2000 corresponds to a value of 2) and ratio 2 mode presents the results in Hz. The maximum frequency that the module can measure on the IN_A and IN_B inputs is 60 kHz. The maximum measurable value is 4,294,967,295 units (1).</p>
Downcounting	<p>This function is used to list a group of operations. In this mode, activation of the synchronization function starts the counter which, starting with a preset value, decreases on each pulse applied to the IN_A input, until it reaches the value 0. This downcounting is made possible when the enable function has been activated. The counting register is thus updated at intervals of 1 ms. One basic use of this mode is to use an output to signal the end of a group of operations (when the counter reaches 0). The smallest pulse applied to the IN_SYNC input is 100 µs. The frequency applied to the IN_SYNC input is at maximum 1 pulse every 5 ms. The maximum value of the preset value is 4,294,967,295 (1). The maximum count value is 4,294,967,295 units (1).</p>
Loop (modulo) counting	<p>This function is used in packaging and labeling applications where actions are repeated in series of moving objects. In the counting direction, the counter increases until it reaches the preset modulo value. On the next pulse, the counter is reset to 0 and counting restarts. In the downcounting direction, the counter decreases until it reaches the value 0. On the next pulse, the counter is reset to the preset modulo value. Downcounting can then restart. The maximum frequency applied to the IN_A and IN_B inputs is 60 kHz. The smallest pulse applied to the IN_SYNC input is 100 µs. The frequency applied to the IN_SYNC input is at maximum 1 pulse every 5 ms. The frequency of the modulo event is at maximum 1 every 5 ms. The maximum modulo and counter value is 4,294,967,295 (1).</p>
32-bit counter counting	<p>This function is used mainly in the axis following: The maximum frequency applied simultaneously to the IN_A and IN_B inputs is 60 kHz. The smallest pulse applied to the IN_SYNC input is 100 µs. The frequency of the referencing event is at maximum 1 every 5 ms. The counter value is between - 2,147,483,647 and + 2,147,483,647 (2).</p>
Width modulation	<p>In this operating mode, the module uses an internal clock generator to supply a periodic signal on the module output Q0. Only the Q0 output is affected by this mode, the Q1 output being independent of this mode. Control of the Q0 output must be at 1 to enable modulation on the Q0 output. The maximum output frequency value is 4 kHz. The frequency applied to the IN_SYNC input is at maximum 1 pulse every 5 ms. Since the Q0 output is source type, a load resistor is needed for the Q0 output signal to change to 0 at the correct frequency. The cyclic ratio adjustment range varies according to the frequency of the Q0 output.</p>

(1) If the measurement value exceeds 2,147,483,647 units then the application must convert the measurement naturally to a signed integer (DINT) or an unsigned integer (UINT).

(2) The counter value is a signed integer (DINT) which must not be converted to an unsigned integer (UINT).

### Functional characteristics of the BMX EHC 0800 module

Configurable functions	Frequency meter	<p>This function measures a frequency, speed, rate or data stream control. As standard, this function measures the frequency received on the IN_A input. This frequency is always expressed in Hz (number of pulses per second), with a precision of 1 Hz. The maximum frequency on the IN_A input is 60 kHz. The maximum cyclic ratio at 60 kHz is 60%.</p>
Count events		<p>This function is used to determine the number of events received intermittently. In this mode, the counter calculates the number of pulses applied to the IN_A input, at time intervals defined by the user. As an option, it is possible to use the IN_AUX input during a period of time, provided that the enable bit has indeed been configured. The module counts the pulses applied to the IN_A input each time the pulse for this input lasts longer than 50 µs (without anti-bounce filter). Pulses with less than 100 ms synchronization are lost.</p>
Downcounting		<p>This function is used to list a group of operations. In this mode, when counting is enabled (software validation via the valid_sync command), a rising or falling edge on the IN_AUX input causes a value, defined by the user, to be loaded into the counter. The counter decreases on each pulse applied to the IN_A input, until it reaches the value 0. Downcounting is made possible when the force_enable command is high (software positioning). The smallest pulse applied to the IN_AUX input is 100 µs. The frequency applied to the IN_AUX input is at maximum 1 pulse every 25 ms.</p>
Loop (modulo) counting		<p>This function is used in packaging and labeling applications where actions are repeated on series of moving objects. The counter increases on each pulse applied to the IN_A input, until it reaches the preset modulo value. On the next pulse in the upcounting direction, the counter is reset to 0 and upcounting restarts. The maximum frequency applied to the IN_A input is 10 kHz. The smallest pulse applied to the IN_AUX input varies according to the selected filter level. The frequency applied to the IN_AUX input is at maximum 1 pulse every 25 ms. The frequency of the modulo event is at maximum 1 every 25 ms. The minimum acceptable modulo value varies according to the frequency of the IN_A input. For example, for a frequency of 10 kHz applied to the IN_A input, the modulo must be higher than 250.</p>
Up/down counter		<p>This function is used for an accumulation, upcounting or downcounting operation on a single input. Each pulse applied to the IN_A input produces:       <ul style="list-style-type: none"> <li>■ upcounting of pulses if the IN_AUX input is high</li> <li>■ downcounting of pulses if the IN_AUX input is low</li> </ul>       The counter values vary between the limits -65,536 and +65,535. The maximum frequency applied to the IN_A input is 10 kHz. Pulses applied to the IN_A input, after a change of direction, are only upcounted or downcounted after a period corresponding to the delay for taking account of the state of the IN_AUX input due to the programmable filter level on this input.     </p>
32-bit counter counting		<p>32-bit counter counting mode is available for channels 0, 2, 4, and 6 (channels 1, 3, 5 and 7 are now inactive). It behaves in the same way as the up/down counting mode using up to 3 physical inputs. It enables simultaneous upcounting and downcounting. The counter values vary between the limits -2,147,483,648 and +2,147,483,647 (31-bit word and 1 sign bit). The eight 16-bit registers can be configured as four 32-bit registers. The maximum frequency applied to the IN_A and IN_B inputs is 10 kHz. The smallest pulse applied to the IN_AUX input is defined according to the filtering applied to this input. The frequency of loading the preset value is at maximum 1 every 25 ms.</p>

### General characteristics

Type of module			BMX EHC 0200	BMX EHC 0800
Modularity			2 channels	8 channels
Number of physical inputs per module			6	2
Number of physical outputs per module			2	—
Application			Upcounting, downcounting, measurement, frequency meter, frequency generator, axis following	Upcounting, downcounting, measurement, interfacing
Frequency on counter inputs	kHz		max. 60	max. 10
Module cycle time	ms		1	5
Number of inputs/outputs per counter channel	Inputs	Number	6	2 in single mode 3 in special dual-phase mode
	Type	V	24 V, Type 3	
	Outputs	Number	2	—
	Type	V	24 V	—
Encoder	10...30 V incremental encoder model with push-pull outputs			
Power supply	Sensor voltage	V	19.2...30 V	
	Actuator current	A	0.5 max. per output 2 per module	—
Distribution of power to the sensors	Yes. Short-circuit and overload protection, 300 mA typical			
Hot swapping	Yes, in certain conditions: the module can be removed and reinserted in its slot while the rack is powered up, but the counter may need to be re-enabled when it is reinserted in its base.			
Insulation voltage from the ground to the bus	V		1500 for 1 min	
Consumption	Typical	mA	See power consumption table page 6/8	

### Input characteristics

Module type			BMX EHC 0200	BMX EHC 0800
Input type			High-speed inputs (IN_A, IN_B, IN_SYNC) and auxiliary inputs (IN_EN, IN_REF, IN_CAP)	High-speed inputs (IN_A, IN_B, IN_AUX)
Number of inputs per channel			6, 24 V	2, 24 V
Inputs	Voltage	V	30 V	
	At state 1	Voltage	11...30 V	
		Current	6 (24 V)	
	At state 0	Voltage	< 5 V	
		Current	< 1.5	
	Current at 11 V	mA	> 2	

### Characteristics of outputs

Output type			BMX EHC 0200	BMX EHC 0800
Number of outputs per channel			2, 24 V, 0.5 A	—
Voltages			19.2...30 V	—
Maximum load current	Each point	A	0.5	—
	Per module	A	1	—
Maximum leakage current at state 0	mA		0.1	—
Maximum voltage drop at state 1	V		< 3	—
Maximum short-circuit output current	Each point	A	1.5	—
Maximum load capacity	μs		< 200	—
Short-circuit and overload	Protection for each channel			
Polarity on each output channel	Default	Normal logic on both channels		
	User configuration	Reverse logic on one or more channels		
Inductive load	The inductive load is calculated by application of the formula: $L = 0.5/I^2 \times F$ where: <input type="checkbox"/> L: load inductance in Henrys <input type="checkbox"/> I: load current in A <input type="checkbox"/> F: switching frequency in Hz			



BMX EHC 0200



BMX EHC 0800



BMX FTB 20●0

### References

#### BMX EHC 0200/0800 counter modules

Description	No. of channels	Characteristics	Reference (1)	Weight kg
Counter modules for 2 and 3-wire 24 V ___ sensors and 10/30 V ___ incremental encoders with push-pull outputs	2	Counting at 60 kHz	BMXEHC0200	0.112
	8	Counting at 10 kHz	BMXEHC0800	0.113

2

### Connection accessories (1)

Description	Composition Use	Unit reference	Weight kg
Connector kit	Two 16-pin connectors and one 10-pin connectors for BMX EHC 0200 module	BMXXTSHSC20	0.021


20-pin removable terminals blocks	Cage clamp	BMXFTB2000	0.093
For BMX EHC 0800 module	Screw clamp	BMXFTB2010	0.075
	Spring-type	BMXFTB2020	0.060

Electromagnetic compatibility kits	Comprising: a metal bar, two sub-bases and one set of spring clamping rings	See page 2/15	–
For BMX EHC 0200/0800 modules			

(1) The shielding on the cord sets carrying the analog signals must always be connected to the BMX XSP●000 shielding connection kit mounted under the rack that holds the analog modules (see page 2/15).


### Connections

#### Pinout for the BMX EHC 0200 module 16-pin connector



Pin number	Symbol	Description
1, 2, 7, 8	24V_SEN	24 V --- output for the sensor power supply
5, 6, 13, 14	GND_SEN	0 V --- output for the sensor power supply
15, 16	FE	Functional earth ground
3	IN_A	Input A
4	IN_SYNC	Synchronization input
9	IN_B	Input B
10	IN_EN	Enable input
11	IN_REF	Referencing input
12	IN_CAP	Capture input


#### Pinout for the BMX EHC 0200 module 10-pin connector




Pin number	Symbol	Description
1	24V_IN	24 V --- input for the input power supply
2	GND_IN	0 V --- input for the input power supply
5	Q0-1	Q1 output of counter channel 0
6	Q0-0	Q0 output of counter channel 0
7	Q1-1	Q1 output of counter channel 1
8	Q1-0	Q0 output of counter channel 1
9	24V_OUT	24 V --- input for the output power supply
10	GND_OUT	0 V --- input for the output power supply

#### Examples of connection to the BMX EHC 0200 module


##### Sensor connections



##### Connection of an incremental encoder




##### Connection of power supplies and actuators (1)



(1) A fast-blow fuse should be used to protect the module electronics in the event of reversed polarity of the power supplies on the inputs and outputs.

### Connections (continued)

Pinout for the connector for the BMX EHC 0800 module 20-pin terminal block





Pin number	Description
1	IN_AUX input of channel 0
2	IN_A input of channel 0
3	IN_AUX input of channel 1
4	IN_A input of channel 1 or IN_B input of channel 0
5	IN_AUX input of channel 2
6	IN_A input of channel 2
7	IN_AUX input of channel 3
8	IN_A input of channel 3 or IN_B input of channel 2
9	IN_AUX input of channel 4
10	IN_A input of channel 4
11	IN_AUX input of channel 5
12	IN_A input of channel 5 or IN_B input of channel 4
13	IN_AUX input of channel 6
14	IN_A input of channel 6
15	IN_AUX input of channel 7
16	IN_A input of channel 7 or IN_B input of channel 0
17	Feedback - 24 V power supply for sensors
18	VDC + Power supply for sensors
19	Functional earth ground, for shielding connection
20	Functional earth ground, for shielding connection


### Examples of connection to the BMX EHC 0800 module

Connection of sensors (1) (2) (3)

Connection of an incremental encoder (1) (2) (3) (4)



- (1) It is advisable to adapt the programmable filtering to the frequency applied to the inputs since using programmable filtering avoids the need to use a shielded cable.
- (2) In the case of an encoder or a high-speed sensor without programmable filtering, it is advisable to use a shielded cable connected to pins 15 and 16 of the connector.
- (3) In the case of a very disturbed environment without programmable filtering, it is advisable to use the BMX XSP 010 electromagnetic protection kit to connect the shielding. In this case it is also advisable to use a 24 c power supply dedicated to the inputs as well as a shielded cable for connecting the power supply to the module.
- (4) A fast-blow fuse should be used to protect the module electronics in the event of reversed polarity of the power supplies.



MFB: Motion control distributed over CANopen



### Presentation

MFB (Motion Function Blocks) is a library of function blocks integrated into the Unity Pro™ software, and is used to set up motion control in the architectures of drives and servo drives on machine buses and CANopen installations:

- Altivar® 31 adjustable speed drive: For asynchronous motors from 0.18 to 15 kW
- Altivar® 71 adjustable speed drive: For asynchronous motors from 0.37 to 500 kW
- Lexium® 05 servo drive: For servo motors from 0.4 to 6 kW
- Lexium® 15LP/MP/HP servo drive: For BSH & BDH servo motors from 0.9 to 42.5 kW
- Lexium® 17D: For BPH, BPL and SER servo motors from 1.5 to 70 A rms (1)
- IcIA® IFA/IFE/IFS: For integrated motor drives from 0.05 to 0.25 kW

In compliance with PLCopen specifications, the MFB library allows easy and flexible motion programming with Unity Pro™ software, as well as axis diagnosis. In maintenance operations, drives can be replaced quickly and efficiently thanks to drive parameter download blocks.

Setting up drives on the CANopen network is facilitated through Motion Tree Manager organization in the Unity Pro™ browser, making it easy for users to access the application drives.

### Applications

The features of the MFB library are particularly suitable for machines with independent axes. For these modular/special machines, MFB function blocks are the perfect solution for controlling single axes. The following are typical applications for this type of architecture:

- Automatic storage/removal
- Handling
- Palletizers/depalletizers
- Conveyors
- Packaging, simple label application
- Grouping/ungrouping
- Adjustment axes in flexible machines, etc.

### Functions


The table below lists the function blocks of the MFB library and the drives compatible with them. The prefix indicates the block family:

- MC: Function block defined by the Motion Function Blocks PLCopen standard
- TE: Function block specific to Telemecanique® products
- Lxm: Function block specific to Lexium® servo drives

Type	Function	Function block	Altivar ATV 31	ATV 71	Lexium 05	15/17D (1)	IcIA IFA/IFE/IFS
Management and motion	Read an internal parameter	MC_ReadParameter					
	Write an internal parameter	MC_WriteParameter					
	Read the current position	MC_ReadActualPosition					
	Read the instantaneous speed	MC_ReadActualVelocity					
	Acknowledge error messages	MC_Reset					
	Stop all active movement	MC_Stop					
	Axis coming to standstill	MC_Power					
	Movement to absolute position	MC_MoveAbsolute					
	Relative movement	MC_MoveRelative					
	Additional movement	MC_MoveAdditive					
	Homing	MC_Home					
	Movement at given speed	MC_MoveVelocity					
	Read diagnostic data	MC_ReadAxisError					
	Read servo drive status	MC_ReadStatus					
Save and restore parameters (FDR)	Read all parameters and store in PLC memory	TE_UploadDriveParam					
	Write all parameters from the PLC memory	TE_DownloadDriveParam					
Advanced Lexium functions	Set the reduction ratio	Lxm_GearPos					
	Read a motion task	Lxm_UploadMTask					
	Write a motion task	Lxm_DownloadMTask					
	Start a motion task	Lxm_StartMTask					
System	Communication with the servo drive	TE_CAN_Handler					

Compatible

(1) Lexium 17D drive supported by MFB with Modicon Premium platform only



## *Motion Tree Manager integrated in the Unity Pro browser*

## Motion Tree Manager

Motion Tree Manager is associated with the Unity Pro™ MFB library, and integrated in its browser. It provides specific assistance for:

- Axis object management
- Axis variable definition
- Drive parameter management

Motion Tree Manager automatically creates links between the CANopen bus configuration and the MFB function block data using a limited amount of configuration data.

## General axis parameters

In this tab, the designer is prompted to define:

- The name of the axis that will identify it in the browser for the entire application
- The address of the drive on the CANopen bus

## Axis parameters

The drop down lists in this tab are used to determine the exact type of drive: family, version.

## Variable names


This last tab is used to identify data structures:

- **Axis Reference**, used by all the instances of function blocks for the axis in question
- **CAN Handler**, used to manage communication with the drive via the CANopen network

## Recipe definition


The “recipes” attached to the axis are the data structures containing all the adjustment parameters of a given drive. This data is used when:

- Changing the drive with restoration of the context during "Faulty Device Replacement" maintenance
- Changing the manufacturing program of the machine, and calling up an appropriate set of parameters, such as servo control gains, limitations etc. adapted to the weight and size of the moving parts.



---

#### General parameters: Axis name and address



### MEB: Programming a movement in absolute mode

Programming, diagnostics and maintenance

Communication between the PLC and drive is automatically set up by the system as soon as a `TE_CAN_Handler` instance is declared in the Unity Pro task with which the axis is associated.

Movements are then programmed by sequencing function blocks from the library in the Unity Pro editor as selected by the user (LD, ST, FBD).

The two function blocks, MC\_ReadStatus, and in some cases MC\_ReadAxisError, are useful for determining the overall status of the axis, and the code of active warnings or errors.

The function blocks TE\_UploadDriveParam and TE\_DownloadDriveParam allow the application to save all the parameters of a drive (recipe) and to then quickly reload them into another drive if the first one fails.



---

## Ethernet TCP/IP networks with Transparent Ready® Services

■ Embedded Web services.....	3/4
■ Ethernet TCP/IP communication services.....	3/8
■ Performances .....	3/16
■ Ethernet integrated port / module selection.....	3/21
■ Ethernet processor/module product data sheet.....	3/22
■ ConneXium™ cabling system.....	3/24

## CANopen machines and installations bus

■ Presentation .....	3/37
■ Description.....	3/38
■ Characteristics.....	3/38
■ References .....	3/39
■ Cabling system .....	3/40

3

## Serial links

■ Modbus® interface and character mode serial link .....	3/42
■ Cabling system .....	3/44

Applications	Processors with integrated Ethernet TCP/IP port	Ethernet TCP/IP module
<b>Type</b>	<b>Ethernet TCP/IP</b>	
<b>Structure</b>	10BASE-T/100BASE-TX	
Physical interface		
Connector type		
Access method		
<b>Medium</b>	CSMA-CD	
	10/100 Mbps	
	Double twisted pair copper cable, category CAT 5E	
	Optical fiber via ConneXium™ wiring system	
<b>Configuration</b>	1 (integrated port)	
Maximum number of devices	100 m (copper cable), 4,000 m (multi-mode optical fiber), 32,500 m (single-mode optical fiber)	
Maximum length		
Number of links of the same type per station	1 with BMX P34 1000/2010 processor	
Other integrated port	2 with BMX P34 2020/2030 processor	
<b>Standard services</b>	Modbus® TCP/IP messaging	
<b>Conformity class</b>	Transparent Ready® server — class B10	
	Transparent Ready® server — class B30	
	Transparent Ready® server — class C30	
<b>Embedded web server services</b>	"Rack viewer" PLC diagnostics "Data editor" access to PLC data and variables	
Standard services	"Alarm viewer" "Graphic Data Editor"	
Configurable services	Hosting and display of user web pages (16 Mb)	
<b>Transparent Ready® communication services</b>	I/O Scanning service	
	FDR service	
	SNMP network management service	
	Global Data service	
	SMTP E-mail notification service	
	SOAP/XML Web services	
	Passband management	
<b>Compatibility with processor</b>	No	
	Yes (client)	
	No	
	Yes	
	—	
<b>Processor or module</b>	BMX P34 2020	BMX P34 2030
	BMX NOE 0100	BMX NOE 0110
<b>Page</b>	3/22	3/23

▲ Available 4<sup>th</sup> quarter 2007. Before this date, please order the **BMX NOE 0100** Ethernet module with **BMX RWS C016M** memory card, same services except Data editor service with pocket PC or PDA terminal and SOAP/XML Web services.

## Processors with integrated machine and installation bus



## Processors with integrated serial link



## CANopen

ISO 11898 (9-pin SUB-D connector)

9-pin SUB-D

CSMA/CA (multiple access)

20 Kbps...1 Mbps depending on distance

Double shielded twisted pair copper cable

63

20 m (1 Mbps)...2,500 m (20 kbps)

1

Serial link

Ethernet TCP/IP

- PDO implicit exchange (application data)

- SDO explicit exchange (service data)

Class M20

-

-

-

-

-

-

-

-

-

BMX P34 2010

BMX P34 2030

3/39

## Modbus® interface and Character mode

Non-isolated, 4-wire RS 232/2-wire RS 485

RJ45

Master/slave with Modbus link,  
Half duplex (RS 485)/Full duplex (RS 232) in character mode

0.3...19.2 Kbps

Double shielded twisted pair copper cable

32 per segment, 247 max.

15 m (non-isolated), 1,000 m with insulating case

1

Read/write bits and words, diagnostics with Modbus link

Send and receive character string in character mode

-

-

-

-

-

-

-

-

-

-

BMX P34 1000

BMX P34 2010

BMX P34 2020

3/46

### Overview of the Web services

In conformity with Schneider Electric Ethernet products (processors and Ethernet modules on Modicon automation platforms, distributed I/O modules, adjustable speed drives/adjustable speed drives and gateways), standard Web functions are integrated in **BMX P34 2020/2030** processors and the **BMX NOE 0100/110** Ethernet network modules on the Modicon M340 platform.

From a simple Internet browser, the standard Web server authorizes the following "ready-to-use" functions:

- Remote diagnostics and maintenance of products
- Display and adjustment of products (read/write variables, status)

With the **BMX NOE 0110 (1)** Ethernet network module, the Web server also offers the following functions:

- Management of PLC alarms (system and application) with partial or total acknowledgement (ready-to-use Alarm Viewer function pages).
- Hosting and display of Web pages created by the user.

The embedded Web server is a real-time data server. All the data can be presented in the form of standard Web pages in HTML format and can therefore be accessed using any Web browser that supports the embedded Java code. The standard functions provided by the Web server are supplied ready-to-use and thus do not require any programming of either the PLC or the client PC device supporting a Web browser.



Modicon M340 hardware configuration

### Standard Web server on the Modicon® M340™ platform

#### Rack Viewer PLC diagnostics function


The Rack Viewer function can be used for PLC system and I/O diagnostics. It displays the following in real-time:

- LED status on the front panel of the PLC
- The PLC type and version
- The hardware configuration of the PLC including the status of the system bits and words
- Detailed diagnostics (2) of each of the:
  - I/O module channels or application-specific channels in the configuration
  - equipment connected on the CANopen bus.

#### Data Editor read/write function for PLC data and variables

The Data Editor function can be used to create tables of animated variables for real-time read/write access to PLC data in the form of lists.

Various animation tables containing specific application variables to be monitored or modified can be created by the user and saved in the standard Web server module.



Data editor variables table

In addition when using FactoryCast™ Web server of the **BMX NOE 0110 (1)** module:

- The variables can be entered and displayed by their symbol (3) (S\_Pump 234)
- The write access option can be enabled/disabled for each variable using the FactoryCast™ software. The write access is protected by a dedicated password
- Dedicated data monitoring tool can be used on pocket PC or PDA terminal (2).


(1) Module available 4<sup>th</sup> quarter 2007. Before this date, please order the **BMX NOE 0100** module with **BMX RWS C016M** memory card.

(2) Function available 4<sup>th</sup> quarter 2007.


(3) Access to symbols available 4<sup>th</sup> quarter 2007. Hence provides access to unlocated data.

# Modicon® M340™ Automation Platform


Ethernet TCP/IP network, Transparent Ready® services, and FactoryCast™ Web server



Alarm display from the diagnostic buffer



Library of predefined graphic objects



Real-time supervision graphic interface

## BMX NOE 0110 module FactoryCast™ Web server

With the **BMX NOE 0110** (1) Ethernet network module, the Web server offers the functions below, in addition to the standard Web services.

### Alarm Viewer function (2)

Alarm Viewer (2) is a ready-to-use, password-protected function. This function can be used to process alarms (display, acknowledgment and deletion) managed at the PLC level by the system or using diagnostic function blocks known as DFBs (system-specific diagnostic function blocks and application-specific diagnostic function blocks created by the user).

These alarms are stored in the diagnostic buffer managed by the Modicon M340 platform (special memory space for storing all the diagnostics events).

The diagnostics viewer is a Web page comprising a list of messages, which displays the following information for each alarm:

- Dates and times of the occurrence removal of a fault
- Alarm message
- Alarm status
- Type of associated diagnostic function block (DFB).

### Graphic Data Editor function

This function is used to create the graphic views animated by the PLC variables that can be accessed via their address or their symbol (3) (access to located data). The ready-to-use graphic editor is available online, connected to the **BMX NOE 0110** module (1).

These views are created from a library of predefined graphic objects by simple copy/paste operations. The objects are configured to suit the user's requirements (color, PLC variables, name, etc).

List of proposed graphic objects:

- Analog and digital indicators
- Horizontal and vertical bar charts
- Boxes for displaying messages and entering values
- Push button boxes
- Functions for recording trends
- Vats, valves, motors, etc

Customized graphic objects can be added to this list. They can be reused in user Web pages that have been created using standard software for editing HTML pages. The views thus created are saved in the **BMX NOE 0110** module and displayed using any Web browser.

### User Web page hosting and display function

The **BMX NOE 0110** Ethernet network module has a 16 Mbyte non-volatile memory (accessible as a hard disk). This allows hosting of Web pages and any user-defined Word or Acrobat Reader document (for example, maintenance manuals, or wiring diagrams).

The Web pages can be created using any standard tool for creation and editing in HTML format. These pages can be enhanced by inserting animated graphic objects linked to PLC variables. These animated objects are created using the Graphic Data Editor. They are then downloaded to the **BMX NOE 0110** module via configuration software of FactoryCast Web server.

The Web pages created can be used, for example, to:

- Display and modify all PLC variables in real time
- Create hyperlinks to other external Web servers (documentation, suppliers, etc)


This function is particularly suitable for creating graphic interfaces used for the following purposes:

- Real-time display and supervision
- Production monitoring
- Diagnostics and help with maintenance
- Operator guides

(1) Module available 4<sup>th</sup> quarter 2007. Before this date, please order the **BMX NOE 0100** module with **BMX RWS C016M** memory card.

(2) Function available 4<sup>th</sup> quarter 2007.

(3) Access to symbols available 4<sup>th</sup> quarter 2007.



3

### FactoryCast™ Web server configuration software

The FactoryCast Web server configuration software is supplied on CD-ROM with the **BMX NOE 0110** FactoryCast module.

This software is used for configuration and administration of the Web server embedded in these modules. It is compatible with Windows® 2000 and Windows® XP operating systems. It provides the following functions:

- Setting the parameters of the FactoryCast functions
- Definition of access security, and passwords
- Importing of PLC symbol databases
- Definition of access to write-enabled variables
- Management of the Web site:
  - Management of default Web site pages
  - Management of user Web site pages (2)
  - Graphic object editor for animating Web pages
  - Downloading of Web pages between the PC and the module
  - Debugging of Web pages in online mode or in simulation mode (including animations and Java beans)
- Simulation mode

The application and the Web site (including the Java animations) can be set up in online mode or in simulation mode. Simulation mode is used to test the operation of the Web application without a FactoryCast module (with no physical connection to a PLC) thereby simplifying debugging.

A graphics editor integrated in the configuration software can be used for easy customization of graphic objects (bar charts, gauges, LEDs, curves, cursors, operator input fields, alphanumeric display fields, buttons, etc).

#### ■ Creation of user Web pages (1)

User Web pages are created graphically using an external HTML editor (FrontPage® or similar, not supplied).

User Web pages created in the FactoryCast environment are actual animated supervision screens and can be used to monitor your process. Based on Web technologies (HTML and Java) they provide real-time access to PLC variables using the FactoryCast graphic object library (Java beans).



### SOAP/XML Web services (2)

The **BMX NOE 0110** FactoryCast module (3) incorporates a standard SOAP/XML data server that provides direct interoperability between automation devices and computer management applications (MES, ERP, SAP, .Net application, etc).

### SOAP/XML Web Services embedded in the PLC

Communication between platforms or applications is now a necessity in a market where **e-manufacturing** and **e-business** are an essential fact of life for companies. Web service technology currently represents the most successful strategy for ensuring interoperability of heterogeneous software applications via an Intranet or the Internet, independently of any platform, operating system and programming language.

The standardization of Web services has come about as a result of joint development between **Microsoft** and **IBM**, among others, validated at the **W3C (World Wide Web Consortium)** as an open standard.

It now provides all the tools, specifications and environments needed for each platform.

Web services are based on standards such as:

- **XML (eXtensible Markup Language)**: the universal standard for data exchange
- **SOAP (Single Object Access Protocol)** carried via the **HTTP (Hypertext Transfer Protocol)** channel.
- **WSDL (Web Services Description Language)** in **XML** format.

SOAP is currently considered to be the reference protocol, including in industry. It has since been adopted by technology leaders such as Microsoft (.NET, SQL Server, Office, etc), IBM (Java, Web Sphere), Lotus, ORACLE-Sub, and SAP.

(1) FactoryCast includes a plug-in for FrontPage® 2000. This plug-in makes it easier to set up animations for real-time access to the PLC variables in HTML pages created by the user. They are created in the HTML editor by simply inserting customized graphic objects.

(2) Web services available 4<sup>th</sup> quarter 2007.

(3) Module available 4<sup>th</sup> quarter 2007.

## SOAP/XML Web services (suite)


## Embedded SOAP/XML Web Services: Modbus® XMLDa Web services

This new Transparent Ready® service offers the previously unused (or uncommon) possibility of making an IT/e-business application interact directly with the control system levels using the same standards.

With the implementation of Modbus XMLDa (*Modbus XML Data access*) Web services in FactoryCast™ Web servers, the IT engineer can easily create an application which will access the desired information directly in the PLC and in real time.

Data exchanges are made in XML standard format in response to a request using SOAP protocol.

The implementation of Web services in control system equipment makes it easy to achieve vertical integration of the control level and the creation of even more collaborative architectures which can be used to link production systems to the corporate management systems. It simplifies access to information; reduces the costs of training, development, and deployments; and increases productivity.



## Implementation of the Modbus® XMLDa Web services: server interface

This implementation enables a SOAP client application (management level computer application, such as MES, ERP) to communicate directly with a FactoryCast Web server module embedded in the PLC.

Exchanges are initiated by the SOAP client application (the server responds to these requests).

■ **Step 1: Creating the client application and learning the Web services.** The development environment (for example, Visual Studio •NET) searches in the FactoryCast server for the list of available services and their WSDL standard interfaces provided by the module.

■ **Step 2: Developing the client application.** The developer integrates the Web service functions using the code retrieved at the learning stage.


■ **Step 3: Executing the client application.** The client application communicates in real time with the FactoryCast Web server module using the SOAP protocol.

Requests implemented in the **BMX NOE 0110** FactoryCast Web server module provides data access to either physical or symbolic variables. They are defined in the table below.

	Modbus® XMLDa functions implemented in each FactoryCast Web server module
Access to data via physical address	ReadDeviceIdentification ReadMultipleRegisters WriteMultipleRegisters ReadCoils WriteMultipleCoils ReadDiscreteInputs
Access to data via symbol	Read, operation to read item list value Write, operation to write item list value Browse, operation to browse item list

## Presentation

BMX P34 2020 / 2030 processors, via their integrated Ethernet port (class 10) and the **BMX NOE 0100/0110** network module (class 30) provide transparent communication on a single Ethernet TCP/IP network.



3

In addition to universal Ethernet services (HTTP, BOOTP/DHCP, FTP, etc) and with the Modicon M340 automation platform, the Transparent Ready device communication services designed for use in automation applications include:

- Modbus® TCP/IP messaging for class 10 or 30 devices
- I/O Scanning service for class 30 devices
- FDR (Faulty Device Replacement) for class 10 or 30 devices
- SNMP (*Simple Network Management Protocol*) network management for class 10 or 30 devices
- Global Data, for class 30 devices
- Bandwidth management for class 10 or 30 devices

The following pages present the various options available through all of these services to provide the optimum choice of solutions when defining a system integrating Transparent Ready devices.

**Functions****Ethernet universal services****HTTP "Hypertext Transfer Protocol" (RFC1945)**

HTTP (*Hypertext Transfer Protocol*) is used to transmit Web pages between a server and a browser. HTTP has been used on the Web since 1990.

Web servers embedded in Transparent Ready automation products provide easy access to products located anywhere in the world from a standard Internet browser such as Internet Explorer.

**BOOTP/DHCP (RFC1531)**

BOOTP/DHCP is used to supply devices with IP parameters automatically. This avoids having to manage each device address individually by transferring this management to a dedicated IP address server.

The DHCP protocol (Dynamic Host Configuration Protocol) is used to assign configuration parameters to devices automatically. DHCP is an extension of BOOTP. The DHCP protocol consists of 2 components:

- One to supply the IP network address.
- One to supply the specific IP parameters to the device from a DHCP server.

*Telemecanique® devices can be:*

- *BOOTP clients used to retrieve the IP address automatically from a server.*
- *BOOTP servers allowing the device to distribute IP addresses to the network stations.*

*Telemecanique® products use BOOTP/DHCP standard protocols to offer the FDR (Faulty Device Replacement) service.*

**FTP "File Transfer Protocol" (RFCs 959, 2228, and 2640)**

File Transfer Protocol (FTP) provides the basic elements for file sharing. FTP is used by several systems to exchange files between devices.

**TFTP "Trivial File Transfer Protocol" (updated firmware)**

Trivial File Transfer Protocol (TFTP) is a network transfer protocol used to connect to a device and download code to it.

For example, it can be used to transfer a boot code to a workstation without a disk drive or to connect and download updates of network device firmware.

*Note : Transparent Ready devices implement FTP and TFTP to transfer certain information to or from products, particularly for downloads of firmware or user-defined Web pages.*

**Functions** (continued)

**Ethernet universal services** (continued)

**SNMP** "Simple Network Management Protocol" (RFCs 1155, 1156 and 1157)

The Internet community has developed the SNMP standard to manage the various network components via a single system. The network management system can exchange data with SNMP agent devices. This function allows the manager to display the status of the network and products, modify their configuration, and feed back alarms in the event of a fault.

*Note : Transparent Ready products are compatible with SNMP and can be integrated naturally into a network administered via SNMP.*

**COM/DCOM** "Distributed Component Object Model"

COM/DCOM (Distributed Component Object Model) or OLE (Object Linking and Embedding) technology consists of Windows® objects which enable transparent communication between Windows® applications.

*Nota : These technologies are used in the OFS (OLE for Process Control Factory Server) data server software.*

Modbus TCP/IP function codes	dec	hex
<b>Bit access</b>		
Read n input bits	02	02
Read n output bits	01	01
Read exception status	07	07
Write 1 output bit	05	05
Write n output bits	15	0F
Read 1 input word	04	04
Read n input words	03	03
Write 1 output word	06	06
Write n output words	16	10
Read device ID	43/14	2B/0E

Examples of Modbus TCP/IP function codes for accessing data and diagnostics.

3

## Functions (continued)

### Modbus® standard communication protocol

Modbus, the industry communication standard since 1979, has been brought together with Ethernet TCP/IP, the medium for the Internet revolution, to form Modbus TCP/IP, a totally open protocol on Ethernet. The development of a connection to Modbus TCP/IP does not require any proprietary component nor the purchase of a license.

This protocol can easily be combined with any product supporting a standard TCP/IP communication stack. The specifications are available free of charge from the following Web site: [www.modbus-ida.org](http://www.modbus-ida.org).

### Modbus TCP/IP, simple and open

The Modbus application layer is simple and familiar, with its 9 million installed connections. Thousands of manufacturers are already using this protocol. Many have already developed a Modbus TCP/IP connection and numerous products are currently available.

The simplicity of Modbus TCP/IP enables any field device, such as an I/O module, to communicate on Ethernet without the need for a powerful microprocessor or lots of internal memory.

### Modbus TCP/IP, high-performance

Modbus TCP/IP offers excellent performance thanks to the simplicity of its protocol and the fast speed of the 100 Mbps Ethernet. This allows a Modbus TCP/IP network to be used in real-time applications such as I/O scanning.

### Modbus TCP/IP, a standard

The application protocol is identical on serial link Modbus, Modbus TCP/IP or Modbus Plus™ networks. Messages can be routed from one network to the other without converting protocol.

Since the Modbus network is implemented on top of the TCP/IP layer, users can also benefit from IP routing that enables devices located anywhere in the world to communicate regardless of the distance between them.

Schneider Electric® offers a complete range of gateways for connecting a Modbus TCP/IP network to existing Modbus Plus™ networks, a Modbus serial link or AS-Interface bus. Please consult your local sales office.

The IANA organization (Internet Assigned Numbers Authority) has allocated the fixed port TCP 502 ("Well known" port) to the Modbus protocol. Thus Modbus protocol has become an Internet standard.

A study by the ARC Advisory Group, the market leader in analysis of the automation and software sectors, has shown that Modbus TCP/IP is the world-leading Ethernet industrial protocol in terms of units sold in 2004.

Modbus and Modbus TCP/IP are recognized by the IEC 61158 international standard as a fieldbus. They also comply with the "Chinese National Standard" managed by ITEI.

### Interfacing CANopen with Modbus TCP/IP

CiA DSP 309-2 provides standardized organization of CANopen data to be carried on a Modbus TCP/IP Ethernet network. The specification reserves the Modbus 43/13 function code for this purpose. This function code is reserved exclusively for CANopen.

### Characteristics of Modbus TCP/IP


Maximum size of data:

- Read: 125 words or registers
- Write: 100 words or registers

# Modicon® M340™ Automation Platform

Ethernet TCP/IP network, and communication services, and Transparent Ready® services

## Functions (continued) I/O Scanning service



The I/O Scanning Service is used to manage the exchange of remote I/O states on the Ethernet network after simple configuration, without the need for any special programming.

I/O scanning is performed transparently by means of read/write requests according to the Modbus® client/server protocol on the TCP/IP profile. This scanning principle via a standard protocol is used to communicate with any device supporting a Modbus server on TCP/IP.

This service allows you to define:

- A %MW word zone reserved for reading inputs.
- A %MW word zone reserved for writing outputs.
- Refresh periods independent of the PLC scan.

During operation, the module:

- Manages TCP/IP connections for each remote device.
- Scans devices and copies the I/O to the configured %MW word zone.
- Feeds back status words used to check that the service is working correctly from the PLC application.
- Applies pre-configured fallback values if a communication problem occurs

An offering is available of hardware and software products used to implement the I/O Scanning protocol on any type of device that can be connected to the Ethernet network (please consult the Modbus-IDA Web site: [www.modbus-ida.org](http://www.modbus-ida.org)).


### Characteristics

- Each Modicon M340 station can exchange a maximum of:
  - 100 write words
  - 125 read words
- Maximum size in the Modicon M340 PLC that manages the service (64 stations max.):
  - with **BMX NOE 0100/0110** network module, 2 %MW Kwords as inputs and 2 %MW Kwords as outputs
  - with **BMX P34 2020/2030** processor, 512 %MW words as inputs and 512 %MW words as outputs

### Diagnostics of the I/O Scanning service

There are 3 ways to perform diagnostics on the I/O Scanning service:

- Via the application program from a specific PLC data zone.
- From the setup software debug screen.
- From the PLC system diagnostic function displayed using an internet browser on a PC station.
- From the ConneXium™ diagnostic software **TCS EAZ 01P SFE10**.
- From the standard SNMP manager software.



## Functions (continued)

## FDR (Faulty Device Replacement) service

The faulty device replacement service uses standard address management technologies (BOOTP, DHCP) and the TFTP (*Trivial File Transfer Protocol*) file management service to simplify maintenance of Ethernet products.


Using FDR, you can replace a faulty device with a new one that will then be detected, configured, and automatically rebooted by the system.

The main steps in replacement are:

- 1 *A device using the FDR service malfunctions.*
- 2 *Another similar device is taken from maintenance storage, preconfigured with the Device name for the faulty device, and installed on the network. Depending on the devices, addressing can be performed using rotary buttons (for example, Advantys™ STB distributed I/O system, a or Advantys™ OTB distributed I/O system) or can be given via the keypad integrated in the device (for example Altivar® adjustable speed drives).*
- 3 *The FDR server detects the new device, allocates it an IP address, and transfers the configuration parameters to it.*
- 4 *The substituted device checks that all these parameters are compatible with its own characteristics and switches to operational mode.*

The FDR server can be:


- A Modicon M340 Ethernet module, **BMX NOE 0100/0110**
- A Modicon® Premium™ Ethernet module, **TSX ETY 4103/5103**
- A Modicon® Quantum™ PLC Ethernet module, **140 NOE 771 01/771 11**
- A Modicon Premium processor with integrated Ethernet port, **TSX P57 0000M**
- A Modicon Quantum processor with integrated Ethernet port, **140 CPU 651 50/60**



3

### Functions (continued)

#### Global Data service



3

The Global Data service exchanges data in real time between stations belonging to the same distribution group. It is used to synchronize remote applications, or even to share a common database between a number of distributed applications.

Exchanges are based on a producer/consumer type standard protocol, avoiding optimum performances with a minimum load on the network. This RTPS (Real Time Publisher Subscriber) protocol is promoted by Modbus-IDA (Interface for Distributed Automation), and is already a standard adopted by several manufacturers.

#### Characteristics


A maximum of 64 stations can participate in Global Data within a single distribution group.

Each station can:

- Publish 1 variable of 1024 bytes. The publication period can be configured from 1 to n processor master task (*Mast*) periods.
- Subscribe between 1 and 64 variables. The validity of each variable is controlled by status bits (*Health Status bits*) linked to a refresh time-out configurable between 50 ms and 1 s. Access to an element of the variable is not possible. The total size of subscribed variables amounts to 4 contiguous Kbytes.

To further optimize the performance of the Ethernet network, Global Data can be configured with the “multicast filtering” option which, combined with switches in the ConneXium™ range (see pages 3/26 to 3/33), distribute data only to Ethernet ports where there is a station subscribed to the Global Data service. If these switches are not used, Global Data is sent in “multicast” mode to all switch ports.

#### Global Data service diagnostics



The diagnostic screens show the status of Global Data using a color code:

- Configured/not configured/faulty
- Published/subscribed


## Functions (continued)

## SNMP network management service

From a network management station, SNMP (*Simple Network Management Protocol*) monitors and checks all components of the Ethernet architecture, ensuring quick diagnostics in the event of a problem.

It is used to:

- Interrogate network components such as computer stations, routers, switches, bridges, or terminal devices to display their status.
- Obtain statistics about the network on which devices are connected.



Automatic recognition of IP devices via the ConneXview diagnostic software for Ethernet industrial networks

3

This network management software adheres to the conventional client/server model. However, to avoid confusion with other communication protocols that use this terminology, we talk instead about:

- ConneXview network diagnostics software, **TCS EAZ 01P SFE10**. For more information, please consult our "Machines & Installations with industrial communications" catalog.
- Network manager for the client application that operates on the computer station.
- SNMP agent for the network device server application

Transparent Ready devices can be managed by any SNMP network manager, including the HP Openview and IBM® Netview®.

The SNMP managers standard protocol is used for access to configuration and management objects that are contained in the device MIB (Management Information Base). These MIBs must comply with certain standards to be accessed by any commercially available manager, but depending on the complexity of products, manufacturers can add certain objects to private databases.

The Transparent Ready private MIB presents management objects specific to the Telemecanique® offering. These objects simplify the installation, setup and maintenance of Transparent Ready devices in an open environment using standard network management tools.

Transparent Ready devices support 2 levels of SNMP network management:

- The Standard MIB II interface: An initial level of network management is accessible via this interface. It enables the manager to identify the devices making up the architecture and retrieve general information on the configuration and operation of Ethernet TCP/IP interfaces.
- The Transparent Ready MIB interface: the management of Transparent Ready devices is improved via this interface. The MIB data set enables the network management system to supervise all the Transparent Ready services.

The Transparent Ready MIB can be downloaded from the FTP server of any Transparent Ready Ethernet module in a PLC.

**Selecting the communication architecture**

When choosing an architecture, be sure to consider the required performance as early as possible. To do this, developers must:

- 1 Know exactly what they need:  
 quantity and type of devices to be connected to one another  
 volume and type of exchanges  
 expected response times  
 environment
- 2 Compare their needs with the characteristics of the available offering, being aware that the actual performance level between any 2 points in an architecture depends on the weakest link in the chain, which may:  
 depend on the hardware  
 but also depend on the applications (size, architecture, operating system, machine power rating, etc) which are often only vaguely defined at this stage of the project.
- 3 Work out from this which is the most suitable architecture.


3

The purpose of the next few pages is to provide the main information and instructions needed to answer the second point. Given that the performance of an Ethernet architecture is linked to several parameters, these pages do not supply all the information needed to calculate the network performance. Their purpose is to focus on the following main aspects:

- **Instructions for calculating the network load** to assist in designing an Ethernet network that meets the demands of the applications.
- **Application response time** to be obtained depending on the configuration used. See page 3/17 to 3/19.
- **Processing capacities of Modicon® M340™, Modicon® Premium™ and Modicon® Quantum™ platforms** used to select the processor and define the number of Ethernet connections required on the PLC, depending on the application. See pages 3/20 and 3/21.®™

**Calculating the network load****Introduction**

When calculating the load on an Ethernet network, the designer must consider all the communication services of all the peripheral devices connected to the network. Because of the outstanding performance of the Ethernet network, the load is often less than the limits of the Ethernet network and does not greatly affect the application response time. This phenomenon is explained by the high speed of the Ethernet network: the network transaction time is 10% less than the application response time. To ensure a low network load and avoid large theoretical calculations, the designer should separate the collision domain so as to limit the network load, using only the switched network (tree, star, or daisy-chain topology).

**Application response time****Modbus® messaging (or Uni-TE) service response time**

Exchanges between the PLC processor and the Ethernet module are synchronous with the PLC scan time, just like the I/O exchanges. On occurrence of an event (for example an input set to state 1), the message is sent on the start of the next cycle. Execution of the PLC program (Modicon® M340™, Modicon® Premium™ or Modicon® Quantum™ PLC) are on average around 1.5 cycle times after occurrence of the event.

The network access time (NAT) appearing in the table below in ms, is the sum of the module transit time and the waiting time before the message can be sent on the network. <sup>®TM</sup>

Processing Modbus TCP/IP message requests	Modicon M340	Modicon Premium	Modicon Quantum
BMX NOE 0100 BMX NOE 0110	BMX P34 2020 BMX P34 2030	TSX ETY 210 TSX ETY 110WS TSX P57 10...57 50	140 NOE 771 01/111 140 CPU 113/311 ●● 140 CPU 434/534 1●
Network access time NAT	< 10 ms	< 10 ms	< 10 ms

The transaction time TT integrates the delay between the sending of a message from a client station 1, its reception by the server station 2, the processing of the request, the sending the response, and its being accounted for by the station 1 (updating an output for example).


As shown in the above block diagram:

- The transaction time TT should be between:

$$2 \times CT1 + 2 \times NAT < TT < 4 \times CT1 + CT2 + 2 \times NAT$$

- The average duration  $TT_{av}$  is equivalent to:

$$TT_{av} = 3 \times CT1 + 0.5 \times CT2 + 2 \times NAT$$

**Global Data service response time**

The transaction time TT integrates the delay between publication of a Global Data service by station 1, its reception, and processing by the remote station, 2 and its being resent to the initial station 1:


For an exchanged variable:

- If  $CT < 5$  ms, transaction time:

$$TT = 5 \text{ to } 6 \times CT$$

- If  $CT \geq 10$  ms, transaction time:

$$TT = 3 \times CT$$




## Application response time (continued)

## I/O Scanning service response time

The response time RT includes the time between accounting for a remote input and updating the state of a remote output. It includes the processing time in the PLC.

This response time RT consists of the following parameters:



- TMod In and TMod Out: Response time of the read/written device, excluding the electrical transit time at the input/output (TMod depends on the device, usually between 1 and 8 ms)
- TIOS In and TIOS Out: Time between 2 read/write operations on the same device (0.3 ms x number of scanned devices), at least equivalent to the configured scan time As TIOS is executed in parallel with the PLC scan, it can be hidden with respect to the response time RT).
- Cycle T: PLC scan time.
- TNet : propagation time on the network (depending on the application, usually TNet = 0.05 ms at 10 Mbit/s and 0.005 ms at 100 Mbit/s).

The response time RT can be estimated with the following 3 formulas:

■  $RT_{min}$ , minimum response time with TIOS hidden and 1 PLC scan:

$$RT_{min} = (TMod In + 0) \times TIOS In + (Tnet + N) \times cycle T + (0 \times TIOS Out) + Tnet + TMod Out$$

■  $RT_{typ.}$ , typical response time with 0.5 TIOS hidden:

$$RT_{typ.} = ((TMod In + 0.5) \times TIOS In + (Tnet + N) \times Cycle T + (0.5 \times TIOS Out) + Tnet + TMod Out)$$

■  $RT_{max}$ , maximum response time with TIOS not hidden:

$$RT_{max} = TMod In + TIOS In + (Tnet + N) \times Cycle T + TIOS Out + Tnet + TMod Out$$

## Application response time (continued)


## I/O Scanning service response time (continued)

Below are the TMod In and TMod Out response times:

Type of distributed I/O	Response time	Min.	Typical	Max.
Momentum 170 ENT 110 02	TMod In	1 ms	1 ms	1 ms
	TMod Out	5 ms	5 ms	5 ms
Momentum 170 ENT 110 01	TMod In	4 ms	6 ms	8 ms
	TMod Out	4 ms	6 ms	8 ms
Advantys STB STB NIP 2212	TMod In	2 ms	3 ms	4 ms
	TMod Out	2 ms	3 ms	4 ms

Below are the TIOS In/TIOS Out times measured between 2 scan cycles (Ethernet network with switches)

Time (ms)



Below is the number of processor cycles N:

Number of processor cycles N	Min.	Typical	Max.
Number of processor cycles N	Min.	Typical	Max.
Modicon® M340™ platform with modules: <b>BMX NOE 0100</b> and <b>BMX NOE 0110</b>	2	2.5	3
Modicon® Premium™ platform with modules: <b>TSX ETY 4103</b> and <b>TSX ETY 5103</b>			
Modicon® Quantum™ platform with modules: <b>140 NOE 771 01</b> and <b>140 NOE 771 11</b>			
Modicon® M340™ processors: <b>BMX P34 2020</b> and <b>BMX P34 2030</b>			
Modicon® Premium™ processors: <b>TSX P57 26/3634M</b> , <b>TSX P57 26/2823M</b> and <b>TSX P57 36/4823AM</b>			
Modicon® Premium™ processors: <b>TSX P57 4634M</b> and <b>5634M</b>	1	1	2
Modicon® Quantum™ processors: <b>140 CPU 651 50</b> and <b>140 CPU 651 60</b>			

©TM

## Processing capacities of Modicon® platforms

## Processing capacity

Use the table below to compare, for each station, the total number of messages received on the Modbus® messaging service (or Uni-TE), if used (value R1, R2 or R3), with the station processor capacity.

Processing Modbus requests for each PLC scan

Modicon M340, Modicon® Premium™ /Atrium™ PLC platforms	Messages received
Communication using EFs or EFBs (PL7™ or Unity Pro™ software)	
Total messages received by the PLC from all the communication modules (1)	4 messages/cycle
BMX P34 20/TSX 57 20	8 messages/cycle
TSX 57 30	12 messages/cycle
TSX 57 40	16 messages/cycle
TSX 57 50 (2)	16/20 messages/cycle

3

Modicon Quantum platform	Limitations of the integrated port		Limitations of the communication modules		Ethernet modules per PLC
	All types of communication request	Additional read/write 4x registers	All types of communication requests	Additional read/write 4x registers	
140 CPU 113 (3)	—	—	1 message/cycle	4 messages/cycle	max. 2
140 CPU 311	—	—	1 message/cycle	4 messages/cycle	max. 2
140 CPU 434/534	—	—	4 messages/cycle	8 messages/cycle	max. 6
140 CPU 651	16 messages/cycle	16 messages/cycle	4 messages/cycle	8 messages/cycle	max. 6

messages/cycle: number of messages received per cycle from the PLC master task (typical cycle of 50 to 100 ms)

## Example:

Quantum 140 CPU 434 12● processor with 4 Ethernet 140 NOE 771 ●1 modules:  
 - 20 messages/cycle for all types of communication requests, and  
 - 32 messages/cycle for the read/write 4x registers

## Ethernet transaction processing capacity

Compare, for each station, the total number of messages received  $\Sigma$  [values R<sub>i</sub>, R<sub>j</sub>] and the total number of messages sent  $\Sigma$  [values E<sub>i</sub>, E<sub>j</sub>] (for example, for station N) with the Ethernet transaction processing capacity indicated below.

Use the elements below for the Ethernet connection per PLC, rather than the number of transactions required by the application.

Ethernet transaction processing capacity	Modicon M340 BMX		Modicon Premium TSX			Modicon Quantum140	
	NOE 0100	P34 2020	ETY 210	ETY 4103/5103	P57 50	NOE 771 01/11	CPU 65 150/160
	NOE 0110	P34 2030	ETY 110WS	W MY 100 (4) P57 10/20/30/40		NWM 100 00 (4)	CPU 67 160
Modbus® messaging	450 transactions/s	200 transactions/s	60 transactions/s	450 transactions/s	500 transactions/s	350 transactions/s	350 transactions/s
I/O Scanning service	2,000 transactions/s	Service not available	Service not available	2,000 transactions/s	2,000 transactions/s	2,000 transactions/s	2,000 transactions/s
Publication of Global Data	800 transactions/s			800 transactions/s	800 transactions/s	800 transactions/s	800 transactions/s

(1) A temporary overload — due, for example, to an adjustment terminal or the temporary connection of an Internet browser — on which a few PLC scans are permitted.

(2) Only with Unity Pro™ software.

(3) Only with Concept™/ProWORX™ software.

(4) Module not featuring I/O Scanning and Global Data services (TSX W MY 100 and 140 NWM 100 00).

# Modicon® M340™ Automation Platform

Ethernet TCP/IP network, and  
Transparent Ready® Services — Performance

## Processing capacities of Modicon® platforms (continued)

### Maximum number of simultaneous TCP/IP connections


The maximum number of simultaneous TCP/IP connections depends on the platform as well as the type of connection to the Ethernet network:

- The 10/100BASE-TX port in network modules.
- The 10/100BASE-TX port integrated in processors.

Number of simultaneous TCP/IP connections	Modicon M340	Modicon Premium	Modicon Quantum
BMX NOE 0100	BMX P34 2020	TSX ETY 210	140 NOE 771 01/11
BMX NOE 0110	BMX P34 2030	TSX ETY 110WS	140 CPU 113/311 ●
Client	16	32	140 CPU 434/534 14B
Server	16	64 (1)	140 CPU 65 150
		16 (1)	140 CPU 65 160
		64 (1)	16 (1)
		64 (1)	64 (1)

(1) With 64 simultaneous TCP/IP connections maximum (clients and servers).

3



3

### Managing the passband of Ethernet TCP/IP modules

The passband management service indicates the load level of the Ethernet network module. This allows the user to monitor any drift and anticipate any problems.

The Ethernet module load is indicated in 3 ways:

- Expected load in the Unity Pro™/PL7™ configuration screen.
- Actual load in the Unity Pro/PL7 diagnostics/debug screen, as well as in the diagnostics pages via the Web. It is displayed in the form of a bar chart animated in real time.
- In the SNMP interface for access by the SNMP network manager.



Ethernet port integrated in the BMX P34 2020/2030

or

Ethernet module BMX NOE 0100/0110

### Ethernet solutions with the Modicon® M340™ platform


The M340 PLC has 2 types of connection to the Ethernet network:

- The 10/100BASE-TX port integrated in **BMX P34 2020/2030** Performance processors, which also process the application, exchanges with other modules supported by the rack and other communication ports (CANopen bus or Modbus serial link).
- The 10/100BASE-TX port in the **BMX NOE 0100** and **BMX NOE 0110** modules on which, unlike the Performance processor, all the resources are allocated to Ethernet TCP/IP communication.

These fundamentally different hardware characteristics result in equally different capacities in terms of service, and performance:

- The integrated port is a low-cost way of satisfying applications that have minimal demands in terms of communication (less than 500 useful messages/s) in environments little affected by interference.
- Where there are a large number of exchanges, or network capacity approaches its limitation, use of a dedicated module is unavoidable.

3



### Description

**BMX P34 2020** and **BMX P34 2030** Modicon M340 processors with integrated Ethernet port have the following on the front panel:

- 1 Securing screw for locking the module in its slot (marked 0) in the rack
- 2 A display unit including at minimum 3 LEDs relating to the Ethernet port:
- 3 A mini B USB connector for a programming terminal (or Magelis® XBT GT operator interface)
- 4 A slot equipped with its Flash memory card for saving the application and activating the standard Transparent Ready® Web server, class B10.
- 5 An RJ45 connector for connection to the 10BASE-T/100BASE-TX Ethernet TCP/IP network

Also included, depending on the model:

- 6 **BMX P34 2020** processor: An RJ45 connector for the Modbus® serial link or character mode link (RS 232C/RS 485, 2-wire, non-isolated)
- 7 **BMX P34 2030** processor: A 9-pin SUB-D connector for the master CANopen machine and installation bus

On the back panel: 2 rotary switches for assigning the IP address in one of 3 modes:

- address set by the position of the two rotary switches
- address set by the application parameters
- address set by the Ethernet TCP/IP BOOTP server

### Characteristics

Module type	Unity Pro™ software	BMX P34 2020	BMX P34 2030
Transparent Class		B10	
Ready services	Standard Web server	Rack Viewer access to the product description and status and to the PLC diagnostics Data Editor access to the configuration functions and PLC variables	
	Standard Ethernet TCP/IP communication service	Modbus TCP messaging (read/write data words)	
Ethernet TCP/IP advanced communication services	I/O Scanning Global Data FDR Client SMTP E-mail notification SNMP network administrator SOAP/XML Web services Bandwidth management	– – Automatic assignment of IP address and network parameters – Yes No Yes	
Structure	Physical interface	10BASE-T/100BASE-TX (RJ45)	
	Data rate	10/100 Mbit/s with automatic recognition	
	Medium	Twisted pair	
Modicon M340 processor	No. of discrete I/O No. of analog I/O No. of application-specific channels Max. no. of Ethernet TCP/IP connections Other integrated communication ports Operating temperature Relative humidity Degree of protection Power supply Conformity to standards LED indicators	1024 256 36 2 (integrated port and BMX NOE 0100/0110 network module) Modbus serial link or character mode 0...+ 60 °C 10...95% non-condensing during operation IP 20 Via the power supply of the rack supporting the processor IEC/EN 61131-2, UL 508, CSA 22.2 n°142, CSA 22.2 n°213 Class 1 Division 2, CE Activity on the Ethernet TCP/IP network (ETH ACT, green) Status of the Ethernet TCP/IP network (ETH STS, green) Data rate on the 10 or 100 Mbit/s Ethernet TCP/IP network, (ETH 100, red) 4 LEDs specific to processor operation (RUN, ERR, I/O, CARD ERR) 1 or 2 LEDs specific to the other communication ports (SER COM or CAN RUN and CAN ERR) (1)	CANopen bus

### References




BMX P34 2020



BMX P34 2030

Description	I/O capacity Memory capacity	Other integrated communication ports	Reference	Weight kg
Processors with integrated Ethernet link	1024 discrete I/O 256 analog I/O 36 app-sp. channels	Modbus serial link or character mode CANopen bus	BMXP342020 BMXP342030	0.205 0.215
Transparent Ready Web server, class B10	4096 Kb integrated			

(1) SER COM for serial link or CAN RUN and CAN ERR for CANopen bus.



### Presentation

The **BMX NOE 0100** and **BMX NOE 0110** modules are a standard module occupying a single slot in the rack of the Modicon M340 platform equipped with a Standard processor or associated Performance processor (maximum of 1 module per configuration)

### Description

The **BMX NOE 0100** module has the following on the front panel:

- 1 Securing screw for locking the module in its slot in the rack
- 2 A display unit consisting of 6 LEDs, including 3 relating to the Ethernet port:
  - ETH ACT LED (green): Activity on the Ethernet TCP/IP network
  - ETH STS LED (green): Ethernet TCP/IP network status
  - ETH 100 LED (red): Data rate on the Ethernet TCP/IP network (10 or 100 Mbit/s)
- 3 A slot equipped with its Flash memory card for application saving and activating the standard Web server, Transparent Ready® Web server, class B30 or C30 depending on model
- 4 An RJ45 connector for connection to the 10BASE-T/100BASE-TX Ethernet TCP/IP network
- 5 A pencil-point RESET button for a cold restart of the module

On the back panel: 2 rotary switches for assigning the IP address in one of 3 modes:

- address set by the position of the two rotary switches
- address set by the application parameters
- address set by the Ethernet TCP/IP network BOOTP server

### Characteristics

Module type	Unity Pro™ software	BMX NOE 0100	BMX NOE 0110
Transparent Class		B30	C30
Ready services	Standard Web server	Rack Viewer access to the product description and status and to the PLC diagnostics Data Editor access to PLC variable via PC terminal	Data Editor access to PLC variable via PC terminal, pocket PC or PDA terminal
	Configurable Web server	Yes	Yes
	User Web pages (available size)	–	Yes (16 Mb)
	Standard Ethernet TCP/IP communication service	Modbus® TCP messaging (read/write data words)	
Ethernet TCP/IP advanced communication services	I/O Scanning	Yes	
	Global Data	Yes	
	FDR server	Automatic assignment of IP address and network parameters	
	SMTP E-mail notification	–	
	SNMP network administrator	Yes	
	SOAP/XML Web services	–	Server
	Bandwidth management	Yes	
Structure	Physical interface	10BASE-T/100BASE-TX (RJ45)	
	Data rate	10/100 Mbit/s with automatic recognition	
	Medium	Twisted pair	
Network module	Operating temperature	0...+60 °C	
	Relative humidity	10...95% non-condensing during operation	
	Degree of protection	IP 20	
	Power supply	Via the power supply of the rack supporting the processor	
	Conformity to standards	IEC/EN 61131-2, UL 508, CSA 22.2 n°142, CSA 22.2 n°213 Class 1 Division 2, CE	
	LED indicators	Activity on the Ethernet TCP/IP network (ETH ACT, green) State of the Ethernet TCP/IP network (ETH STS, green) Data rate on the 10 or 100 Mbit/s Ethernet TCP/IP network. (ETH 100, red) 3 LEDs specific to module operation (RUN, ERR, CARD ERR)	

### References



BMX NOE 0100/0110

Description	Data rate	Transparent Ready class	Reference	Weight kg
Ethernet TCP/IP network module	10/100 Mbit/s	B30	BMXNOE0100	0.200
		C30	BMXNOE0110	▲ 0.200

▲ Available 4<sup>th</sup> quarter 2007


Before this date, please order the **BMX NOE 0100** Ethernet module with **BMX RWS C016M memory card**, same services except Data editor service with pocket PC or PDA terminal and SOAP/XML Web services.

### Presentation

The Ethernet cable provides all cable options to wire IP20 and IP67 devices using copper as well as fiber optics.

### Examples


#### Combined IP20 and IP67 wiring, copper



For key:

**1, 3:** Straight cables,  
**2, 4:** Crossed cord cables,  
**8:** Cables with IP 67 connector,  
see pages 3/26 and 3/27.

### Examples (continued) Combined Copper and Fiber wiring



For key:  
 1, 3: Straight cables,  
 2, 4: Crossed cord cables,  
 5, 6, 7: Fiber optic cables,  
 8: Cables with IP 67 connector,  
 see pages 3/26 and 3/27

# Ethernet in Machines and Installations

Ethernet TCP/IP, Transparent Ready® Services  
Cabling system: ConneXium™ connection components

## Shielded copper connection cables

ConneXium shielded connection cables are available in two versions to meet the various current standards and approvals:

### ■ EIA/TIA 568 standard shielded twisted pair cables

These cables conform to:

- EIA/TIA-568 standard, category CAT 5E,
- IEC 11801/EN 50173 standard, class D.
- Their fire resistance conforms to:
- NFC 32070# C2 classification
- IEC 322/1 standards
- Low Smoke Zero Halogen (LSZH).

### ■ UL and CSA 22.1 approved shielded twisted pair cables

These cables conform to:

- UL and CSA 22.1 standards
- Their fire resistance conforms to NFPA 70.

## EIA/TIA 568 standard shielded twisted pair cables

Description	Preformed at both ends	Rep.	Length m (ft.)	Reference	Weight kg
Straight cables	2 RJ45 connectors For connection to terminal devices (DTE)	1	2 (6.6)	490NTW00002	—
			5 (16.4)	490NTW00005	—
			12 (39.4)	490NTW00012	—
			40 (131.2)	490NTW00040	—
			80 (262.5)	490NTW00080	—
Crossed cord cables	2 RJ45 connectors For connections between hubs, switches and transceivers	2	5 (16.4)	490NTC00005	—
			15 (49.2)	490NTC00015	—
			40 (131.2)	490NTC00040	—
			80 (262.5)	490NTC00080	—

## UL and CSA 22.1 approved shielded twisted pair cables

Description	Preformed at both ends	Rep.	Length	Reference	Weight kg
Straight cables	2 RJ45 connectors For connection to terminal devices (DTE)	3	2 (6.6)	490NTW00002U	—
			5 (16.4)	490NTW00005U	—
			12 (39.4)	490NTW00012U	—
			40 (131.2)	490NTW00040U	—
			80 (262.5)	490NTW00080U	—
Crossed cord cables	2 RJ45 connectors For connections between hubs, switches and transceivers	4	5 (16.4)	490NTC00005U	—
			15 (49.2)	490NTC00015U	—
			40 (131.2)	490NTC00040U	—
			80 (262.5)	490NTC00080U	—

## Glass fiber optic cables

These glass fiber optics are for making connections:

- To a terminal device (DTE)
- Between hubs, transceivers and switches

Description	Preformed at both ends	Rep.	Length	Reference	Weight kg
Glass fiber optic cables	1 SC connector 1 MT-RJ connector	5	5 (16.4)	490NOC00005	—
			1 ST connector (BFOC)	490NOT00005	—
			1 MT-RJ connector	490NOR00003	—
2 MT-RJ connectors		6	3 (9.8)	490NOR00003	—
			5 (16.4)	490NOR00005	—
			15 (49.2)	490NOR00015	—

3



490 NT 000 00



490 NOC 000 05



490 NOT 000 05



490 NOR 000 05

# Ethernet in Machines and Installations

Ethernet TCP/IP, Transparent Ready® Services  
Cabling system: ConneXium™ connection components



TCS EAA F1LF00

## Separate parts for TCS ESM switches

Description	Optical fiber	Type	Reference	Weight kg
Fiber optic modules for Gigabit ports with LC connector (1)	Multimode 50/125µm or 62.5/125µm	1000BASE-SX	TCSEAAF1LFU00	0.040
	Single mode 9/125µm	1000BASE-LH	TCSEAAF1LFH00	0.040
	Multimode 50/125µm or 62.5/125µm Single mode 62.5/125µm	1000BASE-LX	TCSEAAF1LFS00	0.040
Configuration backup key	Via the USB port on the front of the switch, used to: - save and retrieve the switch configuration - update the internal software			
		TCSEAM0100		-

(1) Dimensions W x H x D = 20 x 18 x 50 mm.

3

## Connection components for IP 67 switch

Description	Preformed at both ends	Rep.	Length m (ft.)	Reference	Weight kg
Copper cables	1 IP 67 4-pin M12 connector and 1 RJ45 connector	8	1 (3.3)	TCSEC1M3M1S2	-
			1.5 (4.9)	TCSECL1M3M1X5S2	-
			3 (9.8)	TCSECL1M3M3S2	-
			5 (16.4)	TCSECL1M3M5S2	-
			10 (32.8)	TCSECL1M3M10S2	-
			25 (82)	TCSECL1M3M25S2	-
			40 (131.2)	TCSECL1M3M40S2	-
					-
Power cables	2 IP 67 4-pin M12 connectors	-	1 (3.3)	TCSECL1M1M1S2	-
			1.5 (4.9)	TCSECL1M1M1X5S2	-
			3 (9.8)	TCSECL1M1M3S2	-
			5 (16.4)	TCSECL1M1M5S2	-
			10 (32.8)	TCSECL1M1M10S2	-
			25 (82)	TCSECL1M1M25S2	-
			40 (131.2)	TCSECL1M1M40S2	-
M12/RJ45 adapter	IP 67 female 4-pin M12 connector and female RJ45 connector	-		TCSEAAF11F13F00	-
Power connectors	Female M12 straight connector	-	2 (6.6)	XZCP1164L2	-
			5 (16.4)	XZCP1164L5	-
	Female M12 elbowed connector	-	2.5 (8.2)	XZCP1264L2	-
			5 (16.4)	XZCP1264L5	-
M12/RJ45 adapter	Female M12 straight connector	-	-	XZCC12FDM50B	-
	Female M12 elbowed connector	-	-	XZCC12FCM50B	-

# Ethernet in Machines and Installations

Ethernet TCP/IP, Transparent Ready® Services  
Cabling system: ConneXium™ hub


## Presentation

Hubs (*concentrators*) are used for transmitting signals between several media (ports). Hubs are plug and play devices that require no configuration.

The use of hubs makes it possible to create the following topologies:

- Star topology using hubs
- Tree topology using hubs

Consult our catalog "Ethernet TCP/IP and Web technologies, Transparent Ready".



## 3

### Characteristics and reference

Transparent Ready



Hubs		
Interfaces	Copper cable ports	Number and type
	Shielded connectors	RJ45
	Medium	Shielded twisted pair, category CAT 5E
	Total length of pair	100 m
	Fiber optic ports	Number and type
Topology	Number of cascaded hubs	max. 4
	Number of hubs in a ring	—
Redundancy	P1 and P2 redundant power supplies	
Power supply	Voltage	24 V $\perp\!\!\!\perp$ (18...32), safety extra low voltage (SELV)
	Power consumption	80 mA (130 max. at 24 V $\perp\!\!\!\perp$ )
	Removable connector	5-pin
Operating temperature	0...+ 60 °C	
Relative humidity	10...95% non-condensing	
Degree of protection	IP 30	
Dimensions	W x H x D	40 x 125 x 80 mm
Mounting	On symmetrical DIN rail, 35 mm wide	
Weight	0.530 kg	
Conformity to standards	cUL 60950, UL 508 and CSA 142, UL 1604 and CSA 213 Class 1 Division 2, CE, GL FM 3810, FM 3611 Class 1 Division 2	
LED indicators	Power supply, activity, link	
Alarm relay	Power supply fault, Ethernet network fault or communication port fault (1 A max. voltage-free contact at 24 V $\perp\!\!\!\perp$ )	
Reference	499 NEH 104 10	

# Ethernet in Machines and Installations

Ethernet TCP/IP, Transparent Ready® Services  
Cabling system: ConneXium™ transceivers


## Presentation

The use of ConneXium transceivers makes it possible to perform the following:

- Creation of linear fiber optic bus topologies, for products with twisted-pair cable Ethernet connection.
- Interfacing products with twisted-pair cable Ethernet connection with a fiber optic cable.

Transceivers are plug and play devices that requires no configuration. Consult our catalog "Ethernet TCP/IP and Web technologies, Transparent Ready".

ConneXium transceivers provide fiber optic connections for transmission in areas subject to interference (high levels of electromagnetic interference) and for long distance communications.



Linear topology on optical fiber

3

## Characteristics and reference

Transparent Ready




Transceivers					
Interfaces	Copper cable ports	Number and type	1 x 100BASE-TX port		
		Shielded connectors	RJ45		
		Medium	Shielded twisted pair, category CAT 5E		
		Total length of pair	100 m		
	Fiber optic ports	Number and type	1 x 100BASE-FX port		
		Connectors	SC		
		Medium	Multimode optical fiber		
		Length of optical fiber			
		50/125 µm fiber	3000 m (1)		
		62.5/125 µm fiber	3000 m (1)		
		Attenuation analysis			
		50/125 µm fiber	8 dB		
		62.5/125 µm fiber	11 dB		
Redundancy	P1 and P2 redundant power supplies				
Power supply	Voltage	24 V ... (18...32), safety extra low voltage (SELV)			
	Power consumption	160 mA (190 max. at 24 V ...)			
	Removable connector	5-pin			
Operating temperature	0...+ 60 °C				
Relative humidity	10...95% non-condensing				
Degree of protection	IP 20				
Dimensions	W x H x D	47 x 135 x 111 mm			
Mounting	On symmetrical DIN rail, 35 mm wide				
Weight	0.230 kg				
Conformity to standards	cUL 60950, UL 508 and CSA 142, UL 1604 and CSA 213 Class 1 Division 2, CE, GL				
LED indicators	P1 and P2 power supplies, Ethernet link/port status				
Alarm relay	Power supply fault, Ethernet network fault or communication port fault (1 A max. voltage-free contact at 24 V ...)				
Reference	499 NTR 101 00				

(1) Length depends on the attenuation analysis and attenuation of the optical fiber (typical value: 2000 m).

# Ethernet in Machines and Installations

Ethernet TCP/IP, Transparent Ready® Services  
Cabling system: ConneXium™ unmanaged switches

## Presentation



Switches are used to increase the limits of architectures based on hubs or transceivers, by separating collision domains. Higher layer communication is provided between the ports, and collisions at link layer are not propagated (filtering). They therefore improve performance by better allocation of the pass band due to the reduction of collisions and the network load. Certain ConneXium switch models also enable redundant architectures to be created on twisted pair copper ring or fiber optic.

Switches are plug and play devices that require no configuration. They can also be managed remotely via the SNMP or HTTP protocols for monitoring and diagnostics purposes.

## 3

## Characteristics and references: twisted pair



Switches			Optimized, copper twisted pair, unmanaged	Copper twisted pair, unmanaged
<b>Interfaces</b>	Copper cable ports	Number and type	5 x 10BASE-T/100BASE-TX ports	8 10BASE-T/100BASE-TX ports
		Shielded connectors	RJ45	
		Medium	Shielded twisted pair, category CAT 5E	
		Total length of pair	100 m	
	Fiber optic ports	Number and type	–	
		Connectors	–	
		Medium	–	
		Length of optical fiber		
		50/125 µm fiber	–	
		62.5/125 µm fiber	–	
		9/125 µm fiber	–	
		Attenuation analysis		
		50/125 µm fiber	–	
		62.5/125 µm fiber	–	
		9/125 µm fiber	–	
<b>Topology</b>	Number of switches	Cascaded	Unlimited	
		Redundant in a ring	–	
<b>Redundancy</b>			–	P1 and P2 redundant power supplies
<b>Power supply</b>	Voltage	24 V (19.2...30)	24 V (18...32) safety extra low voltage (SELV)	
	Power consumption	mA max.	120	125 (290 max.)
		Removable connector	3-pin	5-pin
<b>Operating temperature</b>		0...+ 60 °C		
<b>Relative humidity</b>		10...95% non-condensing		
<b>Degree of protection</b>		IP 20		
<b>Dimensions</b>	W x H x D	75.2 x 143 x 43 mm	47 x 135 x 111 mm	
<b>Mounting</b>		On symmetrical DIN rail, 35 mm wide		
<b>Weight</b>		0.190 kg	0.230 kg	
<b>Conformity to standards</b>		UL 508, CSA 1010, EN 61131-2	cUL 60950, UL 508 and CSA 142, UL 1604 and CSA 213 Class 1 Division 2, CE, GL	
<b>LED indicators</b>		Power supply, link status, data rate	P1 and P2 power supplies, Ethernet link/port status	
<b>Alarm relay</b>		–	Power supply fault, Ethernet network fault or communication port fault (1 A max. voltage-free contact at 24 V)	
<b>Reference</b>		499 NES 251 00	499 NES 181 00	

**Characteristics and references: 5 ports, twisted pair and fiber optic**



Switches			Copper twisted pair and fiber optic, unmanaged								
Interfaces	Copper cable ports	Number and type	4 x 10BASE-T/ 100BASE-TX ports	3 x 10BASE-T/ 100BASE-TX ports	4 x 10BASE-T/ 100BASE-TX ports	3 x 10BASE-T/ 100BASE-TX ports					
		Shielded connectors	RJ45								
		Medium	Shielded twisted pair, category CAT 5E								
		Total length of pair	100 m								
Fiber optic ports	Number and type	1 x 100BASE-FX port	2 x 100BASE-FX ports	1 x 100BASE-FX port	2 x 100BASE-FX ports						
		Connectors	SC								
		Medium	Multimode optical fiber		Single mode optical fiber						
		Length of optical fiber									
		50/125 µm fiber	5,000 m (1)	–							
		62.5/125 µm fiber	4,000 m (1)	–							
		9/125 µm fiber	–	32,500 m (2)							
		Attenuation analysis									
		50/125 µm fiber	8 dB	–							
Topology	Number of switches	Cascaded	Unlimited								
		Redundant in a ring	–								
Redundancy			P1 and P2 redundant power supplies								
Power supply	Voltage	24 V ... (18...32), safety extra low voltage (SELV)									
		Power consumption mA max.	200	240	200	240					
		Removable connector	5-pin								
Operating temperature			-40...+70 °C								
Relative humidity			10...95% non-condensing								
Degree of protection			IP 20								
Dimensions			47 x 135 x 111 mm								
Mounting			On symmetrical DIN rail, 35 mm wide								
Weight			0.330 kg	0.335 kg	0.330 kg	0.335 kg					
Conformity to standards			cUL 60950, cUL 508 and CSA 142, UL 1604 and CSA 213 Class 1 Division 2, CE, GL								
LED indicators			P1 and P2 power supplies, Ethernet link status, transmission activity								
Alarm relay			Activity, power supply fault, Ethernet network fault or communication port fault (1 A max. voltage-free contact at 24 V ...)								
Reference			499 NMS 251 01	499 NMS 251 02	499 NSS 251 01	499 NSS 251 02					

(1) Length depends on the attenuation analysis and attenuation of the fiber optic (typical value: 2,000 m).

(2) Length depends on the attenuation analysis and attenuation of the fiber optic (typical value: 15,000 m).

# Ethernet in Machines and Installations

Ethernet TCP/IP, Transparent Ready® Services  
Cabling system: ConneXium™ managed switches

## Characteristics and references: 4 ports, twisted pair and fiber optic

Transparent Ready



3

Switches			Copper twisted pair and fiber optic, managed							
<b>Interfaces</b>	Copper cable ports	Number and type	3 x 10/100BASE-TX ports	2 x 10/100BASE-TX ports	3 x 10/100BASE-TX ports	2 x 10/100BASE-TX ports				
		Shielded connectors	RJ45							
		Medium	Shielded twisted pair, category CAT 5E							
		Total length of pair	100 m							
	Fiber optic ports	Number and type	1 x 100BASE-FX port	2 x 100BASE-FX ports	1 x 100BASE-FX port	2 x 100BASE-FX ports				
		Connectors	Duplex SC							
		Medium	Multimode optical fiber		Single mode optical fiber					
		Length of optical fiber								
		50/125 µm fiber	5,000 m (1)		–					
		62.5/125 µm fiber	4,000 m (1)		–					
		9/125 µm fiber	–		32,500 m (2)					
		Attenuation analysis								
		50/125 µm fiber	8 dB		–					
		62.5/125 µm fiber	11 dB		–					
		9/125 µm fiber	–		16 dB					
	Ethernet services	FDR, SMTP V3, SNTP client, multicast filtering for optimization of the Global Data protocol, configuration via Web access VLAN, IGMP Snooping, RSTP ( <i>Rapid Scanning Tree Protocol</i> ), priority port, data stream control, secure port								
<b>Topology</b>	Number of switches	Cascaded	Unlimited							
		Redundant in a ring	max. 50							
<b>Redundancy</b>			Redundant power supplies, redundant single ring, ring coupling							
<b>Power supply</b>	Voltage	Operation	9.6...60 V .../18...30 V ~, safety extra low voltage (SELV)							
	Power consumption		6.5 W	7.3 W	6.5 W	7.3 W				
	Removable connector		6-pin							
<b>Operating temperature</b>			0...+ 60 °C							
<b>Relative humidity</b>			10...90% non-condensing							
<b>Degree of protection</b>			IP 20							
<b>Dimensions</b>	W x H x D		47 x 131 x 111 mm							
<b>Mounting</b>	On symmetrical DIN rail, 35 mm wide									
<b>Weight</b>	0.400 kg									
<b>Conformity to standards</b>			IEC 61131-2, IEC 61850-3, UL 508, UL 1604 Class 1 Division 2, CSA C22.2 14 (cUL), CSA C22.2 213 Class 1 Division 2 (cUL), CE, GL							
<b>LED indicators</b>			Power supply status, alarm relay status, active redundancy, redundancy management, copper port status and copper port activity							
<b>Alarm relay</b>			Power supply fault, Ethernet network fault, communication port fault, redundancy fault (1 A max. voltage-free contact at 24 V ...)							
<b>Reference</b>			TCS ESM 043F1CU0	TCS ESM 043F2CU0	TCS ESM 043F1CS0	TCS ESM 043F2CS0				

(1) Length depends on the attenuation analysis and attenuation of the fiber optic (typical value: 2,000 m).

(2) Length depends on the attenuation analysis and attenuation of the fiber optic (typical value: 15,000 m).

# Ethernet in Machines and Installations

Ethernet TCP/IP, Transparent Ready® Services  
Cabling system: ConneXium™ managed switches

## Characteristics and references: 4 and 8 ports, twisted pair



Switches			Copper twisted pair, managed	
<b>Interfaces</b>	Copper cable ports	Number and type	4 x 10/100BASE-TX ports	8 x 10/100BASE-TX ports
		Shielded connectors	RJ45	
		Medium	Shielded twisted pair, category CAT 5E	
		Total length of pair	100 m	
	Fiber optic ports	Number and type	–	
		Connectors	–	
		Medium		
		Length of optical fiber		
		50/125 µm fiber	–	
		62.5/125 µm fiber	–	
		9/125 µm fiber	–	
		Attenuation analysis		
		50/125 µm fiber	–	
		62.5/125 µm fiber	–	
		9/125 µm fiber	–	
	Ethernet services		FDR, SMTP V3, SNTP client, multicast filtering for optimization of the Global Data protocol, configuration via Web access VLAN, IGMP Snooping, RSTP ( <i>Rapid Scanning Tree Protocol</i> ), priority port, data stream control, secure port	
<b>Topology</b>	Number of switches	Cascaded	Unlimited	
		Redundant in a ring	max. 50	
<b>Redundancy</b>			Redundant power supplies, redundant single ring, ring coupling	
<b>Power supply</b>	Voltage	Operation	9.6...60 V $\text{---}$ /18...30 V $\sim$ , safety extra low voltage (SELV)	
	Power consumption		5.3 W	5.3 W
	Removable connector		6-pin	
<b>Operating temperature</b>			0...+ 60 °C	
<b>Relative humidity</b>			10...90% non-condensing	
<b>Degree of protection</b>			IP 20	
<b>Dimensions</b>			47 x 131 x 111 mm	74 x 131 x 111 mm
<b>Mounting</b>			On symmetrical DIN rail, 35 mm wide	
<b>Weight</b>			0.400 kg	0.410 kg
<b>Conformity to standards</b>			IEC 61131-2, IEC 61850-3, UL 508, UL 1604 Class 1 Division 2, CSA C22.2 14 (cUL), CSA C22.2 213 Class 1 Division 2 (cUL), CE, GL	
<b>LED indicators</b>			Power supply status, alarm relay status, active redundancy, redundancy management, copper port status and copper port activity	Power supply status, alarm relay status, active redundancy, redundancy management, fiber port status and fiber port activity
<b>Alarm relay</b>			Power supply fault, Ethernet network fault or communication port fault (1 A max. voltage-free contact at 24 V $\text{---}$ )	
<b>Reference</b>			TCS ESM 043F23F0	TCS ESM 083F23F0

# Ethernet in Machines and Installations

Ethernet TCP/IP, Transparent Ready® Services  
Cabling system: ConneXium™ managed switches

## Characteristics and references: 8 ports, twisted pair and fiber optic

Transparent Ready



3

Switches			Copper twisted pair and fiber optic, managed									
<b>Interfaces</b>	Copper cable ports	Number and type	7 x 10/100BASE-TX ports	6 x 10/100BASE-TX ports	7 x 10/100BASE-TX ports	6 x 10/100BASE-T ports						
		Shielded connectors	RJ45									
		Medium	Shielded twisted pair, category CAT 5E									
		Total length of pair	100 m									
	Fiber optic ports	Number and type	1 x 100BASE-FX port	2 x 100BASE-FX ports	1 x 100BASE-FX port	2x 100BASE-FX ports	1 + 1 x 100BASE-FX port					
		Connectors	Duplex SC									
		Medium	Multimode optical fiber			Single mode optical fiber		Single mode optical fiber and multimode optical fiber				
		Length of optical fiber										
		50/125 µm fiber	5,000 m (1)			–		5,000 m (1)				
		62.5/125 µm fiber	4,000 m (1)			–		4,000 m (1)				
		9/125 µm fiber	–			32,500 m (2)		32,500 m (2)				
		Attenuation analysis										
		50/125 µm fiber	8 dB			–		8 dB				
		62.5/125 µm fiber	11 dB			–		11 dB				
		9/125 µm fiber	–			16 dB		16 dB				
	Ethernet services	FDR, SMTP V3, SNTP client, multicast filtering for optimization of the Global Data protocol, configuration via Web access VLAN, IGMP Snooping, RSTP ( <i>Rapid Scanning Tree Protocol</i> ), priority port, data stream control, secure port										
<b>Topology</b>	Number of switches	Cascaded	Unlimited									
		Redundant in a ring	max. 50									
<b>Redundancy</b>			Redundant power supplies, redundant single ring, ring coupling									
<b>Power supply</b>	Voltage	Operation	9.6...60 V .../18...30 V ~, safety extra low voltage (SELV)									
	Power consumption		6.5 W	7.3 W	6.5 W	7.3 W						
	Removable connector		6-pin									
<b>Operating temperature</b>			0...+ 60 °C									
Relative humidity			10... 90% non-condensing									
Degree of protection			IP 20									
<b>Dimensions</b>		W x H x D	74 x 131 x 111 mm									
Mounting			On symmetrical DIN rail, 35 mm wide									
Weight			0.410 kg									
<b>Conformity to standards</b>			IEC 61131-2, IEC 61850-3, UL 508, UL 1604 Class 1 Division 2, CSA C22.2 14 (cUL), CSA C22.2 213 Class 1 Division 2 (cUL), c€, GL									
<b>LED indicators</b>			Power supply status, alarm relay status, active redundancy, redundancy management, fiber port status and fiber port activity									
<b>Alarm relay</b>			Power supply fault, Ethernet network fault or communication port fault (1 A max. voltage-free contact at 24 V ...)									
<b>Reference</b>			TCSESM 083F1CU0	TCSESM 083F2CU0	TCSESM 083F1CS0	TCSESM 083F2CS0	TCSESM 083F2CX0					

(1) Length depends on the attenuation analysis and attenuation of the fiber optic (typical value: 2,000 m).

(2) Length depends on the attenuation analysis and attenuation of the fiber optic (typical value: 15,000 m).

# Ethernet in Machines and Installations

Ethernet TCP/IP, Transparent Ready® Services  
Cabling system: ConneXium™ IP 67 switch

## Characteristics and references: IP 67 unmanaged switch



IP 67 switch			Twisted pair, unmanaged		
Interfaces	Copper cable ports	Number and type	5 x 10BASE-T/100BASE-TX ports		
		Shielded connectors	M12 (type D)		
		Medium	Shielded twisted pair, category CAT 5E		
		Total length of pair	100 m		
	Fiber optic ports	Number and type	–		
		Connectors	–		
		Medium	–		
		Length of optical fiber	–		
		Attenuation analysis	–		
	Ethernet services	Storage and re-routing of received data, auto MDI/MDX (automatic switching depending on whether cables are straight or crossed), automatic negotiation of 10/100 Mbps and duplex mode (on all ports), automatic change of polarity			
Topology	Number of switches	Cascaded	Unlimited		
		Redundant in a ring	–		
Redundancy	–				
Power supply	Voltage	24 V (18...32 V), safety extra low voltage (SELV)			
	Power consumption	100 mA			
	Connector	5-pin M12 (type A, male)			
Operating temperature	0...+60 °C				
Relative humidity	–				
Degree of protection	IP 67				
Dimensions W x H x D	60 x 126 x 31 mm				
Weight	0.210 kg				
Conformity to standards	cUL 508 and CSA 22.2 14				
LED indicators	Power supply, line status, line activity				
Alarm relay	–				
Reference	TCS ESU 051 F0				

### IP 67 cord sets

Ethernet cord sets	Preformed at each end, see page 3/27		
Power supply cables	Preformed at each end with M12 female straight connectors	Preformed at each end with female M12 angled connectors	
Length	2 m	5 m	2.5 m
Reference	XZC P1164L2	XZC P1164L5	XZC P1264L2
Spare power connectors	Female M12 straight connector	Female M12 angled connector	
Reference	XZC C12 FDM 50B	XZC C12 FCM 50B	

# Ethernet in Machines and Installations

Ethernet TCP/IP, Transparent Ready® Services  
Cabling system: ConneXium™ managed switches

## Characteristics and references: 16 and 24 ports, twisted pair, fiber optic

Transparent Ready



3

Switches			Copper twisted pair and fiber optic, managed	Copper twisted pair, managed	Copper twisted pair and fiber optic, managed
<b>Interfaces</b>	Copper cable ports	Number and type	16 x 10/100BASE-TX ports	14 x 10/100BASE-TX ports	22 x 10/100BASE-TX ports
		Shielded connectors	RJ45		
		Medium	Shielded twisted pair, category CAT 5E		
		Total length of pair	100 m		
	Fiber optic ports	Number and type	–	2 x 100BASE-FX ports	
		Connectors	–	Duplex SC	
		Medium	–	Multimode optical fiber	
		Length of optical fiber			
		50/125 µm fiber	–	5,000 m (1)	
		62.5/125 µm fiber	–	4,000 m (1)	
		9/125 µm fiber	–	–	
		Attenuation analysis			
		50/125 µm fiber	–	8 dB	
		62.5/125 µm fiber	–	11 dB	
		9/125 µm fiber	–	–	
	Ethernet services		FDR, SMTP V3, SNTP client, multicast filtering for optimization of the Global Data protocol, configuration via Web access VLAN, IGMP Snooping, RSTP ( <i>Rapid Scanning Tree Protocol</i> ), priority port, data stream control, secure port		
<b>Topology</b>	Number of switches	Cascaded	Unlimited		
		Redundant in a ring	max. 50		
<b>Redundancy</b>			Redundant power supplies, redundant single ring, ring coupling		
<b>Power supply</b>	Voltage	Operation	9.6...60 V $\perp\!\!\!\perp$ /18...30 V $\sim$ , safety extra low voltage (SELV)		
	Power consumption		9.4 W	11.8 W	15.5 W
	Removable connector		6-pin		
<b>Operating temperature</b>			0...+ 60 °C		
<b>Relative humidity</b>			10... 90% non-condensing		
<b>Degree of protection</b>			IP 20		
<b>Dimensions</b>			111 x 131 x 111 mm		
<b>Mounting</b>			On symmetrical DIN rail, 35 mm wide		
<b>Weight</b>			0.600 kg		
			0.650 kg		
<b>Conformity to standards</b>			cUL 60950, UL 508 and CSA 142, UL 1604 and CSA 213 Class 1 Division 2, CE, GL		
<b>LED indicators</b>			Redundant power supplies, single ring	Redundant power supplies, single ring, double ring	
<b>Alarm relay</b>			Power supply fault, Ethernet network fault or communication port fault (1 A max. voltage-free contact at 24 V $\perp\!\!\!\perp$ )		
<b>Reference</b>			TCSESM 163F2CU0	TCSESM 163F23F0	TCSESM 243F2CU0

(1) Length depends on the attenuation analysis and attenuation of the fiber optic (typical value: 2,000 m).

**Characteristics and references: 8 ports and 2 Gigabit ports, twisted pair, fiber optic**

Transparent  
Ready

Switches			Copper twisted pair and fiber optic, managed				Copper twisted pair, managed												
Interfaces	Copper cable ports	Number and type	8 x 10/100BASE-TX ports				8 x 10/100BASE-TX ports and 2 x 10/100/1000BASE-TX ports (Gigabit)												
		Shielded connectors	RJ45																
		Medium	Shielded twisted pair, category CAT 5E																
		Total length of pair	100 m																
Gigabit ports fiber optic (with SFP fiber module to be mounted on SFP connector)	Number and type	2 x 1000BASE-SX ports (1)	2 x 1000BASE-LH ports (2)	2 x 1000BASE-LX ports (3)	–														
	Connectors	LC	–																
	Medium	Multimode optical fiber	Single mode optical fiber	Single mode and multimode optical fiber	–														
	Length of optical fiber	50/125 µm fiber 62.5/125 µm fiber 9/125 µm fiber	550 m 275 m –	– 550 m 8 -72,000 m	550 m 550 m 20,000 m	– – –													
Attenuation analysis	50/125 µm fiber 62.5/125 µm fiber 9/125 µm fiber	7.5 dB 7.5 dB –	– – 6 - 22 dB	11 dB 11 dB 11 dB	– – –														
	Ethernet services			FDR, SMTP V3, SNTP client, multicast filtering for optimization of the Global Data protocol, configuration via Web access VLAN, IGMP Snooping, RSTP ( <i>Rapid Scanning Tree Protocol</i> ), priority port, data stream control, secure port															
Topology	Number of switches	Cascaded	Unlimited																
		Redundant in a ring	max. 50																
Redundancy			Redundant power supplies, redundant single ring, ring coupling																
Power supply	Voltage	Operation	9.6...60 V .../18...30 V ~, safety extra low voltage (SELV)																
	Power consumption		8.9 W + 1 W per SFP fiber module																
	Removable connector		6-pin																
Operating temperature			0...+60 °C																
Relative humidity			10... 90% non-condensing																
Degree of protection			IP 20																
Dimensions			111 x 131 x 111 mm																
Mounting			On symmetrical DIN rail, 35 mm wide																
Weight			0.410 kg																
Conformity to standards			cUL 60950, UL 508 and CSA 142, UL 1604 and CSA 213 Class 1 Division 2, CE, GL																
LED indicators			Power supply status, alarm relay status, active redundancy, redundancy management, fiber port status and fiber port activity																
Alarm relay			Power supply fault, Ethernet network fault or communication port fault (1 A max. voltage-free contact at 24 V ...)																
Reference			TCS ESM 103F2LG0			TCS ESM 103F23G0													

3

(1) With TCS EAA F1LFU00 fiber optic module to be ordered separately, see page 3/27.  
(2) With TCS EAA F1LFH00 fiber optic module to be ordered separately, see page 3/27.  
(3) With TCS EAA F1LFS00 fiber optic module to be ordered separately, see page 3/27.

### Presentation

Schneider Electric has selected CANopen for its machines and installations because of its wealth of functions and its resulting benefits in the automation world. This decision was based on the general acceptance of CANopen, and the fact that CANopen products are increasingly used in control system architectures.

CANopen is an open network supported by more than 400 companies worldwide, and promoted by CAN in Automation (CiA). CANopen conforms to standards EN 50325-4 and ISO 15745-2.


Schneider Electric is heavily involved in working groups, which are important for machine and installation architectures, systems, and products.

### CANopen brings transparency to Ethernet

CAN in Automation and Modbus-IDA have worked together to create a standard that ensures total transparency between CANopen and Modbus TCP/IP. The result of this collaboration has been the CiA DSP309-2 specification, defining communication standards between a Modbus TCP/IP network and a CANopen bus.

The specification defines mapping services enabling CANopen devices to communicate with a Modbus TCP/IP network through a gateway. The data in a CANopen device can be accessed in both read and write mode.

This specification is the first standard available for developing an open standard communication between Modbus TCP/IP and CANopen. It is driving Schneider Electric network solutions toward better integration, diagnostics and configuration of distributed applications. It allows machines and installations to be connected to an Ethernet network continuously, while combining the advantages of each network in its specific area.



The CANopen bus is a multi-master bus ensuring reliable, deterministic access to real-time data in control system devices. The CSMA/CA protocol is based on broadcast exchanges, sent cyclically or on an event, to ensure optimum use of the passband. A message handling channel can also be used to define slave parameters.

The bus uses a double twisted pair on which, with the Modicon M340 platform, 63 devices maximum are connected by daisy-chaining or by tap junctions. The variable data rate between 20 Kbit/s and 1 Mbit/s depends on the length of the bus (between 20 m and 2,500 m).

Each end of the bus must be fitted with a line terminator.

The CANopen bus is a set of profiles on CAN systems, possessing the following characteristics:


- Open bus system
- Data exchanges in real time without overloading the protocol
- Modular design allowing modification of size
- Interconnection and interchangeability of devices
- Standardized configuration of networks
- Access to all device parameters
- Synchronization and circulation of data from cyclic and/or event-controlled processes (short system response time)



Advantys FTB



Advantys OTB



TeSys Quickfit



Altivar 31

Example of devices that can be connected on CANopen

3

### Connectable devices

The Modicon M340 automation platform, via its **BMX P34 2010/2030** processors with integrated CANopen link, performs the role of master on the machine bus.

The following Telemecanique® devices can be connected to the CANopen bus:

- Ø 58 mm Osicoder multi-turn absolute encoders:
  - **XCC 3510P/3515C S84CB**, version ≥ 1.0
- TeSys® U starter-controllers:
  - with **LUL C08** communication module, version ≥ 1.2
- TeSys® D motor-starters, using the TeSys® Quickfit installation help system:
  - with **APP 1CC00/O2** communication module, version ≥ 1.0
- Advantys™ OTB IP 20 Optimum distributed I/O system (I/O extension modules not permitted):
  - with **OTB 1C0 DM9LP** interface module, version ≥ 2.0
- Advantys™ STB IP 20 modular distributed I/O system:
  - with NIM module **STB NCO 1010**, version ≥ 1.0 or **STB NCO 2212**, version ≥ 2.02
- Advantys™ FTB IP 67 monobloc I/O splitter boxes:
  - **FTB 1CNe0000**, version ≥ 1.7
- Preventa™ configurable safety controllers:
  - **XPS MC16ZC/32ZC**, version ≥ 1.10
- Altivar® 31 adjustable speed drives for asynchronous motors 0.18...15 kW:
  - **ATV 31H 00000**, version ≥ 1.1 (1)
- Altivar® 71/61 adjustable speed drives for asynchronous motors 0.75...630 kW:
  - **ATV 61H /71H 00000**, version ≥ 1.1 (1)
- Lexium® 05 servo drives (0.4...6 kW) for BSH servo motors:
  - **LXM 05A0D0000**, version ≥ 1.120 (2)
- Lexium® 15 servo drives (0.9...42.5 kW) for BDH or BSH servo motors:
  - **LXM 15L0**, version ≥ 1.45 (3)
  - **LXM 15MD/15HC**, version ≥ 6.64 (4)
- IcLA® intelligent compact motor-drives from Berger Lahr® (a company of Schneider Electric®):
  - **IFA 60**, version ≥ 1.105 (5)
  - **IFE 71**, version ≥ 1.104 (5)
  - **IFS 60/90**, version ≥ 1.107 (5)

(1) Requires the PowerSuite™ software workshop **VW3 A8 104**, version ≥ 2.00.

(2) Requires the PowerSuite™ software workshop for Lexium 05 servo drive **VW3 A8 104**, version 2.2.0 patch V2.2.0B.

(3) Requires the Unilink® software, version ≥ 1.5.

(4) Requires the Unilink® software, version ≥ 4.0.

(5) Requires the IcLA® Easy software, version ≥ 1.104.

### Setup via Unity Pro™ Software


Configuration of the CANopen bus on the Modicon M340 platform is fully integrated in the Unity Pro software. From the Unity Pro graphic editor, simply select the devices available in the catalog and assign them their CANopen slave address. Exchanges between the CANopen bus and the Modicon M340 processor can be assigned by configuration to the fast or master task.

Predefined profiles or functions are used to create the user interface automatically using process variables (PDO), in such a way that any subsequent modification to the mapping of these variables will have no impact on their topological addressing. Depending on the devices, dedicated configuration screens are used to assign the initial parameters.


The dedicated screens are available for CANopen specialists who wish to optimize the performance of the CANopen bus or re-assign the Process Data Objects (PDO) differently.

Acyclical access to the Service Data Object (SDO) corresponding to any CANopen object of a particular device is possible from the application using the standard communication functions READ\_VAR and WRITE\_VAR, or even from the Unity Pro diagnostic screens.

These screens can be used to display the bus status graphically, as well as to access the diagnostics sent by a faulty device with a single click of the mouse.



Example of Unity Pro configuration screen for Lexium® 05 servo drive and Advantys FTB IP 67 I/O splitter box



BMX P34 2010

BMX P34 2030

### Description

Both of the Performance processors on the Modicon M340 platform, **BMX P34 2010** and **BMX P34 2030**, have an integrated CANopen communication port. They have the following on the front panel:

- 1 Securing screw for locking the module in its slot (marked 0) in the rack
- 2 A display block comprising at least:
  - CAN RUN LED (green): Integrated machine/installation bus operational
  - CAN ERR LED (red): Integrated machine/installation bus faulty
- 3 A mini B USB connector for a programming terminal
- 4 A slot equipped with Flash memory card for backing up the application
- 5 An RJ45 connector for serial link (with **BMX P34 2010** model) or Ethernet TCP/IP port (with **BMX P34 2030** model)
- 6 A 9-pin SUB-D connector for the CANopen Master machine and installation bus

## 3

### Characteristics (1)

Type of bus		CANopen									
<b>CANopen services</b>		M20									
Conformity class		DS 301 V 04.02, 303-2									
Standard		DS 405									
Device profile		–									
Special		–									
<b>Structure</b>		9-pin male SUB-D									
Physical interface		Devices connected by daisy-chaining and/or tap junctions									
Topology		CSMA/CA, carrier sense consumer/producer principle, collision detection and arbitration of message priorities									
Access method		Messages carrying objects: process data (PDO), service data (SDO), network management (NMT), special functions (SYNC, EMCY, TIME)									
Application layer		–									
<b>Transmission</b>		20 Kbit/s...1 Mbit/s depending on bus length									
Data rate		Double shielded twisted pair									
Medium		–									
<b>CANopen physical configuration (1)</b>	No. of slave devices		63 maximum								
	Data rate		1 Mbit/s	800 Kbit/s	500 Kbit/s	250 Kbit/s	125 Kbit/s	50 Kbit/s	20 Kbit/s		
	Maximum length of bus (2)		m	20	40	100	250	500	1000		
	Maximum length of tap-offs on one tap junction (3)		m	0.6	6	10	10	10	2500		
<b>Modicon M340 processor</b>	Limitation per segment		64	32	16	–	–	–			
	Maximum length of segment (4)		m	160	185	205	–	–			
<b>BMX P34 2010</b>							<b>BMX P34 2030</b>				
No. of racks		1 (4, 6, 8 or 12 slots)									
Maximum no. of slots		12 for processor and modules (excluding power supply module)									
<b>Integrated connections</b>	Maximum no. in rack		Discrete I/O	1,024; 704 in single-rack configuration (64 I/O x 11)							
	Analog I/O		256; 66 in single-rack configuration (4I/2Q x 11)	–							
	Process control		Programmable loops (via CONT-CTL process control EFB library)	–							
	Counting		36 channels	–							
	Motion		Independent axes on CANopen bus (via MFB library)	–							
<b>Communication module</b>	Ethernet TCP/IP		–	1 RJ45 port, 10/100 Mbit/s							
	CANopen bus		1 master (9-pin SUB-D)	–							
	Serial link		1 RJ45 port, Modbus® master/slave or character mode	–							
	USB port		1 port, 12 Mbit/s	–							
Internal RAM capacity		Kb	4,096 including 3,584 for the program, constants and symbols and 256 for data								

(1) For more information, please refer to the "Machines & Installations with industrial communications" catalog.

(2) Deduct 15 m per repeater from the length of the bus.

(3) For other restrictions, please refer to the CANopen hardware setup manual available on our website ([www.telemecanique.com](http://www.telemecanique.com)).

(4) With the use of **TSX CAN C50/100/300 CANopen cables** and **TSX CAN CDD03/1/3/5** preformed cord sets.

### Modicon® M340™ Performance processors with integrated CANopen bus link



BMX P34 2010




BMX P34 2030

I/O capacity (1)	Memory capacity	Max. no. of network modules	Integrated communication ports	Reference (3)	Weight kg
<b>Performance BMX P34 20, 1 rack</b>					
1,024 discrete I/O 256 analog I/O 36 app-sp. channels	4,096 Kb integrated	1 Ethernet TCP/IP network	CANopen bus Modbus® serial link	<b>BMXP342010</b>	–
			CANopen bus Ethernet TCP/IP network	<b>BMXP342030</b>	–

3

(1) For I/O capacity in single-rack configuration, see characteristics, page 1/8

### CANopen bus wiring system



*Note : For numbers and references 1, 2, ..., 17, see pages 3/42 and 3/43.*

Different types of cable are available making it possible to create any type of application, including for harsh environments (for a definition of standard and harsh environments, see page 3/42).

Several connectors are available to meet any requirement: straight or 90° angled connectors, or angled connectors with the option of connecting a PC or diagnostic pocket PC.

Power can be supplied to the equipment by means of cables, cord sets and tap junctions: one 24 AWG pair for the CAN signals, one 22 AWG pair for the power supply and the ground.

In addition to the offering for IP 20 wiring, there is also an offering for IP 67 wiring.

# Modicon® M340™ Automation Platform

## CANopen machine and installation bus Wiring system



TSX CAN TDM4



VW3 CAN TAP2

3



TSX CAN KCD F90T



TSX CAN KCD F180T



TSX CAN KCD F90TP

### Standard tap junctions and connectors

Designation	Description	No. (1)	Length	Reference	Weight kg
IP 20 CANopen tap junction	4 SUB-D ports. Screw terminal block for connection of trunk cables Line termination	1	–	TSXCANTDM4	0.196
IP 20 connectors	90° angled CANopen female 9-pin SUB-D. Switch for line termination	2	–	TSXCANKCDF90T	0.046
	Straight (2)	–	–	TSXCANKCDF180T	0.049
	90° angled with 9-pin SUB-D for connecting a PC or diagnostic tool	4	–	TSXCANKCDF90TP	0.051
IP 67 M12 connectors	Male	–	–	FTXCN12M5	0.050
	Female	–	–	FTXCN12F5	0.050
IP 20 CANopen tap junctions for Altivar and Lexium 05 drives	2 RJ45 ports	9	–	VW3CANTAP2	–

### IP 20 standard cables and preformed cord sets

Designation	Description	No. (1)	Length	Unit reference	Weight kg
CANopen cables (24 AWG)	Standard, CE marking: low smoke. Halogen-free. Flame-retardant (IEC 60332-1)	5	50 m	TSXCANCA50	4.930
			100 m	TSXCANCA100	8.800
			300 m	TSXCANCA300	24.560
CANopen preformed cord sets	Standard, UL certification, CE marking: flame-retardant (IEC 60332-2)	5	50 m	TSXCANCB50	3.580
One 9-pin female SUB-D connector at each end (24 AWG )			100 m	TSXCANCB100	7.840
			300 m	TSXCANCB300	21.870
	For harsh environments (3) or mobile installation, CE marking: low smoke. Halogen-free. Flame-retardant (IEC 60332-1). Resistance to oils	5	50 m	TSXCANCD50	3.510
			100 m	TSXCANCD100	7.770
			300 m	TSXCANCD300	21.700
CANopen preformed cord sets	Standard, CE marking: low smoke. Halogen-free. Flame-retardant (IEC 60332-1)	6a	0.3 m	TSXCANCADD03	0.091
One 9-pin female SUB-D connector at each end (24 AWG )			1 m	TSXCANCADD1	0.143
			3 m	TSXCANCADD3	0.295
			5 m	TSXCANCADD5	0.440
CANopen preformed cord sets	Standard, UL certification, CE marking: flame-retardant (IEC 60332-2)	6a	0.3 m	TSXCANCBDD03	0.086
One 9-pin SUB-D connector, One RJ45 connector (24 AWG )			1 m	TSXCANCBDD1	0.131
			3 m	TSXCANCBDD3	0.268
			5 m	TSXCANCBDD5	0.400
CANopen preformed cord sets	Standard, CE marking: low smoke. Halogen-free. Flame-retardant (IEC 60332-1)	6b	0.5 m	TCSCCE4F3M05	–
One 9-pin SUB-D connector, One RJ45 connector (24 AWG )	Standard, UL certification, CE marking: flame-retardant (IEC 60332-2)	6b	1 m	TCSCCE4F3M1	–
			0.5 m	TCSCCU4F3M05	–
			1 m	TCSCCU4F3M1	–
CANopen preformed cord sets	Two 9-pin SUB-D connectors, one male and one female	–	0.5 m	TLACDCBA005	–
			1.5 m	TLACDCBA015	–
			3 m	TLACDCBA030	–
			5 m	TLACDCBA050	–

### IP 67 standard preformed cord sets

Designation	Description	No. (1)	Length	Unit reference	Weight kg
CANopen preformed cord sets	Preformed cord sets of two 5-pin M12 A-coded angled connectors (one male connector and one female connector)	12	0.3 m	FTXCN3203	0.40
			0.6 m	FTXCN3206	0.70
			1 m	FTXCN3210	0.100
			2 m	FTXCN3220	0.160
			3 m	FTXCN3230	0.220
			5 m	FTXCN3250	0.430
	Preformed cord sets with one 5-pin female M12 A-coded connector at one end and wires at the other end	7	3 m	FTXCN3130	–
			5 m	FTXCN3150	–

(1) For numbers, see page 3/41

(2) For connection to the Controller Inside programmable card, the VW3 CAN KCD 180T connector can also be used.

(3) Standard environment:

- Without any particular environmental constraints
- Operating temperature between +5 °C and +60 °C
- Fixed installation
- Harsh environment:**
  - Resistance to hydrocarbons, industrial oils, detergents, solder splashes
  - Relative humidity up to 100%
  - Saline atmosphere
  - Significant temperature variations
  - Operating temperature between -10 °C and +70 °C
  - Mobile installation




VW3 CAN A71



AM0 2CA 001V000



FTX DP2100



XZ CC12•DM50B



XZ CC12•CM50B



FTX CY1208

### IP 20 connection accessories

Designation	Description	No. (1)	Length	Unit reference	Weight kg
CANopen connector	9-pin female SUB-D. Switch for line termination. for Altivar 71 drive (2) Cables exit at 180°	—	—	VW3CANKCDF180T	—
Adapter for Altivar 71	CANopen adapter SUB-D to RJ45 drive	—	—	VW3CANA71	—
Preformed CANopen cord sets for Altivar and Lexium 05 drives	One RJ45 connector at each end	10	0.3 m	VW3CANCARR03	—
			1 m	VW3CANCARR1	—
CANopen bus adapter for Lexium 15 servo drive	Hardware interface for a link conforming to the CANopen standard + one connector for a PC terminal	14	—	AM02CA001V000	0.110
Y-connector	CANopen/Modbus	—	—	TCSCTN011M11F	—

3

### IP 67 connection accessories

#### For Advantys™ FTB monobloc I/O splitter boxes

Designation	Composition	No. (1)	Length m	Reference	Weight kg
IP 67 line terminator	Equipped with one M12 connector (for end of bus)	13	—	FTXCNTL12	0.010
24 V --- power supply connection cables	Equipped with two 5-pin 7/8 connectors	16	0.6	FTXDP2206	0.150
			1	FTXDP2210	0.190
			2	FTXDP2220	0.310
			5	FTXDP2250	0.750
	Equipped with one 5-pin 7/8 connector at one end and wires at the other end	17	1.5	FTXDP2115	0.240
			3	FTXDP2130	0.430
			5	FTXDP2150	0.700
T-junction box for power supply	Equipped with two 5-pin 7/8 connectors	—	—	FTXCNCT1	0.100


#### Separate parts

Designation	Composition	Sold in	Reference	Weight kg
Connectors	7/8 type, 5-pin	Male	FTXC78M5	0.050
		Female	FTXC78F5	0.050
	Straight, M12 type, 5 screw terminals	Male	XZCC12MDM50B	0.020
		Female	XZCC12FDM50B	0.020
	Angled, M12 type, 5 screw terminals	Male	XZCC12MCM50B	0.020
		Female	XZCC12FCM50B	0.020
Sealing plugs	For M8 connector (sold in packs of 10)	—	FTXCM08B	0.100
	For M12 connector (sold in packs of 10)	—	FTXCM12B	0.100
	For 7/8 connector	—	FTXC78B	0.020
Y-connector	Connection of two M8 connectors to M12 connector on splitter box	—	FTXCY1208	0.020
	Connection of two M12 connectors to M12 connector on splitter box	—	FTXCY1212	0.030
Diagnostics adapter	Equipped with two M12 connectors	—	FTXDG12	0.020
Marker labels	For plastic splitter boxes	Packs of 10	FTXBLA10	0.010
	For metal splitter boxes	Packs of 10	FTXMLA10	0.010

(1) For numbers, see page 3/41.

(2) For ATV 71H000M3, ATV 71HD11M3X, HD15M3X, ATV 71H075N4... HD18N4 drives, this connector can be replaced by the TSXCANKCDF180T connector.

**Presentation**



3

The Modbus bus is used for master/slave architectures (it is necessary, however, to check that the Modbus services used by the application are implemented on the devices concerned).

The bus comprises one master station and several slave stations. Only the master station can initiate the exchange (direct communication between slave stations is not possible). Two exchange mechanisms are possible:

- Question/answer, where the requests from the master are addressed to a given slave. The master then waits for the response from the slave.
- Broadcasting, where the master broadcasts a message to all the slave stations on the bus. These stations execute the order without transmitting a response.


**Description**

The **BMX P34 1000 / 2010 / 2020** processors in the Modicon M340 automation platform range integrate a serial link that can operate under Modbus master/slave RTU/ASCII protocol or under character mode protocol.


For this serial port, these processors have the following on the front panel :

- 1 A display block comprising among other LEDs:
- SER COM LED (yellow): Activity on the Modbus serial link (lit) or failure on an equipment present on the link (flashing).
- 2 An RJ45 connector for the Modbus serial link or character mode link (RS 232C/RS 485, non-isolated) and its black indicator **3**.

*Note : For complete processors descriptions, see page 1/5*



BMX P34 1000



BMX P34 2010

BMX P34 2000

**Characteristics**

Protocol	Modbus		Character mode	
Structure	Type	Non-isolated serial link (1)		
	Method of access	Master/slave type	–	
	Physical Interface	RS 232, 2 wires	RS 485, 2 wires	RS 232, 4 wires
Transmission	Mode	Asynchronous in baseband		Asynchronous in baseband
	Frame	RTU/ASCII, Half duplex		Full duplex
	Data rate	0.3...19.2 Kbit/s (default 19.2 Kbit/s)		0.3...19.2 Kbit/s (default 19.2 Kbit/s)
	Medium	Shielded twisted pair		Simple or double shielded twisted pair
Configuration	Number of devices	2 (point-to-point)	32 max. per segment	2 (point-to-point)
	Maximum number of link addresses	248	248	
	Maximum length of bus	15 m	10 m non-isolated link 1000 m isolated link	15 m
	Maximum length of tap links	–	15 m non-isolated link 40 m isolated link	15 m non-isolated link 40 m isolated link
Services	Requests	252 data bytes per RTU request 504 data bytes per ASCII request		1 K data bytes per request
	Security, control parameters	One CRC on each frame (RTU) One LRC on each frame (ASCII)		One LRC on each frame (ASCII)
	Monitoring	Diagnostic counters, event counters		–

(1) For an isolated link, you must use the TWD XCA ISO terminal port cable connector.

3

**Modbus® system functions**

Modbus functions available on serial ports  
integrated to Modicon M340 processors

Code	Modbus slave (server)	Modbus master (client)
01	Read n output bits	Read output bits
02	Read n input bits	Read input bits
03	Read n output words	Read words
04	Read n input words	Read input words
15	Write n output bits	Write n output bits
16	Write n output words	Write n output words


**References**



I/O capacity (1)	Memory capacity	Integrated communication ports	Reference (3)	Weight kg
<b>Standard processor with integrated serial link BMX P34 10</b>				
512 discrete I/O 128 E/S analog I/O 20 application-specific channels	2,048 Kb integrated	Modbus serial link	<b>BMXP341000</b>	0.200
<b>Performance processors with integrated serial link BMX P34 20</b>				
1024 discrete I/O 256 E/S analog I/O 36 application-specific channels	4,096 Kb integrated	Modbus serial link CANopen bus	<b>BMXP342010</b>	0.210
		Modbus serial link Ethernet TCP/IP network	<b>BMXP342020</b>	0.205

Serial link cabling system, see pages 3/46 and 3/47.

## Cabling system



## Extension and adaptation elements for RS 485 serial link

Designation	Description	Reference	Length	Unit reference	Weight kg
<b>Modbus splitter box</b>	- 10 x RJ45 connectors - 1 x screw terminal block	1	—	LU9GC3	0.500
<b>T-junction boxes</b>	- 2 x RJ45 connectors - 1 x integrated cable with RJ45 connector Dedicated for Altivar and Lexium drives	2	0.3 m 1 m	VW3A8306TF03 VW3A8306TF10	0.190 0.210
<b>Passive T-junction box</b>	- Tap-off point, extension of trunk cable - Line termination adapter	—	—	TSXSCA50	0.520
<b>Passive 2-channel subscriber socket, 2 x 15-pin female SUB-D connectors and 2 x screw terminals</b>	- 2-channel tap-off point and extension of trunk cable - Address coding - Line termination adapter	3	—	TSXSCA62	0.570
<b>T-junction box</b>	- Insulation of the RS 485 serial line Screw terminals for main cable. 1 x RJ45 connector for derivation - Line termination adaptation (R = 120 Ω, C = 1 nF) - Line pre-polarized (2 x R = 620 Ω) (1) 24 V <sub>DC</sub> power (2) Mounting on $\approx$ 35 mm	4	—	TWDXCAISO	0.100
<b>T-junction box</b>	3 x RJ45 connectors	—	—	TWDXCAT3RJ	0.080
<b>Modbus / Bluetooth® adapter</b>	- 1 x Bluetooth® adapter (10 m range, class 2) with 1 x RJ45 connector, - 1 x 0.1 m long cord set for PowerSuite™ software with 2 x RJ45 connectors, - 1 x 0.1 m long cord set for TwidoSuite™ software with 1 x RJ45 connector and 1 x mini-DIN connector, - 1 x RJ45/SUB-D male 9-pin adapter for ATV speed drives	—	—	VW3 A8114	0.155
<b>RS 232C/RS 485 line adapter without modem</b>	24 V <sub>DC</sub> /20 mA power supply, 19.2 kbit/s signals	5	—	XGSZ24	0.100
<b>Line terminator</b>	For RJ45 connector (R = 120 Ω, C = 1 nF)	12	Sold in lots of 2	VW3A8306RC	0.200

(1) Polarized termination requires connection to Twido® controller master.

(2) 24 V<sub>DC</sub> power supply, external, or through the serial port integrated in Modicon M340 processors.

### Cables and connecting cord sets for RS 485 serial link

Designation	Description	Reference	Length	Unit reference	Weight kg
RS 485 double shielded twisted pair trunk cables	Modbus serial link, supplied without connector	6	100 m	TSXCSA100	5.680
			200 m	TSXCSA200	10.920
			500 m	TSXCSA500	30.000
Modbus RS 485 cables	2 x RJ45 connectors	7	0.3 m	VW3A8306R03	0.030
			1 m	VW3A8306R10	0.050
			3 m	VW3A8306R30	0.150
Twido® RS 485 cables	1 x RJ45 connector and 1 x 15-pin SUB-D connector	—	3 m	VW3A8306	0.150
			0.3 m	TWDXCARJ003	0.040
			1 m	TWDXCARJ010	0.090
Twido® RS 485 cables	1 x mini-DIN connector for Twido® controller and 1 x RJ45 connector	4	3 m	TWDXCARJ030	0.16
			0.3 m	TWDXCARJ003	0.040
			1 m	TWDXCARJ010	0.090
Twido® RS 485 cables	1 x RJ45 connector and 1 end with wires	5	3 m	VW3A8306D30	0.150
			0.3 m	TWDXCARJ003	0.040
			1 m	TWDXCARJ010	0.090
Cord sets for Magelis XBT display and terminal	1 x RJ45 connector and 1 x 25-pin SUB-D connector for: - XBT N200/N400/NU400 - XBT R410/411 - XBT GT2...GT7 (COM1 port) (1)	11	2.5 m	XBTZ938	0.210
			2 x RJ45 connectors for: - XBT GT1 (COM1 port) - XBT GT2...GT7 (COM2 port)	VW3A8306R30	0.150
			3 m	VW3A8306R30	0.150

3

### Connecting cord sets for RS 232 serial link

Designation	Description	Reference	Length	Unit reference	Weight kg
Cord set for Data Terminal Equipment (DTE: printer...)	Serial link for Data Terminal Equipment (DTE) (2) 1 x RJ45 connector and 1 x 9-pin SUB-D female connector	—	3 m	TCSMCN3M4F3C2	0.150
Cord set for Data Communication Equipment (DCE: modem, converter...)	Serial link for point-to-point equipment (DCE) 1 x RJ45 connector and 1 x 9-pin SUB-D male connector	—	3 m	TCSMCN3M4M3S2	0.150

(1) Must be associated with an XBT ZG909 adapter.

(2) If the DTE is equipped with a 25-pin SUB-D connector, additionally order the 25-pin female / 9-pin male SUB-D TSX CTC 07 adapter.



---

**Unity™ software**

■ Unity Pro™ programming software	4/4
□ Presentation, setup	4/4
□ Software structure	4/9
□ 5 IEC languages	4/12
□ Functions	4/18
□ References	4/29
■ Unity EFB Toolkit software	4/32
■ Unity SFC View software	4/34
■ Unity Loader software	4/36
■ Unity Application Generator	4/40


**Unity Pro™ programming software for:**

- Modicon M340 M
- Premium™ PLC P, Atrium™ PLC A
- Quantum™ PLC Q



IEC 61131-3 languages	Instruction List (IL)	M - A - P	M - A - P - Q	M - A - P - Q
	Ladder (LD)	M - A - P	M - A - P - Q	M - A - P - Q
	Structured Text (ST)	M - A - P	M - A - P - Q	M - A - P - Q
	Function Block Diagram (FBD)	M - A - P	M - A - P - Q	M - A - P - Q
	Sequential Function Chart (SFC)/Grafet	M - A - P	M - A - P - Q	M - A - P - Q
Programming services	Multitask programming (Master, fast and event-triggered)	M - A - P	M - A - P - Q	M - A - P - Q
	Multitask programming (Master, fast, auxiliary and event-triggered)			P (TSX P57 50) Q (140 CPU 651/671)
	Functional view and function modules	M - A - P	M - A - P - Q	M - A - P - Q
	DFB editor and DFB instances	M - A - P	M - A - P - Q	M - A - P - Q
	DDT compound data editor	M - A - P	M - A - P - Q	M - A - P - Q
	Data structure instances and tables	M - A - P	M - A - P - Q	M - A - P - Q
	EF function block libraries & EFB function blocks	M - A - P	M - A - P - Q	M - A - P - Q
	User-definable control loops		A (TSX PCI 20) - P (TSX P57 20)	A (TSX PCI 20) - P (TSX P57 20/30/40/50)
	Programmable control loops (FB library)	M - A - P	M - A - P - Q	M - A - P - Q
	Motion Function Blocks	M - A - P	M - A - P	M - A - P
	Hot Standby PLC redundancy system		P (TSX H57 24M)	P (TSX H57 24/44M) P (TSX H57 24/44M) - Q (140 CPU 67 160)
	System diagnostics	M - A - P	M - A - P - Q	M - A - P - Q
	Application diagnostics	M - A - P	M - A - P - Q	M - A - P - Q
	Diagnostics with location of error source	M - A - P	M - A - P - Q	M - A - P - Q
Debugging and display services	PLC simulator	M - A - P	M - A - P - Q	M - A - P - Q
	Hypertext link animations in graphic languages	M - A - P	M - A - P - Q	M - A - P - Q
	Step by step execution, breakpoint	M - A - P	M - A - P - Q	M - A - P - Q
	Watchpoint	M - A - P	M - A - P - Q	M - A - P - Q
	Operator screens	M - A - P	M - A - P - Q	M - A - P - Q
	Diagnostic viewer	M - A - P	M - A - P - Q	M - A - P - Q
Other services	Creation of hyperlinks	M - A - P	M - A - P - Q	M - A - P - Q
	XML import/export	M - A - P	M - A - P - Q	M - A - P - Q
	Application converters (Concept™, and PL7™ software)	M - A - P	M - A - P - Q	M - A - P - Q
	Utilities for updating PLC operating systems	M - A - P	M - A - P - Q	M - A - P - Q
	Communication drivers for Windows® 2000/XP	M - A - P	M - A - P - Q	M - A - P - Q
	Unity Pro™ Servers - openness -			M - A - P - Q
UDE support	Dynamic exchange with 3rd party tools, OFS			M - A - P - Q
OFS exchanges	Static exchange thru XML/XVM export files	M - A - P	M - A - P - Q	
Compatible Modicon platforms	Modicon M340 PLCs M	BMX P34 1000 BMX P34 20●0	BMX P34 1000 BMX P34 20●0	BMX P34 1000 BMX P34 20●0
	Atrium™ slot-PLCs A	–	TSX PCI 204M	TSX PCI 204M TSX PCI 354M
	Premium™ CPUs P	–	TSX P57 C●0244/0244M TSX P57 104/1634/154M TSX P57 204/2634/254M TSX H57 24M	TSX P57 C●0244/0244M TSX P57 104/1634/154M TSX P57 204/2634/254M TSX P57 304/3634/354M TSX P57 4634/454M TSX H57 24/44M
	Quantum™ CPUs Q	–	–	140 CPU 311 10 140 CPU 434 12U
				140 CPU 311 10 140 CPU 434 12U 140 CPU 651 50/60 140 CPU 671 60
Software name	Unity Pro Small	Unity Pro Medium	Unity Pro Large	Unity Pro Extra Large
Unity Pro™ software type	UNY SPU SF● CD30	UNY SPU MF● CD30	UNY SPU LF● CD30	UNY SPU EF● CD30
Pages	4/27			

EF/EFB function development software in C language	Software for firmware and application loading	Software for designing and generating batch/process applications	SFC View application diagnostic and monitoring software	Pack for developing specific solutions
--	---	--	---	--



Enhancement of EF and EFB function block libraries:  
 Creation of families  
 Development of functions in C language  
 Access to all data and variable types  
 Debugging functions (step by step, breakpoint)  
 Use of functions created in all languages

Supplied with:  
 Microsoft® Visual C++  
 GNU source code and compiler

Simple and easy to use software to upgrade a Modicon M340 PLC when the user doesn't need to display/modify the program. Upload/download:  
 CPU and Ethernet module firmware  
 PLC project, including:  
- Program  
- Located and unlocated data  
- User files and user web pages

UAG specialist software for designing and generating batch/process applications in a "Collaborative Automation" environment. It provides the unique project database:  
 process and control (PLCs)  
 Magelis® HMI user interface  
 SCADA supervision (Monitor Pro V7.2)

Based around re-usable objects (PID, valves, etc) and complying with standard ISA S88, UAG generates the PLC code and the elements required for the HMI system. Complies with the GAMP standard (Good Automation Manufacturing Practice)

ActiveX® control component for monitoring and diagnostics of chart status (SFC or Grafset) in sequential applications:  
 Overview of charts and detailed views  
 Can be integrated in human/machine interface (HMI) applications  
 Access to PLC data via OFS (OPC Factory Server)

Includes EFB function block library for Unity Pro™ software (for Premium™, Atrium™ and Quantum™ CPUs)

Specialist software for developing made-to-order solutions (for example interfaces with an electrical CAD system, automatic application generator, etc):  
 Access to Unity Pro™ object servers  
 Reserved for IT development engineers using Visual Basic or C++

4

Compatible with:  
 Unity Pro™ Small, Medium, Large and Extra Large programming software  
 All Modicon M340 PLCs  
 All Atrium™ slot-PLCs  
 All Premium™ Unity™ CPUs  
 All Quantum™ Unity™ CPUs

Compatible with:  
 Unity Pro™ Small, Medium, Large and Extra Large programming software  
 All Modicon M340 PLCs

Compatible with:  
 Unity Pro™ Extra Large programming software  
 TSX P57 4634/454M and TSX P57 5634/554M Premium™ Unity™ CPUs  
 All Quantum™ Unity™ CPUs


Compatible with:  
 Unity Pro™ Extra Large programming software  
 All Modicon M340 PLCs  
 All Atrium™ slot-PLCs  
 All Premium™ Unity™ CPUs  
 All Quantum™ Unity™ CPUs

Compatible with:  
 Unity Pro™ Extra Large programming software  
 All Modicon M340 PLCs  
 All Atrium™ slot-PLCs  
 All Premium™ Unity™ CPUs  
 All Quantum™ Unity™ CPUs

Unity EFB Toolkit	Unity Loader	Unity Application Generator	Unity SFC View	Unity Developer's Edition
UNY SPU ZFU CD30E	UNY SMU ZU CD30	UNY SEW LF0 CD23	UNY SDU MF0 CD20	UNY UDE VFU CD21E
4/32	4/38	4/40	4/34	4/28

### User interface

Unity Pro's main screen provides access to all available tools in a user-friendly format that has been redesigned on the basis of feedback received from users of Concept™ and PL7™ application design software.




This main screen consists of a general view made up of a number of windows and toolbars, which can be arranged as required on the screen:

1. Menu bar from which all functions can be accessed
2. Toolbar consisting of icons from which the most frequently used functions can be accessed
3. Application browser, which can be used to browse the application based on a conventional and/or a functional view
4. Editor windows area, which can be used to view a number of editors at the same time (configuration editor, Structured Text/Ladder etc. language editors, data editor)
5. Tabs for direct access to editor windows
6. Information window with tabs (User Errors, Import/Export, Search/Replace, etc.)
7. Status bar



File/Edit toolbar



FBD language editor contextual toolbar



PLC toolbar for debug mode



Toolbar with zoom (in and out)

### Accessing functions

All functions can be accessed via drop-down menus from the menu bar. The toolbar, which consists of icons, provides more rapid access to the most frequently used functions. This toolbar, which is displayed by default, can be customized, and is divided into three groups:

- Main toolbars, which are visible at all times
- Contextual toolbar, which is displayed when the corresponding editor is selected
- Toolbar with zoom functions (in and out), full-screen view for editor window


The three groups are classified according to the category of functions available:

- File management (New Project, Open, Save, Print)
- Edit (Undo, Redo, Confirm, Go To)
- Application services (Analyze Project, Build Project, Browse, Find, Access Library)
- Automation platform operating mode (Upload/Download Project, Online/Offline, Run/Stop, Animate, PLC/Simulation Mode)
- Debug mode (Set/Remove Breakpoint, etc.)
- Window display (Cascade, Horizontal, Vertical)
- Online help (non-contextual or contextual)

### Project browser

The project browser can be used:

- To display the contents of a Modicon® M340™, Atrium™, Premium™ or Quantum™ PLC project
- To move between the different components of the application (configuration, program, variables, communication, DFB user function blocks, DDT derived function blocks) created by the user



4

The project can be displayed using two types of view:

- The **structural view**, which provides an overall view of the various components of the application. This representation provides a view of the order in which the program sections are processed in the PLC.
- The **functional view**, which provides a view of the project based on specific function modules. This representation provides a breakdown according to consistent functions in relation to the process to be controlled.

These two types of view, which are available at any time, can be displayed separately or at the same time (horizontal or vertical windows) by clicking the icons in the toolbar.

#### Structural view

This conventional view allows you to access all the different components of the application (configuration, programming, function blocks, debugging, etc.) via the application browser.

The browser gives an overall view of the program and offers fast access to all application components.

- 1 Configuration editor
- 2 DFB (user function block) and DDT (Derived Data Type) editors
- 3 Communication networks editor
- 4 Program editor
- 5 Variables editor
- 6 Animation tables editor
- 7 Operator screens editor
- 8 Documentation editor

From any level in the tree structure, you can:

- 9 Create a hyperlink to a comment or description
- 10 Create a directory for storing hyperlinks used to access a set of user folders

From this level, it is also possible to zoom in and only view the detailed levels for a component on this level.

#### Functional view

Unity Pro software applications support the creation of an application structure for Modicon® M340™, Atrium™, Premium™ and Quantum™ platforms based on function modules comprising:

- Sections (program code)
- Animation tables
- Runtime screens


The designer can define a multi-level tree structure for the application, independently of the multitask structure of the PLC.


Program sections written in Ladder (LD), Structured Text (ST), Instruction List (IL), Function Block Diagram (FBD) or Sequential Function Chart (SFC) language can be associated with each level, along with animation tables and runtime screens.

#### Exporting/Importing function modules


All or part of the tree structure can be exported as function modules. In this case, all program sections on the various module levels are exported.

Utilities make it easy to reuse these modules in new applications by means of data and module name reassignment services.






Hardware configuration



I/O modules parameter setting



Communication folder with 2 networks declared

## Configuration editor

### Hardware configuration

The first step when creating an automation project based on a Modicon® M340™, Atrium™, Premium™ or Quantum™ platform is to select the processor for which a rack and power supply are defined by default.

The configuration editor supports the intuitive and graphics-based modification and extension of this configuration with the following elements:

- Racks, power supply
- PCMCIA memory or communication cards (Atrium/Premium) on the processor
- Discrete I/O, analog I/O or application-specific modules
- Etc

### Configuration and parameter settings for I/O and application-specific modules

From the configuration screen for Modicon M340, Atrium, Premium or Quantum racks, the parameters screen displayed for the module concerned can be used to define the operating characteristics and parameters for the selected application, e.g.:


- Filter values for discrete I/O
- Voltage or current range for analog I/O
- Threshold counter values
- Trajectory of axes for position control
- Weigher calibration for weighing
- Transmission speed for communication
- Presymbolization for variables associated with modules
- Etc

### Configuration and parameter settings for communication networks

The “Communication” folder in the structural view can be used to define the list of networks connected to the PLC station. Then, the parameters for all elements required for networks to function correctly can be set by:


- Creating a logical network to which comments can be associated
- Configuring a logical network defining the various associated network services. Once the network module has been created in the configuration, it must then be associated with one of the logical networks.

Ethernet TCP/IP, Modbus Plus™ and Fipway® network modules are all configured in this way.

**Configuration editor (continued)****Configuration check**

The following information can be accessed at any time during configuration:


- The power consumption statistics for the power supply in each of the racks in the PLC configuration, for all the different voltages provided by each of these power supplies
- The number of inputs/outputs configured (with a Modicon M340, Atrium™ or Premium™ platform)



4

**Configuration of devices on CANopen**

In the same way as for in-rack modules, the configuration of devices on CANopen through a Modicon M340 is fully integrated in the configuration editor.

**Workstation and project configuration**

Unity Pro can be used to configure both the working environment (workstation options) and the content of the project itself.

It is also possible to configure the toolbars and to run third-party applications from Unity Pro.

In addition, users can choose the working language from the list of languages selected when the software was installed.

**Workstation options**

The workstation options cover all the characteristics specific to a given workstation. They are applied when Unity Pro is used to develop any project on that station.

The following elements can be configured:

- How the data in the project being developed is edited and presented (for example, whether or not coils are positioned in the last column of the editor, or the position of the cursor after confirmation of the data entered)
- The application conversion strategy from PL7™, and Concept™ software, IEC and LL984 language
- The function library path
- The opening mode for Unity Pro: either programming or run mode



"Build" tab in the workstation options

### Workstation and project configuration (continued)

#### Project options

Unlike the workstation options, the project options cover characteristics that have a direct impact on the programming and operating capabilities offered by the program in the PLC. They are saved in the application, and, consequently, are attached to the project. They can be modified during the course of the project.

Project option configuration covers the following elements:

- Building the project with all or part of the data it contains so that it can be retrieved on a new terminal
- Use of diagnostic functions, and language for messages
- Warnings generated during project analysis: overlapping of addresses, unused variables etc.
- Language extension: If none of the boxes are checked, the program is strictly compliant with standard IEC 61131-3. Extensions are possible in all five of Unity Pro's languages.
- Access management to runtime screens in online mode


4



User-created toolbar containing all the debugging tools

### Other possible options

Users can create their own toolbars by reusing the default icons provided in the toolbars.



Menu for adding and deleting tool access from Unity Pro

It is also possible to enhance Unity Pro's main menu bar by adding direct links to other software tools.

A utility in the Unity Pro program group can be used to change the working language. This is then applied the next time the program is launched. Six languages are available: English, French, German, Italian, Spanish and Chinese.

## Software structure

The Modicon M340, Atrium™, Premium™ and Quantum™ platforms set up by Unity Pro software support two types of application structure:


- **Single-task:** This is the more simple default structure, in which only the master task is executed.
- **Multitask:** This structure, which is more suitable for high-performance real-time events, consists of a master task, a fast task, periodic tasks, and high-priority event-triggered tasks.

The master, fast and periodic tasks are made up of sections and subroutines. The sections and subroutines can be programmed in any of the following languages: Structured Text (ST), Instruction List (IL), Ladder (LD) or Function Block Diagram (FBD). The event-triggered tasks use the same languages. Sequential Function Chart (SFC) or Grafset language is reserved for master task sections.

The table below lists the possible program tasks for Modicon M340, Atrium, Premium and Quantum PLCs respectively.

Platform	Modicon M340		Premium			Atrium		Quantum	
	BMX P34 1000	BMX P34 2040	TSX P 57 2•244M	TSX P 57 2•(3)4M	TSX P 57 554M	TSX PCI 57 204 M	140 CPU 31110	140 CPU 651 00	140 CPU 671 60
Cyclic or periodic master task	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Periodic fast task	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Periodic auxiliary tasks	—	—	—	—	4	—	—	—	4
Event-triggered tasks									
From modules	32	64	32	64	128	64	64	128	
From timers	32	64	—	—	32	—	16	32	
Total	32	64	32	64	128	64	64	128	

4




## Structure, modular and portable programming

The tasks of a Unity Pro program for Modicon M340, Atrium, Premium™ or Quantum™ platforms are composed of several parts known as sections and subroutines. Each of these sections can be programmed in the most appropriate language for the process to be executed.

Such division into sections enables a structured program to be created and program modules to be generated or added with ease.

Subroutines can be called from any section of the task to which they belong or from other subroutines in the same task.

**Compatibility of languages compliant with IEC standard 61131-3:** Unity Pro software can be configured (*Tools/Project Settings/Language Extensions menu*) to ensure that applications generated are compliant with IEC standard 61131-3. Furthermore, as long as you use only the standard instruction libraries, you will be able to reuse programs created in this way on any Modicon M340, Atrium, Premium, or Quantum platform.



4

### Single-task memory structure

Two types of cyclic execution are supported:

- Normal cyclic execution. This is the default option.
- Periodic execution. This type of execution, as well as the period, are selected by the user during programming when the task parameters are set (master task).

#### Normal execution (cyclic)

At the end of each scan, the PLC system launches a new scan. The execution time of each scan is monitored by a software watchdog whose value is defined by the user (max. 1500 ms).

In the event of overrun, a fault occurs causing:

- The scan to stop immediately (STOP)
- A fault state to be displayed on the front panel of the processor
- The alarm relay for the main rack power supply to be set to 0

#### Periodic execution

A new scan is executed at the end of each period. The execution time of the scan must be less than the time of the period defined (max. 255 ms). In the event of overrun, the latter is stored in a system bit (%S19), which can be reset to 0 by the user (via the program or terminal).

A software watchdog, which can be configured by the user (max. 1500 ms), monitors the scan time. In the event of overrun, an execution fault is indicated (see normal execution). The scan execution times (the last scan, the longest scan and the shortest scan) are stored in system words %SW 30/31/32.


### Multitask software structure

Modicon® M340™, Atrium™, Premium™ and Quantum™ platforms support a multitask structure comprising:

- 1 master task (divided into several sections programmed in ST, IL, LD, FBD, and SFC languages)
- 1 fast task (divided into sections)
- 0 to 4 auxiliary tasks (divided into sections) (1)
- 1 or more event-triggered tasks (only one section per task)


These tasks are independent and are executed in parallel, with the PLC processor managing their execution priority. When an event occurs, or at the start of the fast task scan:

- If any lower-priority tasks are currently being executed, they are suspended.
- The event-triggered task or fast task is executed.
- The interrupted task resumes once execution of the priority task has been completed.




This structure optimizes the way in which processing power is employed and can be used to structure the application and simplify design and debugging, as each task can be written and debugged independently of the others.

(1) Tasks reserved for top-of-the-range Premium TSX P57 5•4M and Quantum 140 CPU 651 •0/67160 processors.



Application browser



Program execution

## Multitask memory structure (continued)

## Master task

This task, which can be periodic or cyclic, executes the main program. It is activated systematically.

Each of its component sections and subroutines can be programmed in Ladder (LD), Function Block Diagram (FBD), Structured Text (ST) or Instruction List (IL) language. Several sections of the master task can be programmed in Sequential Function Chart (SFC) or Grafcet language.

## Fast task

This task, which has a higher priority than the master task, is periodic to allow time for tasks with lower priorities to be executed. It should be used when fast periodic changes in discrete inputs need to be monitored and acknowledged.

The execution of the master task (lower priority) is suspended while the fast task is being executed. Processing operations in this task must be as short as possible, to avoid adversely affecting master task processing operations.

Each of the component sections and subroutines of the fast task can be programmed in Instruction List, Structured Text, Ladder or Function Block Diagram language (ST, IL, LD or FBD).

## Auxiliary tasks

These tasks, which are available on top-of-the-range Premium™ TSX P57 5●4M and Quantum™ 140 CPU 651 ●0/67160 processors, are designed for use with slower types of processing operation such as measurement, process control, HMI, application diagnostics, etc.

Periodic type auxiliary tasks have the lowest level of priority and are executed once the higher-priority periodic tasks (master and fast) have completed their scan.

Each of the component sections and subroutines of the fast task can be programmed in Instruction List, Structured Text, Ladder or Function Block Diagram language (ST, IL, LD or FBD).

4

## Event-triggered tasks

Unlike the tasks described above, these tasks are not linked to one period. The execution of these tasks is triggered asynchronously by:

An event from certain application-specific modules (e.g.: overrun of a counter threshold, change of state of a discrete input)

An event from the event timers

These tasks are processed before all other tasks and are thus suitable for processing requiring very short reaction times in comparison to the arrival of the event.

Modicon® M340™, Atrium™, Premium™ or Quantum™ platforms have 3 levels of priority (these are, in descending order, module event EVT0, module events EVT<sub>i</sub> and timer events Timer<sub>i</sub>).

These tasks, each comprised of a single section, can be programmed in Instruction List, Structured Text, Ladder or Function Block Diagram language (ST, IL, LD or FBD).

## Assignment of I/O channels to tasks

Each of the master, fast or event-triggered tasks reads (at the start of the scan) and writes (at the end of the scan) the inputs assigned to it. By default, they are assigned to the master task.

For the Quantum™ platform, the remote inputs/outputs (RIO) are only assigned to the master task (these assignments can be made per station or for each of the component sections of the task), while the distributed inputs/outputs (DIO) are all assigned to the master task (without assignment to its component sections).

For event-triggered tasks, it is possible to assign input/output channels (1) other than those relating to the event. Exchanges are then performed implicitly at the start of processing for inputs and at the end of processing for outputs.

(1) These channel assignments are made per I/O module for Quantum PLC and per channel for Atrium/Premium PLC inputs/outputs.

### The five IEC languages

The five graphical or textual languages available in Unity Pro are used for programming Modicon® M340™, Atrium™, Premium™ and Quantum™ automation platforms.

The 3 graphical languages are:

- Ladder (LD)
- Function Block Diagram (FBD)
- Sequential Function Chart (SFC) or Grafcet

The 2 textual languages are:

- Structured Text (ST)
- Instruction List (IL)

For these 5 languages, you can use the standard set of instructions compliant with IEC standard 61131-3 to create applications, which can be transferred from one platform to another. Unity Pro software also provides extensions to this standard set of instructions. When they are specific to Modicon M340, Atrium/Premium and Quantum™ PLCs, these extensions support the development of more complex applications in order to maximize the potential of the specific features of each of these platforms.

## 4


### Functionality common to all five language editors

The editors for each of the 5 languages provide a number of common tools used for writing, reading and analyzing programs in a user-friendly manner:

- The text editors for Instruction List (IL) and Structured Text (ST) support:
  - Text entry in insert or overwrite mode
  - The use of dialog boxes for the assisted entry of variables, functions, function blocks or assignment instructions
  - Checks on data entry to detect syntax or semantics errors. The user is informed of the result of this check by red wavy underlining or by a change in the color of the text concerned.
  - Access to a set of colors, which can be used to facilitate reading by distinguishing text (black) from operators (red), language key words (blue), and program comments (green)
- The graphics editors for Ladder (LD) language, Function Block Diagram (FBD) language and Sequential Function Chart (SFC) language feature:
  - A set of graphic elements for direct access to the various graphic symbols in the language via the mouse or keyboard
  - A pop-up menu, which can be accessed by right-clicking with the mouse
- Unlimited number and length of comments. These comments can be positioned as text objects in any cell (graphical languages) or at any point in expressions (textual languages).
- Assisted data entry functions for:
  - Accessing DFB function libraries, the variables editor or the text object for entering comments
  - Initializing a variable reference
  - Initializing the animation table on selected variables
  - Displaying and modifying the properties of the selected variable
  - Creating variables in real time without having to use the data editor
- Cut, Copy, Paste, Delete, Move ...
- Setting bookmarks on lines of text or in the margin so that you can:
  - Easily locate lines in important program sections
  - Browse in an editor by bookmark, label, or the line and column number

## Ladder (LD) language

Each section or subroutine using Ladder language consists of a series of rungs, which are executed sequentially by the PLC. Each rung consists of graphic objects (placed in cells arranged in columns and lines) corresponding to contacts, links, coils, operation blocks, EF/EFB/DFB function blocks, jumps, SR calls, etc.



4

## Program structure (section or subroutine)

Each Ladder language section may contain:

- Between 11 and 64 columns (number set by the user)
- Up to 2000 lines (for all rungs in the section)




Graphics palette in the Ladder language editor


Mixed Display mode supports the unrestricted display of comments, addresses and symbols for the variables used for rungs.

## Function Block Diagram (FBD) language

Function Block Diagram language is a graphical language based on function blocks associated with variables or parameters, which are linked together. This language is particularly suitable for process control applications.



4



Function Block Assistant


## Program structure (section or subroutine)

The graphical language FBD supports three types of function blocks:


- Elementary blocks (EFs)
- Elementary Function Blocks (EFBs), sorted into different libraries depending on their type of use
- Derived Function Blocks (DFBs), which have a structure identical to that of EFBs but are created by the user with the ST, IL, LD or FBD programming languages

Within the same section, subroutines can be called using a specific block. Program jumps to a block instance can also be programmed.


A section programmed in FBD language contains the equivalent of a default grid with 30 columns and 23 rows. This can be extended to a wider page.



SFC structure in the browser



SFC chart



Step properties

## Sequential Function Chart (SFC) and Grafcet language

Sequential Function Chart (and Grafcet) language can be used to describe the sequential part of an automation system in simple graphical format using steps and transitions.

SFC language does not process charts in the same way as Grafcet language:

- SFC only authorizes one token in one chart.
- Grafcet language authorizes several tokens in one chart.

Unity Pro software has one editor for these two languages with the option of defining behavior in the application settings (*Tools/Project Settings/Language Extensions menu*).

4

### Program structure (master task section)

SFC language is only used in sections belonging to the master task. Each SFC section consists of a main chart sub-section CHART and sub-sections for each of the macro-steps. The component parts of the charts are:

- Macro-steps, which are the sole representation of a set of steps and transitions (used to set up a hierarchical chart structure)
- Steps
- Transitions and directed links between steps and transitions

Associated with steps and transitions respectively, the actions and transition conditions can be:

- Integrated into the CHART or macro-step charts, in which case the actions or transition conditions are defined by a single variable
- Processed in specific sections, in which case dedicated processing (to be programmed in Ladder, Function Block Diagram, Structured Text or Instruction List language) is necessary

In order to check that machine scans have been completed successfully, activity times (minimum, maximum) can be associated with each step. These times are set by the user.

### Program structure (section in master task)

For each SFC section, the graphics editor provides a maximum of:


- One grid containing 32 columns and 200 rows, or 6400 cells. Steps, transitions or jumps all need one cell respectively.
- 1024 steps (macro-steps and steps in macro-steps)
- 20 actions assigned to the same step
- 100 steps activated at the same time
- 100 actions activated at the same time

To help you to create basic charts, graphic screens can be used to create "n" steps in series and "m" steps in parallel in a single operation.

Dialog boxes can be used to assign associated properties to steps (activity time, actions), transitions (variable linked to transition condition), etc.

## Structured Text (ST) language

Structured Text language is a sophisticated algorithmic type language, which is particularly suitable for programming complex arithmetic functions, table operations, message handling, etc.



```

S| pump_1 : [MAST]
(* pump_1 management *)
if pump_1.start
    then pump_1.cmd:=true;
    end_if;
if not start and waiting.x
    then pump_1.cmd:=false;
    end_if;
if pump_1.cmd and pump_1.speed<100
    then pump_1.speed:=pump_1.speed+2;
    end_if;
if not pump_1.cmd and pump_1.speed>0
    then pump_1.speed:=pump_1.speed-4;
    end_if;

END_IF;

(* animation drilling & threading *)
high_anim:=not jack_1_out and not jack_3_out;
midle_anim:=jack_1_out and not jack_3_out;
low_anim:=jack_1_out and jack_3_out;
hole_anim1:=end_threading.x or unblocking.x;
hole_anim2:=end_drilling.x or unblocking.x;

(* if no selection hot/cool *)


```

4

## Program structure (section or subroutine)

Structured Text language, which can be used to directly transcribe an analysis based on an organization chart, is structured into expressions composed of a series of instructions organized in lines.

There is no limit to the number of characters an instruction line may contain. The only limit is the program memory available for the Modicon M340, Premium™ and Quantum™ platforms, except on TSX P57 10...40 processors, where the limit is 64 Kb.



Four preformatted expression structures can be called up directly from the toolbar:


- **Conditional action:** IF...THEN...ELSIF...THEN...ELSE...END-IF;
- **Iterative conditional action:** WHILE...DO...END WHILE;  
REPEAT...UNTIL...END\_REPEAT;
- **Repetitive action:** FOR...TO...BY...DO...END\_FOR;
- **Selective action:** CASE...OF...ELSE...END\_CASE;

The operands used in the expressions are bit variables, word variables or variables linked to function blocks.

To make the expressions easier to read, different colors are used to identify objects, language key words and program comments.

## Instruction List (IL) language

Instruction List language is a language representing the equivalent of a Ladder diagram in text form. It can be used to write Boolean and arithmetic equations using all the functions available in the Unity Pro language (calling of functions and function blocks, assignment of variables, creation of program jumps, branching to subroutines within a program section, etc.).



```

(* Simple example *)
LD t#5s
ST delay

(* fault motor *)
LD overspeed
AND hot_temp
ST fault_motor

(* Start the motor after delay (in seconds) *)
CAL MOTOR_TIMER (PT := Delay, IN := start_motor)
LD motor_timer.q
ST motor_run

(* Stop the motor after ten seconds in running *)
CAL stop_timer(motor_run,t#10s)
LDN stop_timer.q
ST start_motor

```


4

## Program structure (section or subroutine)

A program in Instruction List language comprises a sequence of instructions classified into the following different families:

- Bit instructions, e.g. read input: *LD overspeed*
- Function block instructions, e.g. call timer: *CAL MOTOR\_TIMER*
- Numerical instructions using single, double and floating point integers, e.g.: *LD Result ADD Surplus ST Archive*
- Word table or character string instructions, e.g. make assignment: *LD Result:10:= Setpoint:10*
- Program instructions, e.g. SR call: *CALL SR10*

The operands used in the expressions are bit variables, word variables or variables linked to function blocks.



Data editor

### Data editor

The data editor, which can be accessed from the structural view of the project, provides a single tool for performing the following editing tasks:

- Declaration of data including variables and function blocks (declaration of their type, instants and attributes)
- Use and archiving of function block data types in different libraries
- Hierarchical view of data structures
- Searching, sorting and filtering of data
- Creation of a hyperlink to access a description from any variable comment

The data is displayed under four tabs:


- "Variables" tab for the creation and management of the following data instances: bits, words, double words, inputs/outputs, tables, and structures
- "DDT Types" tab for the creation of derived data types (tables and structures)
- "Function Blocks" tabs for the declaration of EFB and DFB function blocks
- "DFB Types" for the creation of DFB user function block data types

Each data instance has several attributes, of which:

- The name and type of the variable are mandatory
- The comment, physical address in the memory or initial values are optional

The data editor columns can be configured (number of columns, order). All the attributes associated with a variable can be displayed in a properties window.

This editor can be accessed at any time during programming by selecting variables for data modification or creation.



Variable attributes

## DFB user function blocks

Users can create their own function blocks for specific application requirements on Modicon® M340™, Atrium™, Premium™ and Quantum™ platforms using Unity Pro software.

Once created and saved in the library, these user function blocks can be reused as easily as EFBs (Elementary Function Blocks).

DFB user function blocks can structure an application, such as when a program sequence is repeated several times in the application or for correcting a standard programming routine. They can be read-only protected or read/write-protected. They can be exported to all other Unity Pro applications.


Using a DFB function block in one or more applications:

- Simplifies program design and entry
- Improves program readability and comprehension
- Facilitates program debugging (all variables handled by the DFB block function are identified in the data editor)
- Enables the use of private variables specific to the DFBs, which are independent of the application

A DFB is set up in several phases:

- The DFB is designed by assigning a name, a set of parameters (inputs, outputs, and public and private internal variables), and a comment via the data editor.
- The code is created in one or more sections of the program, with the following languages selected according to requirements: Structured Text, Instruction List, Ladder or Function Block Diagram (ST, IL, LD or FBD).
- The DFB may be stored in a library with an associated version number.
- A DFB instance is created in the data editor or when the function is called in the program editor.
- This instance is used in the program in the same way as an EFB (Elementary Function Block). (The instance can be created from within the program.)

4




## Main characteristics

Inputs	32 max. (1)
Outputs	32 max. (2)
Inputs/outputs	32 max. (1) (2)
Public internal variables	Unlimited (3), can be accessed via the application program
Private internal variables	Unlimited (3), cannot be accessed via the application program
Comment	1024 characters max.
Program sections	Unlimited, each section can be programmed independently in one of the 4 languages (IL, ST, LD, and FBD).

(1) The maximum cumulative total of inputs and inputs/outputs is 32.

(2) The maximum cumulative total of outputs and inputs/outputs is 32.

(3) For Premium processors, see page 1/9: characteristics of memories, maximal sizes of objects zones, internal unlocated data, DFB & EFB function blocks.



4

Type library manager

### Function block libraries


The function and function block libraries manager contains all the elements provided with Unity Pro software. The functions and function blocks are organized into libraries, which themselves consist of families. Depending on the type of PLC selected and the model of processor, the users will have a sub-set of these libraries available to write their applications. However, the "Base Lib" library contains a set of functions and function blocks, the majority of which are compatible with all platforms. In particular, it contains the blocks compliant with IEC 61131-3.

The "Base Lib" library is structured into families:

- Timers and counters
- Internal process control
- Array management
- Comparison
- Date and time management
- Logic processing
- Mathematical processing
- Statistical processing
- Character string processing
- Type-to-type data conversion

The "Base Lib" library, which covers standard automation functions, is supplemented by other, more application-specific libraries, and some platform-specific functions:

- **Communication library**, providing an easy means of integrating communication programs from PLCs with those used by HMIs from the PLC application program. Like other function blocks, these EFBs can be used in all languages to exchange data between PLCs or to deliver data to be displayed on an HMI.
- **Process control library**. The CONT\_CTL library can be used to set up process-specific control loops. In particular, it offers controller, derivative and integral control functions. CONT\_CTL comes with other families, providing additional algorithms, e.g.: EFBs for calculating mean values, selecting a maximum value, detecting edges or assigning a hysteresis to process variables.
- **Diagnostics library**, which can be used to monitor actuators. Also, it contains EFBs for active diagnostics, reactive diagnostics, interlocking diagnostics, permanent process condition diagnostics, dynamic diagnostics, monitoring of signal groups, etc.
- **I/O management library**, providing services to handle information exchanged with hardware modules (formatting data, scaling...)
- **Motion Function Blocks library** containing a set of predefined functions and data structures to manage motion on drives and servo drives connected on CANopen.
- **Motion library** for motion control and fast counting
- **"System" library**, which provides EFBs for the execution of system functions (such as evaluation of scan time, availability of several different system clocks, SFC section monitoring, and display of system state) as well as management of files inside the Modicon M340 memory cartridge.
- **Obsolete library** containing all function blocks used by legacy programming software that are needed to perform application conversions



User-defined library manager

### Management of user standards

Users may create libraries and families for storing their own DFB function blocks and DDT data structures. This enhancement allows users to take advantage of programming standards adapted to their needs, along with version management. This means that it is possible to:

- Check the version of the elements used in an application program against those stored in the library
- Perform an upgrade, if necessary

## Debugging tools

Unity Pro software offers a complete set of tools for debugging Modicon® M340™, Atrium™, Premium™ or Quantum™ applications. A tool palette provides direct access to the main functions:

- Dynamic program animation
- Setting of watchdogs or breakpoints (not authorized in event-triggered tasks)
- Step-by-step program execution. A function in this mode enables section-by-section execution. Instruction-by-instruction execution can be launched from the previous breakpoint. Three execution commands are therefore possible when the element to be processed is a subroutine (SR) or DFB user block:
  - Detailed step-by-step or "Step Into". This command is used to move to the first element of the SR or DFB.
  - Overall step-by-step or "Step Over". This command is used to process the entire SR or DFB.
  - Outgoing step-by-step or "Step Out". This command is used to move to the next instruction after the SR or DFB element.
- Independent execution of the master (MAST), fast (FAST), auxiliary (AUX), and event-triggered (EVTi) tasks.



Insertion/removal of breakpoint



Execution: step-by-step command

```
s_t Securite:[MAST]
IF Niveau_1 >= 600 THEN Pompe_1 := False;
END_IF;
IF Niveau_2 >= 200 Then Pompe_2 := False;
END_IF;
IF Niveau_3 >= 400 Then Vanne_1 := False;
Vanne_2 := False;
END_IF;
IF Boite = 10 Then Vanne_3 := False;
End_IF;
IF Niveau_3 < 80 Then Chauf_on := False;
      := False;
```

Animation of ST program

## Animation of program elements

Dynamic animation is managed section by section. A button in the toolbar is used to activate or deactivate animation for each section.

When the PLC is in RUN, this mode can be used to view, simultaneously:

- The animation of a program section, regardless of the language used
- The variables window containing the application objects created automatically from the section viewed

Several windows can be displayed and animated simultaneously. The "Tool tip" function, which uses help balloons, can be used to view a variable and its content simultaneously when the object is selected with the mouse (or other pointing device). The user can add inspect windows to display variables inside the program.

4

Two types of animation are supported:

- Standard: The variables of the active section are refreshed at the end of the master task (MAST).
- Synchronized: The breakpoint can be used to synchronize the display of animated variables with a program element, to determine their value at this precise point in the program.

Name	Force	Value	Type	Comment
Initial			Bool	
Niveau_1		470	Int	
Niveau_2		0	Int	
Niveau_3		333	Int	
Baln		0	Int	
Quantite_a_pr...		0	Int	
Quantite_prod...		0	Int	
Pompe_1		1	Bool	
Melange_2		0	Bool	

Animation table


## Animation table

Tables containing the variables of the application to be monitored or modified can be created by data entry or initialized automatically from the selected program section.

In addition to data animation it is possible to:

- Modify bit variables or force them to 0 or 1
- Change the display format
- Copy or move variables
- Search by cross-reference
- Display the list of forced bits

These tables can be stored in the application.




Animation of a DFB program


## Debugging of DFB user function blocks

The parameters and public variables of these blocks are displayed and animated in real time using animation tables, with the possibility of modifying and forcing the required objects.


In the same way as with other program elements, the watchpoint, breakpoint, step-by-step execution, and program code diagnostics functions can be used to analyze the behavior of DFBs. Setting a breakpoint in a DFB user function block instance stops the execution of the task containing this block.



SFC control panel



Simulator control panel



Access to documentation editor

### Debugging in Sequential Function Chart (SFC) language

The various debugging tools are also available in SFC language. However, unlike other sections (IL, ST, LD or FBD) an SFC section executed step by step does not stop execution of the task but instead freezes the SFC chart. Several breakpoints can be declared simultaneously within a single SFC section.

Numerous commands are available in this debugging mode via the control panel:

- Deactivate active step(s)
- Activate initial step(s)
- Disable step execution times
- Freeze chart regardless of transition conditions
- Stop processing steps
- Move to the next step taking account of the transition conditions
- Enable transition and move to next step(s) (detailed step-by-step command, "Step Into")
- Enable transition in order to execute the end of the macro-step (outgoing step-by-step command, "Step Out")
- Chart the steps for which markers have been set.

### PLC simulator

The simulator integrated in Unity Pro can be used to test the application program for Modicon® M340™, Atrium™, Premium™ or Quantum™ PLCs from the PC terminal without having to connect to the PLC processor. The functions provided by the debugging tools are available for debugging the master, fast and auxiliary tasks. As the simulator does not manage the PLC I/O, animation tables can be used to simulate the state of inputs by forcing them to 0 or 1.

The simulator can be connected to third-party applications via an OPC server with OFS (OPC Factory Server) software.

### Documentation editor

The documentation editor is built around the Documentation Browser, which shows the file structure in tree form.

It allows all or part of the application file to be printed in A4 or U.S. letter format on any graphics printer accessible under Windows® that uses True Type technology.

The documentation editor supports the creation of user-specific documentation files using the following headings:

- Title page
- Contents
- General information
- Title block
- Configuration
- EFB, EFB and DFB type function blocks
- User variables
- Communication
- Project structure
- Program
- Animation tables and cross-references
- Runtime screens


The documentation editor can generate the documentation file based on two different structures:

- Structural view: All the objects in the project are associated with their corresponding headings.
- Functional view: The objects in the project are associated with the function modules to which they belong.

The documentation file can be created and saved as the project progresses, from one Unity Pro session to another.

#### Presentation

Diagnostics integrated into Modicon® M340™, Atrium™, Premium™ and Quantum™ automation platforms



4

The diagnostics offer for Modicon M340, Atrium, Premium, and Quantum platforms is based on three components:


- System diagnostics
- DFB and EFB diagnostic function blocks (for system and application diagnostics)
- Error message display system or viewers supplied as standard with Magelis® XBT GT and *i*PC® terminals, Vijeo™ Designer/Monitor Pro™ supervisory software and Unity Pro setup software.

#### Functions



##### System diagnostics

The system diagnostics for the Modicon M340, Atrium, Premium, and Quantum platforms supports the monitoring of system bits/words, and I/O modules, and the activity times (minimum/maximum) of SFC steps. After the user chooses the relevant option in the application configuration, any event will result in time-stamped messages logged inside the diagnostic buffer in the PLC. These events are displayed on a diagnostics viewer (1) automatically without the need of any additional programming.

With the assistance of Unity Pro's integrated diagnostics, this function can be used to perform 1<sup>st</sup> level diagnostics of the elements in the configuration, up to and including each I/O module channel.



(1) Diagnostics viewers are tools used to display and acknowledge error messages relating to diagnostics. They are supplied as standard with Unity Pro, Vijeo Designer and Monitor Pro software, with Magelis terminals, and with the PLC web server which is accessible through a thin client Magelis *i*PC terminal.



Fault cause analysis

### Application diagnostics

Unity Pro software also has a library of function blocks for monitoring, called diagnostic DFBs and EFBs. The library of diagnostic function blocks contains:

#### ■ Manufacturer blocks for system diagnostics

- IO\_DIA input/output fault, which is used to monitor the state of inputs/outputs.
- ASI\_DIA, which monitors whether an error has occurred on the AS-Interface bus (module or bus fault, no slave, slave not configured or faulty).

#### ■ Manufacturer blocks for application diagnostics, for example:

- EV\_DIA, which monitors whether an event (bit status) has the correct value at a given time (no notion of timing).
- MV\_DIA, D\_GRP, D\_REA, which monitor whether an event (the change in the status of a bit) occurs within the specified time conditions.
- ALRM\_DIA, which monitors the combination of the status of 2 bits.
- NEPO\_DIA and TEPO\_DIA, which can be used to check, control and perform diagnostics for elements in the working part of the system made up of the combination of 2 actuators and 2 sensors.

#### ■ Open diagnostics blocks

These enable users to create their own diagnostic function blocks to meet the specific requirements of their applications and therefore to supplement the manufacturer DFBs and EFBs described above. They can be created from 2 model blocks, which must be written in Ladder (LD), Structured Text (ST), Function Block Diagram (FBD) or Instruction List (IL) language.

### Diagnostics with fault cause analysis

When a fault occurs, Unity Pro analyzes the program sections concerned and opens a second window displaying the causes and probable sources of the fault.

The user or process operator is guided through the fault-finding process, enabling machine downtimes to be reduced.

The configuration module or instruction which is the source of the fault can also be accessed via the diagnostics viewer integrated into Unity Pro, directly from the alarm in the viewer output window (see page 4/22).




## Modifying the program with the PLC in RUN

Unity Pro enables changes to be made to the program when the PLC connected to the programming terminal is in RUN. These modifications are made by performing the following operations:

- When necessary, transferring the application from the PLC to the PC terminal running Unity Pro.
- Preparing the program changes. These program modifications can be of any type and in any language (IL, ST, LD, FBD, and SFC), for example adding/deleting SFC steps or actions. Furthermore, modifications can be made to the code of a DFB user function block (although its interface cannot be modified).
- Updating the program in the PLC (in RUN) to reflect these program changes.

This function allows program code and data in different parts of the application to be added or modified in a single modification session (thus making modification unified and consistent with regard to the controlled process). This increased flexibility comes at a cost in terms of the program memory volume required.




## Cross-References functions

The Unity Pro Cross-References function, which is available in standalone mode (offline) and when connected to the PLC (online), allows users to view all the elements of a PLC application by searching for variables of any type. This view indicates where the declared variable is used as well as the mode in which it is used (write, read, etc.).

This function also provides access to the Search/Replace function for variable names.

The variables search can be initialized from any editor (language, data, runtime screen, animation table, etc.).



## Import/export function

The import/export function available in Unity Pro supports the following operations from the structural and functional project views:

- Via the import function, to reuse all or part of a project created previously in the current project
- Via the export function, to copy all or part of the current project to a file for subsequent reuse

The files generated on export are generally in XML format (1). However, variables can also be exported or imported in the following formats:

- .xvm format compatible with OFS data server software
- Source format, in a .scy file compatible with PL7™ design software
- Text format with separator (TAB), in a .txt file for compatibility with any other system

On import, data can be assigned to new instances of the following elements via an assistant:

- DFB function blocks
- DDT data structures
- Simple data

Furthermore, when importing a function module, the data associated with animation tables and operator screens is also reassigned.

The XML import function also supports the transfer of a Modicon® M340™, Atrium™, Premium™ or Quantum™ PLC configuration prepared in the SIS Pro costing and configuration tool for use in the creation of a project in Unity Pro.

This import function means that the user does not have to repeat the PLC configuration process when this has already been completed in the SIS Pro tool.

(1) XML language: Open text-based language providing structural and semantic information.

**Application converters**

Unity Pro's integrated conversion tools can be used to convert PLC applications created with Concept™ and PL7™ programming and setup software in Unity Pro applications.

**Concept™/Unity Pro™ software converter (Quantum™ PLC)**

The conversion can be performed from a Concept V2.5 application (possible in V2.11 or later but only once it has been updated to version V2.5). In order to perform the conversion, the application must be exported to an ASCII file in Concept. The export file is converted into Unity Pro source files automatically. This source file is then analyzed by Unity Pro. At the end of the procedure, a conversion report is generated and an output window displays any conversion errors from which the part of the program to be modified can be accessed directly. The Concept application converter converts the application into Unity Pro but does not guarantee that it will operate correctly in real time. It is therefore essential to test or debug any converted application.

**PL7™/Unity Pro™ software converter (Premium™ and Atrium™ slot PLC)**

The conversion can be performed from a PL7 application V4 or later (Premium PLC or Atrium slot PLC). In order to perform the conversion, the source file (complete application) or source file (user function block) must be exported in PL7. The conversion procedure is similar to that of the Concept conversion described above.

**Note :** Conversion of PLC applications created with Concept, Modsoft®, and ProWORX™ software, in LL984 is possible. Please consult your local sales office.

4

**Operating system update utilities**

OS-Loader software is designed for updating operating systems on Atrium, Premium and Quantum platforms and is supplied with Unity Pro software. It can be used to upgrade the processor and modules from PL7 or Concept software for compatibility with Unity Pro:

- Premium™ TSX P57 2●3M/2623M and TSX P57 3●3M/3623M processors
- Quantum™ 140 CPU 434 12A and 140 CPU 534 14A processors (requires PV 04 or later)
- Ethernet TSX ETY ●102 and 140 NOE 771 ●1 communication modules

These operating system updates are performed as follows for the various types of processor:

- Uni-Telway RS 485 terminal link for Premium™ processors
- Modbus® or Modbus Plus™ terminal link for Quantum processors
- Ethernet TCP/IP network for integrated Ethernet port on Premium processors and Ethernet Premium and Quantum processors (1)

**Note:** For Modicon M340 this service is supplied by Unity Loader (see page 4/38)

(1) Updating the OS on a Quantum 140 CPU 671 60 processor is performed through an Ethernet network on its MT-RJ type optical fiber connector (and through a transceiver or a ConneXium switch for electrical/optical interfacing)

### Communication drivers

The drivers used most frequently on the Atrium™, Premium™ and Quantum™ platforms are installed at the same time as the Unity Pro software.

Unity Pro also includes the following communication drivers, which can be installed as required (1):

Driver type	Windows® XP Windows® 2000	Windows® NT	Windows® 98 Millennium	Windows® 95
Uni-Telway COM port	V1.9 IE20	V1.9 IE17	V1.7 IE18	V7.8 IE18
Uni-Telway TSX SCP 114	V1.2 IE05			
Modbus® COM port	V1.6 IE29			
Fip ISA TSX FPC10 card	V1.4 IE06	V1.3 IE08	V1.4 IE06	V2.4 IE08
Fip TSX FPC20 PCMCIA card	V1.2 IE03	V1.1 IE08	V1.2 IE04	
Ethway	V1.4 IE05	V1.1 IE03	V2.6 IE06 (2)	
ISAway PCX 57, ISA card	V1.2 IE04	V1.5 IE06	V1.2 IE04	V1.2 IE09
PCIway Atrium, PCI card	V1.1 IE09	–		
XIP X-Way on TCP/IP	V1.10 IE22			
USB for USB terminal port	V1.2 IE17	–		

## 4

### Unity Developer's Edition, advanced openness

Advanced openness, which is reserved for experienced IT engineers, supports the development of interfaces between Unity and expert tools as well as specific user-defined functions.

This type of development requires expert IT knowledge in the following areas:

- C++ or Visual Basic languages
- Client/server architectures
- XML and COM/DCOM technologies
- Issues relating to data synchronization

As a supplement to the Unity Pro Extra Large software (3), the UDE (Unity Developer's Edition) development tool **UNY UDE VFU CD21E** can be used to set up made-to-order solutions. In addition to a development kit, it includes the Unity servers and documentation.


Unity Developer's Edition is compatible with:

- Unity Pro™ PLC configuration Extra Large.
- All Modicon® M340™ processors.
- All Atrium™ slot-PLCs.
- All Premium™ Unity™ processors.
- All Quantum™ Unity™ processors.

(1) Also available as separate part **TLX CD DRV 20M**

(2) Windows® 98 only

(3) Only Unity Pro Extra Large implements dynamic databases management for **OFS** data servers and 3<sup>rd</sup> party software.



## References

### Unity Pro™ Small, Medium, Large and Extra Large software packages

The software is available in 4 versions:

- **Unity Pro Small** for programming and setting up Unity automation platforms:
  - Modicon® M340™ PLC — BMX P34 1000 and BMX P34 20●0

- **Unity Pro Medium** for programming and setting up Unity automation platforms:
  - Modicon M340 PLC — BMX P34 1000 and BMX P34 20●0
  - Atrium™ PLC — TSX PCI 57 20
  - Premium™ PLC — TSX 57 0●, 57 10 and 57 20 ®TM

- **Unity Pro Large** for programming and setting up automation platforms:
  - Modicon M340 PLC — BMX P34 1000 and BMX P34 20●0
  - Atrium PLC — TSX PCI 57 20 and 57 30
  - Premium PLC — TSX 57 0●, 57 10, 57 20, 57 30 and 57 40
  - Quantum™ PLC — with 140 CPU 311 10, 434 12U and 534 14U processors

- **Unity Pro Extra Large** for programming and setting up all Unity automation platforms:
  - Modicon M340 PLC — BMX P34 1000, and BMX P34 20●0
  - Atrium PLC — TSX PCI 57 20 and 57 30
  - Premium PLC — TSX 57 0●, 57 10, 57 20, 57 30, 57 40 and 57 50
  - Quantum PLC — with 140 CPU 311 10, 434 12U, 534 14U, 651 50, 651 60 and Hot Standby 140 CPU 671 60 processors

4

### Upgrade kits for Concept™, PL7 Pro™ and ProWORX™ software

Users who have already purchased these installed base software programs **and have a current subscription** may purchase Unity Pro version V3.0 software at reduced prices. These upgrades are only possible for licenses of the same type (from Concept XL group license to Unity Pro Extra Large group license).

### OS Windows® composition and compatibility

Unity Pro multilingual software is compatible with Windows® 2000 Professional and Windows® XP operating systems.

It comprises:

- Documentation in electronic format in 6 languages (English, Spanish, French, German, Italian and Chinese)
- Converters for converting applications created with Concept and PL7 Pro programming software
- PLC simulator

Cables for connecting the processor to the programming PC must be ordered separately.



## References (continued)

## Unity Pro Small version 3.0 software packages

For PLCs	Description	Type of license	Reference	Weight kg
BMX P34 1000	Unity Pro Small software packages	Single-station	UNYSPUSFUCD30	–
BMX P34 20•0		Group (3 stations)	UNYSPUSFGCD30	–
		Team (10 stations)	UNYSPUSFTCD30	–
	Software upgrades from: - Concept S - PL7 Micro - ProWORX™ software NxT/32 Lite	Single-station	UNYSPUSZUCD30	–
		Group (3 stations)	UNYSPUSZGCD30	–
		Team (10 stations)	UNYSPUSZTCD30	–

## Unity Pro Medium version 3.0 software packages

For PLCs	Description	Type of license	Reference	Weight kg
BMX P34 1000	Unity Pro Medium software packages	Single-station	UNYSPUMFUCD30	–
BMX P34 20•0		Group (3 stations)	UNYSPUMFGCD30	–
TSX 57 0•...57 20		Team (10 stations)	UNYSPUMFTCD30	–
TSX PCI 57 20		Single-station	UNYSPUMZUCD30	–
	Software upgrades from: - Concept S, M - PL7 Micro, Junior - ProWORX™ software NxT/32 Lite	Group (3 stations)	UNYSPUMZGCD30	–
		Team (10 stations)	UNYSPUMZTCD30	–

## Unity Pro Large version 3.0 software packages

For PLCs	Description	Type of license	Reference	Weight kg
BMX P34 1000	Unity Pro Large software packages	Single-station	UNYSPULFUCD30	–
BMX P34 20•0		Group (3 stations)	UNYSPULFGCD30	–
TSX 57 0•...57 40		Team (10 stations)	UNYSPULFTCD30	–
TSX PCI 57 20/30		Site (> 10 stations)	UNYSPULFFCD30	–
140 CPU 311 10		Single-station	UNYSPULZUCD30	–
140 CPU 434 12U	Software upgrades from: - Concept S, M - PL7 Micro, Junior, Pro - ProWORX™ software NxT/32 Lite	Group (3 stations)	UNYSPULZGCD30	–
140 CPU 534 14U		Team (10 stations)	UNYSPULZTCD30	–
		Site (> 10 stations)	UNYSPULZFC30	–

## Unity Pro Extra Large version 3.0 software packages

For PLCs	Description	Type of license	Reference	Weight kg
BMX P34 1000	Unity Pro Extra Large software packages	Single-station	UNYSPUEFUCD30	–
BMX P34 20•0		Group (3 stations)	UNYSPUEFGCD30	–
TSX 57 0•...57 50		Team (10 stations)	UNYSPUEFTCD30	–
TSX PCI 57 20/30		Site (> 10 stations)	UNYSPUEFFCD30	–
140 CPU 311 10	Single-station	UNYSPUEZUCD30	–	
140 CPU 434 12U	Software upgrades from: - Concept S, M, XL - PL7 Micro, Junior, Pro - ProWORX™ software NxT Lite, Full	Group (3 stations)	UNYSPUEZGCD30	–
140 CPU 534 14U		Team (10 stations)	UNYSPUEZTCD30	–
140 CPU 651 50/60		Site (> 10 stations)	UNYSPUEZFC30	–
140 CPU 671 60	- ProWORX™ software 32 Lite, Full			

## Unity Developer's Edition

For PLCs	Description	Type of licence	Reference	Weight kg
BMX P34 1000	UDE Unity Developer's Edition	Single-station		
BMX P34 20•0	Requires Unity Pro Extra Large		UNYUDEVFUCD21E	–
TSX 57 0•...57 50				
TSX PCI 57 20/30				
140 CPU 311 10				
140 CPU 434 12U				
140 CPU 534 14U				
140 CPU 651 50/60				
140 CPU 671 60				

## References (continued)

## Documentation for Unity Pro version 3.0

For PLCs	Description	Type of license	Reference	Weight kg
<b>Hardware and software manuals (on DVD)</b>	Platform setup for: - Modicon M340 - Atrium/Premium - Quantum - Momentum	Multilingual: English, Spanish, French, German, Italian and Chinese	<b>UNYUSE909CDM</b>	–
<b>Electromagnetic compatibility of networks and fieldbuses</b>				
<b>Software setup for:</b> - Unity Pro - EF/EFB/DFB function blocks library				
<b>Separate parts</b>				
Description	Use from processor	To PC port	Length	Reference
<b>PC terminal connection cables</b>	USB Mini B port Modicon M340 BMX P34 1000/20●0	USB port	1.8 m	<b>BMXXCAUSBH018</b>
			4.5 m	<b>BMXXCAUSBH045</b>
	Mini-DIN port for Premium TSX 57 1●/2●/3●/4● Atrium TSX PCI 57	RS 232D (15-pin SUB-D connector)	2.5 m	<b>TSXPCX1031</b>
<b>TSX PCX 1031</b>		USB port (USB/RS 485 converter)	0.4 m	<b>TSXCUSB485 (1)</b>
		USB port (Mini-DIN/RJ45 cordset)	2.5 m	<b>TSXCRJMD25</b>
	Modbus port 15-pin SUB-D Quantum 140 CPU 311 10 140 CPU 434 12A 140 CPU 534 14A	RS 232D (15-pin SUB-D connector)	3.7 m 15 m	<b>990NAA26320</b> <b>990NAA26350</b>
<b>TSX CUSB 485</b>	USB port Premium TSX 57 5●	USB port	3.3 m	<b>UNYXCAUSB033</b>
	RJ45 connector for Modbus port Quantum 140 CPU 6●1	RJ45 connector	1 m	<b>110XCA28201</b>
			3 m	<b>110XCA28202</b>
			6 m	<b>110XCA28203</b>

(1) With **TSX CUSB 485** converter, use the **TSX CRJMD 25** cord set (equipped with 1 x mini-DIN and 1 x RJ45 connectors).




BMX XCA USB H0●0



TSX PCX 1031



TSX CUSB 485



## Presentation

Unity EFB Toolkit is the software for developing EF functions and EFB function blocks in C language and is optional software for Unity Pro. It can be used to develop new functions (whose internal code is written in C language) to extend and complete the set of functions proposed as standard in Unity Pro. This software comes with Microsoft® Visual C++ @.Net which can be used to debug the functions used on the Unity Pro PLC simulator. Unity EFB Toolkit also includes a service for creating and managing families of functions, with a view to their integration in the Unity Pro function libraries.

## Setup

C language development software is a tool for managing the whole function while it is being performed. It provides:

- A user-friendly creation interface, integrated in Unity Pro, with automatic file organization
- Powerful tools for testing and debugging
- Management of compatibilities and software versions of created functions
- Generation of files for subsequent installation of functions on other development stations


## Managing function families

The software can be used to define different function families. Functions, known as EFs/EFBs are stored in families, making it possible to create an organized library of functions written in C language.

Once created, these families can be distributed and integrated in the Unity Pro libraries.

They are:

- Arranged in families/functions
- Used in all languages with the same flexibility as standard functions (data entry wizard)
- Managed by the Unity Pro library tool (version management)




## Editing functions

The various tabs in the EFB Toolkit software editor allow the user to create the function by:

- Declaring the interface; all data types are possible (elementary, structures, tables)
- Supporting public and private variables

## Writing the source code file in C language

A function written in C language can access numerous internal PLC services such as the real-time clock, PLC variables, system words, and math functions. In particular, it is possible to perform numerical processing in floating point format.



### Setup (continued)

#### Debugging functions

The function created can be tested after insertion in an application and loading into the Unity Pro PLC simulator.

The Microsoft® Visual C++ tool is used to debug the function.

It is used to:

- Insert breakpoints
- Perform step by step execution
- Display the code with the breakpoints visible
- Display manipulated data

**Note:** To generate the code for a Modicon M340 platform, a specific GNU compiler is used. It is supplied with the Unity EFB Toolkit.



4

### Enhancing the function library

Once the function has been debugged, it can be generated and distributed, and the updating tool supplied with Unity Pro can be used to enhance the libraries on a user station.

Version management means that at any time the user knows the level of functions installed on a station and can update the application with the latest existing versions.


### Compatibility

Unity EFB Toolkit is compatible with Unity Pro Small, Medium, Large, and Extra Large.


Developing EF functions and EFB functions is possible for the Modicon® M340™, Premium™, Atrium™, and Quantum™ platforms.

### References

The companion software for Unity Pro, Unity EFB Toolkit can be used to create EF elementary blocks and EFB elementary function blocks. These are developed in Visual C++ language and are integrated in Unity Pro function block libraries. The Unity EFB Toolkit software and its documentation are supplied in electronic form on CD-ROM in English.



Description	Type of license	Language	Reference	Weight kg
Unity EFB Toolkit, kit for developing EF and EFB blocks	Single (1 station)	English (software and electronic documentation)	UNYSPUZFUCD30E	–



4

### Presentation

Unity SFC View is integrated in human/machine interface (HMI) applications for monitoring Unity Pro sequential applications written in sequential function chart language (SFC or Grafcet) executed by a PLC.

Set up in the same way as an ActiveX® control component, Unity SFC View is used to display status information relating to SFC charts executed by a Modicon® M340™, Premium™ or Quantum™ PLC. Installed on an HMI station, Unity SFC View monitors and controls the status of SFC charts in real time, supplying detailed diagnostic data.

Unity SFC View reads the necessary data from the Unity project database in offline mode. The PLC data is accessed online via the OFS (OPC Factory Server).

Without needing to recreate SFC charts in the HMI environment, Unity SFC View reads the structure of the SFC charts directly from the Unity project database. Modifications made to the SFC application are detected and updated at any time. In online mode, Unity SFC View accesses the PLC diagnostic data, thus enabling awareness and tracking of the occurrence of the first fault and subsequent faults. System downtime is much reduced since Unity SFC View enables maintenance staff to locate the source of the problem much more quickly.

Unity SFC View is designed for end users and system designers who wish to integrate this control into their HMI system. Unity SFC View is compatible with most HMI platforms handling ActiveX® Control components, such as Vjeo™ Look control software or Monitor Pro™ supervisory software, or in a programming environment such as Visual Basic.

## The 3 Unity SFC View views

Unity SFC View offers 3 views:

- An overview for managing selection of SFC charts
- Two detailed views presenting the status and diagnostic data of the selected SFC chart

**The overview** provides a general view of all the SFC charts in a Unity project. It contains real-time data such as current step, simultaneous steps, chart error with indication of the SFC chart status. The overview makes it easy to browse through SFC charts and switch quickly to the detailed view of the desired SFC chart in the Unity Pro application.

**The simple detailed view** shows the elementary data on the active step (or selected step) of the SFC chart in real time. The data displayed may include the name, comment, chart and step status, as well as the activity times (min, max, actual). You can also enable the chart navigation option.

Because of the compact size of the simple detailed view, it is possible to place several instances of it on a single HMI screen relating to a certain part of the process. From this simple detailed mode, you can navigate between HMI screens with SFC View controls and display the detailed view of SFC charts.

**The detailed view** illustrates the details of an SFC chart in real time. The display indicates the current step, the transition awaiting activation and the next step. The actions associated with the steps are displayed along with sequence selections or parallel branches. The detailed diagnostic data includes analysis of the causes of the fault at transition level. Depending on the diagnostic mode, the error grid contains the causes of errors or all the variables assigned to the transition logic. The current state of the various variables and selected errors are identified by different colors.

## Diagnostic mode

Transition logic diagnostics is a key function of Unity SFC View. It minimizes system downtimes in the event of a fault.


Two different diagnostic modes are available:

- Unity SFC View reads the data in the Unity PLC diagnostic buffer. It provides information about faulty or missing events that are preventing the transition from being enabled. This mode does not require any configuration or additional programming in the PLC program.
- Unity SFC View monitors the internal logic of the transition conditions back-to-front. This mode provides diagnostic data concerning all the inputs connected to the transition (not limited to faulty inputs). In this mode, for Premium™, Atrium™ and Quantum™ platforms, Unity SFC View uses specific EFB function blocks linked to the transition conditions. The library for these blocks is supplied with the Unity SFC View software.

## Customization

Unity SFC View offers a programming interface which can be used to integrate the ActiveX® Control component in an HMI application and customize its functions and its operator interface.


The ActiveX® Control component in Unity SFC View can be customized. It accepts properties, methods and events (all the properties have a default value). The properties pages simplify configuration. Unity SFC View accepts scripts with functions such as browsing through charts, and status control of charts, and also events such as error notification or chart selection. This data can be used to launch programs or operator screens.




### *SFC View properties page*

**Possible architectures****Basic architecture**

Unity SFC View is used in a configuration where the OFS and Unity Pro software reside on the same PC platform as the HMI application.

**Distributed architecture**

In a distributed configuration, the OFS and Unity Pro software can be installed on different servers.





### References

When integrated in an HMI application, Unity SFC View can be used to monitor and control charts in applications developed in Sequential Function Chart (SFC) language running on Premium™/Quantum™ Unity PLCs.

The HMI station, compatible with Windows® 2000 or Windows® XP Professional operating systems, must support ActiveX® Control components.

Unity SFC View V2.0 requires:

- Unity Pro V3.● XL, to be ordered separately
- OFS V3.3 data server software, to be ordered separately

Unity SFC View multilingual software, supplied on a CD-ROM, includes:

- The SFC View ActiveX® Control component
- The EFB function block library for Unity Pro V3.●
- An example of how to integrate SFC View in Unity Pro projects
- The electronic documentation (English, French and German)

The Unity SFC View integration example illustrates the main possibilities offered by Unity SFC View. This is an executable program which does not need HMI software in order to run. It helps the user understand how to configure and use the Unity SFC View ActiveX® Control component.

Description	Type of license	Reference	Weight kg
<b>Unity SFC View software packages</b> (version V2.0)	Single (1 station)	<b>UNYSDUMFUCD20</b>	—
	Team (10 stations)	<b>UNYSDUMFTCD20</b>	—
	Site (100 stations)	<b>UNYSDUMFFCD20</b>	—



## Presentation

Unity Dif application comparison software for Modicon M340/Premium/Atrium/Quantum platforms is an optional program which complements the Unity Pro Extra Large programming software. It is used to compare two Unity applications generated by Unity Pro and automatically provide an exhaustive list of all the differences between them.

The Unity Dif program increases productivity in the main life phases of a control system based on a M340/Premium/Atrium/Quantum platforms:

- Application development and debugging.
- Starting up installations and processes.
- Operation and maintenance of installations and processes.

Unity Dif software is an efficient tool for handling Unity applications for:

- Control system design offices.
- Operation and maintenance managers.
- Installers and systems integrators.

□

## Software setup

The Unity Dif software can be used in one of two modes:

- Interactive mode, when the comparison is launched by an operator command (double-click on the Unity Dif software icon).
- Automatic mode, when it is launched by a previously established call command.

These comparison commands locate all the differences between two applications in terms of:

- The hardware configuration (Modicon M340/Premium/Atrium/Quantum)
- The network configuration (Ethernet TCP/IP network, CANopen bus and RIO remote I/O)
- The entire of variables and function block instances
- The application structure and its content (regardless of the language(s) used)
- The function modules.
- The code for the DFB user function blocks and DDT compound data.
- The project options.

The result of the comparison between the two applications can be:

- Displayed.
- Printed.
- Saved in .txt format in a differences list.

## Comparison


The end of the comparison operation is signalled by the appearance of the application browser with its two tabs.



1 Identification tab for accessing the characteristics of the two applications being compared. The differences are marked by the sign #.

2 Browser tab for accessing the application multilevel tree structure.

(1) RIO remote I/O for Modicon Quantum platform.




## Setup (continued)

### Display of results

The representation of the application multilevel tree structure, which can be accessed via the browser tab after launching a comparison, is annotated by 4 symbols in which the information associated with application **1** appear in blue and those associated with application **2** appear in red:

-  This branch, found in this level of the tree structure, contains at least one difference
-  This block contains at least one difference
-  This section is only present in application 1
-  This section is only present in application 2



In the example opposite, a difference on the rung causing changeover to manual mode is detected:

- 1 This line displayed in blue belongs to application 1 [Prj1]
- 2 This line displayed in red belongs to application 2 [Prj2]

The source code extracts of both applications can be used to locate the differences precisely.

4

### Differentiation report

The "Report" command allows to generate the report file (.txt):

```
Compared Files:
[Prj1] D:\Test\UDIF\ATV17.XEF
[Prj2] D:\Test\UDIF\ATV25.XEF

DateTime of ReportGeneration : 26/03/2007 10:16:13
Machine Name : so-fravier
Windows UserName : FR.ACCEVRavier

First file : D:\Test\UDIF\ATV17.XEF
Name : 0A604
Size : 1024,72 KB
Date : 2007-1-24 (yyyy-mm-dd)
Time : 14:16:17 (hhmmss)
Version : 1.0.20
Product : Unity Pro V2.2.0.c806
Company : Schneider Automation
PLC Address : {2.0}SYS_XIP01

Second file : D:\Test\UDIF\ATV25.XEF
Name : 0A604
Size : 4183,58 KB
Date : 2007-1-24 (yyyy-mm-dd)
Time : 14:15:33 (hhmmss)
Version : 1.0.403
Product : Unity Pro V2.2.0.c806
Company : Schneider Automation
PLC Address : {2.0}SYS_XIP01

Compared Part(s):
Configuration MODIFIED : 0 ADDED : 21 DELETED : 21 MOVED : 0
Derived Data Types NO DIFFERENCES
Device Types NO DIFFERENCES
Variables & FB Instances MODIFIED : 29 ADDED : 71 DELETED : 24 MOVED : 0
Communication MODIFIED : 0 ADDED : 0 DELETED : 2
Motion NO DIFFERENCES
Program MODIFIED : 88 ADDED : 0 DELETED : 0 MOVED : 0
    Function Block Diagram MODIFIED : 276 ADDED : 383 DELETED : 446 MOVED : 0
    Ladder Diagram MODIFIED : 276 ADDED : 4291 DELETED : 4195 MOVED : 0
    Structured Text NO DIFFERENCES
    Instruction List NO DIFFERENCES
    Sequential Function Chart NO DIFFERENCES
Animation Tables MODIFIED : 0 ADDED : 60 DELETED : 24 MOVED : 0
Functional Modules MODIFIED : 23 ADDED : 0 DELETED : 0 MOVED : 0
Project Settings NO DIFFERENCES

Non compared part(s) :

Filters :
Shown : 1, 2, #
Hidden : =

Report in Tree View:
( ) 0A604
    +-(#) Configuration
        +-(#) Xbus
            +-(#) 0 : TSXK12
            +-(#) 1 : TSXP574634M
            +-(#) 3 : TSXET4103
    +-(#) Derived Data Types
    +-(#) Derived FB Types
        +-(#) KESS_DE_3_F_TEST
            +-(#) KESS_DE_3_F_TEST


```

### Reference

This software extension used to compare two PL7 applications generated by Unity Pro software version ≥ V2.1

Function	Target extension PLC target	Type of device	Reference	Weight kg
<b>Unity Dif application comparison software extension</b>	Unity Pro Extra Large Modicon M340/ Premium/Atrium CD-Rom containing software and electronic documentation (English-French)	Single (1 station) Modicon M340/ Premium/Atrium Quantum	<b>UNYSDUDFUCD20</b>	–



4



Unity Loader: Project tab

## Presentation

Unity Loader is companion software to Unity Pro and is used to perform maintenance operations on automation applications. Its easy setup and the small size of its executable make it an essential tool for updating Modicon M340 PLC projects when it is not necessary to read or modify the program. It is also essential software for updating the embedded software on the M340 PLC. It performs the following two main functions:

- Transfer of automation project components from the PC to the PLC or from the PLC to the PC, such as the program, data, files and user Web pages stored in the memory cartridge
- Transfer of embedded software from the PC to the processor or Ethernet communication modules


## Software graphic interface

The software is designed to be used by people with limited automation expertise. The interface consists of four tabs, and buttons within each of the tabs to perform different operations.

- The first tab, Project, is used for project transfers: program, data and user files. The three exchange operations between the PC and the processor can be sequenced together in a single command.
- The second tab, Operating System, is used to update the embedded software in the PLC. The screen displays the detailed content of the PLC firmware versions, and when a file is selected on the PC, the characteristics of that file are displayed.
- The third tab, Options, is used to configure the working environment, including the location of files on the PLC, and selection of one of six languages (English, Spanish, French, German, Italian, and Chinese) for the interface and online help.

The last tab can be used to display information about the software.

**Note:** Regardless of which tab is selected, the connection status with the PLC is displayed, along with commands for connecting/disconnecting and changing the PLC operating mode.



Unity Loader: Operating System tab

## Modicon® M340™ PLC project transfer

### Exchanges between the PC and the PLC processor

The software can be used to transfer the components of a project in either direction:

- Program: binary and source, if the application has been built using the source format
- Data file: located and unlocated data
- Data on the processor memory cartridge: user files (if the cartridge allows this)

Unity Pro can be used to transfer the application from either the application file .stu, or the archive file .sta. The program file and data formats, along with the functions performed by Unity Loader, are identical to those built and used by Unity Pro. When the cartridge-based user files are transferred from the PLC to the PC, a private file specific to Unity Loader is created. The operation is then possible in the other direction. Unity Pro cannot be used to perform this type of transfer.

In order to simplify project management, Unity Loader defaults to store the three files read in the PLC in the same directory with an identical file name (the project name by default), but with a different file extension. The default choice suggested can be modified by the user.

Once connected to the PLC, Unity Loader displays the characteristics of the data read in the PLC. Similarly, when the files are selected on the PC, the corresponding characteristics are also displayed. All the data necessary to decide on the action required is displayed on a single screen. The three components of the project are selected by default, provided that they are valid for the chosen direction of transfer. Transfer of one or two of the components can be disabled. All of the transfers are performed in a single command.

#### Modicon® M340™ PLC project transfer (continued)

##### File transfer to the Modicon M340 PLC Ethernet communication module

The BMX NOE 0100/BMX NOE 0110 communication modules contain a memory cartridge that can store user web pages, depending on the model used. When Unity Loader is connected to the communication module, web pages can be transferred from the module to the PC or vice versa. The operating mode is identical to that available for exchanges with the processor.

#### Updating embedded software in the Modicon® M340™ processor and Ethernet communication modules

Firmware can be updated by following the same principle as that used for transferring projects.

Once connected to the PLC, Unity Loader displays the characteristics of the firmware read in the PLC. Similarly, when a file corresponding to a valid file for the firmware is selected on the PC, the corresponding characteristics are also displayed. All the data necessary to decide on whether the update should be performed is displayed on a single screen.



Unity Loader: Network scanning

#### Communication between the PC and the PLC

Unity Loader uses two communication vectors, USB and Ethernet. USB is always available for exchanges with the PLC processor. Ethernet is essential for exchanges with the Ethernet modules and can also be used for exchanges with processors which have an integrated Ethernet port.

PLC	Type	Ethernet port	USB port
BMX P34 1000	CPU		
BMX P34 2010	CPU		
BMX P34 2020	CPU		
BMX P34 2030	CPU		
BMX NOE 0100	Ethernet module		
BMX NOE 0110	Ethernet module		

Supported

When Unity Loader is connected to an Ethernet network, it is possible to define a range of addresses to be scanned and thus display all the devices recognized on the network. By selecting the Modicon M340 PLC, the transfer operations can then be performed.

All connection and transfer operations, along with any errors, are recorded in a trace file stored in the PC.

#### Compatibility

Unity Loader is compatible with Modicon M340 PLCs.

Its use is totally independent from Unity Pro. Program files and PLC data are compatible between Unity Pro and Unity Loader.



#### Reference

Unity Loader is available in two formats. It is automatically provided with all versions of Unity Pro Small, Medium, Large and Extra Large. It can also be ordered separately.

The product includes a graphic interface and documentation in six languages (English, Spanish, French, German, Italian, and Chinese).



Description	Type	Reference	Weight kg
Unity Loader	Single license	UNYSMUZUCD30	-



### Unity Application Generator for designing and generating process applications

Unity Application Generator (UAG) is a specialized software productivity tool for modeling and generating process applications in a collaborative environment.

For process type applications, UAG provides a single database containing all the project information (process model, control configuration and SCADA integration). Using an approach based on reusable control devices (PID, motor, valve, etc.), UAG which complies with the standard ISA S88 and generates the PLC code (Unity Pro & Concept), plus all the elements required by the HMI monitoring system (Magelis) or SCADA (Monitor Pro V7.2 (1) or third-party supervision system).

Single entry and central information management ensure data consistency and the integration of the control (PLC) and monitoring (HMI/SCADA) systems.

### Process models

#### Physical model (process view)

Process components and logical structuration of the process are based on the ISA S88 standard.

Adopting the ISA S88 standard provides the following benefits:

- Considerable process flexibility.
- Significant reduction in development and delivery timescales.
- A standardized, uniform solution.
- Reuse of sub-elements.

UAG offers the 6 structural levels from the ISA S88 standard (site, area, process cell, unit, equipment module and control module):

These levels can be found again within the applications structure (supervision and PLC) generated by UAG. Process parameters for control devices, such as motors, control loops and valves, are set at control module level.

#### Topological model (automation view)

In a Collaborative Control environment, UAG can be applied to the entire process' control, monitoring and supervision topology. The topological view includes all devices with I/O points, as well as the communication channels between these devices.

UAG supports:

- Architectures comprising automation platforms.
- Modicon Quantum, Premium and Atrium with Unity Pro.
- Modicon Quantum and Momentum with Concept.
- SCADA systems (Monitor Pro, iFix or generic), Magelis panels.
- Ethernet TCP/IP and Modbus Plus communication networks.
- Third-party devices.


The process for configuration of networks, PLC applications with their I/O and other devices of the topological model, takes place directly in UAG.

#### Completness model (project view)

The physical and topological models are independent and can be created in parallel by independent process and automation experts.

The models are integrated via simple drag & drop operations between the two views. This integration simply involves assigning PLC I/O points to control devices (valves, motors, etc.).

### Control Loop



### Integrating your expertise in UAG

#### Smart Control Devices (SCoDs)

UAG software is an object-oriented tool based on these Smart Control Devices. These elements describe a part of the process, including all the aspects of the process control system:

- Links to the PLC logic.
- Links to the graphic representation in the supervisory system.
- Description of I/O interfaces.
- Description of interfaces intended for HMI/SCADA supervisory.
- Information related for handling alarms and events.
- Documentation.

In UAG these multi-faceted elements are called SCoDs (Smart Control Devices). They are created using UAG's specific SCoD editor.

A SCoD is defined for each control devices, and is created with the help of the SCoD editor by:

- Using the DFB or EFB interface of the PLC logic (Unity Pro/Concept) by importing FBD Language.
- Assigning a supervisory graphic reference (Monitor Pro (1) or others).
- Defining the Smart control Device parameters and their behavior in the process control system:
  - control device parameters and attributes from the process side (operating modes, threshold limits, alarm texts, etc.).
  - I/O parameters and attributes for PLC logic,
  - parameters and attributes for HMI/SCADA supervisory.
- Defining configuration screens for the UAG user interface.
- Defining default or initial parameters.

This means that **you can integrate your process expertise and know-how** in your own SCoD libraries and reuse them again and again in all your UAG applications.


### Customization

UAG can be used to define your own standards and apply them. It provides a uniform solution based on your standards, and prepares for validation operations. During the design phase, the risk of error is kept to a minimum, thereby reducing debugging and maintenance costs too.

UAG can be used to customize:

- The selection of SCoD libraries.
- The symbols nomenclature used in UAG.
- The selection of PLC platforms and modules.
- The definition of access levels, display formats, units of measurement, etc. used for HMI/SCADA supervisory.
- The user documentation.
- Security.

This means that **you can integrate your process expertise and standards** in all your UAG applications.



**Integrating your expertise in UAG (continued)**  
Modeling process applications

Once you have created the customization based on your standards and chosen your SCoD libraries, UAG offers you a simple, user-friendly, application-specific method of working.

The process is defined using the physical model (process view), exploiting the expertise provided at customization and SCoD library creation stages. This means that the process behavior and the process configuration screens match exactly your requirements.

The process control is defined using the topological model (automation view), again, in accordance with your customization.

- Process design using UAG is made easy through functional analyses. It allows the user to reliably track the exact project status. In order to be able to detect any error or oversight as soon as possible, UAG analyzes the project and flags any bugs at the various levels of the project, for instance:

- At physical model level:

- SCoD instance attributes that are missing or over limit,
    - invalid or missing interlock parameters.

- At topological model level:

- Communication channels between devices that are not defined,
    - invalid or missing communication parameters.

- At project level:

- SCoD data is being transmitted from another PLC, but communication with this device has not been configured,
    - the SCoD data is not assigned to any PLC I/O variable,
    - behavior on response time for I/O variables that is not defined.

This means that **your process expertise and know-how** is made available to be used in UAG, ensuring consistent process application modeling.

**Generating process applications**

UAG provides at a single point all the process information intended for the project's multiple applications (PLCs, HMI/SCADA), along with the communication parameters.

When applications are generated this information is used to create the configuration and part of the control logic in using IEC 61131-3 FBD functional language. The following items are generated:

- At PLC level:

- Hardware configuration,
  - localized and non-localized data with its initial value and symbol,
  - initialization,
  - inter-PLC communication and distributed I/O (I/O Scanning on Ethernet or Peer Coop on Modbus Plus),
  - DFB/EFB block data (information from SCoDs),
  - interlocks.

- At HMI/SCADA level:

- Data for graphic animations,
    - localized data with its corresponding symbol (display, alarm, archiving information.),
    - user access rights.

- At communication level:

- Communication driver configuration (Monitor Pro (1) and iFIX),
    - configuration data for third-party devices (via an XML interface).

The generation process in UAG is incremental, which makes it possible to supplement the various applications with their dedicated tools outside UAG without any risk. Incremental generation in UAG only impacts changed elements within the applications, which ensures that any additions made using the dedicated tools are stored permanently. This means that **your process expertise and know-how** is quickly operational in your process without any errors or oversights.


### Validation

#### Validation

UAG is a specialized functional tool for process experts and has been developed to comply with the following process standards:

- ISA S88.
- GAMP (Good Automation Manufacturing Practice).

#### Validation procedures



UAG uses ISA S88 standard terminology for batch control and adopts the GAMP methodology for creating an automated system.

The inclusion of these two standards provides major support in the task of approving and validating processes. Validation according to FDA 21CFR Part 11 regulations is simplified by UAG, as it provides:

- All process information at a single point, based on functional analysis.
- Automatic generation of process applications by UAG.
- Archiving in compliance with FDA regulations.
- A log of all interactions by UAG.
- Electronic documentation.

UAG tracks and documents every modification made. The version control system, in compliance with regulation FDA 21 CFR Part 11, ensures simple, straightforward validation.

### Active collaboration

#### Compatible with third-party tools

UAG arranges existing information according to your operating objectives and constraints. Open import/export interfaces are available at every level, facilitating the connection of third-party tools at any time. This means that you can share your expertise by reusing, for example, data from your CAD tools.


#### Total user accessibility

With its multi-user environment and common language, UAG facilitates sharing among process and PLC developers, as well as maintenance engineers and operating staff.

**UAG ensures optimum productivity throughout your application's entire life cycle.**

## Interfacing with SCADA applications

UAG can openly interface with many of the SCADA systems currently available on the market.



## Direct integration

Direct integration by UAG automatically generates the Monitor Pro V7.2 supervisory application elements, which are:

- Variables with symbol and attributes.
- Alarm server configuration.
- Trend server configuration (real time and historical).
- Mimics (graphic objects) of the devices.
- Configuration of the Modbus TCP/IP communication driver.

In addition, for each modification by UAG, the Monitor Pro V7.2 application is automatically updated without any conflicts or risk of disruption of added or changed elements.


UAG therefore ensures data consistency between the automation control and the supervisory level.


This type of direct integration is also available with the iFix supervisory and control system (GE Fanuc).

## Open integration

Open integration is based on all the UAG application information made available via XML file format. This XML file is generated by UAG and can be imported into many third-party SCADA systems, once it has been customized using the XLS style sheets specific to the third-party system.

Regardless of whether direct or open integration is involved, UAG provides you with total consistency within your control, monitoring and supervision system throughout the application's entire life.





### References

This specialized software program UAG (Unity Application Generator) is multilingual (available in English, French and German) and is compatible with the Windows 2000 Professional and Windows XP operating systems.

UAG can be used to model and generate process applications in a collaborative environment. It generates the PLC code (Unity Pro & Concept) and the elements required by the HMI monitoring system (Magelis), SCADA (Monitor Pro V7.2 or third-party supervision systems).

There are two types of software license available for UAG: Medium (M) and Large (L). They are determined by the functional level of the HMI integration:

- The Medium version generates HMI information using customizable XML files (XSL style sheets).
- The Large version also provides customizable XML files, direct integration for Monitor Pro and iFix supervision systems featuring the generation of SCADA applications with variables and attributes, mimics (graphic objects), alarm tables and communication driver configuration.

Documentation is supplied in electronic format.

#### UAG software suites

Description	Type Code generated	License type	Reference	Weight kg
UAG software suites (Unity Application Generator)	Medium	Single (1 machine)	<b>UAGSEWMFUCD21</b>	–
		Site	<b>UAGSEWMFFCD21</b>	–
	Large	Single (1 machine)	<b>UAGSEWLFCUD21</b>	–
		Site	<b>UAGSEWLFFCD21</b>	–

Coming soon!



---

## Advantys™ Telefast® ABE7 pre-wired I/O system

■ Presentation, combinations .....	5/8
■ References	
□ Passive connection sub-base for discrete inputs/outputs .....	5/10
□ Adaptation sub-bases with soldered relays and removable terminal blocks	5/12
□ Adaptation sub-bases for or with plug-in relays.....	5/13
□ Plug-in relays.....	5/15
□ Connection sub-bases for counter and analog channels.....	5/16
□ Accessories for connection sub-bases .....	5/17
■ Dimensions .....	5/18

## Phaseo® power supplies

■ Phaseo Universal range of regulated switch mode power supplies .....	5/20
--	------

## Human/machine Interfaces

Applications	Discrete inputs or outputs			
	Optimum "Low cost"	Optimum "Miniature"	Universal	
	817436	817437	817438	
				
<b>Relay amplification</b>	—			
<b>Equipped with relay</b>	—			
<b>Control voltage</b>	24V ...			
<b>Output voltage</b>	24V ...			
<b>Output current per channel</b>	0.5 A			
<b>Modularity</b>	16		8 - 12 - 16	
<b>No. of terminals per channel</b>	1	1 to 3	1	2
<b>Type of connection terminals</b>	Signal	Signal, common (configurable 24 V ... or 0 V)	Signal	Signal, common (configurable 24 V ... or 0 V)
<b>Connectors</b>	20-pin HE10 connector			
<b>Terminal block</b>	Removable	No	No	
	Terminal type	Screw	Screw or spring	
<b>Additional or optional* function</b>	Low cost version fitted with cable	Miniature sub-bases	Compact size *	Type 2 input * (1)
<b>Device type</b>	ABE7H20E... ABE7H32E...	ABE7H16C...	ABE7H...R1... ABE7H...R50	ABE7H...R2... ABE7H...S21
<b>Pages</b>	5/10		5/11	

(1) For TSX Micro and Premium PLCs

**Discrete inputs and outputs**

**Optimum "Miniature"**

**Optimum**



— Plug-in electromechanical or solid state

— No Yes

24V —

24V — 24V — (solid state)  
5... 24V — 230 V ~ (electromechanical)

0.5 A 0.5 A 5 A (E.M.), 2 A (solid state) 5 A (th)

16 16  
8 passive inputs  
8 relay outputs

1 2 1

Signal,  
2 common connections between  
the inputs and the outputs. Signal, common,  
2 common connections between  
the inputs and the outputs. 1 N/O contact and common, 4 output channels  
2 input connection points

20-pin HE10 connectors

No  
Screw

Miniature sub-base  
Synergy with Tego® Power and Micro PLC Miniature sub-base - Common per 4 channels  
Synergy with Tego® Power and Micro PLC

**ABE7H16CM11** **ABE7H16CM21** **ABE7P16M111** **ABE7R16M111**


5/10

5/14

5/13

5

**5**

Applications	Discrete output				
	“Optimum”	“Universal”	“Optimum”	“Universal”	
					
<b>Relay amplification</b>	Electromechanical, fixed		Electromechanical or solid state		
<b>Equipped with relay</b>	Yes	Yes	No	No	
<b>Control voltage</b>	24 V $\perp\!\!\!\perp$				
<b>Output voltage</b>	5 V $\perp\!\!\!\perp$ ... 30 V 230 V $\sim$	5 V $\perp\!\!\!\perp$ ... 150 V 230 V $\sim$	24 V $\perp\!\!\!\perp$ (solid state) 5 V $\perp\!\!\!\perp$ ... 24 V, $\sim$ 230 V (E.M.)	5 V $\perp\!\!\!\perp$ ... 150 V 230 V $\sim$	
<b>Output current per channel</b>	2 A (th)	3 A (th)	5 A (th)	2 A (solid state), 6 A (electromechanical)	
				Depends on relay mounted 0.5 to 10 A	
<b>Modularity</b>	8	8 - 16	16	8 or 16	
<b>No. of terminals per channel</b>	2	1	2	1	
<b>Type of connection terminals</b>	1 N/O contact and common Voltage-free	1 N/O contact	1 N/O contact and common	1 N/O contact	
				Signal, Polarities	
<b>Connectors</b>	20-pin HE 10 connector				
<b>Terminal block</b>	Removable	Yes	Yes	No	
	Terminal type	Screw or spring		Screw	
				Screw or spring	
<b>Additional or optional* function</b>	Miniature sub-base Latching relay	voltage-free or common per 8 channels	Miniature sub-bases Common per 4 channels	Isolator and fuse	
<b>Device type</b>	ABE7R08S216●	ABE7R●S1●●	ABE7R●S2●●	ABE7R16T111	ABE7P16T111
					ABE7P16T2●●● ABE7P08T3●●●
<b>Pages</b>	5/12		5/13	5/14	

Discrete outputs "Universal"	Discrete inputs "Universal"
---------------------------------	--------------------------------



Electromechanical, plug-in	Solid state, fixed	–	–	Solid state, fixed	Solid state, plug-in		
Yes	Yes	–	–	Yes	No		
24 V $\perp\!\!\!\perp$				From 24 V $\perp\!\!\!\perp$ to 230 V $\sim$	From 5 V TTL to 230 V $\sim$		
5 V $\perp\!\!\!\perp$ ... 150 V 230 V $\sim$	24 V $\perp\!\!\!\perp$						
5A (th)	8 A (th)	from 0.5 to 2 A	125 mA	0.5 A	125 mA		
16							
2 to 3	2 to 6	2	3	2			
1 C/O contact or 1 N/O contact and common	1 C/O contact or 2 C/O contacts and common	Signal and 0 V	Signal 24 V $\perp\!\!\!\perp$ and 0 V	Signal can be isolated, Protected common	Signal Signal and common		
20-pin HE 10 connector							
No	Yes	No	No	Yes	No		
Screw	Screw or spring		Screw	Screw or spring			
Voltage-free or common: 8 channels	Fault signal	Isolator and fuse (indicator)	3-wire proximity sensor	Isolator and fuse (indicator)	–		
4 channels							
ABE7R16T2●	ABE7R16T3●	ABE7S●S2B●	ABE7H16F43	ABE7H16R3●	ABE7H16S43	ABE7S16E2●	ABE7P16F31●
5/13	5/12	5/11		5/12	5/15		

5

## Applications

## Analog signals and special functions



## Compatibility

TSX Micro™ PLC	Premium™ PLC		Standard	Modicon® M340™ PLC BMX ART 0414 / 0814 BMX AMI 0410
----------------	--------------	--	----------	---

## Type of signal

Counter inputs and analog I/O	Counter inputs Axis control Position control	Analog inputs Current Voltage Pt 100	Analog outputs Current Voltage	Analog inputs
----------------------------------	--	---	--------------------------------------	---------------

## Functions

Passive connection, point-to-point with shield continuity		Direct connection Cold-junction compensation or distributed 4 protected isolated power supplies
---	--	--

5

## Modularity

1 counter channel or 8 analog inputs + 2 analog outputs	8 channels	4 channels	4 channels
--	------------	------------	------------

## Control voltage

24 V ...		—
----------	--	---

## Output voltage

24 V ...		—
----------	--	---

## Output current per channel

25 mA		—
-------	--	---

## No. of terminals per channel

2	2 or 4	2 or 4	2 or 4
---	--------	--------	--------

## Connector type

15-pin SUB-D + 9-pin SUB-D	25-pin SUB-D	25-pin SUB-D
----------------------------	--------------	--------------

Terminal block  
Removable  
Terminal type

No	No	No
Screw	Screw	Screw

## Device type

ABE7CPA01	ABE7CPA02	ABE7CPA21	ABE7CPA412/410
-----------	-----------	-----------	----------------

## Pages


5/16
------

## Analog signals and special functions



Standard	Premium TSX AEY810	Premium TSX CAY●1 TSX CTY2C	Premium TSX AEY1614	Premium TSX PAY2●2
Analog inputs Current Voltage Pt 100	Isolated analog inputs	Inputs Counter	Inputs for thermocouples	Inputs/outputs
Distribution of sensor power supplies per limiter (25 mA)	Distribution of isolated sensor power supplies per converter	Acquisition of value from an absolute encoder	Connection of 16 thermocouples with cold junction compensation	Safety module (BG)
8 channels	8 channels	1 channel	16 channels	12 Emergency stops
24 V ___				
24 V ___				
25 mA				—
2 or 4	—	2 or 4	1	
25-pin SUB-D	25-pin SUB-D	15-pin SUB-D	25-pin SUB-D	50-pin SUB-D
No Screw	No Screw or spring	No Screw	No Screw	No Screw
<b>ABE7CPA03</b>	<b>ABE7CPA31●</b>	<b>ABE7CPA11</b>	<b>ABE7CPA12</b>	<b>ABE7CPA13</b>
5/16				

5



5

- 1 Discrete **BMX DDI  $\bullet\bullet$ 02K** input modules, **BMX DDO  $\bullet\bullet$ 02K** output modules and **BMX DDM 3202K** mixed I/O modules equipped with one or two 40-pin connectors. The module modularity ( $\bullet\bullet$ ) is 32 or 64 channels.
- 2 Cord set equipped with connectors (one 40-pin connector with one or two 20-pin HE 10s). 2 models are available: cord sets with one or two 20-wire sheaths (22 AWG) equipped with an HE 10 moulded connector, **BMX FCC  $\bullet\bullet$ 1/ $\bullet\bullet$ 3**.  
These cord sets are available in 0.5, 1, 2, 3, 5 or 10 m lengths.
- 3 16-channel Optimum or Universal Advantys Telefast ABE7 passive connection sub-bases or adapter sub-bases.
- 4 Cord set equipped with connectors (including one 25-pin SUB-D type on the sub-base end). 2 models are available, depending on the type of connections on the analog module side:
  - 20-pin screw terminal block, **BMX FCA $\bullet\bullet$ 0** cord set for **ABE7CPA410** sub-bases
  - 40-pin connector, **BMX FCA $\bullet\bullet$ 2** cord set for **ABE7CPA412** analog input module
 These cord sets are available in 1.5, 3 or 5 m lengths.
- 5 Sub-bases for analog input modules:
  - ABE7CPA410** for connection on a screw terminal block of 4 current/voltage inputs of the **BMX AMI 0410** analog module, with supply of 4 isolated protected power supplies for the current loop inputs.
  - ABE7CPA412** for connection on a screw terminal block of 4 thermocouple inputs for the **BMX ART 0414/0814** analog module, with supply of cold-junction compensation for these inputs.
- 6 **ABE7ACC02** sub-base for splitting 16 into 2 x 8 channels, allows connection to an 8-channel sub-base.
- 7 8-channel Optimum or Universal Advantys Telefast ABE7 passive connection sub-bases or adapter sub-bases.


(1) Connection of the 24 V ... power supply is only possible using Advantys Telefast ABE7 sub-bases. Equipotentiality of the 0 V ... supplies is required.

## I/O modules on the Modicon M340 platform

		Discrete 24 V ---					Analog			
		Inputs		Outputs		Inputs/ Outputs	Inputs		Outputs	
		2 x 16 I	4 x 16 I	2 x 16 Q	4 x 16 Q	1 x 16 I 1 x 16 Q	4 I	4 I	2 x 4 I	2 Q
With Modicon M340 modules	BMX	DDI 3202K	DDI 6402K	DDO 3202K	DDO 6402K	DDM 3202K	AMI 0410	ART 0414	ART 0814	AMO 0210
Preformed cord sets (at both ends)	BMX	FCC●●1/FCC●●3				FCC●●3	FCA●●0	FCA●●2	FCA●●0	FCA●●0
<b>Passive connection sub-bases</b>										
Optimum 16 channels	ABE7H20E●● low-cost									
Universal 8 channels	ABE7H16C●● miniature									
Universal 16 channels	ABE7H08R●●	(1)	(1)	(1)	(1)	(1)				
	ABE7H08S21	(1)	(1)	(1)	(1)	(1)				
	ABE7H16R1●●									
	ABE7H16R50●									
	ABE7H16R2●●									
	ABE7H16S21●									
	ABE7H16R3●									
	ABE7H16R23									
	ABE7H16S43									
	ABE7H16F43									
<b>Input adapter sub-bases with solid state relays</b>										
Universal 16 channels	ABE7S16E2●●									
	Welded solid state relays, removable terminal blocks									
	ABE7P16F31●									
	Removable solid state relays									
<b>Output adapter sub-bases with welded relays, removable terminal blocks</b>										
Optimum & Universal 8 channels	ABE7S08S2B●●			(1)	(1)	(1)				
	Solid state relays									
	ABE7R08S111●/7R08S21●●			(1)	(1)	(1)				
	Electromechanical relays									
Optimum & Universal 16 channels	ABE7S16S●●B●●									
	Solid state relays									
	ABE7R16S111●/7R16S21●●									
	Electromechanical relays									
<b>Output adapter sub-bases with removable relays</b>										
Universal 8 channels	ABE7P08T330●			(1)	(1)	(1)				
	Solid state relays									
Optimum & Universal 16 channels	ABE7R16T●●●/7R16M111									
	Electromechanical relays									
	ABE7P16T●●●/7P16M111									
	Solid state and/or electromechanical relays									
<b>Sub-bases for analog I/O</b>										
4 channels	ABE7CPA410									
	ABE7CPA412									
	ABE7CPA21									

 Preformed cord sets

(1) Via the ABE7ACC02 splitter sub-base used to separate 16 channels into 2 x 8 channels



## Passive connection sub-base for discrete inputs/outputs

## Optimum Low Cost sub-bases

Function	No. of channels	No. of terminals per channel	No. of terminals on row number	For PLCs	Length of PLC connection cable	Type of connection	Reference	Weight
Input or output	16	1	2	Modicon M340 Modicon TSX Micro Modicon Premium	1 2 3	Screw	ABE7H20E100 ABE7H20E200 ABE7H20E300	0.330 0.410 0.480
				Siemens S7	1.5 3	Screw	ABE7H32E150 ABE7H32E300	0.360 0.460



## Optimum Miniature sub-bases

Function	No. of channels	No. of terminals per channel	No. of terminals on row number	LED per channel	Polarity distribution	Type of connection	Reference	Weight
Input or output	16	1	1	No Yes	No No	Screw	ABE7H16C10 ABE7H16C11	0.160 0.160
		2	2	Yes	0 or 24 V	Screw	ABE7H16C21	0.205
		3	3	Yes	0 or 24 V	Screw	ABE7H16C31	0.260
Input and output	16 (1)	1	1	Yes	No	Screw	ABE7H16CM11	0.160
		2	2	Yes	0 or 24 V	Screw	ABE7H16CM21	0.200

(1) 8 I + 8 O: these products have 2 common connections which enable inputs and outputs to be connected to the same sub-base at the same time.





ABE7H16R50



ABE7H16R31

## Passive connection sub-base for discrete signals (continued)

## Universal sub-bases

Function	No. of channels	No. of terminals per channel	LED per channel	Polarity distribution	Isolator (I) per channel	Type of connection	Reference	Weight
Input or output	8	1	1	No	No	—	Screw	ABE7H08R10
				Yes	No	—	Screw	ABE7H08R11
		2	2	Yes	0 or 24 V	—	Screw	ABE7H08R21
						I	Screw	ABE7H08S21
								0.245
	12	1	1	No	No	—	Screw	ABE7H12R10
				Yes	No	—	Screw	ABE7H12R11
		2	No	No	—	Screw	ABE7H12R50	0.196
		2	2	No	0 or 24 V	—	Screw	ABE7H12R20
				Yes	0 or 24 V	—	Screw	ABE7H12R21
						I	Screw	ABE7H12S21
								0.375
	16	1	1	No	No	—	Screw	ABE7H16R10
				Yes	No	—	Screw	ABE7H16R11
						Spring	ABE7H16R11E	0.274
		2	No	No	—	Screw	ABE7H16R50	0.196
				Yes	0 or 24 V	—	Screw	ABE7H16R50E
		2	2	No	0 or 24 V	—	Screw	ABE7H16R20
				Yes	0 or 24 V	—	Screw	ABE7H16R21
						Spring	ABE7H16R21E	0.300
						I	Screw	ABE7H16S21
							Spring	ABE7H16S21E
		3	3	No	0 or 24 V	—	Screw	ABE7H16R30
				Yes	0 or 24 V	—	Screw	ABE7H16R31
								0.346
Type 2 input (1)	16	2	2	Yes	0 or 24 V	—	Screw	ABE7H16R23
Input	16	2	1	Yes	24 V	I, F (2)	Screw	ABE7H16S43
Output	16	2	1	Yes	0 V	I, F (2)	Screw	ABE7H16F43
								0.640

(1) For Modicon Premium.

(2) With LED to indicate blown fuse.

## Connection interfaces

Advantys™ Telefast® ABE7 pre-wired system

Discrete input/output adaptation sub-bases

with soldered relays and removable terminal blocks

### Adaptation sub-bases with soldered relays, removable terminal blocks

#### Input Universal sub-bases with solid state relays

No. of channels	No. of terminals per channel	Isolation PLC/Operative part	Voltage	Type of connection	Reference	Weight kg
16	2	Yes	24 V ...	Screw	ABE7S16E2B1	0.370
				Spring	ABE7S16E2B1E	0.370
			48 V ...	Screw	ABE7S16E2E1	0.370
				Spring	ABE7S16E2E1E	0.370
			48 V ~	Screw	ABE7S16E2E0	0.386
				Spring	ABE7S16E2E0E	0.386
			110 V ~	Screw	ABE7S16E2F0	0.397
				Spring	ABE7S16E2F0E	0.397
			230 V ~	Screw	ABE7S16E2M0	0.407
				Spring	ABE7S16E2M0E	0.407

#### Output Universal sub-bases with solid state relays

No. of channels	Isolation PLC/Operative part	Output voltage	Output current	Fault detection signal (1)	Type of connection	Reference	Weight kg
8	No	24 V ...	0.5 A	Yes (2)	Screw	ABE7S08S2B0	0.252
					Spring	ABE7S08S2B0E	0.252
		2 A	0.5 A	Yes (2)	Screw	ABE7S08S2B1	0.448
					Spring	ABE7S08S2B1E	0.448
16	No	24 V ...	0.5 A	Yes (2)	Screw	ABE7S16S2B0	0.405
					Spring	ABE7S16S2B0E	0.405
		2 A	5 A	Non	Screw	ABE7S16S1B2	0.400
					Spring	ABE7S16S1B2E	0.400

#### Output Optimum & Universal sub-bases with electromechanical relays

No. of channels	Relay width	Number of contacts	Output current	Polarity distribution/operative part	Type of connection	Reference	Weight kg
8	5 mm	1 N/O	2 A	Contact common per group of 4 channels	Screw	ABE7R08S111	0.252
					Spring	ABE7R08S111E	0.252
		1 N/O	2 A	Voltage-free	Screw	ABE7R08S216	0.448
					Spring	ABE7R08S216E	0.448
16	5 mm	1 N/O	2 A	Contact common per group of 8 channels	Screw	ABE7R16S111	0.405
					Spring	ABE7R16S111E	0.405
		1 N/O	5 A	Voltage-free	Screw	ABE7R16S210	0.405
					Spring	ABE7R16S210E	0.405
16	10 mm	1 N/O	5 A	Voltage-free	Screw	ABE7R16S212	0.400
					Spring	ABE7R16S212E	0.400
		1 N/O	5 A	Common per group of 8 channels on both poles	Screw	ABE7R16S214	0.400
					Spring	ABE7R16S214E	0.400



ABE7R08S216

(1) A fault on a sub-base output Qn will set PLC output Qn to special mode, which will be detected by the PLC.

(2) Can only be used with modules with protected outputs.

## Adaptation sub-bases, for plug-in relays

## Input Universal sub-bases for solid state relays (1)

No. of channels	No. of terminals per channel	For relay type	Isolation PLC/Operative part	Input connection	Type of connection	Reference	Weight kg
16	2	ABS7E ABR7 ABS7S33E	Yes	Voltage-free	Screw	ABE7P16F310	0.850
				Spring		ABE7P16F310E	0.850


Polarity distribution Screw ABE7P16F312 0.850

## Output Optimum &amp; Universal sub-bases with electromechanical relays (2)



ABE7R16M111

No. of channels	Relay width	For relay type	No. and type of contacts	Polarity distribution/operative part	Reference	Weight kg
16	5 mm	ABR7S11	1 N/O	Contact common per group of 4 channels	ABE7R16T111	0.600
				Contact common per group of 4 output channels + 2 input common terminals	ABE7R16M111 (3)	0.600
	10 mm	ABR7S21	1 N/O	Voltage-free Common on both poles (4)	ABE7R16T210 ABE7R16T212	0.735 0.730



ABE7R16T210

ABR7S23	1 C/O	Voltage-free Contact common (4)	ABE7R16T230 ABE7R16T231	0.775 0.730
12 mm	ABR7S33	1 C/O	Voltage-free Common on both poles (5)	ABE7R16T330 ABE7R16T332
	ABR7S37	2 C/O	Voltage-free	ABE7R16T370

5

(1) Not equipped with relays.

(2) Both technologies (electromechanical and solid state) may be combined on the same sub-base.

(3) 2 connection methods are available, enabling inputs and outputs to be connected to the same sub-base at the same time.

(4) Per group of 8 channels.

(5) Per group of 4 channels.

# Connection interfaces

Advantys™ Telefast® ABE7 pre-wired system  
Discrete output adaptation sub-bases  
for plug-in relays

## Adaptation sub-bases for plug-in relays (1)

### Output Optimum & Universal sub-bases for solid state and/or electromechanical relays (2)

No. of relay channels	Relay width	For relay type	Isolator per channel	Fuse per channel	Polarity distribution/operative part	Type of connection	Reference	Weight kg	
16	5 mm	ABR7S11 ABS7SC1B	No	No	Contact common per group of 4 channels		ABE7P16T111	0.550	
					Contact common per group of 4 output channels and 2 common input terminals		ABE7P16M111 (2)	0.550	
	10 mm	ABR7S2● ABS7SA2● ABS7SC2● ABE7ACC20	No	No	Voltage-free	Screw	ABE7P16T210 (3)	0.615	
						Spring	ABE7P16T230 (3)	0.655	
					Yes	Voltage-free	Screw	ABE7P16T230E (3)	0.655
							ABE7P16T214	0.675	
					No	Common on both poles (4)	Screw	ABE7P16T212	0.615
					Yes	Common on both poles (4)	Screw	ABE7P16T215	0.670
8	12 mm	ABR7S33 ABS7A3● ABS7SC3●● ABE7ACC21	No	No	Voltage-free	Screw	ABE7P08T330	0.450	
						Spring	ABE7P08T330E	0.450	
16	12 mm	ABR7S33 ABS7A3● ABS7SC3●● ABE7ACC21	No	No	Voltage-free	Screw	ABE7P16T330	0.900	
						Spring	ABE7P16T330E	0.900	
					Common on both poles (5)	Screw	ABE7P16T332	0.900	
		ABR7S33 ABS7A3M ABS7SC3E ABE7ACC21	No	Yes	Voltage-free	Screw	ABE7P16T334	0.900	
				Yes	Common on both poles (5)	Screw	ABE7P16T318	1.000	
						Spring	ABE7P16T318E	1.000	

(1) Not equipped with relays.

(2) 2 connection methods are available, enabling inputs and outputs to be connected to the same sub-base at the same time.

(3) With relay ABR7S21 for sub-base ABE7P16T210, with relay ABR7S23 for sub-base ABE7P16T230●.

(4) Per group of 8 channels.

(5) Per group of 4 channels.

57



ABS7SC1B

## Plug-in solid state relays

Relay width	Functions	Input circuit		Output circuit		Unit reference	Weight kg
		Current	Nominal voltage	Current (1)	Nominal voltage		
5 mm	Output	---	24 V	2 A	24 V ---	ABS7SC1B	0.010
10 mm	Output	---	24 V	0.5 A	5...48 V ---	ABS7SC2E	0.016
					24...240 V ~	ABS7SA2M	0.016
12 mm	Input	---	5 V TTL 24 V Type 2 48 V Type 2	—	24 V ---	ABS7EC3AL ABS7EC3B2 ABS7EC3E2	0.014
			~ 50 Hz ~ 60 Hz ~ 50 Hz	48 V 110...130 V 230...240 V	— — —	ABS7EA3E5 ABS7EA3F5 ABS7EA3M5	0.014
	Output	---	24 V	2 A Self-protected 1.5 A	24 V --- 5...48 V --- 24...240 V ~	ABS7SC3BA ABS7SC3E ABS7SA3MA	0.016 0.016 0.016

## Plug-in electromechanical relays

Relay width	Control voltage	Output current (1)	Number of contacts	Sold in lots of	Unit reference	Weight
5 mm	24 V ---	5 A (lth)	1 N/O	4	ABR7S11	0.005
10 mm	24 V ---	5 A (lth)	1 N/O 1 C/O	4 4	ABR7S21 ABR7S23	0.008 0.008
12 mm	24 V ---	10 A (lth) 8 A (lth)	1 C/O 2 C/O	4 4	ABR7S33 ABR7S37	0.017 0.017
	48 V ---	8 A (lth)	1 C/O	4	ABR7S33E	0.017

61



ABR7S2

61



ABR7S3

5

## Accessory

Description	Reference	Weight kg
Extractor for 5 mm miniature relays	ABE7ACC12	0.010

(1) See characteristics table for specifications of relays in the sub-bases.

# Connection interfaces

Advantys™ Telefast® ABE7 pre-wired system  
Connection sub-bases  
for counter and analog channels

## Connection sub-bases for counter and analog channels

Functions	For Modicon PLCs	Compatible modules	Type of connection Telefast 2 side	Type of connection	Reference	Weight kg
<b>Counting and analog</b>	TSX Micro	Integrated analog and counter TSX 37 22 TSX CTZ●A	15-pin SUB-D	Screw	<b>ABE7CPA01</b>	0.300
<b>Counting, Axis control, Position control</b>	Premium	TSX CTY●A TSX CAY●1	15-pin SUB-D	Screw	<b>ABE7CPA01</b> (	0.300
<b>Parallel output absolute encoder connection</b>	Premium	TSX CTY●A TSX CAY●1	15-pin SUB-D	Screw	<b>ABE7CPA11</b>	0.330
<b>Distribution of 4 thermocouples</b>	Modicon M340	BMX ART 0414 BMX ART 0814	25-pin SUB-D	Screw	<b>ABE7CPA412</b>	0.180
<b>Distribution of 16 thermocouples</b>	Premium	TSX AEY1614	25-pin SUB-D	Screw	<b>ABE7CPA12</b>	0.300
<b>Passive distribution of 8 channels on screw terminal block with shielding continuity</b>	Premium	TSX ASY810 TSX AEY1600 TSX A●Y800	25-pin SUB-D	Screw	<b>ABE7CPA02</b>	0.290
<b>Distribution and supply of 4 analog channels protected isolated</b>	Modicon M340	BMX AMI 0410	25-pin SUB-D	Screw	<b>ABE7CPA410</b>	0.180
<b>Distribution and supply of 4 analog output channels</b>	Premium	TSX ASY410 TSX AEY420	25-pin SUB-D	Screw	<b>ABE7CPA21</b>	0.180
<b>Distribution and supply of 8 analog channels with limitation of each current loop</b>	Premium	TSX AEY800 TSX AEY1600	25-pin SUB-D	Screw	<b>ABE7CPA03</b>	0.330
<b>Distribution and supply of 8 analog input channels isolated from each other with 25 mA/ channel limiter</b>	Premium	TSX AEY810	25-pin SUB-D	Screw Spring	<b>ABE7CPA31</b> <b>ABE7CPA31E</b>	0.410 0.410
<b>Safety</b>	Premium	TSX PAY2●2	25-pin SUB-D	Screw	<b>ABE7CPA13</b>	0.290




ABE7CPA01




ABE7CPA412/410/21




ABE7CPA02




ABE7ACC02




ABE7ACC80 + ABE7ACC81




ABE7BV20



ABE7TES160



AR1SB3



ABFC08R\*\*\*

## Software

Description	Operating system	Reference	Weight kg
Software for marking customer labels	Under Windows® version 3.1 or 95	ABE7LOGV10	0.350
Pack of 25 pre-cut label sheets (160 labels)	—	ABE7LOGF25	0.200


## Accessories

Description	No. of channels	Characteristics	Sold in lots of	Unit reference	Weight kg
Kit for mounting on solid plate	—	—	10	ABE7ACC01	0.008
Splitter sub-base	—	16 as 2 x 8 channels	1	ABE7ACC02	0.075
Redundant output sub-base	—	16 as 2 x 16 channels	1	ABE7ACC10	0.075
Redundant input sub-base	—	16 as 2 x 16 channels	1	ABE7ACC11	0.075
Plug-in continuity blocks	—	Width 10 mm	4	ABE7ACC20	0.007
		Width 12 mm	4	ABE7ACC21	0.010
Locating device for removable terminal block	—	—	100	ABE7ACC30	0.100
Enclosure feedthrough with industrial connector	32	40-pin	1	ABE7ACC80	0.300
Plug-in 40-pin male connector	32	For mounting on ABE7ACC80	1	ABE7ACC81	0.370
Enclosure feedthrough with CNOMO M23 connector (1 x 20-pin HE 10 connector, PLC end)	16	19-pin	1	ABE7ACC82	0.150
	8 and 12	19-pin	1	ABE7ACC83	0.150
Impedance adapter for Type 2 compatibility	—	Used with ABE7ACC82 and ABE7ACC83	1	ABE7ACC85	0.012
IP 65 cable gland	—	For 3 cables	5	ABE7ACC84	0.300
Additional snap-on terminal blocks (shunted terminals)	8	10 screw terminals	5	ABE7BV10	0.030
		10 spring terminals	5	ABE7BV10E	0.030
	16	20 screw terminals	5	ABE7BV20	0.060
		20 spring terminals	5	ABE7BV20E	0.060
I/O simulator sub-base	16	Display, forcing inhibition, continuity	1	ABE7TES160	0.350
Self-adhesive marker tag holder	—	For 6 characters	50	AR1SB3	0.001
Quick-blow fuses 5 x 20, 250 V, UL	—	0.125 A	10	ABE7FU012	0.010
		0.5 A	10	ABE7FU050	0.010
		1 A	10	ABE7FU100	0.010
		2 A	10	ABE7FU200	0.010
		4 A	10	ABE7FU400	0.010
		6.3 A	10	ABE7FU630	0.010

## Jumper accessories

Description	For common	Color	Distance between cable ends	Reference	Weight
			cm		
Jumper Modularity 8 x 1 mm <sup>2</sup>	Coil	White	12	ABFC08R12W	0.020
			2	ABFC08R02W	0.010
~	Red		12	ABFC08R12R	0.020
			2	ABFC08R02R	0.010
---	Blue		12	ABFC08R12B	0.020
			2	ABFC08R02B	0.010

Common side view

ABE7H20E●●●  
ABE7H32E●●●


ABE

7H20E/7H32E●●●

b

b1

c


ABE7H16C●●/ABE7H16CM●●,  
ABE7●16M111/ABE7●16T111ABE 7H16C●●, 7●16M111,  
7H16CM●● 7●16T111

a

b

b1

c

ABE7H16R50, ABE7H12R50,  
ABE7H08R1●, ABE7H08R21,  
ABE7R08S111/S111E,  
ABE7H08S21, ABE7CPA21/40/412

ABE

7H16/12/08●●● 7R08S111●  
7CPA21/410/412



b

b1

c

1 Additional shunt terminal block ABE7BV10/7BV20

Common side view

ABE7H16R2●, ABE7H12R2●, ABE7H16R3●,  
ABE7H16R1●, ABE7H12R1●, ABE7H12S21,  
ABE7H16S2●, ABE7R16S11●, ABE7R08S210,  
ABE7S08S2B0, ABE7CPA02, ABE7CPA03  
ABE7S16S1B2, ABE7R08S216ABE7R16S21●, ABE7S16S2B0/S2B02E,  
ABE7S16E2●●/S16E2●●E,  
ABE7S08S2B1/S08S2B1E  
ABE7CPA31

5

ABE

7●●●●● 7●R08S210●, 7S16S1B2●, 7R08S216

b

b1

c

c1


All sub-bases

b1


c

1 Additional shunt terminal block ABE7BV10/7BV20

ABE7R16T2●●, ABE7P16T2●●




ABE7CPA01, ABE7CPA11/CPA12/CPA13




ABE7R16T3●●, ABE7P16T3●●, ABE7P16F31●

Common side view




Note : details of the front view are the same as for the ABE7CPA01.



ABE7P08T330



ABE7ACC02




ABE7ACC03


ABE7ACC04, ABE7ACC05  
ABE7ACC10, ABE7ACC11

Note : Drawing representing ABE7ACC04 and ABE7ACC05

ABE7ACC80




ABE7ACC82, ABE7ACC83




5


ABE7ACC84



ABE7TES160



Mounting hole dimensions for sub-bases using mounting kit ABE7ACC01



ABE7	G	H
ACC02	38	82
ACC03	53	101
ACC04	53	101
ACC05	53	101
ACC10/11	53	101
H08R●●	72	82
H08S21	72	82
H12R50	72	82
H16R50	72	82
R08S111	72	82
CPA01	131	82
CPA02	113	82
CPA1●	131	82
CPA03	113	82

ABE7	G	H
H12R1●	113	82
H12R2●	113	82
H16R1●	113	82
H16R2●	113	82
H16R3●	113	82
H12S21	113	82
H16S21	113	82
R08S210	113	82
R16S111	113	82
R16S21●	194	82
S08S2B0	113	82
S08S2B1	194	82

ABE7	G	H
H16F43	194	82
H16S43	194	82
S16E2●●	194	82
S16S1B2	113	82
S16S2●●	194	82
R16T2●●	199	101
P16T2●●	199	101
R16T3●●	260	101
P08T330	150	101
P16T3●●	260	101
P16F3●●	260	101

## Power supplies

## Regulated switch mode

## Phaseo Modular range and Optimum range industrial power supplies



## Input voltage

<b>Connection to world-wide line supplies</b>	United States - 120 V (in phase-to-neutral) - 240 V (in phase-to-phase)
Europe	- 230 V (in phase-to-neutral) - 400 V (in phase-to-phase)
United States	- 277 V (in phase-to-neutral) - 480 V (in phase-to-phase)

100...240 V ~  
120...250 V --- (see pages 13 and 14)

Single-phase (N-L1) or 2-phase (L1-L2) connection

Single-phase (N-L1) connection

-

## IEC 61000-3-2 conformity

Yes for ABL 7RP, not for ABL 8REM and not applicable for ABL 8MEM and ABL 7RM

## Protection against undervoltage (U &gt; 19 V)

Yes

## Protection against overloads and short-circuits

Yes, voltage detection. Automatic restart on elimination of the fault

## Diagnostic relay

-

## Compatibility with function modules

-

## Power reserve (Boost)

1,25 to 1,4 In during 1 minute, depending on model (with ABL 8MEM)

No

## Output voltage

5 V ---	12 V ---	24 V ---	48 V ---
		<b>ABL 8MEM2403 (Modular)</b>	
		<b>ABL 8MEM2406 (Modular)</b>	
		<b>ABL 8MEM24012 (Modular)</b>	
	<b>ABL 8MEM12020 (Modular)</b>		
		<b>ABL 7RM24025 (Modular)</b>	<b>ABL 7RP4803 (Optimum)</b>
		<b>ABL 8REM24030 (Optimum)</b>	
<b>ABL 8MEM05040 (Modular)</b>			
	<b>ABL 7RP1205 (Optimum)</b>	<b>ABL 8REM24050 (Optimum)</b>	

## Pages

Consult our "Phaseo Power supplies and transformers" catalog

(1) Except ABL 8RPM24200. ~ 100...120 V and ~ 200...240 V.

(2) --- / --- converter module, requires to be associated with the Phaseo Universal range power supply.

---

**Regulated switch mode****Phaseo Universal range industrial power supplies**

100...120 V ~ and 200...500 V ~ (1)	380...500 V ~	24 V ---
Single-phase (N-L1) or 2-phase (L1-L2) connection	–	–
	3-phase (L1-L2-L3) connection	–
	3-phase (L1-L2-L3) connection	–
Yes	–	–
Yes	–	–
Yes, current limitation or undervoltage detection	Yes, current limitation	–
Yes, depending on model	–	–
Yes with buffer module, battery and battery check modules, redundancy module and discriminating downstream protection module	–	–
1,5 In during 4 seconds	No	–
24 V ---	5 V ---	7...12 V ---
–	–	–
–	–	–
–	–	–
–	–	–
ABL 8RPS24030	–	ABL 8DCC12020 (2)
ABL 8RPS24050	–	–
ABL 8RPS24100	–	ABL 8DCC05060 (2)
ABL 8RPM24200	ABL 8WPS24200	–
	ABL 8WPS24400	–

# Power supplies and transformers

Power supplies for DC control circuits

Regulated switch mode power supplies

Phaseo® power supplies, Universal range



ABL 8RPS24050 Modicon M340 automation platform

## Switch mode power supplies: Universal range

The **ABL 8RPS/RPM/WPS** power supply offer is designed to provide the DC voltage necessary for the control circuits of automation system equipment. Comprising six products, this range meets the needs encountered in industrial and commercial applications. These compact electronic switch mode power supplies provide a quality of output current that is suitable for the loads supplied and compatible with the **Modicon M340**, **Premium** and **Quantum** ranges. When used with additional function modules, they ensure continuity of service in the event of network power outages or application malfunctions. Clear guidelines are given on selecting the function modules and upstream protection devices which are often used with them, and thus a comprehensive solution is provided that can be used in total safety.

The Universal range of Phaseo power supplies must be connected in phase-to-neutral or phase-to-phase for **ABL 8RPS/RPM**, and in 3-phase for **ABL 8WPS**. They deliver a voltage that is precise to 3%, whatever the load and whatever the type of line supply, within the ranges:

- 85 to 132 V  $\sim$  and 170 to 550 V  $\sim$  for **ABL 8RPS**
- 85 to 132 V  $\sim$  and 170 to 264 V  $\sim$  for **ABL 8RPM**
- 340 to 550 V  $\sim$  for **ABL 8WPS**

Their very wide input voltage range allows a considerable reduction of parts held in stock and offers a distinct advantage in terms of machine design.

Conforming to IEC standards and UL and CSA certified, they are suitable for universal use.

**ABL 8RPS/RPM** and **ABL 8WPS** power supplies are all equipped with a harmonic filter, ensuring compliance with standard 61000-3-2 concerning harmonic pollution.

All the Universal range of Phaseo power supplies have protection devices to ensure optimum performance of the automation system. Their operating mode can be configured as required by the user:

■ **Manual reset protection mode:** Priority is given to the voltage so as to guarantee the PLC logic states and nominal operation of the supplied actuators.


■ **Automatic reset protection mode:** Priority is given to the current to allow troubleshooting for example, or to ensure continuity of service until the arrival of the maintenance team.

The Universal range of Phaseo power supplies also has a power reserve, allowing them to deliver a current of 1.5 In at regular intervals. This avoids the need to oversize the power supply if the device has a high inrush current, while ensuring optimum performance of the automation system.

The diagnostics for the Universal range of Phaseo power supplies are available on the front of the device via LEDs (Uout and Iout) and via a volt-free relay contact (whether or not the PLC states are guaranteed).

All products are equipped with an output voltage adjustment potentiometer in order to be able to compensate for any line voltage drops in installations with long connection cable runs.

These power supplies are designed for direct mounting on a 35 mm  $\square$  rail.



#### Switch mode power supplies: Universal range (continued)

There are four references available in the Universal range of Phaseo power supplies for phase-to-neutral or phase-to-phase connection:

■ <b>ABL 8RPS24030</b>	72 W	3 A	24 V ...
■ <b>ABL 8RPS24050</b>	120 W	5 A	24 V ...
■ <b>ABL 8RPS24100</b>	240 W	10 A	24 V ...
■ <b>ABL 8RPM24200</b>	480 W	20 A	24 V ...

The Universal range of Phaseo power supplies also features two references for 3-phase connection:

■ <b>ABL 8WPS24200</b>	480 W	20 A	24 V ...
■ <b>ABL 8WPS24400</b>	960 W	20 A	24 V ...

A range of function modules also allows functions to be added to the Universal range of Phaseo power supplies so as to ensure continuity of service:

- A Buffer module or Battery check modules combined with their batteries to ensure continuity of service in the event of a network power outage
- A Redundancy module to meet the most demanding requirements for continuity of service even if the power supply fails
- Downstream electronic Protection modules to ensure that the protection in the application is discriminating
- Converter modules delivering nominal voltages of 5 and 12 V ... from the 24 V ... output of the Universal range of Phaseo power supplies

5


#### Description

##### Universal range of power supplies

The Universal range of Phaseo regulated switch mode power supplies,

**ABL 8RPS2400/RPM24200/WPS2400**, comprise:

- 1 Spring clip for 35 mm ... rail
- 2 4 mm<sup>2</sup> enclosed screw terminals for connection of the AC voltage (single-phase, phase-to-phase or 3-phase connection)
- 3 Protective glass flap
- 4 Clip-on marker label
- 5 Locking catch for the glass flap (sealable)
- 6 Protection mode selector
- 7 Output voltage adjustment potentiometer
- 8 Output voltage status LED (green and red)
- 9 Output current status LED (green, red and orange)
- 10 Screw terminals for connection of the diagnostic relay contact, except **ABL 8RPS24030**
- 11 4 mm<sup>2</sup> (10 mm<sup>2</sup> on **ABL 8WPS2400** and **ABL 8RPM24200**) enclosed screw terminals for connection of the DC output voltage



## Technical characteristics

Type of power supply	ABL 8RPS24030	ABL 8RPS24050	ABL 8RPS24100	ABL 7RPM24200
<b>Certifications</b>	CB scheme EN 60950-1, UL (pending), cCSAus			
<b>Conformity to standards</b>	Safety IEC/EN 60950-1, EN 61204, SELV EMC EN 61000-6-1, EN 61000-6-2, EN 61000-6-3, EN 61000-6-4, EN 61204-3			
<b>Input circuit</b>				
<b>Input values</b>	Nominal voltage phase-to-neutral (N-L1) or phase-to-phase (L1-L2)	<b>V</b>	100...120 V ~/200...500 V ~	100...120 V ~ / 200...240 V ~
	Limit voltage	<b>V</b>	85...132 V ~/170...550 V ~	85...132 V ~ / 170...264 V ~
	Permissible frequencies	<b>Hz</b>	47...63	
	Maximum inrush current	<b>A</b>	30 for 2 ms max.	
	Power factor		0.59 at 120 V ~/0.51 at 240 V ~	0.69 at 120 V ~/0.68 at 240 V ~
	Efficiency at nominal load		> 87 %	> 88 %
	Dissipated power at nominal load	<b>W</b>	7.8	15.5
			31	57.6
<b>Anti-harmonic filtering</b>				Yes, via integrated PFC (Power Factor Correction) passive filter
<b>Output circuit</b>				
<b>Compatibility with function modules</b>				Buffer, battery and battery check unit, redundancy, discriminating protection
<b>Diagnostics</b>	LEDs on front panel Relay			Current (green, orange and red), voltage (green, red and off) Relay closed $U_{out} > 21.6$ V contact 230 V ~, 0.5 A max; 24 V ~, 5 mA min
<b>Nominal output values</b>	Nominal output voltage ( $U_{out}$ )	<b>V</b>	24 ~	
	Current	<b>A</b>	3	5
	Power	<b>W</b>	72	120
				240
				480
<b>Permissible temporary inrush current (boost)</b>		<b>A</b>	1.5 In for 4 s maximum, see curves on page 5/27	
<b>Precision</b>	Nominal output voltage ( $U_{out}$ )	<b>V</b>	Adjustable 24...28.8	
	Line and load regulation		1 %...3 %	
	Residual ripple - noise	<b>mV</b>	< 200 (peak-peak)	
<b>Holding time for I max.</b>	$U_{in} = 100$ V ~	<b>ms</b>	≥ 20	
	$U_{in} = 240$ V ~	<b>ms</b>	≥ 40	
	$U_{in} = 400$ V ~	<b>ms</b>	≥ 120	
<b>Protection</b>	Against short-circuits			Permanent, automatic or manual restart
	Against overloads			< 1.10 In (after "boost" function)
	Against overvoltages	<b>V</b>	30...32 ~	
	Against undervoltages	<b>V</b>		Tripping if $U_{out} < 21.6$ (in manual mode)
	Thermal			Yes
<b>Operating and environmental characteristics</b>				
<b>Connections</b>	Input	<b>mm<sup>2</sup></b>	2 x 0.5...4 screw terminals (22...12 AWG) + ground	
	Output	<b>mm<sup>2</sup></b>	4 x 0.5...4 screw terminals (24...10 AWG) + ground (1)	
	Diagnostic relay	<b>mm<sup>2</sup></b>	–	2 x 2.5 removable screw terminal block
<b>Mounting</b>	On $\square$ rail		35 x 7.5 mm and 35 x 15 mm	
<b>Operating position</b>			Vertical	
<b>Connections</b>	Series		Possible, see page 5/28	
	Parallel		Possible, see page 5/28	
<b>Degree of protection</b>			IP 20 conforming to IEC 60529	
<b>Environment</b>	Operating temperature	<b>°C</b>	- 25...+ 60 (derating from 50°C, see page 5/26)	
	Storage temperature	<b>°C</b>	- 40...+ 70	
	Maximum relative humidity		90% during operation, 95% in storage	
	Vibration acc. to EN 61131-2		3...11.9 Hz amplitude 3.5 mm & 11.9 -150 Hz acceleration 2 g	
<b>Protection class</b>	According to VDE 0106 1		Class I	
<b>Dielectric strength</b> 50 Hz for 1 min	Input/output	<b>V rms</b>	4000 ~	3000 ~
	Input/ground	<b>V rms</b>	3500 ~	2500 ~
	Output/ground	<b>V rms</b>	500 ~	
<b>Input fuse incorporated</b>			No	
<b>Emissions</b> according to EN 61000-6-3	Radiation		EN 55022 Class B and GL levels	
	Conducted on the power line		EN 55022 Class B and GL levels	
	Harmonic currents		IEC/EN 61000-3-2	
<b>Immunity</b> according to EN 61000-6-2 and GL	Electrostatic discharge		IEC/EN 61000-4-2 (6 kV contact/8 kV air)	
	Radiated electromagnetic fields		IEC/EN 61000-4-3 level 3 (10 V/m)	
	Induced electromagnetic fields		IEC/EN 61000-4-6 level 3 (10 V/m)	
	Rapid transients		IEC/EN 61000-4-4 (4 kV)	
	Surges		IEC/EN 61000-4-5 (2 kV)	
	Primary outages		IEC/EN 61000-4-11 (voltage dips and interruptions)	

(1) No ground screw on ABL 8RPM 24200 power supply

## Technical characteristics

Type of power supply	ABL 8WPS24200	ABL 8WPS24400
<b>Certifications</b>	CB scheme EN 60950-1, UL (pending), cCSAus	
<b>Conformity to standards</b>	Safety EN 60950-1, EN 61204, SELV EMC EN 61000-6-1, EN 61000-6-2, EN 61000-6-3, EN 61000-6-4, EN 61204-3	
<b>Input circuit</b>		
<b>LED indication</b>	–	
<b>Input values</b>	Nominal values 3 phase (L1-L2-L3)	V 380-500 V ~
	Permissible values	V 320-550 V ~
	Permissible frequencies	Hz 47...63
	Maximum inrush current	A 25 for 2 ms max.
	Power factor	0.65
	Efficiency at nominal load	> 92%
	Dissipated power at nominal load	W 38.4
		76.8
<b>Anti-harmonic filtering</b>	Yes, via integrated PFC (Power Factor Correction) passive filter	
<b>Operating mode in the event of phase failure</b>	V	Operation possible for a few minutes then protection trips
<b>Output circuit</b>		
<b>Compatibility with function modules</b>	Buffer, battery and battery check unit, redundancy, discriminating protection	
<b>Diagnostics</b>	LEDs on front panel Relay	Current (green, orange and red), voltage (green, red and off) Closed relay $U_{out} > 21.6$ V, contact 230 V ~, 0.5 A max; 24 V ---, 5 mA min
<b>Nominal output values</b>	Output voltage ( $U_{out}$ ) Current Power	V 24 --- A 0...20 W 480
		0...40 960
<b>Permissible temporary inrush current (boost)</b>	A	1.5 In for 4 s maximum, see curves on page 5/27
<b>Precision</b>	Output voltage ( $U_{out}$ ) Line and load regulation Residual ripple - noise	V Adjustable 24...28.8 1 %...3 % mV < 200 (peak-peak)
<b>Holding time for I max</b>	$U_{in} = 400$ V ~	ms ≥ 18
		≥ 14
<b>Protection</b>	Against short-circuits Against overloads Against overvoltages Against undervoltages Thermal	Permanent, automatic or manual restart < 1.10 In (after "boost" function) V 30...32 --- V Tripping if $U_{out} < 21.6$ (in manual mode) Yes
<b>Operating and environmental characteristics</b>		
<b>Connections</b>	Input Output Diagnostic relay	mm <sup>2</sup> 3 x 0.5...4 screw terminals (22...12 AWG) + ground 4 x 0.5...10 screw terminals (22...8 AWG) 2 x 2.5 removable screw terminal block
<b>Mounting</b>	On $\square$ rail	35 x 7.5 mm and 35 x 15 mm
<b>Operating position</b>		Vertical
<b>Connections</b>	Series Parallel	Possible, see page 5/28 Possible, see page 5/28
<b>Degree of protection</b>		IP 20 conforming to IEC 60529
<b>Environment</b>	Operating temperature Storage temperature Maximum relative humidity Vibration acc. to EN 61131-2	°C - 25...+ 60 (derating from 50°C, see page 5/26) - 40...+ 70 90% during operation, 95% in storage 3...11.9 Hz amplitude 3.5 mm & 11.9 -150 Hz acceleration 2 g
<b>Protection class according to VDE 0106 1</b>		Class I
<b>Dielectric strength</b>	Input/output 50 Hz for 1 min Input/ground Output/ground	V rms 4000 ~ V rms 3500 ~ V rms 500 ~
<b>Input fuse incorporated</b>		No
<b>Emissions</b>	Radiation according to EN 61000-6-3	EN 55022 Class B and GL levels
	Conducted on the power line	EN 55022 Class B and GL levels
	Harmonic currents	IEC/EN 61000-3-2
<b>Immunity</b>	Electrostatic discharge according to EN 61000-6-2 and GL Radiated electromagnetic fields Induced electromagnetic fields Rapid transients Surges Primary outages	IEC/EN 61000-4-2 (6 kV contact/8 kV air) IEC/EN 61000-4-3 level 3 (10 V/m) IEC/EN 61000-4-6 level 3 (10 V/m) IEC/EN 61000-4-4 (4 kV) IEC/EN 61000-4-5 (1 kV) IEC/EN 61000-4-11 (voltage dips and interruptions)


### Output characteristics

#### Derating

The ambient temperature is a determining factor that limits the power an electronic power supply can deliver continuously. If the temperature around the electronic components is too high, their life will be significantly reduced.

The nominal ambient temperature for the Universal range of Phaseo power supplies is 50°C. Above this temperature, derating is necessary up to a maximum temperature of 60°C.

The graph below shows the power (in relation to the nominal power) that the power supply can deliver continuously, depending on the ambient temperature.



5

ABL 8RPM, ABL 8RPS, ABL 8WPS mounted vertically

Derating should be considered in extreme operating conditions:

- Intensive operation (output current permanently close to the nominal current, combined with a high ambient temperature)
- Output voltage set above 24V (to compensate for line voltage drops, for example)
- Parallel connection to increase the total power

### General rules to be complied with

Intensive operation	See derating on above graph. Example for ABL 8RPS: - Without derating, from 0°C to 50°C - Derating of nominal current by 2%, per additional °C, up to 60°C
Rise in output voltage	The nominal power is fixed. Increasing the output voltage means that the current delivered must be reduced.
Mounting	To allow heat dissipation, the power supplies must not be in contact with each other.

In all cases, there must be adequate convection around the products to assist cooling. There must be sufficient clearance around the Universal range of Phaseo power supplies:

- 50 mm above and below
- 10 mm on the sides

#### Output characteristics (continued)

##### Behavior in the event of overloads

Behavior in the event of overloads:

■ **Automatic reset protection mode (current limiting):** If the output current exceeds approximately 1.2 In, the output current is limited to this value. The value of the output voltage can then be less than 21 V but the diagnostic relay opens, allowing the anomaly to be fed back to the automation system and thus prevent feedback of any undefined logic state. On elimination of the overload, the output voltage reverts to its preset value.


■ **Manual reset protection mode (undervoltage detection):** If the output current exceeds approximately 1.2 In, the power supply stops completely before the output voltage drops below 21 V and no longer delivers any current. The fault is memorized as long as voltage is present at the power supply primary. The power supply will become operational again, if the fault has disappeared, after de-energizing the primary for a few seconds.

**Note :** In both these modes, any overload of less than 1.5 In and lasting less than 4 s will be absorbed by the "boost" circuit and the voltage delivered will stay within the specified limits (adjustment voltage +/- 3%).

#### Load limit


##### Manual reset protection mode

ABL 8RPM24200/ABL 8RPS24●●●/ABL 8WPS24●●●




##### Automatic reset protection mode

ABL 8RPM24200/ABL 8RPS24●●●/ABL 8WPS24●●●



5

#### "Boost" repeat accuracy



The **ABL 8RPS/RPM/WPS** Universal range of Phaseo power supplies has a power reserve, allowing them to supply the application with energy up to 1.5 times the nominal current at the intervals illustrated by the graph opposite.

The "boost" amplitude and repeat accuracy depend on:

- The overload duration
- The overload intensity
- The period between each consumption peak

When the power supply can no longer cope (repeated overloads, overload duration > 4 seconds, power rating > 150% of nominal power) the integrated protection trips.

This type of operation is described in detail in the user manual, which can be downloaded from our website, [www.telemecanique.com](http://www.telemecanique.com).


#### Behavior in the event of phase failure on three-phase power supplies

The **ABL 8WPS24●00** Universal range of Phaseo power supplies is capable of starting and delivering a nominal current and voltage for a few minutes in the event of failure of one phase. Their protection (thermal) then trips and they are reset automatically.


### Output characteristics (continued)

#### Series or parallel connection

##### Series connection



##### Parallel connection



##### Family Series

**ABL 8RPS/8RPM/8WPS** 2 products max. (1)

##### Parallel

2 products max.


*Note : Series or parallel connection is only recommended for products with identical references.*

For better availability, the power supplies can also be connected in parallel using the **ABL8 RED24400** Redundancy module.

### Selection of protection on the power supply primaries

Type of line supply	115 V $\sim$ phase-to-neutral		230 V $\sim$ phase-to-phase		400 V $\sim$ phase-to-phase	
Type of protection	Thermal-magnetic circuit-breaker	gG/gL fuse	Thermal-magnetic circuit-breaker	gG/gL fuse	Thermal-magnetic circuit-breaker	gG/gL fuse
ABL 8RPS24030	Telemecanique GB2 (IEC) (2)	Merlin Gerin C60N (IEC) C60N (UL)	2 A (8 x 32)	Telemecanique GB2 (IEC) (2)	Merlin Gerin C60N (IEC) C60N (UL)	2 A (8 x 32)
ABL 8RPS24050	GB2 CD07	MG24443	2 A (8 x 32)	GB2 CD07	MG24443	2 A (8 x 32)
ABL 8RPS24100	GB2 CD08	MG24444	4 A (8 x 32)	GB2 CD08	MG24443	2 A (8 x 32)
ABL 8RPS24100	GB2 CD12	MG24447	6 A (8 x 32)	GB2 CD08	MG24444	4 A (8 x 32)
ABL 8RPM24200	GB2 CD16	MG24449	10 A (8 x 32)	GB2 CD12	MG24447	6 A (8 x 32)
ABL 8WPS24200	—	—	—	—	—	—
ABL 8WPS24400	—	—	—	—	—	—

### Schemes



(1) Two Shottky diodes  $l_{min}$  = power supply  $l_n$  and  $V_{min} = 50 V$   
(2) UL certification pending

# Power supplies and transformers

Power supplies for DC control circuits

Regulated switch mode power supplies

Phaseo® power supplies, Universal range



ABL 8RPS24050



ABL 8RPM24200



ABL 8WPS24200



ABL 8BUF24400



ABL 8BBU24200



ABL 8RED24400

## Regulated switch mode power supplies: Phaseo Universal range

Input voltage	Secondary			Reset	Conforming to standard EN 61000-3-2	Reference	Weight kg
	Output voltage	Nominal power	Nominal current				
<b>Single-phase (N-L1) or phase-to-phase (L1-L2) connection</b>							
100...120 V -	24...28.8 V	72 W	3 A	Auto/man	Yes	ABL 8RPS24030	0.300
200...500 V ~	---	120 W	5 A	Auto/man	Yes	ABL 8RPS24050	0.700
- 15%, + 10%		240 W	10 A	Auto/man	Yes	ABL 8RPS24100	1.000
50/60 Hz							
100...120 V/200...240 V ~	24...28.8 V	480 W	20 A	Auto/man	Yes	ABL 8RPM24200	1.600
- 15%, + 10%	---						
50/60 Hz							
<b>3-phase connection (L1-L2-L3)</b>							
380...500 V ~	24...28.8 V	480 W	20 A	Auto/man	Yes	ABL 8WPS24200	1.600
± 10 %	---	960 W	40 A	Auto/man	Yes	ABL 8WPS24400	2.700
50/60 Hz							

## Function modules for continuity of service

Function	Use	Designation	Reference	Weight kg
<b>Continuity after a power outage</b>	Holding time 100 ms at 40 A and 2 s at 1 A	Buffer module	ABL 8BUF24400	1.200
	Holding time 9 min at 40 A...2 hrs at 1 A (depending on use with a battery check module-battery unit and load) (1)	Battery check module 20 A output current	ABL 8BBU24200	0.500
		Battery check module 40 A output current	ABL 8BBU24200	0.700
		3.2 Ah battery module (2)	ABL 8BPK24A03	3.500
		7 Ah battery module (2)	ABL 8BPK24A03	6.500
		12 Ah battery module (2)	ABL 8BPK24A12	12.000
<b>Continuity after a malfunction</b>	Paralleling and redundancy of the power supply to ensure uninterrupted operation of the application excluding AC line failures and application overloads	Redundancy module	ABL 8RED24400	0.700
<b>Discriminating downstream protection</b>	Electronic protection (1...10 A overload or short-circuit) with 4 output terminals from a Universal range Phaseo power supply	Protection module with single-pole breaking (3)	ABL 8PRE24100	0.270
		Protection module with 2-pole breaking (4) (3)	ABL 8PRP24100	0.270

## .../... converters (for use with Universal range of Phaseo power supplies)

Primary (5)	Secondary		Reference	Weight kg
	Output voltage	Nominal current		
24 V ---	5...6.5 V ---	6 A	ABL 8DCC05060	0.300
- 9%, + 24%	1.7 A	7...15 V ---	ABL 8DCC12020	0.300

## Separate and replacement parts

Designation	Description	Composition	Unit reference	Weight kg
<b>Fuse assemblies</b>	For ABL 8PR●24100 discriminating Protection modules	4 x 3 A, 4 x 7.5 A and 4 x 15 A	ABL 8FUS01	-
	For ABL 8BPK24A●● Battery	4 x 20 A and 6 x 30 A	ABL 8FUS02	-
<b>Clip-on marker labels</b>	All products except ABL 8PR●●●●●●●	Order in multiples of 100	LAD 90	0.030
	ABL 8PR●●●●●●●	Order in multiples of 22	ASI20MACC5	-

<b>DIN rail mounting kit</b>	For ABL 8BPK2403 Battery Module	Single unit	ABL 1A02	-
<b>Cables</b>	Connection cable between ABL8 BBU RS232 3 m and PC for updating the software	USB 3 m	SR2CBL01	0.150
<b>EEPROM memory</b>	Backup and duplication of ABL8 BBU parameters	Single unit	SR2MEM02	0.010

(1) For table of compatibility of battery check module-battery unit with holding time depending on the load, consult our "Phaseo Power supplies and transformers" catalogue.

(2) Supplied with 20 or 30 A fuse depending on the model.

(3) Supplied with four 15 A fuses.


(4) Local reset via pushbutton or automatic reset on elimination of the fault and diagnostic relay.

(5) Voltage from a 24 V --- Universal range Phaseo power supply.

▲ Available 2<sup>nd</sup> quarter 2007.

## Dimensions


ABL 8RPS24\*\*\*/ABL 8RPM24200/ABL 8WPS24\*\*\*  
Common side view




ABL 8	a	b
RPS24030	120	44
RPS24050	120	56
RPS24100	140	85
RPM24200	140	145
WPS24200	155	95
WPS24400	155	165

## Internal schemes


ABL 8RPS24030



ABL 8RPS24050




ABL 8RPS24100




5


ABL 8RPM24200



ABL 8WPS24200




ABL 8WPS24400




### Line supply connection schemes


Single-phase (L-N) 100 to 120 V




Phase-to-phase (L1-L2) 200 to 500 V



3-phase (L1-L2-L3) 3 x 380 to 500 V



Single-phase (L-N) 200 to 500 V



Applications	Display of text messages	Display of text messages and/or semi-graphics
--------------	--------------------------	---

Type of unit	Compact display units
--------------	-----------------------



Display	Type	Back-lit green LCD, height 5.5 mm or Back-lit green, orange or red LCD, height 4.34...17.36 mm	Back-lit monochrome matrix LCD (240 x 64 pixels), height 5.3 or 10.6 mm
	Capacity	2 lines of 20 characters or 1 to 4 lines of 5 to 20 characters	4 to 8 lines of 20 to 40 characters

Data entry	Via keypad with 8 keys (4 with changeable legends)	Display only or via keypad with 4 function keys + 1 service key or 5 service keys
------------	--	---

5

Memory capacity	Application	512 Kb Flash	384 Kb Flash EPROM
	Extension via type II PCMCIA	–	–

Functions	Maximum number of pages	128/200 application pages 256 alarm pages	600 application pages 256 alarm pages 256 print-out form pages (1)
	Variables per page	40...50	50
	Representation of variables	Alphanumeric	Alphanumeric, bargraph, gauge
	Recipes	–	–
	Curves	–	–
	Alarm logs	Depending on model	–
	Real-time clock	Access to the PLC real-time clock	–
	Alarm relay	–	No

Communication	Serial link	RS 232 C/RS 485	RS 232C or RS 422/485
	Downloadable protocols	Uni-TE, Modbus	Uni-TE, Modbus, AEG and for PLC brands: Allen-Bradley, GE Fanuc, Omron, Siemens
	Printer link	RS 232C serial link (1)	–

Development software	XBT L1001 and XBT L1003 (under Windows 98, 2000 and XP)		
Operating systems	Magelis		

Type of terminal	XBT N	XBT HM
------------------	-------	--------

Pages	Consult our "Human/Machine Interfaces" catalogue (1) Depending on model.		
-------	---	--	--

Display of text messages  
Control and parametering of data

Display of text messages and/or semi-graphics  
Control and parametering of data

Compacts terminals



Back-lit green, orange and red LCD, height 4.34...17.36 mm

Back-lit monochrome matrix LCD (240 x 64 pixels), height 5.3 or 10.6 mm

1 to 4 lines of 5 to 20 characters

4 to 8 lines of 20 to 40 characters

Via keypad with  
12 keys for function or numeric input (according to the context)  
+ 8 service keys

Via keypad with  
12 function keys  
10 service keys  
12 numeric keys  
4 soft function keys

512 Kb Flash

512 Kb Flash EPROM

–

128/200 application pages  
256 alarm pages

800 application pages  
256 alarm pages  
256 print-out form pages (1)

40...50

50

Alphanumeric

Alphanumeric, bargraph, gauge

–

–

Depending on model

Access to the PLC real-time clock

No

RS 232C/RS 485

RS 232C or RS 422/485

Uni-TE, Modbus

Uni-TE, Modbus, AEG and for PLC brands: Allen-Bradley, GE Fanuc, Omron, Siemens

RS 232C serial link (1)

XBT L1001 and XBT L1003 (under Windows 98, 2000 and XP)

Magelis

**XBT R**


**XBT PM**

Consult our "Human/Machine Interfaces" catalogue

5

Applications	Display of text messages and graphic objects Control and parametering of data
--------------	--

Type of unit	Graphic terminals
--------------	-------------------



Display	Type	Colour LCD TFT with touch-sensitive screen (320 x 240 pixels) with optimum viewing angle (1)
	Capacity	5,7" (color) 10,4" (color)

Data entry	Via keypad with: - 10 static function keys - 8 soft function keys - 12 service keys - 12 alphanumeric keys	Via touch-sensitive screen	Via keypad with: - 12 static function keys - 10 soft function keys - 12 service keys - 12 alphanumeric keys
------------	--	----------------------------	---

Memory capacity	Application	16 Mb Flash EPROM (via PCMCIA type II card)
	Extension	-

Functions	Maximum number of pages	50 to 720 application, alarm, help and print-out form pages depending on the memory card used (512 alarms maximum)	30 to 480 application, alarm, help and print-out form pages depending on the memory card used (512 alarms maximum)
	Variables per page	64	
	Representation of variables	Alphanumeric, bitmap, bargraph, gauge, potentiometer, selector	
	Recipes	125 records maximum with 5000 values maximum	
	Curves	16	
	Alarm logs	Yes	
	Real-time clock	Access to the PLC real-time clock	
	Discrete inputs/outputs	1 alarm relay	
	Multimedia inputs/outputs	-	

Communication	Downloadable protocols	Uni-TE, Modbus, KS and for PLC brands: GE Fanuc, Omron, Allen-Bradley and Siemens	Uni-TE, Modbus, KS, Modbus TCP/IP, Uni-TE TCP/IP (1) and for PLC brands: GE Fanuc, Omron, Allen-Bradley and Siemens
	Asynchronous serial link	RS 232C or RS 422/485	
	USB Ports	-	
	Bus and networks	Modbus Plus, Fipio/Fipway avec carte additive PCMCIA type III (1), -	Ethernet TCP/IP (10BASE-T/100BASE-TX) (1)
	Printer link	RS 232C serial link (1)	

Development software	XBT L1003 (under Windows 98, Windows 2000 and Windows XP)		
----------------------	---	--	--

Operating systems	Magelis		
-------------------	---------	--	--

Type of terminal	XBT F01	XBT F02/F03
------------------	---------	-------------

Pages	Consult our "Human/Machine Interfaces" catalogue (1) Depending on model. (2) Uni-TE version V2 for Twido/TSX Micro/Premium PLCs.		
-------	--	--	--

**Display of text messages and graphic objects**  
**Control and parametering of data**

**New Technology touch-sensitive graphic terminals**



Back-lit monochrome (amber or red mode) LCD STN (320 x 240 pixels)	Back-lit monochrome or colour LCD STN or back-lit colour LCD TFT (320 x 240 pixels)	Back-lit colour LCD STN or color LCD TFT (640 x 480 pixels)	Back-lit colour LCD STN or color LCD TFT (640 x 480 pixels)	Back-lit colour LCD TFT (800 x 600 pixels)	Back-lit colour LCD TFT (1024 x 768 pixels)
3,8" (monochrome)	5,7" (monochrome or colour)	7,5" (colour)	10,4" (colour)	12,1" (colour)	15" (colour)

Via touch-sensitive screen 6 dynamic function keys	Via touch-sensitive screen
---	----------------------------

8 Mb Flash EPROM	16 Mb Flash EPROM	32 Mb Flash EPROM
– By Compact Flash card 128, 256, 512 Mb or 1 Gb (except XBT GT2110 model)		

Limited by the internal Flash memory capacity	Limited by the internal Flash memory capacity or Compact Flash card memory capacity
---	---

Unrestricted (8000 variables max.)

Alphanumeric, bitmap, bargraph, gauge, tank, curves, polygons, button, light

32 groups of 64 recipes of 1024 ingredients max.

Yes, with log

Yes

Built-in

–	1 input (reset) et 3 outputs (alarm, buzzer, run)
–	1 audio input (microphone), 1 composite vidéo input (numerical or analog camera), 1 audio input (loudspeaker) (1)

Uni-TE (2), Modbus, Modbus TCP/IP (1) and for PLC brands: Mitsubishi, Omron, Allen-Bradley and Siemens

RS 232C/485 (COM1)	RS 232C/RS 422/485 (COM1) and RS 485 (COM2)
–	1 (application download) 2 (application download and peripherals)
–	
Ethernet TCP/IP (10BASE-T) (1)	Ethernet TCP/IP (10BASE-T/100BASE-TX) (1)
–	RS 232C serial link (COM1), USB port for parallel printer

Vijeo Designer VJD ●●D TGS V44M (under Windows 2000 and Windows XP)

Magelis (CPU 100 MHz RISC)	Magelis (CPU 133 MHz RISC)	Magelis (CPU 266 MHz RISC)
----------------------------	----------------------------	----------------------------

<b>XBT GT11</b>	<b>XBT GT21/22/23</b>	<b>XBT GT42/43</b>	<b>XBT GT52/53</b>	<b>XBT GT63</b>	<b>XBT GT73</b>
-----------------	-----------------------	--------------------	--------------------	-----------------	-----------------

Consult our "Human/Machine Interfaces" catalogue

Applications	"All in One" compact products	
Model		
15" screen XGA (1024 x 768)	Data entry via keyboard	
	Data entry via keyboard and touch screen	
	Data entry via touch screen	●
12" screen XGA (1024 x 768)	Data entry via touch screen	
12" screen SVGA (800 x 600)		●
Pages	43632/7	

Model	Smart iPC	
Control box	Processor	Intel Celeron M 600 MHz   VIA 667 MHz
	Storage	1 GB Compact Flash
	RAM	256 MB expandable up to 1024 MB   256 MB expandable up to 512 MB
	CD-ROM drive	–
	Floppy disk drive	–
	Slots available for expansion	1 x PCMCIA slot   1 x type III/type I   1 x PCMCIA slot   1 x type III or 2 x type I
	Ethernet TCP/IP Network	2 x 10BASE-T/100BASE-TX (RJ45)   1 x 10BASE-T/100BASE-TX (RJ45)
	I/O ports	4 x USB + 1 x USB on front panel, 1 x RS232   2 x USB, 1 x COM1, 1 x COM2, 1 x parallel, 1 x PS2 keyboard, 1 x PS2 pointing device
	Operating system	Windows Embedded XPe SP2
	Pre-installed application or software package	Web edition or HMI edition - Vijeo Designer Run-Time
	Power supply	~ 100...240 V   ... 24 V
	Type of PC or Control box	MPC ST2 1NAJ 10●   MPC ST5 2NDJ 10●
Pages	Consult our "Human/Machine Interfaces" catalogue	

**“All in One” compact products**



**Modular products**

(Control box to be connected to a front panel or used as a stand-alone device) (1)



**Front panel**

		<b>MPC NA5 0NNN 20N</b>	
		<b>MPC NB5 0NNN 20N</b>	
●			<b>MPC NT5 0NNN 20N</b>
●			
●			
43634/6		43631/7	



5

Compact iPC	Control box 102	Control box 402
Intel Celeron M 1.3 GHz	VIA 667 MHz or Pentium 4 M 1.7 GHz	Intel Celeron M 1.3 GHz or Intel Pentium M 1.6 GHz
Hard disk ≥ 40 GB	Hard disk ≥ 20 GB	Hard disk ≥ 40 GB, removable
512 MB expandable up to 1024 MB	256 or 512 MB depend. on model	512 MB expandable up to 2 GB
–	Yes	Yes, removable. Combined DVD-R/CD-RW drive available as an option.
–	Yes	Yes
1 x PCI bus slot 1 x PCMCIA slot 1 x type III/type I	1 x PCI bus slot 1 x PCMCIA slot 1 x type III or 2 x type II	1 x PCI bus slot and 2 x type 1/2 (or 1 x type III) PCMCIA slots 4 x PCI bus slots and 2 x type 1/2 (or 1 x type III) PCMCIA slots
2 x 10BASE-T/100 BASE-TX (RJ45)	1 x 10BASE-T/100 BASE-TX (RJ45)	1 x 10BASE-T/100BASE-TX (RJ45)
4 x USB + 1 x USB on front panel 1 x RS232	2 x USB, 1 x COM1, 1 x COM2, 1 x parallel 2 x PS2	2 x USB, 1 x COM1, 1 x COM4 and 1 x parallel, 1 x VGA external video port, 1 x PS/2 port (2)
Windows 2000 or Windows XP Pro	Windows XP Pro or Windows 2000 operating system pre-installed	
Vijeo Designer Run-Time	Package A: Vijeo Look Run-Time	Package A: Vijeo Look Run-Time or Package B: Vijeo Look Build-Time
~ 100...240 V	~ 115...230 V or ... 24 V depending on the model	
<b>MPC KT2 2NA● 00●</b>	<b>MPC KT5 ●NA● 00●</b>	<b>MPC EN0 ●Ne● 00N</b>
		<b>MPC DN0 ●Ne● 00N</b>

Consult our “Human/Machine Interfaces” catalogue

(1) To use a Control box without a front panel screen, you will require the mounting panel MPC NP0 0NNN 00NN.

(2) Port not operational when the Control box is fitted with the front panel screen.

## Applications

Traditional architecture, HMI executed on dedicated terminal or PC platform

Configuration software for user interface applications



## Target products

## Type

Operating system on terminals

Magelis XBT N/R  
Magelis XBT H/P/E/HM/PM  
Magelis XBT F/FC  
(1)

Magelis XBT G (1)  
Magelis XBT GT

Proprietary Magelis operating system

## Functions

Reading/writing of PLC variables

Display of variables

Data processing

Sharing of variables between HMI applications

Saving of variables to external database

Yes

Yes

—

—

—

Yes, with Java programming

## Development of graphics applications

Native library of graphic objects

Container Active X

Java Beans

Curves and alarms

Scripts

Yes

—

—

—

Yes

Yes, with log

Java

## Online modification of applications

—

## Communication between PLCs and HMI application

Via I/O drivers

## Uploading of applications

Yes

—

## Simulation of HMI applications

Yes

## Redundancy

—

## Recipe management

Yes

—

## Report printing

Form, historical data and alarm pages

On the fly alarms, historical data

## Access security

Linked to user profiles

## Software compatible with OS

Windows 98, 2000 or Windows XP

Windows 2000 or Windows XP

## Type of software

XBT L1000

Vijeo Designer



## Pages

Consult our "Human/Machine Interfaces" catalogue

(1) Magelis XBT terminals behave transparently on restoration of power.

<b>SCADA supervisory software</b>	<b>Web architecture, embedded HMI in PLC</b>
	<b>Ethernet TCP/IP modules with embedded Web server</b>
<p>Magelis Compact iPC industrial PCs Magelis Modular iPC industrial PCs PC micro-computers Servers</p> <p>Microsoft Windows</p>	<p>TSX Micro TSX ETZ Premium TSX ETY Quantum 140 NOE 771 FactoryCast Gateway TSX ETG 10●0</p>
	<p>Premium TSX WMY 100 Quantum 140 NWM 100 00</p>

Yes	—	Yes
Yes Client/server architecture	—	
Yes	—	Yes + E-mail transmission triggered by event
Yes	—	
—	Yes	
C compiler integrated	—	
Yes	—	Yes
Via OFS data server	Via internal bus on Premium/Quantum platforms	
Yes		
—	—	Yes
Yes	—	
Yes	—	
All information in the real-time database	—	

5

Windows XP, Servers	Windows 98/2000/NT, Windows XP	Windows 2000 or Windows XP
<b>Vijeo Citect</b>	<b>FactoryCast</b>	<b>FactoryCast HMI</b>

Consult our "Human/Machine Interfaces" catalogue

(2) Specific memory area with Modicon Premium (with PL7 or Unity Pro software) and Quantum (with Unity Pro software) PLC platforms.



---

## Technical information

■ Standards, certifications, and environmental conditions .....	6/2
■ Automation product certifications and community regulations .....	6/6
■ Power consumption table .....	6/8

## Index

■ Product reference index .....	6/9
---------------------------------	-----

### Standards and certifications

Modicon M340 PLCs have been developed to conform to the principal national and international standards concerning electronic equipment for industrial automation systems.

- Requirements specific to programmable controllers: functional characteristics, immunity, resistance, safety, etc.: IEC/EN 61131-2, CSA 22.2 N° 142, UL 508.
- Merchant navy requirements of the main international bodies (with ABS, BV, DNV, GL, LR, RINA, RMRS): IACS (*International Association of Classification Societies*)
- Compliance with European Directives:
  - Low Voltage: 73/23/EEC amendment 93/68/EEC,
  - Electromagnetic Compatibility: 89/336/EEC amendments 92/31/EEC and 93/68/EEC.
- Electrical qualities and self-extinguishing capacity of insulating materials: UL 746C, UL 94.
- Hazardous areas classification: CSA 22.2 No. 213, Class I, Division 2, Groups A, B, C and D.

### Characteristics

#### Service conditions and recommendations relating to environment

Temperature	Operation	°C	0...+ 60			
	Storage	°C	- 40...+ 85			
Relative humidity	Operation	%	93...95 without condensation according to IEC/EN 60060-2-30 Db			
	Storage	%	93...95 without condensation according to IEC/EN 60060-2-30 Db			
Altitude		m	0...4000, temperature derating above 3000 m: 1 °C / 400 m, equals + 55 °C at 4000 m			
Supply voltage			BMX CPS 2010	BMX CPS 3020	BMX CPS 2000	BMX CPS 3500
~: according to IEC/EN 61131-2	Nominal voltage	V	24 ...	24...48 ...	100...240 ~	100...240 ~
...: according to IACS E10 battery without charge	Limit voltages		18...31.2 ...	18...62.4 ...	85...264 ~	85...264 ~
	Nominal frequencies	Hz	—	—	50/60	50/60
	Limit frequencies	Hz	—	—	47/63	47/63

6

### Protective treatment of Modicon® M340™ PLCs

Modicon M340 PLCs meet the requirements of "TC" treatment (*Treatment for all Climates*).

For installations in industrial production workshops or environments corresponding to "TH" treatment (*treatment for hot and humid environments*), Modicon M340 PLCs must be embedded in envelopes with a minimum IP 54 protection, in compliance with IEC/EN 60664 and NF C 20 040.

Modicon M340 PLCs themselves offer **protection to IP 20 level** and **protection against pins** (enclosed equipment) (1). They can therefore be installed without an envelope in reserved-access areas which do not exceed **pollution level 2** (control room with no dust-producing machine or activity). The pollution level 2 does not take account of more severe environmental conditions: air pollution by dust, smoke, corrosive or radioactive particles, vapors or salts, attack by fungi, insects, ...

(1) In the case where a position is not occupied by a module, a **BMX XEM 010** protection cover must be installed.

**Environment tests****Immunity to LF interference (CE) (1)**

Name of test	Standards	Levels
<b>Voltage and frequency variation</b>	IEC/EN 61000-4-11 IACS E10 / IEC 60092-504	0.9 Un/0.95 Fn for 30 minutes; 1.10 Un/1.05 Fn for 30 minutes; 0.8 Un/0.9 Fn for 1,5/5 seconds; 1.2 Un/1.1 Fn for 1,5/5 seconds
<b>Direct voltage variation</b>	IEC/EN 61131-2 IEC/EN 61000-4-11 IEC 60092-504 IACS E10 (battery without charge)	0.85 Un...1.2 Un for 30 minutes with 5% ripple (peak values)
<b>Harmonic 3</b>	IEC/EN 61131-2	10% Un; 0° for 5 min...180° for 5 min
<b>Inter harmonic</b>	IACS E10 / IEC 60092-504	H2...H200 - 10% (H15), 10%...1% (H15...H100) and 1% (H100...H200)
<b>Short momentary interrupt</b>	IEC/EN 61131-2 IEC/EN 61000-4-11/-6-2	10 ms with $\sim$ supply; 1 ms with $\equiv$ supply
<b>Voltage shut-down/start-up</b>	IEC/EN 61131-2	Un-0-Un; Un for 60 s; 3 cycles separated by 10 s Un-0-Un; Un for 5 s; 3 cycles separated by 1 to 5 s Un-0.9-UdI; Un for 60 s; 3 cycles separated by 1 to 5 s

Where:

Un: nominal voltage

Fn: nominal frequency

UdI: detection level when powered

**Immunity to HF interference. (CE) (1)**

Name of test	Standards	Levels
<b>Damped oscillatory wave</b>	IEC/EN 61000-4-12 IEC/EN 61131-2 Zone C	$\sim$ / $\equiv$ main supply, $\sim$ auxiliary supply, discrete $\sim$ I/O (unshielded): 2.5 kV in common mode, 1 kV in differential mode $\equiv$ auxiliary supply, discrete $\sim$ I/O (unshielded) and analog I/O: 1 kV in common mode, 0.5 kV in differential mode All shielded cable: 0.5 kV in common mode
<b>Electrical fast transient bursts</b>	IEC/EN 61000-4-4 IEC 61131-2 / IACS E10	$\sim$ / $\equiv$ main and auxiliary supplies, discrete $\sim$ I/O (unshielded): 2 kV in wire mode, 2 kV in common mode Discrete $\equiv$ I/O (unshielded), analog I/O and all shielded cable: 1 kV in common mode
<b>Surge</b>	IEC/EN 61000-4-5 IEC/EN 61131-2 Zone B IACS E10	$\sim$ / $\equiv$ main and auxiliary supplies, discrete $\sim$ I/O (unshielded): 2 kV in common mode, 1 kV in differential mode Discrete $\sim$ I/O (unshielded) and analog I/O: 0.5 kV in common mode, 0.5 kV in differential mode All shielded cable: 1 kV in common mode
<b>Electrostatic discharges</b>	IEC/EN 61000-4-2 IEC/EN 61131-2 Zone B IACS E10	6 kV contact, 8 kV air
<b>Radiated electromagnetic field</b>	IEC/EN 61000-4-3	15 V/m : 80 MHz...2 GHz Sinusoidal modulation amplitude 80% / 1 kHz + internal clock frequency
<b>Conducted interference induced by radiated field</b>	IEC/EN 61000-4-6 IEC/EN 61131-2 IACS E10	10 V : 0,15 MHz...80 MHz Sinusoidal modulation amplitude 80% / 1 kHz + spot frequency

**Electromagnetic emissions (CE) (1) (2)**

Name of test	Standards	Levels
<b>Interference voltage</b>	EN 55011, Class A IEC/EN 61131-2 IEC/EN 61000-6-4 FCC part 15  IACS E10	150 kHz...500 kHz: quasi-peak 79 dB ( $\mu$ V); average 66 dB ( $\mu$ V) 500 kHz...30 MHz: quasi-peak 73 dB ( $\mu$ V); average 60 dB ( $\mu$ V)  Values according general power distribution zone
<b>Interference field</b>	EN 55011, Class A IEC/EN 61131-2 IEC/EN 61000-6-4 FCC part 15  IACS E10	30 MHz...230 MHz: quasi-peak 40 dB (measurement at 10 m), quasi-peak 50 dB (measurement at 3 m) 230 MHz...2 GHz: quasi-peak 47 dB (measurement at 10 m), quasi-peak 57 dB (measurement at 3 m)  Values depending on general power distribution zone

(1) Devices must be installed and wired in compliance with the instructions provided in the manual "Grounding and Electromagnetic Compatibility of PLC Systems", pdf format on CD-Rom support included in Unity Pro software packages or on DVD UNY USE 909 CD M reference (see page 4/31).

(2) These tests are performed without a cabinet, with devices **fixed on a metal grid** and wired as per the recommendations in the manual "Grounding and Electromagnetic Compatibility of PLC Systems".

(CE): tests required by European directives CE, and based on IEC / EN 61131-2 standards.

**Environment tests (continued)****Immunity to climatic variations**

Name of test	Standards	Levels
Dry heat	IEC/EN 60068-2-2 Bd IACS E10	60 °C for 16 hours
Cold	IEC/EN 60068-2-1 Ab & Ad IACS E10	0 °C for 16 hours with start at 0 °C
Continuous humid heat	IEC/EN 60068-2-78 Ca	60 °C with 93% relative humidity for 96 hours
Cyclical humid heat	IEC/EN 60068-2-30 Db	55 °C; 25 °C with 93...95% relative humidity with 2 cycles of 12 hours/12 hours
Cyclical temperature variations	IEC/EN 60068-2-14 Na & Nb IEC/EN 61131-2	0...60 °C with 5 cycles of 3 hours/3 hours

**Withstand to climatic variations**

Name of test	Standards	Levels
Dry heat (power off)	IEC/EN 60068-2-2 Bb & Bd	85 °C for 96 hours
Cold (power off)	IEC/EN 60068-2-1 Ab & Ad IEC/EN 60068-2-48	- 40 °C for 96 hours
Humid heat (power off)	IEC/EN 60068-2-30 dB	25...60 °C with 93...95% relative humidity with 2 cycles of 12 hours/12 hours
Heat shocks (power off)	IEC/EN 60068-2-14 Na & Nb	- 40...85 °C with 2 cycles of 3 hours/3 hours

## Environment tests (continued)

## Immunity to mechanical constraints (1) (power on)

Name of test	Standards	Levels
<b>Sinusoidal vibrations</b>	IEC/EN 60068-2-6 Fc IACS E10	3 Hz...100 Hz/1 mm amplitude / 0.7 g, transition frequency 13.2 Hz Endurance to resonance frequency 90 min/axis Application coefficient < 10
<b>Sinusoidal vibrations</b> (Class 3M7)	IEC/EN 60068-2-6 Fc IEC/EN 61131-2 Specific profile	5...150 Hz with 10 mm amplitude / 3 g, transition frequency 9 Hz Endurance: 10 cycles of 1 octave/min
<b>Shocks</b>	IEC/EN 60068-2-27 Ea	30 g - 11 ms; 3 shocks/direction/axis (2)
<b>Bumps</b>	IEC/EN 60068-2-29 Eb	25 g - 6 ms; 100 bumps/direction/axis (3)
<b>Plugging / unplugging</b>	IEC/EN 61131-2	For modules and connectors 50 operations for permanent connections 500 operations for non-permanent connections

## Withstand to mechanical constraints (power off)

Name of test	Standards	Levels
<b>Flat free-fall</b>	IEC/EN 60068-2-32 Ed method 1 IEC/EN 61131-2	10 cm / 2 falls
<b>Controlled position free-fall</b> (for handheld product)	IEC/EN 60068-2-31 Ec IEC/EN 61131-2	30 ° or 10 cm / 2 falls
<b>Random free-fall</b> (equipment in packaging)	IEC/EN 60068-2-32 method 1 IEC/EN 61131-2	1 m / 5 falls
<b>Vibrations, transports</b> (Class 2M3)	IEC/EN 60721-4-2 IEC/EN 60068-2-64 Fh	Stationary vibrations, random: 5 m²/s³ from 10...100 Hz, 7 dB/octave from 100...200 Hz, 1 m²/s³ de 200...2000 Hz, 30 min duration

## Equipment and personnel reference information (1) (CE)

Name of test	Standards	Levels
<b>Dielectric strength</b>	UL 508/CSA 22-2 No.142 / FM IEC/EN 61131-2	2 Un + 1000 V / 1 min
<b>Insulation resistance</b>	UL 508/CSA 22-2 No.142 / FM IEC/EN 61131-2	Un < 50 V: 10 MΩ 50 V ≤ Un ≤ 250 V: 10 MΩ
<b>Continuity of earth ground</b>	UL 508/CSA 22-2 No.142 / FM IEC/EN 61131-2	30 A for 2 min, R < 0,1 Ω
<b>Leakage current</b>	IEC/EN 61131-2	I < 3.5 mA after disconnecting
<b>Protection offered by enclosures</b>	IEC/EN 61131-2	IP 20 and protection
<b>Withstand to impacts</b>	UL 508/CSA 22-2 No.142 / FM IEC/EN 61131-2	500 g sphere: fall from 1.3 m
<b>Stored energy injury risk</b>	IEC/EN 61131-2	After 10 s, max. 37 % Un
<b>Overload</b>	UL 508/CSA 22-2 No.142 / FM IEC/EN 61131-2	50 cycles 1 s / 9 s to Un and 1.5 In
<b>Endurance</b>	UL 508/CSA 22-2 No.142 / FM IEC/EN 61131-2	12 cycles 100 ms / 100ms, 988 cycles 1 s / 1 s and 5000 cycles 1 s / 9 s to Un and In
<b>Temperature rise</b>	IEC/EN 61131-2/UL 508 CSA 22-2 No.142/UL 1604 CSA 22-2 No.213 / FM	Ambient temperature 60 °C

(1) Devices must be installed, wired and maintained in compliance with the instructions provided in the users manual.

(2) In case of using fast actuators (response time y 15ms) driven by relay outputs: 15 g - 11 ms; 3 shocks/direction/axis

(3) In case of using fast actuators (response time y 15ms) driven by relay outputs: 15 g - 6 ms; 100 bumps/direction/axis.

(CE): tests required by European directives (CE), and based on IEC / EN 61131-2 standards.

# Technical information

## Automation products certifications

In some countries, certification of certain electrical components is enforced by law. A standard conformity certificate is then issued by the official organization. Each certified product must carry approval symbols when enforced. Use aboard merchant navy vessels generally requires prior approval (= certification) of an electrical device by certain marine classification authorities.

Key	Certification body	Country
<b>CSA</b>	Canadian Standards Association	Canada
<b>C-Tick</b>	Australian Communication Authority	Australia
<b>GOST</b>	Gost Standard Scientific Research Institute	C.I.S., Russia
<b>UL</b>	Underwriters Laboratories	USA
Key	Classification authority	Country
<b>IACS</b>	International Association of Classification Societies	International
<b>ABS</b>	American Bureau of Shipping	USA
<b>BV</b>	Bureau Veritas	France
<b>DNV</b>	Det Norske Veritas	Norway
<b>GL</b>	Germanischer Lloyd	Germany
<b>LR</b>	Lloyd's Register	United Kingdom
<b>RINA</b>	Registro Italiano Navale	Italy
<b>RMRS</b>	Russian Maritime Register of Shipping	C.I.S.

The table below shows the situation as at 01.10.2006 for certifications obtained or pending from organizations for base PLCs. An overview of certificates for Telemecanique products is available on our Internet website:

[www.telemecanique.com](http://www.telemecanique.com)

### Product certifications

Certified Pending certification	Approvals					
	UL	CSA	C-Tick	GOST	Hazardous locations Class I, Div 2 (1)	ATEX
	USA	Canada	Australia	CIS, Russia	USA, Canada	Europe
<b>Advantys STB</b>					FM	
<b>Advantys Telefast ABE 7</b>						
<b>ConneXium</b>					(2)	
<b>Magelis iPC</b>	(3)				UL	
<b>Magelis XBT GT</b>						Cat 3 G-D
<b>Magelis XBT F/FC/HM/PM</b>						
<b>Magelis XBT N/R</b>					CSA/UL	Cat 3 G-D
<b>Modicon M340</b>					CSA	
<b>Modicon Momentum</b>						
<b>Modicon Premium</b>				(2)	CSA	
<b>Modicon Quantum</b>				(2)	FM (2)	
<b>Modicon TSX Micro</b>						
<b>Twido</b>	(3)	(2)			UL (2)	

(1) **Hazardous locations:** UL 1604, CSA 22.2 no. 213 or FM 3611, certified products are acceptable for use in hazardous locations of Class I, division 2, groups A, B, C and D or unclassified only.

(2) Depending on product, consult our website: [www.telemecanique.com](http://www.telemecanique.com)

(3) **cULus** North American certification (Canada and USA).

Local certifications		
<b>BG</b>	Germany	TSX DPZ 10D2A safety module (TSX Micro). TSX PAY 262/282 safety modules (Premium).
<b>SIMTARS</b>	Australia	Modicon TSX Micro automation platform Modicon Premium automation platform (PL7)
<b>AS-Interface</b>	Europe	TWD NOI 10M3 master module (Twido). TSX SAZ 10 master module (TSX Micro). TSX SAY 1000 master modules (Premium).

# Technical information

## Automation products certifications Community regulations

### Marine classification

	Marine classification authorities						
	ABS	BV	DNV	GL	LR	RINA	RMRS
	USA	France	Norway	Germany	UK	Italy	C.I.S.
Advantys STB	(1)						
Advantys Telefast ABE 7							
ConneXium				(2)			
Magelis iPC							
Magelis XBT GT							
Magelis XBT F/FC/HM/PM							
Magelis XBT N/R							
Modicon M340	(3)						
Modicon Momentum							
Modicon Premium (4)	(2)	(2)	(2)	(2)	(2)	(2)	(2)
Modicon Quantum				(2)		(2)	
Modicon TSX Micro							
Twido			(2)	(2)	(2)		

(1) Also meets US Navy requirements, ABS-NRV part 4.

(2) Depending on product, consult our website: [www.telemecanique.com](http://www.telemecanique.com).

(3) Request for Marine certifications forecast 1<sup>st</sup> quarter of 2007.

(4) Modicon Premium, also KRS (Korean register of Shipping) certified.

### Community regulations

#### European directives

The opening of European markets implies a harmonization of regulations in the various European Union member states.

European Directives are documents used to remove obstacles to the free movement of goods, and their application is compulsory in all states of the European Union. Member states must transcribe each Directive into their national legislation and, at the same time, withdraw any conflicting regulations.

The Directives, particularly those of a technical nature, only set objectives, called "general requirements".

Manufacturers must take all necessary measures to ensure that their products conform to the requirements of each Directive relating to their equipment.

As a general rule, manufacturers affirm that their products conform to the necessary requirements of the Directive(s) by applying the e mark to their product. The e marking is applied to Telemecanique products where relevant.

6

#### The significance of e marking

- The e marking on a product means that the manufacturer certifies that its product conforms to the relevant European Directives; it is necessary so that a product which is subject to any Directive(s) can be marketed and freely moved within the European Union.
- The e marking is intended solely for the national authorities responsible for market regulation.

For electrical equipment, conformity of the product to standards indicates that it is suitable for use. Only the guarantee of a recognized manufacturer provides an assurance of high quality.

One or more Directives, as appropriate, may apply to our products, in particular:

- The Low Voltage Directive 72/23/EEC amended by Directive 93/68/EEC: The e marking under the terms of this Directive is compulsory as of January 1, 1997.
- The Electromagnetic Compatibility Directive 89/336/EEC, amended by Directives 92/31/EEC and 93/68/EEC: The e marking on the products covered by this Directive has been compulsory since January 1, 1996.
- Directive e ATEX 94/9/EC.

## *Choice of BMX CPS power supply modules*

# Modicon® M340™ Automation Platform

## Power consumption table

The power required to supply each **BMX XBP 000** rack depends on the type and number of modules installed. It is therefore necessary to create a power consumption table for each rack to define the most suitable **BMX CPS 000** power supply module for each rack. The table below can be used to calculate the consumption on the 2 or 3 different voltages (depending on model) to be supplied by the **BMX CPS 000** power supply module: 3,3 V, 24 V rack, 24 V sensors.

### **Procedure:**

- Ensure that the power supply module corresponds to the power supplies available for the two or three voltages.
- Ensure that the total power absorbed on these three voltages does not exceed the overall power of the power supply module.
- Values to be entered according to the type of Modicon M340 configuration.

(1) Typical value given for 100% of inputs or outputs at state 1.



# Product reference index

<b>CHAPTER 1</b>									
BMXCP2000.....	490NOC00005 .....	26	TSXCANCADD5 .....	.42	UNYUDEVFUCD21E .....	.30	ABE7R08S111E .....	.12	
BMXCP2010.....	490NOR00003 .....	26	TSXCANC8100 .....	.42	UNYUSE909CDM .....	.31	ABE7R08S210 .....	.12	
BMXCP3020.....	490NOR00005 .....	26	TSXCANC8300 .....	.42	UNYXCAUS8033 .....	.31	ABE7R08S210E .....	.12	
BMXCP3500.....	490NOR00015 .....	26	TSXCANC850 .....	.42	<b>CHAPTER 5</b>		ABE7R08S216 .....	.12	
BMXP341000.....	490NTC00005 .....	26	TSXCANCBD03 .....	.42	ABE7ACC01 .....	.17	ABE7R16M111 .....	.13	
BMXP342010.....	490NTC00005U .....	26	TSXCANCBD1 .....	.42	ABE7ACC02 .....	.17	ABE7R16S111 .....	.12	
BMXP342020.....	490NTC00015 .....	26	TSXCANCBD5 .....	.42	ABE7ACC10 .....	.17	ABE7R16S111E .....	.12	
BMXP342030.....	490NTC00015U .....	26	TSXCANC100 .....	.42	ABE7ACC11 .....	.17	ABE7R16S210 .....	.12	
BMXRMS008MP.....	490NTC00040 .....	26	TSXCANC300 .....	.42	ABE7ACC12 .....	.15	ABE7R16S210E .....	.12	
BMXRMS008MPF.....	490NTC00040U .....	26	TSXCANC50 .....	.42	ABE7ACC20 .....	.17	ABE7R16S212 .....	.12	
BMXXB0600.....	490NTC00080 .....	26	TSXCANKCDF180T .....	.42	ABE7ACC21 .....	.17	ABE7R16S212E .....	.12	
BMXXBP0400.....	490NTC00080U .....	26	TSXCANKCDF90T .....	.42	ABE7ACC30 .....	.17	ABE7R16T111 .....	.13	
BMXXBP0800.....	490NTW00002 .....	26	TSXCANKCDF90TP .....	.42	ABE7ACC80 .....	.17	ABE7R16T210 .....	.13	
BMXXBP1200.....	490NTW0002U .....	26	TSXCANTDM4 .....	.42	ABE7ACC81 .....	.17	ABE7R16T212 .....	.13	
BMXXCAUSBH018.....	490NTW00005 .....	26	TSXCSA100 .....	.47	ABE7ACC82 .....	.17	ABE7R16T230 .....	.13	
BMXXCAUSBH045.....	490NTW0005U .....	26	TSXCSA200 .....	.47	ABE7ACC83 .....	.17	ABE7R16T231 .....	.13	
BMXXEM010.....	490NTW00012 .....	26	TSXCSA50 .....	.47	ABE7ACC84 .....	.17	ABE7R16T330 .....	.13	
BMXXSP0400.....	490NTW0012U .....	26	TSXCSA50 .....	.46	ABE7ACC85 .....	.17	ABE7R16T332 .....	.13	
BMXXSP0600.....	490NTW00040 .....	26	TSXCSA62 .....	.46	ABE7BV10 .....	.17	ABE7R16T370 .....	.13	
BMXXSP0800.....	490NTW00040U .....	26	TSXSCPCM4530 .....	.47	ABE7BV10E .....	.17	ABE7S08S2B0 .....	.12	
BMXXSP1200.....	490NTW00080 .....	26	TWDXCAISO .....	.46	ABE7BV20 .....	.17	ABE7S08S2B0E .....	.12	
BMXXTSCPS10.....	490NTW00080U .....	26	TWDXCARJ03 .....	.47	ABE7BV20E .....	.17	ABE7S08S2B1 .....	.12	
BMXXTSCPS20.....	AM02CA001V000 .....	43	TWDXCARJ010 .....	.47	ABE7CPA01 .....	.16	ABE7S08S2B1E .....	.12	
CHAPTER .....	1	BMXNOE0100 .....	.23	TWDXCARJ030 .....	.47	ABE7CPA01 .....	.16	ABE7S16E2B1 .....	.12
STBXP3010.....	15	BMXNOE0110 .....	.23	TWDXCAT3RJ .....	.46	ABE7CPA02 .....	.16	ABE7S16E2B1E .....	.12
STBXP3020.....	15	BMXP341000 .....	.45	VW3A8114 .....	.46	ABE7CPA03 .....	.16	ABE7S16E2E0 .....	.12
		BMXP342010 .....	.41	VW3A8306 .....	.47	ABE7CPA11 .....	.16	ABE7S16E2E0E .....	.12
<b>CHAPTER 2</b>		BMXP342010 .....	.45	VW3A8306D30 .....	.47	ABE7CPA12 .....	.16	ABE7S16E2E1 .....	.12
BMXDDI1602.....	16	BMXP342020 .....	.22	VW3A8306R03 .....	.47	ABE7CPA13 .....	.16	ABE7S16E2E1E .....	.12
BMXDDI3202K.....	16	BMXP342020 .....	.45	VW3A8306R10 .....	.47	ABE7CPA21 .....	.16	ABE7S16E2F0 .....	.12
BMXDDI6402K.....	16	BMXP342030 .....	.22	VW3A8306R30 .....	.47	ABE7CPA31 .....	.16	ABE7S16E2F0E .....	.12
BMXDAI1602.....	16	FTXBLA10 .....	.43	VW3A8306R30 .....	.47	ABE7CPA31E .....	.16	ABE7S16E2M0 .....	.12
BMXDAI1603.....	16	FTXC7BB .....	.43	VW3A8306RC .....	.46	ABE7CPA410 .....	.16	ABE7S16E2M0E .....	.12
BMXDAI1603 .....	16	FTXC7BF5 .....	.43	VW3A8306T03 .....	.46	ABE7CPA412 .....	.16	ABE7S16S1B2 .....	.12
BMXDAI1604 .....	16	FTX78M5 .....	.43	VW3A8306T10 .....	.46	ABE7F012 .....	.17	ABE7S16S1B2E .....	.12
BMXDDO1602 .....	16	FTXCM08B .....	.43	VW3CANAT1 .....	.43	ABE7F050 .....	.17	ABE7S16S2B0 .....	.12
BMXDDO1612 .....	16	FTXCM12B .....	.43	VW3CANCARR03 .....	.43	ABE7F100 .....	.17	ABE7S16S2B0E .....	.12
BMXDDO3202K .....	16	FTXCN12F5 .....	.42	VW3CANCARR1 .....	.43	ABE7F200 .....	.17	ABE7TES160 .....	.17
BMXDDO6402K .....	16	FTXCN12M5 .....	.42	VW3CANKCDF180T .....	.43	ABE7F400 .....	.17	ABFC08R02B .....	.17
BMXDAO1605 .....	16	FTXCN3130 .....	.42	VW3CANTAP2 .....	.42	ABE7F630 .....	.17	ABFC08R02R .....	.17
BMXDAOA0805 .....	16	FTXCN3150 .....	.42	XBTZ938 .....	.47	ABE7H08R10 .....	.11	ABFC08R02W .....	.17
BMXDAOA1605 .....	16	FTXCN3203 .....	.42	XGSZ24 .....	.46	ABE7H08R11 .....	.11	ABFC08R12B .....	.17
BMXDDM16022 .....	17	FTXCN3206 .....	.42	XZCC12FCM50B .....	.27	ABE7H08R21 .....	.11	ABFC08R12R .....	.17
BMXDDM16025 .....	17	FTXCN3210 .....	.42	XZCC12FCM50B .....	.43	ABE7H08S21 .....	.11	ABFC08R12W .....	.17
BMXDDM3202K .....	17	FTXCN3220 .....	.42	XZCC12FDM50B .....	.27	ABE7H12R10 .....	.11	ABR7S11 .....	.15
BMXFTB2000 .....	17	FTXCN3230 .....	.42	XZCC12MCM50B .....	.43	ABE7H12R20 .....	.11	ABR7S21 .....	.15
BMXFTB2010 .....	17	FTXCN3250 .....	.42	XZCC12MDM50B .....	.43	ABE7H12R21 .....	.11	ABR7S23 .....	.15
BMXFTB2020 .....	17	FTXCNCT1 .....	.43	XZCP1164L2 .....	.27	ABE7H12R50 .....	.11	ABR7S33 .....	.15
BMXFTW301 .....	17	FTXCNLT1 .....	.43	XZCP1164L5 .....	.27	ABE7H12S21 .....	.11	ABR7S37 .....	.15
BMXFTW501 .....	17	FTXCY1208 .....	.43	XZCP1264L2 .....	.27	ABE7H16C10 .....	.10	AB57EA3E5 .....	.15
BMXFTW1001 .....	17	FTXCY1212 .....	.43	XZCP1264L5 .....	.27	ABE7H16C11 .....	.10	AB57EA3F5 .....	.15
BMXFCW301 .....	17	FTXDG12 .....	.43	<b>CHAPTER 4</b>		ABE7H16C21 .....	.10	AB57EA3M5 .....	.15
BMXFCW501 .....	17	FTXDGP2115 .....	.43	CHAPTER 4		ABE7H16C31 .....	.10	AB57EC3AL .....	.15
BMXFCW1001 .....	17	FTXDGP2130 .....	.43	110XCA28201 .....	.31	ABE7H16CM11 .....	.10	AB57EC3B2 .....	.15
BMXFCW303 .....	17	FTXDGP2150 .....	.43	110XCA28202 .....	.31	ABE7H16CM21 .....	.10	AB57EC3E2 .....	.15
BMXFCW503 .....	17	FTXDGP2206 .....	.43	110XCA28203 .....	.31	ABE7H16F43 .....	.11	AB57SA2M .....	.15
BMXFCW1003 .....	17	FTXDGP2210 .....	.43	990NAA26326 .....	.31	ABE7H16R10 .....	.11	AB57SA3MA .....	.15
BMXFC051 .....	17	FTXDGP2220 .....	.43	990NAA26350 .....	.31	ABE7H16R11 .....	.11	AB57SC1B .....	.15
BMXFC101 .....	17	FTXDGP2250 .....	.43	BMXXCAUSBH018 .....	.31	ABE7H16R11E .....	.11	AB57SC2E .....	.15
BMXFC201 .....	17	FTXMLA10 .....	.43	BMXXCAUSBH045 .....	.31	ABE7H16R20 .....	.11	AB57SC3B .....	.15
BMXFC301 .....	17	LU9GC3 .....	.46	TSXCRJMD25 .....	.31	ABE7H16R21 .....	.11	AR1S83 .....	.17
BMXFC501 .....	17	TCSCCE4F3M05 .....	.42	TSXCRJUS848 .....	.31	ABE7H16R23 .....	.11	CHAPTER 6	
BMXFC1001 .....	17	TCSCCU4F3M05 .....	.42	UNYSDUDFUCD20 .....	.39	ABE7H16R30 .....	.11	BMXAM01410 .....	.8
BMXFC103 .....	17	TCSCCU4F3M1 .....	.42	UNYSDUMFFCD20 .....	.37	ABE7H16R61 .....	.11	BMXAMM0600 .....	.8
BMXFC203 .....	17	TCSCTN101M11F .....	.43	UNYSDUMFTCD20 .....	.37	ABE7H16R50 .....	.11	BMXAMO0210 .....	.8
BMXFC303 .....	17	TCSEAF11F13F00 .....	.27	UNYSDUMFUCD20 .....	.37	ABE7H16S21 .....	.11	BMXART0414 .....	.8
BMXFC503 .....	17	TCSEAF11LFH00 .....	.27	UNYSPUEZGCD30 .....	.30	ABE7H16S21E .....	.11	BMXART0814 .....	.8
BMXFC1003 .....	17	TCSEAF11LFS00 .....	.27	UNYSPUEFFCD30 .....	.30	ABE7H16S43 .....	.11	BMXCP2000 .....	.8
BMXAM0410 .....	31	TCSEAF11LFU00 .....	.27	UNYSPUEGCD30 .....	.30	ABE7H20E100 .....	.10	BMXCP2010 .....	.8
BMXART0414 .....	31	TCSEAF11M00 .....	.27	UNYSPUEFTCD30 .....	.30	ABE7H20E200 .....	.10	BMXCP3020 .....	.8
BMXART0814 .....	31	TCSEC1M3M1S2 .....	.27	UNYSPUEFUCD30 .....	.30	ABE7H20E300 .....	.10	BMXDDI1602 .....	.8
BMXAM00210 .....	31	TCSECL1M1M1052 .....	.27	UNYSPUEZFC30 .....	.30	ABE7H20E300 .....	.10	BMXDDI3202K .....	.8
BMXAMM0600 .....	31	TCSECL1M1M1S2 .....	.27	UNYSPUEZGCD30 .....	.30	ABE7H32E150 .....	.10	BMXDDI6402K .....	.8
BMXFTB2000 .....	31	TCSECL1M1M1X552 .....	.27	UNYSPUEZTC30 .....	.30	ABE7H32E300 .....	.10	BMXDDAI1603 .....	.8
BMXFTB2010 .....	31	TCSECL1M1M2S52 .....	.27	UNYSPUEZUC30 .....	.30	ABE7LOG25 .....	.17	BMXDDAI1604 .....	.8
BMXFTB2020 .....	31	TCSECL1M1M3S5 .....	.27	UNYSPULFTCD30 .....	.30	ABE7LOGV10 .....	.17	BMXDDAO1605 .....	.8
BMXFTW301S .....	31	TCSECL1M1M40S2 .....	.27	UNYSPULFTCD30 .....	.30	ABE7P08T730 .....	.14	BMXDDDI1602 .....	.8
BMXFTW501S .....	31	TCSECL1M1M5S2 .....	.27	UNYSPULFTCD30 .....	.30	ABE7P08T730E .....	.14	BMXDDI3202K .....	.8
BMXFCW301S .....	31	TCSECL1M3M10S2 .....	.27	UNYSPULFTCD30 .....	.30	ABE7P16F310 .....	.13	BMXDDI6402K .....	.8
BMXFCW501S .....	31	TCSECL1M3M1X552 .....	.27	UNYSPULFTCD30 .....	.30	ABE7P16F310E .....	.13	BMXDDM16022 .....	.8
ABE7CPA410 .....	31	TCSECL1M3M2S2 .....	.27	UNYSPULFTCD30 .....	.30	ABE7P16F312 .....	.13	BMXDDM16025 .....	.8
ABE7CPA412 .....	31	TCSECL1M3M3S2 .....	.27	UNYSPULFTCD30 .....	.30	ABE7P16M111 (2) .....	.14	BMXDDM3202K .....	.8
BMXFC1A50 .....	31	TCSECL1M3M40S2 .....	.27	UNYSPULZUCD30 .....	.30	ABE7P16T111 .....	.14	BMXDDO1602 .....	.8
BMXFC1A50 .....	31	TCSECL1M3M5S2 .....	.27	UNYSPUMFCD30 .....	.30	ABE7P16T210 (3) .....	.14	BMXDDO1612 .....	.8
BMXFC500 .....	31	TCSCMCN3M4F3C2 .....	.47	UNYSPUMFTCD30 .....	.30	ABE7P16T212 .....	.14	BMXDDO3202K .....	.8
BMXFC1A52 .....	31	TCSCMCN3M4M3S2 .....	.47	UNYSPUMFUCD30 .....	.30	ABE7P16T214 .....	.14	BMXDDO6402K .....	.8
BMXFC1A52 .....	31	TLACDCBA005 .....	.42	UNYSPUMZGCD30 .....	.30	ABE7P16T215 .....	.14	BMXDDO805 .....	.8
BMXFC1A52 .....	31	TLACDCBA15 .....	.42	UNYSPUMZTC30 .....	.30	ABE7P16T230 (3) .....	.14	BMXDR1A605 .....	.8
BMXEH0200 .....	41	TLACDCBA030 .....	.42	UNYSPUMZUCD30 .....	.30	ABE7P16T230E (3) .....	.14	BMXEHC0200 .....	.8
BMXEH0800 .....	41	TLACDCBA050 .....	.42	UNYSPUSFGCD30 .....	.30	ABE7P16T318 .....	.14	BMXEHC0800 .....	.8
BMXFTSHS20 .....	41	TXCANCA100 .....	.42	UNYSPUSFTCD30 .....	.30	ABE7P16T318E .....	.14	BMXNOE0100 .....	.8
BMXFTB2000 .....	41	TXCANCA300 .....	.42	UNYSPUSFUCD30 .....	.30	ABE7P16T330 .....	.14	BMXNOE0110 .....	.8
BMXFTB2010 .....	41	TXCANCA50 .....	.42	UNYSPUSZGCD30 .....	.30	ABE7P16T332 .....	.14	BMXP341000 .....	.8
BMXFTB2020 .....	41	TXCANCADD03 .....	.42	UNYSPUSZCD30 .....	.30	ABE7P16T334 .....	.14	BMXP342010 .....	.8
<b>CHAPTER 3</b>		TXCANCADD1 .....	.42	UNYSPUSZUCD30 .....	.30	ABE7R08S111 .....	.12	BMXP342020 .....	.8
		TXCANCADD3 .....	.42	UNYSPUZFUCD30E .....	.33	ABE7R08S111 .....	.12		

*Product reference index*  
*(continued)*

---

BMXP342030 .....8



Platform for machine manufacturers  
Modicon® M340™ PLC  
Unity™ software



Platform for machines and manufacturing processes  
Modicon® Premium™  
Unity™ and PL7™ software



Platform for continuous and semi-continuous industrial processes and infrastructure sites  
Modicon® Quantum™  
Unity™, Concept™ and ProWORX™ 32 software

## The efficiency of Telemecanique® branded *solutions*

Used in combination, Telemecanique products provide quality solutions, meeting all your **Automation** and **Control** applications requirements.



## A worldwide presence

### Constantly available

- More than 5 000 points of sale in 130 countries.
- You can be sure to find the range of products that are right for you and which comply fully with the standards in the country where they are used.

### Technical assistance wherever you are

- Our technicians are at your disposal to assist in finding the optimum solution for your particular needs.
- Schneider Electric offers all necessary technical assistance, throughout the world.

[www.us.telemecanique.com](http://www.us.telemecanique.com)

### North American Operating Division

**Schneider Electric**  
1415 South Roselle Road  
Palatine, IL 60064  
  
TEL: 847-397-2600  
[www.schneider-electric.com](http://www.schneider-electric.com)  
[www.us.telemecanique.com](http://www.us.telemecanique.com)

Due to evolution of standards and equipment, the characteristics indicated in texts and images of this document do not constitute a commitment on our part without confirmation.

Design: Schneider Electric  
Photos: Schneider Electric  
Printed by: Delzer Lithograph

*Simply Smart!*