

WELCOME to the quick guide

Pencllic Mouse combines ergonomically sound design with modern mouse technology to bring you unparalleled precision, comfort and efficiency.

Mouse setup

Insert the battery into the mouse

Charge the battery with the included micro usb charging cable until full.

Set the mouse power switch on the bottom of the mouse to ON

Install the Pencllic Mouse B3

Standard PC Bluetooth device installation

Activate the Bluetooth connection on the computer.

Press the button under the mouse to activate the Bluetooth search on the mouse.

Search for Bluetooth devices on your computer.

Select Pencllic Mouse B3 once found.

Install the mouse and the Pencllic Mouse B3 is ready to use.

Trouble installing your Pencllic Mouse B3. Please look at www.pencllic.se/troubleshooting

HOW TO USE YOUR Pencllic Mouse

1, Hold Pencllic Mouse like a pen, the bottom part acts like a traditional mouse.

2, Let your forearm and your hand rest on a surface, while keeping your shoulders relaxed.

3, The pen part can be adjusted to suit specific grips.

Fixate the bottom part with one hand and rotate the pen to the preferred angle with the other.

- Left click 1
- Right click 2
- Middle click 3
- Scroll wheel 4
- On-off button 5
- DPI switch 6
- **Bluetooth connect button 7**

TROUBLESHOOTING

<http://www.Pencilic.se/troubleshooting>

- Check the battery.
- When the battery needs charging the LED on the mouse will show red. When the battery is fully charged a green light will be displayed.
- Cursor movement may be effected by very glossy surfaces.
- **Trouble connecting finding the Bluetooth connection, please look at www.pencilic.se/troubleshooting**

TECHNICAL SPECIFICATIONS

The supported platforms for Pencilic Mouse are all operating systems that support HID 1.1. These include Windows XP or later, Mac OSX version 10.1 or later and most Linux/BSD flavors. No extra software/driver installation is needed.

- **Bluetooth connection**
- Operates on almost any surface without any pad or tablet.
- Implements a 3-buttons and scroll wheel mouse.
- AAA 1.2V NiMH Recharging battery (Everyday use last approximately 3 months before charging is needed).
- LR 03/AAA/1.5V Alkaline None rechargeable battery can be used. **NOTE: DO NOT RECHARGE**
- Energy saving mode starts after 10 min, press a button to start.
- Wireless reach, minimum 5 metres.
- Dpi settings 800-1200-1600.

Measurements:

- Height: 140 mm Base: 44.1 x 20 mm
- Weight: 41 g

TECHNICAL SUPPORT

Should you require additional technical support with your Pencllic Mouse™, please use our Web site for further information or contact our support group through e-mail. Call Technical Support during business hours, central European time plus one hour.

Contact: + 46 8 544 98 995 or email: info@pencllic.se

All rights reserved of Bluetooth® is owned by Bluetooth SIG and is used under licence.

SPRÅK: ord på 13 språk

Svenska, norska, danska, finska, tyska, franska, spanska, italienska, holländska, portugisiska, turkiska och grekiska. + polska

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device complies with Industry Canada RSS-210 standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a PCB and maximum -1.2dBi gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.