


Powering your PhotoSpring


❶ Check all items




❷ Get kickstand and identify pointy heel




❸ Insert kickstand heel to device bottom-left




❹ Rotate down until it snaps in place




❺ Connect AC adapter




❻ Press power button 5 seconds



❼ Tap on Welcome screen to start device setup



❽ Remove kickstand by pressing tab and rotating up



Getting started with your PhotoSpring

Follow 3 easy steps to start enjoying your photos everyday:

- 1) Connect kickstand and power adapter.
- 2) Turn on PhotoSpring and follow setup instructions.
- 3) Create PhotoSpring account or use email to send photos and videos.

*Don't forget to invite family and friends
to send photos and videos to your PhotoSpring.*



Warranty Policy

PhotoSpring warrants to the original end user customer or purchaser of this Product ("You") that the Product is free from defects in material and workmanship, subject to the conditions stated herein, a period from the date of purchase of the product in its original sealed packaging until the expiration date of the Limited Warranty as specified in the Warranty Period. (If no proof of the date of purchase is provided, the warranty period will be considered to have started three (3) months after the date the product was manufactured.)

In the event PhotoSpring determines, in its sole discretion, that the Product suffers from material defects in manufacture and does not substantially conform to the published specifications under normal use, for as long as You own the Product, and subject to the conditions and exceptions stated in this Agreement, PhotoSpring will, at its option, either:

- (1) repair or replace the Product with a new or refurbished Product of equal or greater capacity, or another product of similar functionality; or
- (2) refund the current market value of the Product at the time the warranty claim is made to PhotoSpring if PhotoSpring is unable to repair or replace the Product.

Warranty Limitations

The warranty stated herein shall not apply if:

- (i) the Product was not used in accordance with all accompanying instructions,
- (ii) the Product was not used for its intended function and environment,
- (iii) any failure or defect arose out of the presence of a third party product, software or component, whether authorized or not,
- (iv) any failure or defect was the result of improper installation, misuse, unauthorized repair, modification or accident, and
- (v) there exist any other circumstances which PhotoSpring determines is evidence of a breach of this Agreement by You.

In addition, PhotoSpring is not responsible for any cost related to data recovery in the event of data loss to the Product.

This warranty does not cover Products which, by way of example, have been received improperly packaged, altered, or physically damaged. Products will be inspected upon receipt.

Welcome to your PhotoSpring

*Start enjoying all your photos and videos and
rediscover the moments you've been missing*

**Have questions? Need help?
We're here for you**

For support please visit
<http://photospring.com>
(click Support or Chat)

or contact us

Phone: 1-310-763-9091

Toll-free: 1-888-669-3624

Email: support@photospring.com



photospring

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Radio Frequency Interference Statement Warning:

To comply with the limits for an FCC Class B computing device, always use the shielded signal cord supplied with this unit. The Federal Communications Commission warns that changes or modifications of the unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canadian Doc Notice

For Class B Computing Devices This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the Radio Interference Regulation of the Canadian Department of Communications.

CE mark for Class B ITE

(Following European standard EN55022/1998; EN61000-3-2/1995; EN61000-3-3/1995, EN55024/1998, EN60950-1/2001)