
- At the prompt, INSERT FORM FOR RECEIPT, insert an envelope or postage meter tape sheet to print receipt.
- Press the C (Clear) key to return the postage to \$0.00.



Amount remaining in POSTAGE BY PHONE® — account at Pitney Bowes after transfer.



**After setting up the Meter**Use the Quick Reference Guide under the meter for How To's on:

- Adjusting the Display Contrast
- Changing the Date and Time
- Locking the Meter
- Printing Postage
- Replacing Ink Cartridge
- Using the Meter Ads/Messages



### read this first...

THE METER IS SHIPPED WITHOUT POSTAGE. You transfer funds to the meter as part of the setup

Choose an appropriate location for the meter Position the meter close to both a power and phone outlet. The meter must be plugged into a power outlet at all times.

**Make sure you have an analog telephone line** Some commercial phone systems use digital lines that may damage the meter. Like the meter, most fax machines, credit card readers and modems also require analog lines. The meter can share a line with these devices. When in doubt, ask the person responsible for your phone system.

**Unpack the Meter** Remove all contents from the shipping box and locate

> Do not attach the power cord to the meter until Step 7.









### **Troubleshooting**

- Black square lines display

   Unplug the power cord from the wall outlet.
- Remove the batteries. Wait 15 seconds; then plug in the meter. Reinstall batteries.
- Reset date and time using **Setup** key.

#### Display is blank

Ensure the power supply is plugged in. Examine pins on connector to see if any are bent or broken.

#### **REFILL FAILED - CHECK ACCT#**

The account number is noted in the top right hand corner of this

Press the  ${\bf Setup}$  key repeatedly until CHANGE POSTAGE ACCOUNT NUMBER? displays; press  ${\bf yes}.$ 

#### NO DIAL TONE

Ensure phone cord is plugged in both meter and wall. If it is, the telephone line may not be an analog line. Try using a fax machine line.

#### **CANNOT REACH DATA CENTER**

Check the number you have entered as a dialing prefix. Some phone systems require a pause between dialing the prefix and the number. Clear any error messages by pressing the **C** (Clear) key.

Use the decimal (.) key to enter a pause after the prefix.

Press the Setup key repeatedly until CHG PB PHONE #? displays; press **yes**. Key in a prefix, if needed, followed by 1-800-848-3764 (ex:9.1800 848 3764)

#### PRINTER JAMMED


The yellow shipping blocks have not been removed. Lift the cover and remove the two shipping blocks.

#### Still have questions?

Visit our Web Site at:

www.pitneyworks.com/metersupport to view FAQ's and Operators Guide or call us at 1-800-468-8454.

# **Postage Meter Quick Install Guide**



www.pitneyworks.com/metersupport

5

#### **Install Ink Cartridge**

- Lift the meter cover and remove the yellow plastic stop.
- Open the blue cartridge cover by squeezing the side tabs and pivoting the cover back.
- Remove the second yellow block from the lnk Cartridge holder.
- Pull the tape off the lnk Cartridge and place lnk Cartridge into meter.
- Snap blue cartridge cover in place.

 $\Lambda$ 

Use only Pitney Bowes ink. All other inks could damage the meter.







#### **Install Batteries**

- Remove the blue battery cover behind the printer by lifting up on the two tabs.
- Install all three batteries with the positive terminal (+) facing to the right. Replace the battery cover and close the meter cover.





## 7

#### **Connect Power**

- Connect the power cord to the meter with the arrow facing up.
- Plug the other end of the cord into an outlet that is not controlled by a switch or surge protector; there is no on/off switch on your meter.





#### **Prime Printhead**

- At the prompt, CANNOT FIND ZIP-REFILL REQUIRED, press Yes/Enter key.
- At the prompt, IMPORTANT-IS INK INSTALLED?, press Yes/Enter key. This will begin the ink loading process.

The meter displays the message PLEASE WAIT while it performs the maintenance process. This takes about three minutes.



#### Print Test

- At the prompt, INSERT FORM FOR PRINT TEST, insert a
  postage tape sheet or any envelope into the meter. Insert the
  envelope or tape sheet face up all the way into the slot and
  slide it to the right.
- At prompt PERFORM PRINTER MAINTENANCE press the No key if print test is okay and Yes/Enter if the print test fails.



Example of good test print - no missing horizontal lines or breaks in the vertical lines.

#### Initializing Setup

- Press the No key to all prompts except the following:
- At the prompt, INSPECTION REQUIRED, press C (Clear) key. Meter will display the date and the postage amount, press Setup key.
- At the prompt, CHANGE DATE?, press Yes/Enter key and enter the current date (mm/dd/yy), press the Enter key when finished.
- At the prompt, CHANGE TIME?, press Yes/Enter key and enter in the current time in HH:MM format. Press the Yes/Enter key when finished. You will be prompted for the A.M. or P.M. selection.
- If your phone system requires a dailing prefix such as "9" to obtain an outside line press the **Yes/Enter** key. Enter the dailing prefix plus the POSTAGE BY PHONE® number. (Example: 9.1.800.848.3764) If your system requires a pause between dailing the prefix and the number enter a decimal (.) for the pause.
- At the prompt, PB PHONE#?, the POSTAGE BY PHONE® DATA CENTER phone should be displayed. If you do not need to modify the phone number to include a dialing prefix press the No key.


**Note:** Some phone systems require a pause between dialing the prefix and the number.

- At the prompt, CHANGE POSTAGE ACCOUNT#?, press the Yes/Enter key.
- At the prompt, INSPECTION REQUIRED? press the C (Clear) key.

## A.

#### Add Postage to the Meter - Postage Refill

 Connect one end of the phone cord supplied to meter and plug the other end into a phone jack.



- Press the Refill key.
- Enter the amount of postage you wish to add to the meter in whole dollar amount. Press the Yes/Enter key. The meter automatically dials the data center and transfers funds to the meter.

If you receive the CANNOT REACH DATA CENTER OR NO DIAL TONE, see "Troubleshooting" on the back page. (Call waiting and voice mail beeps can disrupt funds transfers.)

(Step11 continues on back...)