

User Manual

Model Name: PF302

General Speaker Setup & Pairing:

- Select a BT 2.0 or above device (mobile phone or music player) for pairing.
- Turn on the Main Power Switch of PF302 at the back.
Remark: Make sure your PF302 has been fully charged.
- Activate your BT device to the searching mode (new device searching).
- Press and hold “Stand-by or Phone & Phone” key at the side of PF302 till the flashing of BLUE/RED LED, PF302 will have 3mins (searchable time) for your BT device to pair with.
- <<Plastoform PF302>> will be displayed in your BT device. Please select it for pairing. “0000” is the pairing code if necessary.
- PF302 will stop flashing & with a sound effect to specify it is paired with the BT device.
Remark: Pairing steps are for 1st time connection, simple steps could be done by either PF302 or your BT device in future use.
- Double check with your BT device to see PF302 is connected.
Remark: PF302 will also stop flashing with another sound effect to specify pairing failure after the 3mins. Repeat from the activation of your BT device to try again the pairing with PF302.

Connection & Operation (Music) Instruction:

- Turn on the Main Power Switch of PF302 at the back.
- To Power up the unit: Press “Stand-by or Phone” key at the side of PF302 till BLUE LED is on
Remark: Make sure PF302 has been fully charged & the Main Power Switch is on
- Turn on your BT device and select the connection w/ <<Plastoform PF302>>
- Play & Pause Music: Press “Stand-by or Phone” key at the side
- To play Next song: Press “>>|” key at the side
- To play Previous song: Press “|<<” key at the side
- To Fast Forward: Press & hold “>>|” key at the side
- To Rewind: Press & hold “|<<” key at the side
- To adjust the Volume: Adjust the volume level either in PF302 or your BT device
- To Power down the unit: Press the Stand-by or Phone key at the side of PF302 till BLUE LED is off
Remark: If HFP/HSP is available in your BT mobile ONLY (No A2DP), such as iPhone 2G, PF302 could perform as a speaker phone.

Operation (Speaker Phone) Instruction:

- To Answer a call: Press Any Key at the side
- To Reject a call: Press & hold “Stand-by or Phone” key at the side
- To Hang-up a call: Press “Stand-by or Phone” key at the side
- To Switch the call in between PF302 & mobile: Press & hold “Stand-by or Phone” key at the side
- To Answer Call Waiting (3rd Party): Double Press “Stand-by or Phone” key at the side

- To Toggle in between 3rd Party/Original call: Double Press “Stand-by or Phone” key at the side
- To Redial Last Calling number: Double Press “Stand-by or Phone” key at the side

Remark: PF302 could perform as a speaker phone, ONLY HFP/HSP is available in your BT mobile,

Battery Recharge & Firmware Upgrade Instruction:

- PF302 could be recharged in any status by USB power (thru the provided USB cable from PC; or from USB adaptor “Not included”)
- PF302 firmware upgrade is available thru USB cable from PC

LED indicator (on the Speaker):

- LED Off – Power OFF
 - BLUE LED ON – Power ON
 - Flashing of BLUE/RED LED – Pairing mode
 - RED LED ON – Low Battery Level
 - Flashing of RED LED – Almost No Power
 - Flashing of BLUE LED – Battery is Recharging
- Remark: No LED indication if Main Power Switch-off at the back

Specification:

- Total 6W output (3W / Channel)
- Full-range (35mm) driver / Channel + Passive Radiator
- Distortion <= 10 %
- S/N ratio:>75dB@1W
- Frequency Response: 200Hz – 15k Hz
- Li—polymer Batt: 1150mAh
- Playtime: 5hours in 80% Volume
- Recharging Time: 3hours
- (Optional) Power Adaptor: 5VDC @ 500mA

Compatibility (Bluetooth device)

- BT 2.0 or above device with A2DP/AVRCP/ HFP/ HSP

Trouble Shooting:

Sound not Clear or no sound	- Please check PF302 or BT device Volume Level
Playing Music Not Transfer from BT device to PF302	- Make sure your BT device has A2DP - Check if both devices are connected - Restart PF302 for auto-connecting with your

	BT device
LED No Power	<ul style="list-style-type: none"> - Make sure PF302 Main Switch is ON - Make sure PF302 is charged.
Sound is Too small / too much distortion	<ul style="list-style-type: none"> - Adjust the volume level of PF302 or BT device
Phone call Not Answer by PF302	<ul style="list-style-type: none"> - Make sure your mobile has HSP/HFP - Check if both devices are connected - Restart PF302 for auto-connecting with your BT device
No Music Resume after hanging up a call	<ul style="list-style-type: none"> - Press play to resume music
No Music Control by PF302	<ul style="list-style-type: none"> - Make sure your BT device has AVRCP

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.