

## Wireless keyboard with touchpad

Your new computer has a 2.4 GHz wireless keyboard with touchpad. It uses digital radio technology to ensure unhindered communication between the keyboard and your computer.

The transmission and reception of the keyboard are free from angle restrictions.

### Set up the keyboard

#### Step 1: Remove USB receiver

- Remove the USB receiver (1) from the bottom cover.

#### Step 2: Connect the USB receiver


- Plug the USB receiver dongle into a USB port on your PC.
- Your computer will take around 10 seconds to detect the keyboard.

#### Step 3: Press the power button (2) to turn on the keyboard

#### Low battery

The LED (3) will flash rapidly (on 0.5 sec; off 0.5 sec) for one minute.














To charge the battery, plug the USB charging cable (4) into a USB port while the computer is switched on.




ST.12300.041



Recyclable Paper

	Windows Key	Press to open the Start Menu
	Application Key	Press the Application key to open a context menu (same function as a right-click on a mouse)
	Previous Track	Skip to the previous track in the active player
	Play/Pause	Play or pause the track or video in the active player
	Stop	End the track or video in the active player
	Next Track	Skip to the next track in the active player
	Mute	Press this key to mute / unmute the audio
	Volume Down	Press this key to decrease the volume
	Volume Up	Press this key to increase the volume
	Sleep	Press this key to switch to standby mode (depending on the settings in the BIOS setup or operating system)
	Search	Activate the default Internet / file search function
	Email	Use this key to start the standard email program for your system
	Internet	Use this key to launch the standard browser for your system


Some of the following descriptions only apply to operating systems that support the functions, such as Windows® 7.



Standard mouse functions (move the cursor, click, double-click, and drag)



Scroll up or down by sliding two fingers on the touchpad.




Zoom in or out using two-finger pinch gestures.




Tap and hold two fingers on the touchpad to right-click.



Swipe two fingers to the left or right to go to the previous or next file.



Rotate one finger clockwise / counterclockwise while holding a second finger stationary to rotate images.



Flip-3D by three fingers sliding down.

**Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*FCC Caution:* Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.