



4

Automatic connection:
 • Green LED on Receiver = mouse movement
 • Red LED on Receiver = low battery

Install the driver.

5

TEST THE MOUSE

Try using the mouse. If it does not work as expected, make sure that you completed the following procedures as specified earlier in these instructions:

- Each battery is new and inserted correctly.
- The receiver is properly connected to the computer.
- The receiver and mouse are properly positioned within their wireless range.

If the mouse is still not working, try reconnecting the mouse to the receiver.

1

Press the button and open the battery door to insert one AA battery.

2

Slide out the USB receiver

On: Receiver In
 Off: Receiver Out

3

Once receiver is out, LED on mouse will light up

- GREEN light = battery good
- RED light blinking slowly = low battery
- RED light blinking rapidly = extremely low

6

TO RECONNECT THE MOUSE TO THE RECEIVER

1. Make sure that the mouse and receiver are positioned as specified earlier in these instructions.
2. Press the button on the wireless receiver, and then immediately press the button on the bottom of the mouse.

6-1. Press

6-2. Press

7

STORING THE RECEIVER IN THE MOUSE

1. For added portability or when the mouse is not in use, you can slide the receiver into its slot on the bottom of the mouse.
2. Power can be automatically switched off after the receiver fully stored.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference.
 (2) This device must accept any such interference that may be received and cannot be avoided.

The manufacturer has been notified and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment.
 This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If interference does occur, adjusting the antenna or the orientation of the mouse may help.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.