

SlimPort®
NANO·CONSOLE

QUICK START GUIDE

WELCOME TO YOUR

SlimPort®

NANO·CONSOLE

Sharing your screen with your SlimPort
NANO·CONSOLE is as easy as using your phone.
Use this quick start guide to begin.

HERE'S WHAT COMES WITH YOUR NANO-CONSOLE.

Battery Tray
(Inside the remote)




Batteries (2)
Type: CR2032 3V
(located inside the remote)




NANO
Remote



HDMI Cable




Tower



Micro-USB Charging Cable

Base




SETTING UP YOUR NANO·CONSOLE

Your NANO·CONSOLE is designed to hold your device as it connects to larger displays. One side of the base has a raised lip.


Attach the tower to the base so the writing on the top of the tower (“Slim**Port** NANO·CONSOLE”) reads from left to right when aligned with the lip.

The NANO Remote is designed to rest on the surface of the tower. See page 8 for more information on how to use the NANO Remote.



CONNECTING YOUR DEVICE TO THE NANO-CONSOLE


Plug the Micro-USB connector that is permanently attached to the NANO-CONSOLE into the Micro-USB port on your SlimPort-enabled device.



Tip: You can also charge your device by plugging the provided untethered Micro-USB cable into the NANO-CONSOLE and then into your device's USB wall charger as normal.



CONNECTING YOUR NANO-CONSOLE TO YOUR TV OR MONITOR



Connect your NANO-CONSOLE by running an HDMI cable from the HDMI OUT port on the NANO-CONSOLE to an HDMI IN port on your big screen.

To your device's wall charger or USB port on your TV

Tip: The NANO-CONSOLE includes an auxiliary port you can use to connect other devices that have a high-definition video output to your TV or monitor as needed. However, when a SlimPort-enabled device and another device are both plugged in, the NANO-CONSOLE will select the video from the SlimPort-enabled device to show on the big screen.

SlimPort-enabled Device




Other Device



SEEING YOUR SMALL SCREEN ON THE BIG SCREEN

Set the input on your TV or monitor to the HDMI port the NANO-CONSOLE is connected to. After a few moments, the device's screen should now be visible on the TV or monitor.



YOUR NANO REMOTE

The NANO Remote is how you interact with your device on the big screen. It's designed to mimic the experience of using your device in your hand.

Note: If your device is not running Android 5.1 or later, the Recent Apps button will not do anything when you press it.

Main Touchpad



Back Button

Home Button

Recent Apps Button

Battery Tray



(2) Batteries
Type: CR2032 3V
(located inside the remote)



Battery Tray



+/- Volume Button



LED Light




SETTING UP YOUR NANO REMOTE

The NANO Remote comes with two CR2032 coin batteries. To activate the batteries and power the remote, pull the plastic tab sticking out of the battery tray. This allows the batteries to power the remote.

Note: You should not need to remove the tray for this.



Note: There is no on/off switch on the NANO Remote; the remote will automatically go into sleep mode after 3 minutes of inactivity. It will wake up when you click on the touchpad.



CHANGING YOUR NANO REMOTE'S BATTERIES

When you need to replace the batteries, remove the tray, discard the old batteries and fit new ones into the tray with the + side facing down.


The battery tray only fits into the remote one way. If you try and put the battery tray in upside-down it will not slide in easily.



Note: With average use, the batteries should last approximately 3 months before needing to be replaced.

CONNECTING THE NANO REMOTE TO YOUR DEVICE


The NANO Remote connects to your device via a version of Bluetooth® called, Bluetooth Smart (also referred to as Bluetooth Low Energy). Once the batteries have been installed, hold the volume + button and the touchpad button simultaneously for **3 seconds**. The LED light on the remote will begin to blink. The remote is now Bluetooth discoverable.



Next, go to your device's settings panel and turn on Bluetooth. Wait a moment and the remote will show up as "NANO·CONSOLE Remote". Select the remote to connect and your remote will be connected to your device. You can now start using your NANO Remote to control your device.

Note: If your device's hardware or operating system does not support Bluetooth Smart, it will not be able to connect with the NANO Remote.

USING THE VOLUME BUTTON



The +/- Volume Button on the right side of your NANO Remote allows you to increase and lower the volume of your audio out from your phone.

Tip: Depending on your device manufacturer and the version of Android you are using, pressing the Volume Button will increase and decrease volume a little bit at a time, or it can turn on sound or mute the sound.

Fun tip: When using the standard Android camera app, pressing "+" on the Volume Button will take a picture. Your NANO Remote can be used as a selfie remote!

GETTING THE HANG OF THE NANO REMOTE



The touchpad of the remote works like the screen of your device. When using the remote, a cursor will indicate where your finger would be on the screen.

Click the main touchpad to reproduce a tap, click and hold to drag items and scroll through documents and screens.

Take a moment to practice clicking, dragging items, navigating from one screen to another and scrolling through documents. Using apps you're familiar with should shorten the learning curve a bit.

Fun fact: Our favorite way of learning the finer points of clicking, dragging and manipulating objects with the NANO Remote is playing Angry Birds!

THE LED LIGHT ON YOUR NANO REMOTE

The LED light on the front of your NANO Remote will blink several different ways to communicate different things.

- When the remote is woken up, it will blink **once**
- When the remote is in pairing mode, it will blink for **2 minutes**
- When the remote's batteries are low, it will blink rapidly for **3 seconds** every time you wake it up



TROUBLESHOOTING

If your device screen does not appear on the TV or monitor:

- Check that the HDMI cable is firmly and securely plugged into the HDMI OUT port of the tower and an HDMI IN port on your TV or monitor. Check that the Micro-USB cable from the tower is firmly and securely inserted into the mobile device.
- Check that the correct input is selected on the TV.
- Make sure your device's screen is on.

If you cannot view video from a device attached to the VIDEO IN port on the tower:

- Disconnect the SlimPort-enabled device from the NANO-CONSOLE to allow the tower to auto-switch to the VIDEO-IN port.
- If you are using an optional adapter to plug your non-SlimPort-enabled phone into the NANO-CONSOLE, check that the Micro-USB connector from the Micro-USB to HDMI adapter is properly inserted into the mobile device and it is the correct adapter for your device.
- Try steps from question 1 of this guide.

If you are streaming video from the Internet using a Wi-Fi network:

- For best results, try to use a 5 GHz Wi-Fi network instead of a 2.4 GHz Wi-Fi network. 2.4 GHz is a radio frequency that is used by Wi-Fi networks, Bluetooth devices, computers, microwave ovens, cordless phones, and many other electronic devices, which can cause interference and reduce Wi-Fi performance to your device.

If you are having trouble pairing the NANO Remote to your device:

- Make sure your NANO Remote is in Bluetooth pairing mode. In the Bluetooth settings screen on your device, press the “Search for devices” menu item so your device can look for the discoverable NANO Remote.
- Turn off Bluetooth on your device, turn back on Bluetooth on your device, and start the pairing process again.
- Another device may have been previously paired to the NANO Remote. Turn off Bluetooth on that previously paired device and start the pairing process again.
- Make sure your device supports Bluetooth Smart (also referred to as Bluetooth Low Energy).
- If you have just installed new batteries in the NANO Remote, check that the new batteries are installed correctly.

If the volume switch only turns the volume on and off (mute):

- Depending on your device manufacturer and the version of Android you are using, pressing the Volume Button will increase and decrease volume in steps, or it can turn on sound or mute.

For additional troubleshooting tips, Frequently Asked Questions (FAQs), customer support, and to sign up for the NANO-CONSOLE Email Newsletter, visit:

www.nanoconsole.com/support

SAFETY, COMPLIANCE, AND WARRANTY

United States

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Radiation Exposure Statement:

The product complies with the US/Canada portable RF exposure limit set forth for an uncontrolled environment and is safe for intended operation as described in this manual. Further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or the device is set to lower output power if such function is available.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance of this device could void the user's authority to operate the equipment.

Responsible party information
Analogix Semiconductor, Inc.
3211 Scott Boulevard, Suite 100
Santa Clara, CA 95054 USA
+1-408-988-8848

Canada

This device complies with RSS-247 of the Industry Canada Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Ce dispositif est conforme à la norme CNR-247 d'Industrie Canada applicable aux appareils radio exempts de licence.

Son fonctionnement est sujet aux deux conditions suivantes:

- 1) le dispositif ne doit pas produire de brouillage préjudiciable, et
- 2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable

Radiation Exposure Statement:

The product complies with the US/Canada portable RF exposure limit set forth for an uncontrolled environment and is safe for intended operation as described in this manual. Further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or the device is set to lower output power if such function is available.

Déclaration d'exposition aux radiations:

Le produit est conforme aux limites d'exposition pour les appareils portables RF pour les États-Unis et le Canada établies pour un environnement non contrôlé.

Le produit est sûr pour un fonctionnement tel que décrit dans ce manuel. La réduction des expositions RF peut être augmentée si l'appareil peut être conservé aussi loin que possible du corps de l'utilisateur ou que le dispositif est réglé sur la puissance de sortie la plus faible si une telle fonction est disponible.

Korea

해당무선설비는 전파혼신가능성이있으므로인명안전과관련된서비스는할수없음.
이기는가정용(B급) 전자파적합기기로서주요가정에서사용하는것을목적으려하며,
모든지역에서사용할수있습니다.

Taiwan

低功率電波輻射性電機管理辦法

第十二條

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

製造者：東莞東聚電子電訊製品有限公司

進口商：Analogix Taiwan Office

進口商地址：6F., No. 75, Zhouzi Street, Nei Hu District, Taipei 114, Taiwan

進口商電話：+886 2 8751 5196

Limited Warranty:

Analogix warrants to the original retail purchaser this product to be free from defects in materials and workmanship under ordinary consumer use for one (1) year from the date of original retail purchase. If this product is found to be defective within that time, we will repair or replace it. The warranty period is not extended if we repair or replace the product. This limited warranty does not cover accidental damage, wear and tear, misuse, neglect, fire, or other external causes, modifications, repair, commercial use, or consequential or incidental loss. Under no conditions is Analogix liable for loss of, or damage to devices; nor loss of, or damage to, programs, records, or data; nor any consequential or incidental damages, even if Analogix has been informed of their possibility. This limited warranty does not affect your statutory rights.

If you have any questions, comments, or concerns about your Analogix product or your limited warranty, please contact us.

Email: support@analogix.com

Web: www.nanoconsole.com/support



Bluetooth®
SMART



SlimPort®
NANO·CONSOLE

BEFORE RETURNING THIS PRODUCT

If you have any questions or concerns about your SlimPort NANO·CONSOLE, please go to www.nanoconsole.com/support for help, or email us at support@analogix.com.

©2015 Analogix Semiconductor, Inc. All rights reserved. SlimPort and NANO·CONSOLE logos are trademarks of Analogix Semiconductor, Inc.; SlimPort is a trademark of Analogix Semiconductor, Inc., which may be registered in various jurisdictions. Reg. U.S. Pat. & Tm. Off. Android is a trademark of Google Inc. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Analogix Semiconductor is under license. Angry Birds is a trademark of Rovio Entertainment Ltd. All other trademarks are the property of their respective owners. Patents pending. v072915