


EF-6309C Manual

1 Product parts



2 Operation Instruction

- 1、 Turn on FM radio inside car. Choose an empty FM channel. i.e 88.9 MHz.
- 2、 Insert accessory adaptor to car charge. And insert adaptor output to DC jack of transmitter.
- 3、 Insert the audio jack of transmitter to earphone jack of MP3、 MP4、 IPOD、 CD.
- 4、 Press MP3 or MP4 or IPOD or CD play button, Then Press and hold for one second for turn on the transmitter. The transmitter LCD show the last frequency used previous automatically.
- 5、 Press once briefly channel up/down button. Frequency adjust UP or down with step 0.1MHz. Press and hold button for several seconds frequency adjust with step 1MHz. Tune in the radio to the same frequency as the product such as 88.9Mhz.
- 6、 LCD display show frequency and with backlight. LED of backlight turn off automatically after 7 seconds operation stop. MP3 or MP4 or IPOD or CD player turn off or pause more than 1 minute Transmitter turn off automatically.
- 7、 Put the transmitter on the car radio side. Tune in the car radio to enjoy dulcet music.

3 Key and jack introduction

- 1、 Power Key — — Press and hold for one second for turn on or off transmitter
 - 2、 + Next Key — — Press once briefly channel up button. Frequency adjust UP with step 0.1MHz. Press and hold button for several seconds frequency adjust UP with step 1MHz.
 - 3、 - Previous Key — — Press once briefly channel down button. Frequency adjust down with step 0.1MHz. Press and hold button for several seconds frequency adjust down with step 1MHz.
 - 4、 DC jack — — connect the DC 3V car charge.
 - 5、 LCDdisplay — — Display the transmitter channel and battery capability.
 - 6、 audio wire — — connect the earphone jack of IPOD or MP3 or CD or MD.
- 4 Accessory: 3V adaptor(1PCS)

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interface, and (2) This device must accept any interface received , including interference that may cause undesired operation.