

# ELWN: FIT - TRUE WIRELESS - INSTRUCTION CARD

• 250GSM WHITE PAPER

OUTSIDE

BACK

FRONT




More Information At: [www.elwn.com/faq](http://www.elwn.com/faq)



**FIT**

Instructions:  
Pairing Earbuds To Mobile Device




DIE LINE


CENTER FOLD

INSIDE

## Pairing Earbuds




To Turn On, Press & Hold Power Button On Both Left & Right Earbuds

1. Press and hold the on/off button on both the left & right earbuds, and look for the blue light to indicate they have successfully turned on.
2. On your mobile device, access your Bluetooth settings. Make sure Bluetooth is in discoverable mode (On).
3. While wearing earbuds, select ELWN Fit True Wireless from the list of Bluetooth devices and listen for the pairing tone from your earbuds. This indicates that pairing is complete, and that you are ready to use your Bluetooth earbuds with your mobile device.
4. To confirm pairing is complete, look for the Bluetooth icon  in the status bar of your device.

## Troubleshooting

- Charge earbuds for at least 1 hour before using.
- Always keep earbuds within range while pairing for best results.
- If no indicator light is seen when pressing the on/off button, then recharge earbuds using the provided USB cable.
- To pair your earbuds to a new device, or to re-initiate pairing mode, press both volume buttons on the left earphone and hold down until the blue light starts flashing.

# INSTRUCTION CARD PLACEMENT



## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.