
REVISIONS					
ZONE REV DESCRIPTION		DATE	APPROVED		
A ADDITION OF OPTIONAL SEAL FAIL RELAY		1/11/15			
	В	ADDITION OF OPTIONAL LOW LEVEL ALARM	5/2/16		



MULTI-TAP TRANSFORMER
CONNECT FACTORY TAGGED WIRES TO L1 & L2 ON TERMINAL
BLOCK 3 AND CONNECT TO APPROPRIATE TRANSFORMER
PRIMARY VOLTAGE TAP. SEE BELOW FOR CONNECTIONS:

FOR 208V OPERATION, CONNECT L1 & L2 TO TRANSFORMER TAPS H1 & H2.

FOR 240V OPERATION, CONNECT L1 & L2 TO TRANSFORMER TAPS H1 & H3.

FOR 480v OPERATION, CONNECT L1 & L2 TO TRANSFORMER TAPS H1 & H4.

DASHED LINE INDICATES FIELD WIRING.

USE COPPER CONDUCTORS ONLY.

TEMPERATURE RATING OF CONDUCTORS IS TO BE 60°C (167°F).

BRANCH CIRCUIT PROTECTION SHALL BE PROVIDED BY THE INSTALLER: MUST BE SIZED ACCORDING TO PUMP/MOTOR MANUFACTURING SPECIFICATIONS.

VERIFY CORRECT OPERATION OF CONTROL PANEL AFTER INSTALLATION IS COMPLETE.

DRAWN BY:		DATE:	
	MM	11/1/14	
APPROVED BY:		DATE:	
			TITLE:

THIS DRAWING CONTAINS
PROPRIETARY INFORMATION
AND SHALL NOT BE USED
OR DISCLOSED WITHOUT
PRIOR WRITTEN
AUTHORIZATION.



WS3P-TP-300X CONTROL SCHEMATIC


 SIZE
 DWG NO.
 PART NO.
 WS3P-TP-300X
 REV

 B
 1524
 WS3P-TP-300X
 B

 SCALE
 NONE
 SHEET
 1 OF 3



	REVISIONS			
ZONE	REV	DESCRIPTION	DATE	APPROVED
	А	ADDITION OF OPTIONAL SEAL FAIL RELAY	1/11/15	
	В	ADDITION OF OPTIONAL LOW LEVEL ALARM	5/2/16	



MULTI-TAP TRANSFORMER
CONNECT FACTORY TAGGED WIRES TO L1 & L2 ON TERMINAL
BLOCK 3 AND CONNECT TO APPROPRIATE TRANSFORMER
PRIMARY VOLTAGE TAP. SEE BELOW FOR CONNECTIONS:

FOR 208V OPERATION, CONNECT L1 & L2 TO TRANSFORMER TAPS H1 & H2.

FOR 240V OPERATION, CONNECT L1 & L2 TO TRANSFORMER TAPS H1 & H3.

FOR 480 $\nu$  OPERATION, CONNECT L1 & L2 TO TRANSFORMER TAPS H1 & H4.

DASHED LINE INDICATES FIELD WIRING.

USE COPPER CONDUCTORS ONLY.

TEMPERATURE RATING OF CONDUCTORS IS TO BE 60°C (167°F).

BRANCH CIRCUIT PROTECTION SHALL BE PROVIDED BY THE INSTALLER: MUST BE SIZED ACCORDING TO PUMP/MOTOR MANUFACTURING SPECIFICATIONS.

VERIFY CORRECT OPERATION OF CONTROL PANEL AFTER INSTALLATION IS COMPLETE.

DRAWN BY:		DATE:	
	MM	11/1/14	
APPROVED BY:		DATE:	
			TITLE:

THIS DRAWING CONTAINS
PROPRIETARY INFORMATION
AND SHALL NOT BE USED
OR DISCLOSED WITHOUT
PRIOR WRITTEN
AUTHORIZATION.



WS3P-TP-300X
CONTROL SCHEMATIC

 SIZE
 DWG NO.
 PART NO.
 WS3P-TP-300X
 REV


 B
 1524
 WS3P-TP-300X
 B


 SCALE
 NONE
 SHEET
 2 OF 3





REVISIONS					
ZONE REV DESCRIPTION		DATE	APPROVED		
	Α	ADDITION OF OPTIONAL SEAL FAIL RELAY	1/11/15		
	В	ADDITION OF OPTIONAL LOW LEVEL ALARM	5/2/16		

## FIELD WIRING CONNECTIONS









MULTI-TAP TRANSFORMER CONNECT FACTORY TAGGED WIRES TO L1 & L2 ON TERMINAL BLOCK 3 AND CONNECT TO APPROPRIATE TRANSFORMER PRIMARY VOLTAGE TAP. SEE BELOW FOR CONNECTIONS:

112

113

114

117

118

119

122 123 124

FOR 208V OPERATION, CONNECT L1 & L2 TO TRANSFORMER

FOR 240V OPERATION, CONNECT L1 & L2 TO TRANSFORMER TAPS H1 & H3.

FOR 480v OPERATION, CONNECT L1 & L2 TO TRANSFORMER

DASHED LINE INDICATES FIELD WIRING.

USE COPPER CONDUCTORS ONLY.

TEMPERATURE RATING OF CONDUCTORS IS TO BE 60°C (167°F).

BRANCH CIRCUIT PROTECTION SHALL BE PROVIDED BY THE INSTALLER: MUST BE SIZED ACCORDING TO PUMP/MOTOR MANUFACTURING SPECIFICATIONS.

VERIFY CORRECT OPERATION OF CONTROL PANEL AFTER INSTALLATION IS COMPLETE.

DRAWN BY:		DATE:	
	ММ	11/1/14	
APPROVED BY:		DATE:	
			TITLE:

THIS DRAWING CONTAINS PROPRIETARY INFORMATION AND SHALL NOT BE USED OR DISCLOSED WITHOUT PRIOR WRITTEN AUTHORIZATION.



WS3P-TP-300X CONTROL SCHEMATIC

SIZE DWG NO. PART NO. REV В WS3P-TP-300X В 1524 3 OF 3 SCALE NONE SHEET

