

HEYPLUS OWS Manual


Product Accessories



Product Parameters

Model Name: HEYPLUS OWS
Bluetooth Version: V 5.3
Support Protocol: HSP/HFP/A2DP/AVRCP
Frequency Range: 2.40 ~ 2.48 Ghz
Horn Specification: 1510 16 ohm
Battery Capacity: 70 mAh (earphone) 600 mAh (storage box)
Playing Time: about 7 hours (earphone) 30 (storage box)
Charging Time: 45 minutes (headset) 2 hours (storage box)
Input: 5V/1000mA
Output: 5V 300mA
Charging Interface: TYPE-C

Schematic diagram



Function Description

Power On

1. Open the charging compartment cover to turn on the device.
2. Press and hold the MFB key for 2 seconds to start the device.

Bluetooth Connection

1. **First-time use connection:** After opening the storage box, the headset will automatically enter the Bluetooth pairing mode (red and blue lights flashing alternately); Search for "A12" on your phone and click to connect and pair.
2. **Successful pairing:** After successful pairing, the headset will turn off the red and blue lights, and at the same time, the headset will give a prompt tone of successful connection.
3. **Automatic reconnection:** After the first successful connection, the earphone will be turned on for about 6 seconds in subsequent use. Left and Right Back Connection to the Phone

Shut Down

1. When the device is powered on and not connected, touch and hold for 5 seconds to shut it down. Manual shutdown is not supported when it is connected.
2. Put the earphone into the charging compartment, close the cover to shut down the device.

Headphones Charging

1. Put the earphone into the charging compartment, close the compartment, and turn off the earphone.
2. Put the earphone into the charging compartment and close the cover for charging.

Open Bluetooth Headset

Charge for 10 minutes, use for 4 hours

Functional operation

Power On/Off:

When the storage box is opened, the earphone automatically turned on, and when the storage box is closed, the earphone turns off.

Music mode:

Play/Pause: Double-click function key

Previous Song: In play status, 3 consecutive clicks on the left ear function key

Next Song: In play status, 3 consecutive clicks on the right ear function key

Volume -: Press and hold the function button in the left ear to decrease the volume.

Volume+: Press and hold the function button on the right ear to increase the volume.

Call Mode:

Answer/End: Double tap the function key


Reject: press and hold the function key for 2 seconds

Game/Music Mode:

Standby State 3: Click the right ear function key repeatedly

Voice Assistant On/Off

Standby State 3: Click the left ear function key (the phone must support this function)



Bluetooth Pairing Connection

Bluetooth Pairing: After opening the storage box, the headset automatically enters the Bluetooth pairing mode (red and blue lights flash alternately); the phone searches for "Heyplus ows" and clicks to connect and pair.

(If the device is no found, please turn off the Bluetooth of the device and then turn it on again for re-search)


Successful Pairing: After successful pairing, the red and blue lights of the headset will turn off, and the headset will emit a prompt tone indicating a successful connection.

Automatic Reconnection: After the initial successful connection, the headset will automatically reconnect to the phone in approximately 6 seconds after being turned on.

Factory Reset

When the left and right earphones cannot be paired or connected to a device, you can reset them by following these steps:

1. Disconnect and delete the pairing information of "Heyplus ows" from your mobile phone.
2. Put both earphones in the charging compartment. (Make sure that the earphones are not in a low battery state. If they are low on battery, charge them for 5 minutes before performing the reset.)
3. Press and hold the reset button on the charging compartment for 5 seconds to initiate the headset reset. During the reset process, the LED lights on the charging compartment and the earphones will flash three times.
4. After resetting, close the charging compartment and charge the earphones to complete the reset process.



Cautions

1. Do not disassemble, repair or modify the headset for any reason, as it may cause fire, electronic breakdown, or permanent damage to the product.
2. Do not expose the product to excessively low or high humidity environments (below 0 °C or above 45 °C).
3. Do not look directly at the product indicator light when it is turned on, and keep it away from the eyes of children or animals.
4. Do not use this device in thunderstorm weather, as it may cause equipment malfunction or electric shock hazards.
5. Do not use strong chemicals, cleaning agents or harsh detergents to clean equipment or its accessories.
6. Do not put the equipment near heat sources or exposed fire sources, such as electric heaters, microwave ovens, ovens, water heaters, fire candles or other places that may produce high temperatures
7. Do not listen to music at a high volume for a long time to cause hearing damage. Please adjust the appropriate volume when using the equipment.
8. Do not attempt to replace the battery yourself. This device has a non-removable built-in battery, and self-replacement may damage the battery or the device. It is not recommended to replace it privately.
9. Do not contact the magnetic stripe card (such as bank card, telephone card, etc.) with the equipment for a long time, otherwise the magnetic stripe card may be damaged by the magnetic field.
10. Before cleaning and maintenance, stop using the device, close all applications, and disconnect all connections or cables from other devices.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

. Increase the separation between the equipment and receiver.
. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

. Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. RF Exposure Information

The device was evaluated to meet general RF exposure requirements. This equipment should be installed and used with a minimum distance of 0 mm between the radiator and your body.