

Safety: For safety information related to your battery charger terminal, see the information included with that product.

Product Support: For Technical Support or for help not available in this manual, contact the RGIS Service Depot @ 1-800-874-4841.

FCC Notice (United States): This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a commercial installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE Notice (European Notice): The Conformité Européenne symbol found on this product indicates compliance to the EMC Directive and the Low Voltage Directive of the European Union. This means that the product meets the following technical standards: EN 55022 (CISPR22), EN 55024 (CISPR 24) (IEC 61000 4-2, 4-3, 4-3, 4-5, 4-6, 4-8, 4-11), EN 61000 3-2 (IEC 61000 3-2), EN 61000 3-3 (IEC 61000 3-3), EN60950 (IEC 60950 3rd Ed; 1999; 2000).

Battery Notice: The sealed batteries that work with this product comply with all applicable shipping regulations as prescribed by industry and legal standards.

GETTING STARTED GUIDE

RGIS RM-1 Inventory Device

Rev 1.0

632-190001-00

Warnings and Precautions



WARNING: The RM-1 is designed with adequate safeguards to protect users from shock and other hazards when used as specified within this documentation. If users use the RM-1 in a manner not specified by this document, the protection provided by the RM-1 may be impaired. Please read the documentation before using the RM-1.




WARNING: The RM-1 device is designed to function with the Tyco battery pack number 610-180007-00 ONLY.




WARNING: The battery used in this device may present a risk of fire or chemical burn if mistreated. DO NOT disassemble, heat above 60c, crush or puncture, short circuit external contacts, or dispose in fire or water.

Class 2 Laser Products	<ul style="list-style-type: none"> Complies with 21CFR1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated July 26, 2001. EN60825-1:1994+A1:2002+A2:2001 IEC60825-1: 2001-08 Caution: Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous laser light exposure. Class 2 laser scanners use a low power, visible light diode. As with any very bright light source, such as the sun, the user should avoid staring directly into the light beam. Momentary exposure to a Class 2 laser is not known to be harmful. Complies with FDA standards for laser products except for deviations under Laser Notice 50, dated 7/26/2001.
Battery Operation	The battery voltage should be in the range 2.5V to 4.2V when inserted into the RM-1.
User Serviceability	Do not disassemble the RM-1 device. It contains no user-serviceable parts. Please return to the factory for repair.
Liquids	Avoid spilling liquids on the RM-1. Liquids spilled onto the RM-1 could short circuit it. If liquids are accidentally spilled, let the RM-1 dry before use. Rated IPX0.
Battery Disposal	Dispose of used batteries according to the manufacturer's instructions.
Battery Charger	Consult the manufacturer's operational manual for battery charger operational procedures.

Note: Typical performance at 73.4° F (23° C) on high quality symbols.




*Minimum distance determined by symbol length and scan angle





Shipping Contents





- RM-1 Inventory Device. Model Number: 610-190040
- Rechargeable Li-ion battery packs. Part Number: 610-180007-00
- RGIS RM-1 Getting Started Guide

Specifications
RM-1 Model: 610-1900040
Battery Model: 610-180007-00
Nominal Input Voltage Rating: 3.7 V dc  nominal
Operating Ambient Temperature: 0°C to +30°C (+32°F to +90°F)
Storage Temperature: -20°C to +70°C (-4°F to +158°F)

RM-1 Operation

1. Insert battery into the RM-1, ensuring the battery pack is latched properly.
2. Press the black power button on the side of the device. The RM-1 device will power on and display the RM-1 Inventory Menu.
3. To put the RM-1 into sleep mode, the user should “tap” the power button. The user can return the RM-1 unit into operational mode by tapping the power button again.
4. The user can cold boot the RM-1 unit by holding down the power button for approximately 8 seconds.
5. It is recommended that users put the RM-1 unit in sleep mode by tapping the power button prior to removing the battery pack.
6. Users should consult the RGIS RM-1 Users Guide for more detailed operational instructions.
7. Users should consult the RM-1 Battery Charger Guide for detailed operational notes for battery charging.





Repair Instructions

If the RM-1 Audit device is malfunctioning or technical issues arise, contact the RGIS Service Depot. Do not attempt to disassemble the RM-1 Audit unit without contacting the RGIS Service Depot.

RGIS Inventory Specialist
Attention: Service Depot
2000 East Taylor Road
Auburn Hills, MI 48308-1504
USA

Contact Number:
1-800-874-4841

