

## 1.6 User Manual

### BASIC OPERATIONS

#### **Pairing with your Bluetooth phone**

Pairing will create a unique and encrypted wireless link between two Bluetooth enabled devices, such as your Bluetooth phone and Bluetooth headset

- 1 Ensure that the headset is off (see **Turning the headset** on/off).
- 2 Press and hold the Multi-Function button until the lights Flash 3 times in blue
- 3 Set your Bluetooth phone to discover the headset by following your phone' s guide. Typically, the steps involve going to a 'Setup' , 'Connect' , or 'Bluetooth' menu on your phone and then selecting the option to discover Bluetooth devices.
- 4 Your phone will find the R200 headset and ask if you want to pair with it. Confirm this by pressing the Yes or OK key.
- 5 Enter a passkey or PIN, 0000 (4 zeros), then press the Yes or OK key.

**IMPORTANT:**If pairing was successful, the indicator light will flash in blue rapidly before going to flashing. If unsuccessful, the light remains on, and you will need to re-attempt pairing.

#### **Wearing the headset**

Wear the headset on your ear. In general, you will get better performance when there are no obstructions (including parts of your body) between the headset and the phone. Depending on what ear you are going to wear the headset, simply adjust the hook accordingly.



▲ Left



▲ Right

## Making a call

### **Making a voice activated call**

If the voice recognition feature is on, you can make a voice activated call.

1 Press the Multi-Function button once. You will hear the voice-activation tone.

2 Say the name of the person you wish to call.

Depending on your phone, this feature may not be supported.

### **Redialing the last number**

1 Press the Multi-Function button about 3 sec and listen for the voice-activation tone. To perform last number redial

**IMPORTANT:** Depending on your phone, you should press the Multi-Function button briefly or press and hold it to redial the last number.

## Ending a call

Press the Multi-Function button once.

## Answering a call

- After you hear the ring tone, press the Multi-Function button once.
- If you answer the call with your phone, you can transfer the call to a headset by pressing the Multi-Function button.

**IMPORTANT:** Do not hold the Multi-Function button down too long when making a call with your voice, ending, or answering a call. This should only be a quick tap.

## **Rejecting a call**

When you receive a call, press and hold the Multi-Function button for 3 seconds to reject the call.

## **Adjusting the volume**

Press [**▲**] on the side of the headset to increase the volume level and [**▼**] to decrease the volume level.

## **Safety approvals**

### **FCC**

#### **FCC ID:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Users are not permitted to make changes or modify the device in any way.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.