

13/2/06

**Remote Control Set Channel on Remote-**

• To set the channel of the remote, slide the CHANNEL switch to your desired channel number.

**Set Channel on the main unit-**

• To set the channel of the main unit, press MENU and touch "CH" to select the same channel number as the remote and then touch "HOME".

**Temporary temperature override -**

• With the Mode switch of the main unit in HEAT or COOL and the unit at the HOME screen, When the 8082C receives a remote command for a TEMPORARY adjustment, The MANUAL OVERRIDE screen comes on showing the new target temperature, and the temporary icon will be blinking. After about 15 seconds, the home screen will return showing the room temperature and the new target temperature.


The remote beeps to let you know it is working. The main unit beeps when it receives a remote command. The TEMPORARY icon comes on which shows the displayed Target Temperature is different from the programmed setting.

**To cancel the Remote temperature overrides -**

• Press the remote's "RESET" button once. The main unit will return to its program at the start of the next time slot.



**Beep Pattern**  
The remote beeps once and then 3 seconds later beeps 1, 2, or 3 times (depending on channel selection) and sends the signal. The thermostat beeps when it receives the signal.  
**Note:** The unit sends a one degree increment for each time you press the UP or DOWN arrow on the remote. Pressing the remote once per 3 second interval gives the unit time to respond to your command. Faster pressing can give unreliable results.



**To Replace Batteries in the remote -**

Open the compartment as shown. Insert the A23 (MN21) size battery as shown and then replace the cover closed.



**NOTE:** The remote control system for the 8082c operates on external "C" wire power only. The thermostat must be connected to the "C" wire or a 24vac power source for the remote to function. If your unit is operating on Batteries only, then the remote function is disabled to protect battery life.

**Remote Control frequency 312MHz:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the follow two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help