


XIJ-25364 2.4G Wireless Game Controllers User's Manual

1. Product information

Key Function



Mode and LED Indicator

Xinput :

Directinput

2. Applicable Description

(1) Application and Connection

PC : Windows XP/7/8/8.1/10

(2) Driver Description

PC : No need driver on Xinput mode except Windows XP , plug and play; If you need to open the vibration mode in DirectInput, need to install driver.

3. Operating Instructions



Power ON/OFF/sleep mode

- (1) Power on : (Press HOME to start gamepad.)
- (2) Power off: (Press "BACK"+"B" 5 seconds, the LED Indicator and ABXY back light turn off , the gamepad shutdown)
- (3) Sleep mode:(Wait for more than 5 minutes for no activate , light OFF, The gamepad is turned off)

Mode switch

Hold the HOME key about 5 seconds, to switch the mode between Xinput, DirectInput



Charge Indicator

- (1)No battery : LED indicator and ABXY backlight are OFF
- (2)Low battery : the lights flashing
- (3)Charging : the LED indicator flashes slowly
- (4)Full : If the gamepad in sleep mode ,the indicator will be off, In operation, the indicator shows the current mode

Operating menu

First connecting

- (1) Plug the receiver into the device, and open the device, the device will identify the receiver
- (2) Press HOME to start the gamepad
- (3) 4 LED Indicator flash , gamepad is pairing with the wireless receiver automatically
- (4) When the pairing is successful ,Will be one of the three Xinput , Directinput mode

(Note : If the pairing is unsuccessful, unplug the wireless receiver , turn off the gamepad and Repeat the above steps)


Automatic reconnect

gamepad is turned off under normal connection, but the wireless receiver is still working properly , Press HOME key to start the gamepad to quick connect automatically



Bursts

Press and hold the "TURBO" while pressing the button you want to bursts, such as: "TURBO"+"A", then A key feature is enabled bursts. to repeat above steps to cancel the bursts.



JD-Switch Function

(Press the BACK + LS(left stick), the function of D-pad and LS stick will be exchanged

Reset gamepad

When an exception occurs gamepad, such as Keys disorder, or crash, Unable to connect. Try to restart the device ` gamepad or select Reset gamepad

Reset mode : Insert into the hole on the back of gamepad with sharp article, Press the RESET button to reset the gamepad

Specification

Product Name	wireless 2.4G Gamepad	Product Type	XIJ-25364
Application	PC(Windows XP/7/8)	Operating Temperature	-20 °C ~ + 65 °C
		Humidity	20 ~ 80%
		Operating Mode	Xinput/DirectInput
Charging voltage	3.7~5V	Charging current	1A~2A
Charging duration	3~6h	working Current	Last 150mA
Size	155x110x60mm	Product weight	205g

Suggestion: Based on the characters of Li-ion battery, please charge the battery at least once every 6 months to achieve the maximum battery life span.

NOTE:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*** RF warning for Portable device:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.