433CTG



read this manual carefully before installing the product. Thank you for choosing an RCS product. You are recommended to RCS

CONTENTS

- TRANSMITTER INTRODUCTION

- 1A General information
- 1B Technical specifications
- 1C Main features
- 2 CODING
- 3 MEMORIZATION
- 4 BATTERY ACCESS

5 - TROUBLESHOOTING

1A - General information

synchronyzed transmitter and receiver. The operating frequency is any scanning and copying risk. A special algorithum allows to keep 433.92MHz. The receiver, RCS-433R, which opertes with this The code sent by the transmitter changes at each activation avoiding Ithas very high security coding systme. (KeeLoq Hopping Code) entry systems, anti-burgiar systems and access control systems The 433CTG has been designed for programmable telephone

> any type of access control system, equiped with this type of protocol. transmitter, has a Wiegand 26 bit format output, suitable with

it is a 12V 23A battery The L1028 Alkaline battery has a life of about 12 months

regulation as well as the Canadian CRTC regulations This product fully complies with Part 15 of the USA FCC

IB - Technical specifications

Supply: Number of keys 1 Alkaline 12V 23A battery

Battery life:

Current consumption :

Operating frequency:

433.92 MHz

13 mA

12 - 24 months

AM / ASK

Code combinations :

Rated e.r.p.: Modulation:


Operating temperature: Range in free space:

Overall dimensions:

Weight

-20 , +55 °C 61 x 36 x 16 mm 50 - 100 mW 100 - 200 m

1C - Main features



2 - CODING

Each transmitter is manufactured and sold with a different univocal serial number set-in-factory. The real transmitted code is the result of a special algorithm which combines a serial number, a manufacturer key and a synchronization number.


3 - MEMORIZATION

The transmitter security code, key code and facility code has to be stored onto the receiver. Your own installer or reseller will perform this operation during the installation or will give you the necessary instructions for proper memorization.

4 - BATTERY ACCESS

To access the battery take a coin and insert into slot on left bottom of transmitter and turn coin 1/4 turn. Insert the 1 Alkaline 12V battery with the negative side first towards the spring. Be sure the PCB board is in place before closing.

NOTE:Please dispose of the battery correctly, it is hazardous waste.



5 - TROUBLESHOOTING

The transmitter led blinks	The radio emission isn't verifiable The transmitter led is ON.	The radio emission isn't verifiable The transmitter led is OFF.	FAULT
Replace the transmitter battery	Check the receiver supply.	Replace the transmitter battery	SOLUTION

33CIG

① IC:5983A-T433CTG

② FCC ID : TG 6T433CTG

This device complies with Part. 15 of the FCC Rules Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept interference received, including interference that may cause undesired operation.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications

Any changes or modification not expressly approved by the party responsible could void the user's authority to operate the device.

Notice

Any changes or modification to RCS equipment not expressly approved by RCS could void the equipment warranty and/or guarantee.

GUARANTEE

The guarantee period of all RCS transmitter batteries is 6 months, beginning from the manufacturer date. During this period, if the product does not work correctly, due to a defective component, the product will be repaired or substituted at the discretion of the producer.

The guarantee does not cover the plastic container integrity.

REMOTE CONTROL SOLUTIONS, LLC

4862 E. Baseline Rd. Suite 104 Mesa, AZ 85206 USA Office: (480)-281-1878

Fax: (480)-281-1883
Web Site: www.rcsremotes.com
e-mail: info@rcsremotes.com