


Just  
**Wireless®**




FM Transmitter  
**USER'S MANUAL**  
C52-M

# OPERATION MANUAL



Play/Pause/Channel

# OPERATION MANUAL



## FEATURES

- 1 FM transmitter
- 2 Charges your device via USB power port
- 3 Supports USB drive
- 4 3.5mm jack aux-in function
- 5 LED display screen

## SPECIFICATIONS

- 1 Input voltage:12-24V, output power: 5V DC/2.4A
- 2 Supports MP3 and WMA format files

## FM TRANSMITTER FUNCTION

- 1 Plug the FM transmitter into your vehicle's DC power port.
- 2 Connect your device to your FM transmitter using the supplied 3.5 mm aux cable.
- 3 Tune your radio to an unused FM station, where you should only hear static, then match to the same frequency on your FM transmitter unit. To change frequency press the "▶ ||/CH" and hold until frequency on display is flashing, then press "▶" button to increase the frequency or press "◀" button to decrease the frequency. The FM transmitter will play music through your car stereo once the frequency is matched.
- 4 If using a flash drive containing MP3/WMA files, insert it into the **left** USB port (indicated by the "🎵" symbol), it will play the MP3 files automatically. Only the **left** USB port can serve as a USB reader.

## CHARGER FUNCTION

When unit is plugged in to your car's DC power port, connect your device to the USB power output port (indicated by the "⚡" symbol) with a compatible USB cable (not included).

*Note: You can play music while charging your device.*

## QUICK GUIDE

OPERATION GUIDE	FM TRANSMITTER
1. How to Play and Stop	Press "▶■/CH": Play music Second Press: "▶■/CH": Pause playback
2. How to adjust the Volume	Press and Hold "▶"Button: Increase Volume Press and Hold "◀" Button: Decrease Volume
3. How to change the channel	Press "▶■/CH" and hold until Frequency flashes, then press "▶" Button to increase the frequency, or press "◀" Button to decrease the frequency
4. How to choose music	Press "▶"Button: Play the next song Press "◀"Button: Play the previous song

## FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Just  
**Wireless**<sup>®</sup>

SKU 20086

REV022018