

# **♦** Charging

Plug the micro USB connector of the AC-USB adaptor into the micro USB port of the Wireless Tablet Folio Speaker.

- Note: 1. The charging LED light in Green and turn off when fully charged.
  - Don't use the emergency charger nor play music during charging the Wireless Tablet Folio Speaker.



# **♦** Emergency Smartphone Charger

- 1. Power on the Wireless Tablet Folio Speaker.
- Plug in the USB connector of the USB peripheral device to the A type USB port of the Wireless Tablet Folio Speaker.
  - Note: 1. The max. output of the Emergency Charger is DC 5V/0.5A.
    - Don't charge the Wireless Tablet Folio Speaker nor play music during using the emergency charger.
    - Make the Wireless Tablet Folio Speaker has fully battery power before to use this function.



## **♦ Part Names**



## Pairing

 Slide the power switch to the left to power on the Wireless Tablet Folio Speaker. The Power LED light in Green.



- 2. Find the device name "JS812-3" from the Setting \ Bluetooth of the tablet and pair with the Wireless Tablet Folio Speaker.
- 3. The B.T LED blink in Green during the BT transmitting.



### **♦** Feature

- Wireless Tablet Folio Speaker
- Non-stop music for 8~10 hours
- Low power consumption
- USB port A type for emergency charger function
- Tablet folio can fit almost all 10 " tablet (iPad series, Samsung Galaxy Tab2...)


## **◆** Specification

Item	Specification
Version	3.0
Connect Distance	10 meter
Paper Speaker	10 W
Built-in Battery	Li-ion Rechargeable 2200 mAh
Tablet Size	Fit almost all 10" table

CAUTION
RISK OF EXPLOSION IF BATTEY IS REPLACED
BY AN INCORRECT TYPE
DISPOSE OF USED BATTERIES ACCORDING
TO THE INSTRUCTIONS

#### Part Names





Federal Communications Commission (FCC) Statement

5 21

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected -Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1) this device may not cause harmful interference and

2) this device must accept any interference received, including interference that may cause undesired operation of the device.

#### FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.