INSTRUCTION MANUAL

Bluetooth Wireless Headphones Model:iB81

Warnnings

This appliance is intended for domestic household use only and should not be used for any other purpose or in any other application, such as for non domestic use or in a commercial environment.

Bluetooth Pairing Mode

- 1. Press and hold the Multi-function button on your iB81 headphones for about 5 seconds until the LED flash rapidly in blue and red and with voice prompts "Power on" and "Pairing", this indicates the headphones enter Bluetooth pairing mode.
- 2. Turn on the Bluetooth function of your device so it begins searching for a compatible device, 'iB81' should appear on your laptop, phone or music player's compatible devices list. You may also see a message such as 'Not Paired'. Tap on that message to complete the pairing process. If your device asks for a 'password' to complete the pairing process, enter '0000'.
- 3. When pairing is successful the blue LED indicator on iB81 headphones will remain 'On'. Your headphones are now ready for use.

Tip: If no device is paired within 3 minutes, the iB81 will exit the pairing mode and power off.

Bluetooth Auto-Linking Mode

- Press and hold the Multi-function button on your iB81 headphones for about 3 seconds until the blue LED indicator flash slowly, this indicates the headphones enter Bluetooth Auto-Linking Mode.
- 2. The headphones will pair with the last paired Bluetooth enabled device if there is any within the Bluetooth operation range.

Tip: Tip: If no device is paired within 3 minutes, the iB81 will exit the pairing mode and power off.

Switching the Power On and Off

- 1. Press and hold the Multi-function button for approximately 3 seconds until the LED indicator turns solid blue if linked or blinking blue if not linked. This indicates that the power is 'On'.
- 2. Press and hold the Multi-function button for approximately 3 seconds until the LED indicator turns red and then shuts off. This indicates that the power is 'Off'.

Aux Playback

1. Insert one port of an audio cable to the headphone and the other port to any audio device such as laptop, phone or music player.

Hands-free Call

- 1. Press the multi-function button shortly to answer the call when there is an incoming call.
- 2. Double press the multi-function button to reject the call when there is an incoming call.
- 3. Double press the multi-function button to redial last number you called..
- 4. Press the multi-function button shortly to end the call during a phone call.
- 5. Press the multi-function button twice to transfer the call between headphones and mobile phones.
- 6. Push the multi-function button up to volume up, vice versa.

Tips: Hands-free call functions only work when Bluetooth Connected.

Hands-free Call Waiting

- 1. Press the multi-function button shortly to answer the 2nd call when there is an incoming call during the phone call.
- 2. Press and hold the multi-function button for approximately 2 seconds to reject the 2nd call when there is an incoming call during the phone call.
- 3. Press the multi-function button shortly to end the 2nd call during the phone call.
- 4. Press and hold the multi-function button to transfer the phone conversations during two phone calls.
- 5. Double press the multi-function button to transfer the phone call between headphones and phone.
- 6. Push the multi-function button up to volume up, vice versa.

Charging the Headphones

The headphones have a built-in Lithium battery. The battery is rechargeable and provides approx 15-hour continuous operation when fully charged.

Use the charging cable to charge the speaker. The red indicator light will illuminate.

The red indicator light will go out when the headphones are fully charged.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

In order to comply with RF exposure requirements, a minimum distance of 5mm must be maintained between the antenna and all persons