Size: 153mm x 120mm Printing color: Black

Dec 14, 2012.







**Bluetooth Wireless** Stereo Speaker System with USB Charging



P1

# iBT25

### Introduction

Thank you for purchasing the iHome iBT25. This product is designed to provide high quality wireless sound for your iPad, iPhone, iPod, computer, PDA or other Bluetooth audio device.

Along with the included Quick Bluetooth Connection Guide this instruction booklet explains the basic operation and care of the unit. Please read them carefully and keep for future reference.

### Maintenance

- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other
  protective material should be placed between it and the furniture.
- Clean your unit with a soft cloth moistened only with mild soap and water. Stronger cleaning agents, such as benzene, thinner or similar materials can damage the surface of the unit.

iBT25

FCC ID: EMOIBT25 IC: 986B-IBT25

**FCC** Information

**FCC Radiation Exposure Statement** 

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This Device complies with RSS-102 of the IC Rules; Operation is subject to the following two conditions:

(1) This device may not cause harmful interference and

(2) This device must accept any interference received, including interference that may cause undesired operation. The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

QDID:B020415

### Information FCC

iBT25

IC: 986B-IBT25

FCC ID: EMOIBT25

### Déclaration de la FCC relative à l'exposition aux radiations

Cet équipement est conforme aux limites d'exposition aux radiations de la FCC RF fixées pour un environnement non contrôlé. Ce transmetteur ne doit pas être installé ou utilisé en conjonction avec une autre antenne ou un autre transmetteur.

Cet appareil est conforme à la norme RSS-102 de la règlementation d'Industrie Canada ; son utilisation est soumise aux deux conditions suivantes :

(1) Cet appareil ne doit pas causer d'interférences nuisibles

[2] Ce dispositif doit accepter toute interférence reçue, incluant l'interférence causée par une opération non désirée. Cet appareil répond aux critères d'exemption des limites d'évaluation courante indiquées à la section 2.5 de la norme RSS 102 et de conformité aux expositions aux radiofréquences de la norme RSS 102; les utilisateurs peuvent obtenir des informations sur l'exposition aux radiofréquences et la conformité au Canada.

Cet appareil est conforme à la section 15 des règlements de la FCC, son utilisation est soumise aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences nuisibles et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences qui peuvent causer un mauvais fonctionnement.

- Avertissement : Tout changement ou modification apporté à cet appareil sans le consentement expresse de la partie responsable pour la conformité peut annuler le droit de l'utilisateur d'utiliser cet appareil.
- REMARQUE: Cet équipement a été testé et jugé conforme aux limitations pour un appareil numérique de Classe B, selon la Section 15 de la règlementation FCC.

Ces limites sont conçues pour offrir une protection raisonnable contre les interférences nocives d'une installation résidentielle. Cet équipement génère, utilise et peut émettre des fréquences radio et, s'il n'est pas installé et utilisé selon les instructions, peut causer des interférences nuisibles aux communications radio.

Cependant, il n'y a aucune garantie qu'une interférence ne prendra pas place dans une installation particulière. Si cet équipement ne cause pas d'interférence nocive à la réception de la radio ou du téléviseur, ce qui peut être déterminé en allumant et fermant l'équipement, l'utilisateur est encouragé à tenter de corriger l'interférence en utilisant l'un ou l'autre des moyens suivants:

- Réorientez ou resituez l'antenne de réception.
- Augmentez la séparation entre l'équipement et le récepteur.
- Branchez l'équipement dans une prise d'un circuit différent que celui dans lequel est branché le récepteur.
- Consultez le marchand ou un technicien expérimenté en radio/téléviseur pour obtenir de l'aide.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

QDID:B020415


# iBT25

### Table of Contents

Included/ Meet Your iBT25
Setting Up the Unit/Turning the Unit ON and OFF
Using Bluetooth:Pairing Your Device
Playing Audio Via Bluetooth
Playing Audio Via Aux line-in
Charging Via USB Port/ Switching Grille Covers
Consumer Product Safety Guide 8-9
Troubleshooting 10
Warranty

# Included • iBT25 Speaker • Extra removable grille • Stereo 3.5 mm audio cable • 100V-240V universal AC adaptor iBT25 Speaker Extra removable grille Extra removable grille

Nov 05, 2012




### Setting Up the Unit

 Connect the included AC adaptor to the DC jack located on the back of the unit and connect the other end to a working wall outlet.

### Turning the Unit ON and OFF

- 1. Once the AC adaptor is properly connected, press the **Power Button** located on top of the unit to turn the unit ON. The blue power indicator on the front of the unit will light. Press the **Power Button** again to enter standby, or "green mode", which uses less power, but still allows normal operation. The blue power indicator will turn off. **Note** that if no audio is detected within 3 minutes when power is on, the unit automatically reverts to green mode.
- 2. *Press and hold* the **Power Button** for 2 seconds to turn the unit OFF.

# Using the iBT25



### Using Bluetooth: Pairing Your Device

NOTE: See the iBT25 Bluetooth Connection Guide for complete pairing details.

- 1. Turn on your Bluetooth-enabled device and turn on Bluetooth capability as described in the device's user manual.
- 2. Press and hold the Pairing Button (located on the back of the unit) for 2 seconds. The unit will turn on and attempt to auto link to a previously paired device for 10 seconds, indicated by the front and back indicator lights flashing blue. If a linked device is found, the indicator lights will glow solid blue.
- 3. If no linked device is found, the unit will enter pairing mode, and the lights will flash blue while the unit attempts to pair. "iHome iBT25" should appear on your device's menu. If "Not Connected" or similar message appears, tap on this to begin/complete pairing. If your device asks for a password, enter **1234** on the keyboard of your device. If no device is paired within 3 minutes, the unit will revert to its previous state. To retry pairing, follow steps 1 to 3.
- 4. Once paired with a device, the blue indicator lights will glow steadily and a confirmation tone will sound. There should be an indication on your device that pairing is complete. On some devices, you must then select "Use as Audio Device (stereo)" or similar on the device's Bluetooth menu. Once paired, your device should link to the iBT25 whenever within range.

### Pairing with a Different Device

When you power ON the speaker, it will automatically link with the previously paired Bluetooth device as long as that device is still within range (approx. 30 feet). So, to pair with a different device you must turn off the Bluetooth capability of the already paired device.


### Playing Audio Via Bluetooth

- Press the Power Button to turn on the unit. The front and back blue lights will flash as the unit searches
  for a previously paired device, and then turn solid blue once a previously paired device is detected.
  You can then listen to audio streamed wirelessly from your paired iPad, iPhone, iPod or other
  Bluetooth device.
- 2. Use the controls on your Bluetooth device to play or pause audio and navigate tracks.
- 3. Adjust the volume on the unit by pressing the **Volume Down Button** or **Volume Up Button**. You can also adjust volume on your device.
- 4. When done listening, press and hold the Power Button for 2 seconds to turn the unit OFF.

Note: Audio playing through the unit via the Aux line-in jack will be interrupted whenever Bluetooth audio is detected.

### Playing Audio via Aux In

- 1. Connect one end of the included 3.5mm stereo audio cable to the Aux line-in jack on the back of the unit and connect the other end to the headphone or line-out jack on your audio device.
- 2. Press the **Power Button** on the unit to turn it on.
- 3. Power on the audio device and use the controls on the device to play or pause audio, and navigate tracks.
- 4. Adjust the volume on the unit by pressing the **Volume Down Button** or **Volume Up Button**. You can also adjust volume on your device.
- 5. When done listening, press and hold the **Power Button** for 2 seconds to turn the unit OFF. Remember to turn off your audio device, too.




### Charging Devices via USB Port

- 1. Connect the standard size end of a USB cable (not included) to the USB Port on back of the unit and connect the other end to the charging port on your device.
- 2. Monitor the charging on your device. Some devices use a proprietary charging method and will not charge using the USB Port. If this happens, you must charge your device using the charger that came with it

### Switching Grille Covers

- 1. Gently pry the current grille away from the unit and set aside in a safe place
- 2. Carefully line up the other grille with the posts/holes/whatever there is and press gently into place.



# Consumer Product Safety Guide IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

- 1. Water and Moisture The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
- 2. Ventilation The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, which may impede the flow of air through the ventilation openings.
- 3. **Heat** The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
- 4. Power Sources The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
- 5. Power-Cable Protection Power supply cables should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. It is always best to have a clear area from where the cable exits the unit to where it is plugged into an AC socket.
- 6. Cleaning The unit should be cleaned only using a warm damp cloth. Do not use solvents, etc.
- 7. Objects and Liquid Entry Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.

- 8. Attachments Do not use attachments not recommended by the product manufacturer.
- 9. Lightning and Power Surge Protection Unplug the unit from the wall socket and disconnect the antenna or cable system during a lightning storm or when it is left unattended and unused for long periods of time. This will prevent damage to the product due to lightning and power-line surges.
- 10. **Overloading** Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
- 11. Damage Requiring Service The unit should be serviced by qualified service personnel when:
  - A. the power supply cable or plug has been damaged.
  - B. objects have fallen into or liquid has been spilled into the enclosure.
  - C. the unit has been exposed to rain.
  - D. the unit has been dropped or the enclosure damaged.
  - E. the unit exhibits a marked change in performance or does not operate normally.
- 12. **Periods of Nonuse** If the unit is to be left unused for an extended period of time, such as a month or longer, the power cable should be unplugged from the unit to prevent damage or corrosion.
- 13. Servicing The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to qualified service personnel.

Questions? Visit www.ihomeaudio.com or call 1-800-288-2792 Toll Free

## Troubleshooting

### Unit doesn't respond (no power)

- Check that all connections are correct and properly plugged in.
- Make sure your device is properly paired with the iBT25.
- Make sure the Power is ON, indicated by a solid blue light on the front of the unit.

### Trouble pairing device/computer with iBT25

Bluetooth implementation varies depending on your device's hardware and operating system. Please see our website for updates on pairing.

- Make sure you have the latest firmware for your device.
- Make sure your device is working properly. Check your device's manual for details on Bluetooth pairing and linking.
- When you power ON the speaker, it will automatically link with the last previously paired Bluetooth device if the device is still within range (approx. 30 feet). To pair with a different device you must turn off Bluetooth capability on the already paired device, or take it out of range.

For further information and to see the latest instructions, visit www.ihomeaudio.com/support

### Limited 1 Year Warranty

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of one (1) year from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center authorized by SDI Customer Service. The product must include proof of purchase, including date of purchase. An out-of-warranty fee for service will be charged for units that are received without proof of purchase

Before returning this product for service, please first replace the batteries (if applicable) with fresh ones, as exhausted or defective batteries are the most common cause of problems encountered.

batteries are the most common cause of problems encountered.
If service is still required:

1. Call SDI Customer Service at 1-800-288-2792 for Return Authorization and for the address of the Factory Service Center.

2. Remove the batteries (if applicable) and pack the unit in a well padded, heavy corrugated box. SDI is not responsible for damage that occurs during shipping to the Factory Service Center.

3. Enclose a photocopy of your sales receipt, credit card statement, or other proof of the date of purchase, if within the warranty period. Also include your name and address information, a brief description for why the unit is being returned, and the return authorization number. No unit can be processed without a return authorization number.

4. Write the return authorization number on the side of the shipping package and send the unit prepaid and insured to the Factory Service Center address authorized by SDI Customer Service.

Disclaimer of Warranty
NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products
which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by
unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players,
CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.
This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original
purchaser. In no event will SDI or any of its affiliates, contractors, resellers, their officers, directors,
shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits,
actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential
damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other
rights which vary from state to state.

Your acknowledgement and agreement to fully and completely abide by the above mentioned disclaimer of warranty is
contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI
product.

© 2012 SDI Technologies, Inc. All rights reserved Questions? Visit www.ihomeaudio.com or call 1-800-288-2792 Toll Free

iBT25-11052012-A Printed in China