

iBT371 QSG

Size: 120 x 100 (mm)

November 14, 2016

BACK

FRONT

iHome

Model: iBT371

QUICK START GUIDE

Bluetooth Pairing & Playing

- » Make your device "discoverable" by turning on Bluetooth mode.
- » Press and hold the **Power Button** for 2 seconds to turn on unit.

Pairing the First Time

- » The first time the unit is powered on it will enter auto-pairing mode.

Manual Pairing

- » Power on speaker
- » Press and hold the **Bluetooth Pairing Button** for 2 seconds.

- » Select "iHome iBT371" on your device's Bluetooth menu to complete pairing.
- » Control audio volume with **Volume Buttons**.
- » Control track navigation through your device.

Speakerphone

- » The speaker must be on and connected with a paired Bluetooth device to receive calls.
- » Press the **Bluetooth/Speakerphone Button** to answer call.
- » Press the **Bluetooth/Speakerphone Button** again to end call.

Contact Us: 1•800•288•2792

For warranty and full instructions visit: [www.ihome.com/support](http://www.ihome.com/support)

iHome


Model: iBT371

QUICK START GUIDE

CHARGE UNIT BEFORE USE - ABOUT 2 HOURS

In the Box » iBT371 speaker » charging cable

- » Connect the micro-USB plug on the included charging cable to the USB in charging jack on the speaker.
- » Connect the larger USB plug to a powered USB port such as a USB AC adapter.



LED Status indicator

- Flashing red = low battery
- Solid red = charging
- Red LED off = fully charged
- Flashing blue and red = pairing

Color Changing Modes

- » Press the **Color Mode Button** to cycle through modes:  
SLOW FAST FAVORITE COLOR PULSE TO MUSIC  
PRESET PULSE OFF

Waterproof Operation

- » For waterproof operation, ensure the waterproof cover on side of unit is pressed completely flush with the unit.

Contact Us: 1•800•288•2792

For warranty and full instructions visit: [www.ihome.com/support](http://www.ihome.com/support)

**FCC Information**

FCC ID: EMOIBT371

FCC Radiation Exposure Statement

IC: 986B-IBT371

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

**This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.**

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



IBT371Q5G-111416-A

Printed in China

**Internal Rechargeable Lithium-ion Battery**

This device uses an internal non-replaceable rechargeable lithium-ion battery that should last the lifetime of the device. If you suspect your battery may be dead, try charging it for an extended period of time and try resetting the unit. If this fails, contact Customer Service at 1-800-288-2792.

**WARNING/DISPOSAL OF UNIT**

Do NOT attempt to change the battery. Doing so will void the warranty and could cause injury and damage to your device. To dispose of the unit, follow the instructions below:

- Never dispose of used batteries/electronics with ordinary solid wastes, since they contain toxic substances.
- Always dispose of used batteries/electronics in accordance with the prevailing community regulations.
- Many electronics retailers now recycle batteries and other electronic components at no charge

**GENERAL BATTERY PRECAUTIONS**

- Never use or charge a battery if it appears to be leaking, discolored, deformed, or in any way abnormal.
- Never disassemble the unit or attempt to remove battery as that could cause leakage of alkaline solution or other electrolytic substances.
- Avoid charging a rechargeable battery when the temperature is not within 5°C - 35° C (41° - 95° Fahrenheit).
- Never expose a battery to any liquid.
- Never expose a battery to excessive heat such as direct sunlight or fire. Never use a battery pack in an unventilated vehicle where excessive internal temperatures may be encountered.
- Always keep batteries out of the reach of infants and small children.