

Front Cover


iHome

Quick Start Guide

Voice Activated Bluetooth Bedside Speaker System with USB Charging
Model: iGV1

What's in the box:

- iGV1
- Power adapter



What you'll need:

- Wi-Fi network
- Apple device running iOS 9.1 or later or Android 5.0 or later connected to your preferred Wi-Fi network


For full warranty and full instructions visit: www.ihome.com/support

Contact Us: 1-800-288-2792

Inside page

Setup Overview

- 1 Connect power adapter into DC jack on back of unit and plug into working wall outlet.



- 2 Download the Google Home app from the App Store or Google Play.




- 3 Follow in-app instructions for account setup and to establish your speaker's Wi-Fi connection.

- 4 Connect your Google account to enjoy the voice capability of your iGV1.

Questions? www.ihome.com
1-800-288-2792

Inside page

Controls



Play/Pause Button
Press to play/pause audio

Mute Button
Press to mute microphone

Bluetooth Button
Press to enter Bluetooth mode to pair devices

Volume Buttons
Press to adjust volume levels up or down

Track Buttons
Press to skip to next or previous track

Snooze/Display Dimmer Button
Press to cycle through four display dimmer settings: High, 3, 2, 1, and OFF.

Set up your default snooze time (for example, 10 minutes) using the Google Home app. When alarm sounds, press Snooze to activate the feature.

Google Home Button
The iGV1 features far field voice recognition. Google Assistant function can also be triggered by tapping the Google Home Button. Download the Google Home App for more features.

USB Port (back of unit)
While unit is connected to AC power, connect USB cable to charge devices

Back Cover

iHome

For warranty and full instructions visit: www.ihome.com/support
© 2018 SDI Technologies, Inc. All rights reserved.
Questions? Visit www.ihome.com or call 1-800-288-2792 Toll Free

IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read and follow all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

1. Water and Moisture - The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
2. Ventilation - The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, which may impede the flow of air through the ventilation openings.
3. Heat - The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
4. Power Sources - The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance. Only use the AC adapter that came with the unit.
5. Power-Cable Protection - Power supply cables should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. It is always best to have a clear area from where the cable exits the unit to where it is plugged into an AC socket.
6. Cleaning - The unit should be cleaned only using a warm damp cloth. Do not use solvents, etc.
7. Objects and Liquid Entry - Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.
8. Attachments - Do not use attachments not recommended by the product manufacturer.
9. Lightning and Power Surge Protection - Unplug the unit from the wall socket and disconnect the antenna or cable system during a lightning storm or when it is left unattended and unused for long periods of time. This will prevent damage to the product due to lightning and power-line surges.
10. Overloading - Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
11. Damage Requiring Service - The unit should be serviced by qualified service personnel when:
 - A. the power supply cable or plug has been damaged.
 - B. objects have fallen into or liquid has been spilled into the enclosure.
 - C. the unit has been exposed to rain.
 - D. the unit has been dropped or the enclosure damaged.
 - E. the unit exhibits a marked change in performance or does not operate normally.
12. No naked flame sources, such as lighted candles, should be placed on the apparatus*
13. The power adapter, used as the disconnected device, it is always best to have a clear area from where the cable exits the unit to where it is plugged into an AC socket
14. Periods of Nonuse - If the unit is to be left unused for an extended period of time, such as a month or longer, the backup battery should be removed from the unit to prevent damage or corrosion.
15. Servicing - The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to qualified service personnel.

FCC Information

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B)/NMB-3(B)

Canada Statement

This device complies with Industry Canada's licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage;
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device has been evaluated to meet general RF exposure requirement.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
Le dispositif a été évalué à satisfaire l'exigence générale de l'exposition aux rf.

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

Operations in the 5.15-5.25GHz band are restricted to indoors usage only.
The product integrates a transmitting antenna and does not allow replacement.

Les opérations dans la bande 5,15-5,25GHz sont limitées à une utilisation en intérieur uniquement.
Le produit comprend une antenne émettrice non remplaçable.