

# WiFi Docking Station Manual

## 1. Introduction

WiFi Docking Station is a device for 30K that charges and provides auto firmware upgrade.

WiFi Docking Station can automatically connect to the router through the mobile app, automatically download the latest firmware available for 30K, and can always upgrade to the latest firmware through comparing firmware version when the user plugs 30K into the USB port to charge.

## 2. WiFi Docking Station features


- Supports WiFi related IEEE 802.11b, IEEE 802.11g, IEEE 802.11n
- Smartphone App for iPhone and Android
- Firmware upgradeable

## 3. Contents

- Wifi Docking Station
- USB Cable
- DC Charger : Input – 100-240V~50//60Hz Max 0.3A, Output - 5V/1A
- Plug : UL/EU/UK/AU Types

## 4. Product description







## 5. Getting started

### a. Power On:


Insert the USB port into the charger and insert the Micro USB Port into the “USB power port”

### b. Connecting to WiFi


1. Open the mobile app



2. Connect to WiFi Docking



3. Setting WiFi Docking Station configuration




4. Select the WiFi router to connect to.



5. Enter the password of the selected WiFi router and click "Connect"




6. Wifi Docking Station is connecting to the router.
7. Click "Setup Complete" when connected



Connected to WiFi Network

Setup Complete

- 
8. After following these steps, Wifi Docking Station should be connected to WiFi. "WiFi status" LED will show blue light if the WiFi router is connected successful and show red light if there has been a failure to connect.
  9. To change the router connection, repeat the steps above.
  10. You can update Sena devices such as 30K manually and update WiFi Docking Station



**c. Charging 30K**

Plug in the Micro USB to 30K to charge the device. The "Charging status LED" will show red light while charging and turn blue when the device is fully charged.

**d. Upgrading Firmware**

Firmware will be upgraded automatically while charging 30K through checking the firmware version and downloading the latest firmware available.

"Firmware upgrade status" LED will show blue light when upgrade finished and blink while firmware is upgrading.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements.

The device can be used in fixed/mobile exposure conditions. The min separation distance is 20cm.