

# BT969CR 英文说明书



BC BT969CR

BT969CR : WIRE-FREE EARBUDS

English

## 1. Using your BT969CR True Wireless Earphones

Before use: Charge both earbuds by placing it inside the charging case and the earbuds will automatically charge once they are inserted.

**STEP 1** Turn off the Bluetooth function from your music device. eg.Mobile phone or music device.

**STEP 2** Fully charge the earbud and case. Take out the earbuds from the charging case after they have charged, it will turn on automatically, even it is not charging. If earbuds are not powered on, press and hold the power button on the two earbuds at the same time for about 2 seconds until the white light on earbuds start to flash. Then release

**STEP 3** Wait about 3-5 seconds for the two earbuds to connect to each other automatically. After the two earbuds are successfully paired, one earbud flashes a white light, the other earbud's light flashes once in 5 seconds, and the two earbuds will be paired successfully and prompts "connected", and the earbuds enter the waiting connection state and prompts "pairing". If the two earbuds are not pairing, both earbuds flash white. place both earbuds in the charging case, then remove them and wait for 3 seconds. One earbud flashes white, and the other earbud's light flashes once every 5 seconds and prompts "Connected", it indicates that the earbud reset is complete.

**STEP 4** You can now turn on the Bluetooth function of your mobile phone. Search and select BT969CR. Wait 5 seconds. Both earbuds will flash white every 5 seconds and a voice will sound "Connected".

## 2. Using your BT969CR True Wireless Earphones

**To use your Wireless Earphones After setting them up**

Turn off the bluetooth function on your phone or device and then Press the power-on button on both earbuds for 2 seconds at the same time to turn them on. Wait 3 seconds for them to connect to each other automatically. Autopair: Alternatively, if both earbuds are inside the charging case. Remove the earbuds from the case. A white light on earbuds will turn on indicating the earbuds are awake, wait 3 seconds, and it will be ready to pair with your bluetooth device. Then turn on your bluetooth function on your device and it should automatically pair with the BT969CR earbuds.

## 3. Turning off the earbuds

Press and hold the left earbud and right earbud at the same time for about 4 seconds and the earbuds will be powered off (Fig.1)

## 4. Charging the Earphones

a) Power off the earbuds and then put both earbuds inside the Charging Case.

b) The case will charge the earbuds automatically after you put both earbuds inside the charging case. When the earbuds are charging, the white light on earbuds and digital light are always on, the RGB light and the L/R flowing light is flashing. Before charging the earbuds make sure the charging case is fully charged - see point 5 below. Note: It will take approximately 2 hours to charge the earbuds. The Charging case will automatically stop charging when the earbuds are fully charged. When the earbuds are fully charged, the white light on earbuds, digital light, RGB light and L/R flowing light go off.

## 5. Case Charging

Plug the charging cable to the case. The white digital light on charging case and RGB light flashing indicates charging, charge for minimum 2 hours. (The charging case must be fully charged in order to charge the earbuds) When charging is complete, the white digital light will change to "OK" and RGB light go off.

## 6. Music functions

When you are listening to the music, short press the button on either earbud: one for music playing, one for music pause. When the earbuds are approaching very low battery power, one of the earbuds will turn off to save power while the other will continue to play.

## 7. Phone calls

Picking up a phone call - short press the button on the earbud to answer the phone call and short press again to end the call. Long press (2sec) to reject the call.

## Trouble Shooting

In the event that your True Wireless is not connecting to your device.

1) Make sure both earbuds are fully charged.

2) The music device is not more than 5 meters away from the phone and free from interference from other bluetooth devices.

3) If the earbuds are on, turn them off by pressing the power button for 4 seconds, and follow Steps 1 - 4 again to reconnect the earbuds and the phone.

## If only one earphone is working

1) Make sure both units are properly charged

2) The mobile or music device is not more than 5 meters away from the buds.

3) Reset your earbuds by following steps 1 - 4.

## If the volume is low

1) Turn up the volume on your device

2) Make sure the your mobile device is fully charged and within 5 meters range.



# WIRE-FREE EARBUDS

## If earbuds are not charging or not holding a charge.

1) Make sure the charging case is fully charged. See point 5

2) Place the earbuds inside charging case and the charging case will automatically charge the earbuds. When the white light on earbuds, the digital light is solid, RGB light and the L/R flowing light is flashing, it means that the earbuds are charging.

3) Always turn off the earbuds before putting them back in the charging case. Press the button on both earbuds for 4 seconds to power off. (Fig.1)

## If after some time, the earbuds are not pairing correctly.

1) Delete the earbuds from your phone by going to the phone's Bluetooth settings.

2) Reset the earbuds by placing them inside the charging case.

3) Follow Step 1-4 on the first page of this manual to re-pair your earbuds to your phone device. Also it is good to check that the earbuds and charging case are fully charged.

## Charging your device

Only use a power adapter with applicable country regulations and international and regional safety standards. Other power adapters may not meet applicable safety standards, and using such adapters could pose a risk of death or injury. Avoid prolonged skin contact with the charging cable and connector when the charging cable is connected to a power source because it may cause discomfort or injury. Sleeping or sitting on the charging cable or connector should be avoided.

## Important Safety Instructions

1. Read these Instructions.

2. Keep these Instructions.

3. Heed all Warnings.

4. Follow all instructions.

5. Do not use this device near water.

6. Clean only with a dry cloth.

7. Do not block any ventilation openings. Use in accordance with the manufacturer's instructions.

8. Do not charge near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

9. Discontinue use if damaged.

10. Protect the cord from being walked on or pinched particularly at plugs, convenience receptacles, to the point where they exit from the device.

11. Only use attachments/accessories specified by the manufacturer.

12. Unplug this apparatus during lightning storms and when charging is completed.

13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

14. Headphones are capable of producing sound levels which can be harmful to your hearing. Do not listen at high volume for prolonged periods of time.

Headphones may block out surrounding sounds.

Never wear headphones while operating a vehicle. Headphones may block out surrounding sounds.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Headphones may block out surrounding sounds.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

English

## Specifications:

• Model Number: BT969CR

• Bluetooth Version: 5.3

• Earphone Battery capacity: 25mah+25mah=50mah

• Case Battery capacity: 150mah

• Power Input: DC 5V/1A

• Protocol: A2DP/AVDTP/AVRCP/RFCOMM/HFP/HSP/SP/HID

• Works with Bluetooth enabled devices version 3 and below

• Communication system: Bluetooth Specification version 5.3

• Operating temperature: 0°C to 40°C

• Radio Frequency: 2.402 GHz-2.480 GHz

• RF Output Power: 3.14 dBm (Max)

Note: Playback and charge times mentioned are approximate and based on earbuds and case being fully charged, and playback at 50% volume. Playback and charge times may vary and performance may be affected by multiple factors including but not limited to battery conditions, ambient temperature, listening volume, and/or distance from the source audio device.

USB Type-C\* and USB-C\* are registered trademarks of USB Implementers Forum.

**Limited 90-Day Warranty:** Sentry warrants this product to be free from defects in materials and workmanship for 90 days from the date of original purchase. This warranty does not pertain to damage resulting from accident, abnormal use, misuse or neglect. Any defective product will be replaced if returned to an authorized Sentry dealer or to Sentry directly at: PO Box 885, One Bridge Street, Hillburn, NY 10931. Please enclose a \$5 check for return shipping.

**FCC ID: 2ACP4BT969CR Model: BT969CR**

Sentry Industries Inc declares that radio equipment BT969CR is in compliance with Directive 2014/53/EU. The EU declaration of conformity is available at <https://sentryindustries.com/european-declaration-of-conformity/>

Conformity with Directives This product is CE marked to denote conformity with Directives 73/23/EEC (low voltage) and 89/336/EEC (Electromagnetic Compatibility), as amended. Environmental Protection Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sentry Industries Inc. is under license. Other trademarks and trade names are those of their respective owners.



**Supplier's Declaration of Conformity 47 CFR 47 CFR Part 15.21, 15.105(b)**

**Compliance Information**

**Sentry Bluetooth Earphone and Headphone**

**Responsible Party -**

**Sentry Industries Inc**

**One Bridge street, Hillburn, NY 10931**

**Tel +1 845 753 2910**

## FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment!

English