

# 英文说明书



BC BTA255

fig 1.



ACTIVE NOISE CANCELLATION

## WIRE-FREE EARBUDS

### BTA255 : ACTIVE NOISE CANCELLATION WIRE-FREE EARBUDS

English

#### 1. Using your BTA255 True Wireless Earphones

Before use: Charge both earbuds by placing it inside the charging case and the earbuds will automatically charge once they are inserted.  
**STEP 1** Turn off the Bluetooth function from your music device, eg mobile phone or music device.  
**STEP 2** Fully charge the earbud and case. Take out the earbuds from the charging case after they have charged, it will turn on automatically, even it is not charging. If earbuds are not powered on, press and hold the power button (fig 1) on both earbuds at the same time for about 4 seconds until the blue light on the earbuds lights on first, and then the red and blue lights flash, indicating that the earbuds have entered pairing mode.

**STEP 3** Wait about 4 seconds for the two earbuds to connect to each other automatically. After the two earbuds are paired successfully, it prompts "pairing" and there is a "beep" sound, one of the earbuds will be flashing red-blue, and another earbud's light will be off. If both earbuds are not paired, both earbuds will flash red and blue lights, press the button (fig 1) on both earbuds 7 times in a row to reset the earbuds, you will hear a "beep" sound, wait for 10 seconds to pair automatically, then the red and blue lights of one earbud will flash alternately, and another earbud light will be off.

**STEP 4** You can now turn on the Bluetooth function of your mobile phone. Search and select BTA255. Wait 4 seconds. Both earbuds will have no lights flashing and a voice will sound "Connected", then it is ready to use with your device.

#### 2. Using your BTA255 True Wireless Earphones

**To use your Wireless Earphones After setting them up**

Turn off the bluetooth function on your phone or device and then Press the power-on button on both earbuds for 4 seconds at the same time to turn them on. Wait 4 seconds for them to connect to each other automatically. Autopair. Alternatively, if both earbuds are inside the charging case, remove the earbuds from the case. Red and blue lights on earbuds will turn on indicating the earbuds are awake, wait 5 seconds, and it will be ready to pair with your bluetooth device. Then turn on your bluetooth function on your device and it should automatically pair with the BTA255 earbuds.

#### 3. Turning off the earbuds

Press and hold the left earbud and right earbud at the same time for about 4 seconds and the earbuds will be powered off (Fig 1)

#### 4. Charging the Earphones

a) Power off the earbuds and then put both earbuds inside the Charging Case.

b) The case will charge the earbuds automatically after you put both earbuds inside the charging case. When the earbuds are charging, the red light on earbuds and blue digital light are always on, and the L/R flashing light is flashing. Before charging the earbuds make sure the charging case is fully charged - see point 5 below. Note: it will take approximately 2 hours to charge the earbuds. The Charging case will automatically stop charging when the earbuds are fully charged. When the earbuds are fully charged, both lights on earbuds and charging case will be off.

#### 5. Case Charging

Plug the charging cable to the case. Blue light on charging case flashing indicates charging, charge for minimum 2 hours. The charging case must be fully charged in order to charge the earbuds. The charging complete the blue flashing indicate will be change to solid and the number 100 is displayed.

#### 6. Music functions

When you are listening to the music, short press the button on either earbud: one for music playing, one for music pause. Press and hold the left earbud for 1 second to lower the volume, press and hold the right earbud for 1 second to increase the volume and a "beep" sound will be heard when the volume reaches the highest or lowest level and quick double click the button (fig 1) to switch between transparency mode (prompting "Transparent mode") and ANC mode (prompting "ANC ON" and "ANC OFF"). When the earbuds are approaching very low battery power, one of the earbuds will turn off to save power while the other will continue to play.

#### 7. Phone calls

Picking up a phone call - short press the button on the earbud to answer the phone call and short press again to end the call. Short press twice to reject the call.

#### Trouble Shooting

In the event that your True Wireless is not connecting to your device.

1) Make sure both earbuds are fully charged.

2) The music device is not more than 5 meters away from the phone and free from interference from other bluetooth devices.

3) If the earbuds are on, turn them off by pressing the power button for 4 seconds, and follow Steps 1 - 4 again to reconnect the earbuds and the phone.

#### If only one earphone is working

1) Make sure both units are properly charged.

2) The mobile or music device is no more than 5 meters away from the buds.

3) Reset your ear buds by following steps 1 - 4.

#### If the volume is low

1) Turn up the volume on your device

2) Make sure the your mobile device is fully charged and within 5 meters range.

#### If earbuds are not charging or not holding a charge.

1) Make sure the charging case is fully charged. See point 5

2) Place the earbuds inside charging case and the charging case will automatically charge the earbuds. When the red light on earbuds, the blue digital light is solid and the L/R flashing light is flashing, it means that the earbuds are charging.

3) Always turn off the earbuds before putting them back in the charging case. Press the button on both earbuds for 4 seconds to power off (Fig 1)

#### If after some time, the earbuds are not pairing correctly.

1) Delete the earbuds from your phone by going to the phone's Bluetooth settings.

2) Reset the earbuds by clicking both earbuds button (fig 1) 7 times.

3) Follow Step 1-4 on the first page of this manual to re-pair your earbuds to your phone device. Also it is good to check that the earbuds and charging case are fully charged.

#### Charging your device

Only use a power adapter with applicable country regulations and international and regional safety standards. Other power adapters may not meet applicable safety standards, and using such adapters could pose a risk of death or injury. Avoid prolonged skin contact with the charging cable and connector when the charging cable is connected to a power source because it may cause discomfort or injury. Sleeping or sitting on the charging cable or connector should be avoided.

#### Important Safety Instructions

1. Read these Instructions.

2. Keep these Instructions.

3. Read all Warnings.

4. Follow all instructions.

5. Do not use this device near water.

6. Clean only with a dry cloth.

7. Do not block any ventilation openings. Use in accordance with the manufacturer's instructions.

8. Do not charge near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.

9. Do not reuse use if damaged.

10. Protect the cord from being walked on or pinched particularly at plugs, convenience receptacles, to the point where they exit from the device.

11. Only use attachments/accessories specified by the manufacturer.

12. Unplug this apparatus during lightning storms and when charging is completed.

13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

14. Headphones are capable of producing sound levels which can be harmful to your hearing. Do not listen at high volume for prolonged periods of time.

Headphones may block out surrounding sounds.

Never wear headphones while operating a vehicle. Headphones may block out surrounding sounds.

Never wear headphones while operating a vehicle. Use with caution. User assumes all risks associated with the use of this product.

#### WARNING

-CAUTION: To prevent electric shock, use only compatible and certified USB charging devices.

-WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

-CAUTION: Use of controls or adjustments or performance of procedures other than those specified may damage your device.

-WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

-WARNING: Always store in a cool dry location.

-WARNING: Headphones are capable of producing sound levels which can be harmful to your hearing.

Do not listen at high volume for prolonged periods of time. Headphones may block out surrounding sounds.

Never wear headphones while operating a vehicle. Use with caution.

Do not use this product.

-WARNING: Don't over insert into ear canal. Discontinue use at the first sign of discomfort. Only use designed pads.

Do not use dirty or damaged ear pads.

Contains small parts that may present a choking hazard. Keep away from children.

English

#### Specifications:

- Model Number: BTA255

- Bluetooth Version: 5.3

- Earphone Battery capacity: 35mah-35mah-35mah

- Case Battery capacity: 200mah

- Power input: DC 5V/1A

- Protocol: A2DP/HFP/AVRTP/AAC/HSP/HSPSSP/SMP/ATT/GAP

- Works with Bluetooth enabled devices version 3 and below

- Communication system: Bluetooth Specification version 5.3

- Operating temperature: -40 °C to 85 °C

- Radio Frequency: 2.402 GHz-2.480 GHz

- RF Output Power: 1-14 dBm (Max)

Note: Playback and charge times mentioned are approximate and based on earbuds and case being fully charged, and playback at 50% volume. Playback and charge times may vary and performance may be affected by multiple factors including but not limited to battery conditions, ambient temperature, listening volume, and/or distance from the source audio device.

USB Type-C and USB-C are registered trademarks of USB Implementers Forum.

**Limited 90-Day Warranty** : Sentry warrants this product to be free from defects in materials and workmanship for 90 days from the date of original purchase. This warranty does not pertain to damage resulting from accident, abnormal use, misuse or neglect. Any defective product will be replaced if returned to an authorized Sentry dealer or to Sentry directly at: PO Box 885, One Bridge Street, Hillburn, NY 10931. Please enclose a \$5 check for return shipping.

**FCID: ZACP4BTA255 Model#BTA255**

Sentry Industries Inc declares that selling equipment BTA255 is in compliance with Directive 2014/53/EU. The EU declaration of conformity is available at <https://sentryindustries.com/european-declaration-of-conformity/>

Conformity with Directives This product is CE marked to denote conformity with Directives 73/23/EEC (low voltage) and 89/330/EEC (Electromagnetic Compatibility), as amended.

Environmental Protection Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sentry Industries Inc. is under license. Other trademarks and trade names are those of their respective owners.

CE RoHS BC FCC E

**Supplier's Declaration of Conformity 47 CFR Part 15.21, 15.105(b)**

#### Compliance Information

Sentry Bluetooth Earphone and Headphone

Responsible Party

Sentry Industries Inc

One Bridge Street, Hillburn, NY 10931

Tel: +1 845 753 2910

English

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.