





### Specifications:

Driver Unit: 52mm Sensitivity: 106dB+/-3dB Frequency: 20Hz-20KHz Impedance: 32+/-3ohms Playback: 4HR@50% volume CLASS 1 LED PRODUCT

Communication system: Bluetooth Specification version 5.3 Battery Capacity: 400mAh Operating Temperature: 0 °C to 40 °C Radio Frequency: 2 402 GHz-2 480 GHz

Note: Actual playback times and charge times are approximate and based on 50% volume, and the product is fully charged. Battery performance may be affected by multiple factors including but not limited to ambient temperature, listening volume, and/or distance from the source audio device. USB Type-C® and USB-C® are registered trademarks of USB Implementers Forum.

### Bluetooth Pairing/Connection:

Turn on the product. Bluetooth mode will be activated automatically. Enable bluetooth function on your media device. Search the bluetooth device named SPBTRGB. Click or tap to connect (pair). After successful connection (pairing), you will hear "connected" Now you can play music, or use bluetooth phone functions. Key Functions:

On/Off: Press and hold the & for 3 seconds to turn on/off. Music Pause: Press the ▶ button to pause playing, and press the ▶ again to resume playback. Volume Increase: Press and hold the but button, Volume Reduction: Press and hold the button

Next Song: Press the PH button. Previous Song: Press the PH button. Answer/Hang-up: Press the putton to answer when the call is incoming, and press it again to hang up. Rejection: Double click the & button then release it. Change mode: Press the & button to switch FM mode. Lighting control: Press the \* button to change the color of the light.

Disconnect: Press and hold the HII button for 3 seconds to disconnect the bluetooth.

## Solutions to conventional problems

- Unsuccessful connection and pairing
- 1. Check whether the speaker is in the search state, or reboot
- 2. Too many peripheral Bluetooth devices make searching difficult, turn off other Bluetooth devices
- 3. Check if there is any Bluetooth device connected to this machine around, it needs to be disconnected
- Low or distorted sound 1. Please charge the battery when the voltage is low
- 2. Check the volume of the Bluetooth device and adjust the volume to a suitable sound level(different songs have different decoding rates and different response sound effects)
- 3. Reopen the Bluetooth speaker and mobile phone digital device Bluetooth connection
- Music breaks

Whether it exceeds the effective connection distance of the speaker, or whether there is an obstacle between the speaker and the Bluetooth device

## Included Cables





To change divisor.

They the small side of the USBC cable into the usb changing port on your headset and plug the large ensistous bont on a computer, or a calapter (not included, SPRINGE, when the product is changing the LED light will keep in red color, when the product is fully changed the red LED light will be off

## Important Safety Instructions & Warnings

A USECDOSVIKE

Only use a power adapter with applicable country regulations and international and regional safety standards Other power adapters may not meet applicable safety standards, and using such adapters could pose a risk of death or injury.

Avoid projonged skin contact with the charging cable and connector when the charging cable is connected to a power source because it may cause discomfort or injury. Sleeping or sitting on the charging cable or connector should be avoided.

### Important Safety instructions

- - 1. Read these Instructions 2. Keep these Instructions
  - 3. Heed all Warnings.
  - 4 Followall instructions

  - 5. Do not use this device near water
  - 6. Clean only with a dry doth.
  - Do not block any ventilation openings. Use in accordance with the manufacturer's instructions.

  - 8. Do not charge near any heat sources such as radiators, heat registers, stoyes, or other apparatus (including amplifiers) that produce heat.
  - Discontinue use if damaged.
  - 10. Protect the cord from being walked on or pinched particularly at plugs, convenience receptacles to the point where they exit from the device. 11. Only use attachments/accessories specified by the manufacturer.
  - 12. Unplug this apparatus during lightning storms and when charging is completed.
  - 13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is
  - damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
  - 14. Headphones are capable of producing sound levels which can be harmful to your hearing. Do not listen at high volume for prolonged periods of time. Headphones may block out surrounding sounds.
  - Never wear head obones while one rating a whide Head obones may block out surmunding sounds

Never wear headphones while operating a vehicle. Use with caution, User assumes all risks associated with the use of this product.

CALITION: To prevent electric shock, use only compatible and certified USB charging devices.

WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

CAUTION: Use of controls or adjustments or performance of procedures other than those specified may damage your device.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the

WARNING: Always store in a cool dry location.

WARNING: Headphones are canable of producing sound levels which can be harmful to your hearing.

Do not listen at high volume for prologged periods of time. Headphones may block out summerfor sounds. Never wear headphones while operating a vehicle. Like

with caution. User assumes all risks associated with the use of this product.

WARNING: Don't over insert into ear ranal. Discontinue use at the first sign of discomfort. Only use designed packs Do not use dirty or damaged ear packs.

Contains small parts that may present a choking hazard. Keep away from children.

# 90-Day Warranty

Sentry warrants this product to be free from defects in materials and workmanship for 90-days from the date of original purchase. This warranty does not pertain to damage resulting from accident, abnormal use, misuse or, neglect. Any defective product will be replaced if returned to an authorized Sentry dealer or to Sentry directly P.O. Box 885. One Bridge St. Hillburn, NY 10931, Please enclose a check for \$5.00 for shipping & handling.

FCC ID: 2ACPASPRTRGR Model: SPRTRGR

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG,Inc. and any use of such marks by Sentry Industries Inc. is under license. Other trademarks and trade names are those of their respective

Sentry Industries inc declares that radio equipment SPBTRGB is in compliance with Directive 2014/53/EU. The EU declaration of confirmity is available at https://sentryindustries.com/european-declaration-of-conformity/ Confirmity with Directives

This product is CE marked to denote conformity with Directives 73/23/EEC (low voltage) and 89/336/EEC (Electromagnetic Compatibility) as amended

Environmental Protection Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist, Check with

your Local Authority or retailer for recycling advice.

Supplier's Declaration of Conformity 47 CFR 47 CFR Part 15 21 15 105(b)

Compliance Information

Sentry Bluetooth Speaker

Responsible Party -

Sentry Industries Inc

One Bridge street Hillburn NY 10931 Tel +1 845 753 2910

### FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful

interference, and (2) this device must accept any interference received, including interference that may cause undesired operation "NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the ECC Bules These

limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or

- more of the following measures:
- · Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

WARNING: To prevent possible hearing damage, do not listen at high volume levels for long periods. For traffic safety, do not use earphones while

driving or cycling. If you have a pacemaker or other electrical medical devices, you should consult your physician before using the product. Choking hazard: The product, packaging and some of the included accessories may present a choking hazard to small children. Keep these

accessories away from small children. The bags themselves or the many small parts they contain may cause choking if ingested.

Danger: Improper battery replacement may cause an explosion and injury.