






<p>FCCID:2AL9B-40011BT</p> <p>VIVITAR</p> <p>Bluetooth Earphones</p>  <p>Operation manual - VRT40011BT-FEX Please read the manual before operating this product.</p>	<p>Contents</p> <p>1 Introduction 1</p> <p>2 Package Contents 2</p> <p>3 Product Diagram 2</p> <p>4 How To Use 3</p> <p>4.1 General functions 3</p> <p>4.2 Pairing to mobile phone 4</p> <p>4.3 Charging your headphones 5</p> <p>5 Product Specifications 6</p> <p>6 FAQ 7</p> <p>Compatible with all Bluetooth® enabled devices</p> <p>The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc.</p>	<p>1.Introduction</p> <p>Congratulations, and thank you for choosing Vivitar Bluetooth Earphones. This manual will help you operate the Vivitar Bluetooth Earphones, but you should first familiarize yourself with the Bluetooth® functionality of your mobile phone or smart device before using it.</p> <p>Safety Rules</p> <ol style="list-style-type: none"> Please follow the rules depicted in this manual closely to ensure your safety. Before using the product, we would strongly encourage you to read through this user manual. Be wary of any edges, uneven surfaces, metal parts, accessories and its packaging to prevent any possible injury or damage. Do not modify, repair or dismantle the product. Doing so may result in fire, electric shock, complete breakdown of the product, etc. All of which are not covered under warranty. Do not use any diluent or volatile liquid to clean the product. Do not use the product in a hazardous location. 	<p>2. Package Contents</p>  <p>3.Product Diagram</p> 	<p>4.How To Use</p> <p>4.1.General Functions</p> <table border="1"> <thead> <tr> <th>Desired Result</th> <th>Required Action</th> </tr> </thead> <tbody> <tr> <td>Turn on & Enter the pairing mode</td> <td>Long press the Multi-Function Button.</td> </tr> <tr> <td>Pairing</td> <td>Use a Bluetooth® enabled mobile phone or other Bluetooth® enabled device to perform necessary pairing actions.</td> </tr> <tr> <td>Turn off</td> <td>Long press the Multi-Function Button.</td> </tr> <tr> <td>Charging</td> <td>Plug the Micro USB plug into the micro USB charging port.</td> </tr> <tr> <td>Answering a Call</td> <td>Press the Multi-Function Button to answer phone calls, press the Multi-Function Button again to end calls. Press two times will redial.</td> </tr> <tr> <td>Play / Pause Music</td> <td>When listening to music press the multi-function button to play music and press it again to pause music</td> </tr> <tr> <td>Vol-/ Previous Track</td> <td>Short press the - button for move previous song, long press for turn down the volume.</td> </tr> <tr> <td>Vol+/ Next Track</td> <td>Short press the + button for move next song, long press for turn up the volume.</td> </tr> </tbody> </table>	Desired Result	Required Action	Turn on & Enter the pairing mode	Long press the Multi-Function Button.	Pairing	Use a Bluetooth® enabled mobile phone or other Bluetooth® enabled device to perform necessary pairing actions.	Turn off	Long press the Multi-Function Button.	Charging	Plug the Micro USB plug into the micro USB charging port.	Answering a Call	Press the Multi-Function Button to answer phone calls, press the Multi-Function Button again to end calls. Press two times will redial.	Play / Pause Music	When listening to music press the multi-function button to play music and press it again to pause music	Vol-/ Previous Track	Short press the - button for move previous song, long press for turn down the volume.	Vol+/ Next Track	Short press the + button for move next song, long press for turn up the volume.
Desired Result	Required Action																					
Turn on & Enter the pairing mode	Long press the Multi-Function Button.																					
Pairing	Use a Bluetooth® enabled mobile phone or other Bluetooth® enabled device to perform necessary pairing actions.																					
Turn off	Long press the Multi-Function Button.																					
Charging	Plug the Micro USB plug into the micro USB charging port.																					
Answering a Call	Press the Multi-Function Button to answer phone calls, press the Multi-Function Button again to end calls. Press two times will redial.																					
Play / Pause Music	When listening to music press the multi-function button to play music and press it again to pause music																					
Vol-/ Previous Track	Short press the - button for move previous song, long press for turn down the volume.																					
Vol+/ Next Track	Short press the + button for move next song, long press for turn up the volume.																					
		1	2	3																		

<p>4.2.Pairing to a mobile phone</p> <p>To use your Bluetooth Earphones, you must first pair your Bluetooth Earphones to a Bluetooth enabled device. Once your Bluetooth Earphones are paired to a smart device, they will remain paired and automatically recognize each other whenever they are with in range.</p> <p>Pairing to a Bluetooth® Enabled Mobile Phone</p> <ul style="list-style-type: none"> Turn on your smart device/Phone and ensure the Bluetooth® function is turned on/activated. Long Press the multi-function button for 2-3 seconds and the LED lights will start to flash red and blue, you are now in pairing mode. In your Bluetooth® settings under search devices the smart device will list the "Vivitar 40011BT" Bluetooth Earphones as a discovered device, tap or select "Vivitar 40011BT" and your Bluetooth Earphones should now be connected. The Blue LED light will start to flash once you are paired successfully 	<p>4.3.Charging your headphones</p> <p>Use the Micro USB Cable provided with your Bluetooth Earphones. Connect the Micro USB plug to the Micro USB charging port on the Earbuds.</p> <p>Connect the USB plug to a USB port on a PC/Laptop or a wall adapter in order to start charging the Earbuds.</p> <p>* Make sure to charge the headphones for a minimum of 3 hours before initial use.</p> 	<p>5.Product Specifications</p> <table border="1"> <tr> <td>Driver Diameter</td> <td>10mm</td> </tr> <tr> <td>Frequency Range</td> <td>20Hz-20KHz</td> </tr> <tr> <td>Sensitivity</td> <td>98dB +/- 3dB</td> </tr> <tr> <td>Impedance</td> <td>16 ohms</td> </tr> <tr> <td>Bluetooth® Version</td> <td>4.2</td> </tr> <tr> <td>Power Supply</td> <td>Lithium Battery</td> </tr> <tr> <td>Battery Capacity</td> <td>80 mAh</td> </tr> <tr> <td>Receiver Distance</td> <td>max. 10m</td> </tr> <tr> <td>Charging Time</td> <td>2 Hours</td> </tr> <tr> <td>Playing Time</td> <td>2.5-4 Hours</td> </tr> </table> 	Driver Diameter	10mm	Frequency Range	20Hz-20KHz	Sensitivity	98dB +/- 3dB	Impedance	16 ohms	Bluetooth® Version	4.2	Power Supply	Lithium Battery	Battery Capacity	80 mAh	Receiver Distance	max. 10m	Charging Time	2 Hours	Playing Time	2.5-4 Hours	<p>6.FAQ</p> <p>1. Why is there no power even when the Headphones are turned on? Ans: Ensure the battery has been charged up to 2 hours for initial use.</p> <p>2. There is no sound during playback. Ans: Check the connection between the headphones and the phone or computer, if the connection is not established, please connect again. Make sure the headphones are paired with your Bluetooth® enabled device.</p> <p>FCC Statement</p> <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. 	<p>Vivitar One Year Warranty</p> <p>This warranty covers the original consumer purchaser only and is not transferable.</p> <p>This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.</p> <p>What is Not Covered by Warranty</p> <p>Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.</p> <p>To Obtain Warranty Service and Troubleshooting Information: Call 1-800-592-9541 in the U.S. or visit our website at www.vivitar.com.</p> <p>To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other item or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepai red.</p>
Driver Diameter	10mm																							
Frequency Range	20Hz-20KHz																							
Sensitivity	98dB +/- 3dB																							
Impedance	16 ohms																							
Bluetooth® Version	4.2																							
Power Supply	Lithium Battery																							
Battery Capacity	80 mAh																							
Receiver Distance	max. 10m																							
Charging Time	2 Hours																							
Playing Time	2.5-4 Hours																							
4	5	6	7	8																				