


## A Quick Look at Your Device



## Charging Your Earphones

Your earphones have a built-in, rechargeable lithium-polymer battery. To avoid damage, do not attempt to remove the battery. The full performance of the battery is only achieved after a few charging-discharging cycles. Charge the battery fully before first use. To do so, follow the steps below:

1. Connect one end of the included USB charging cable to the charging port on your earphones. Then plug the other end of the USB charging cable into a USB port on your computer or a suitable power adapter in order to recharge the internal rechargeable battery.

**NOTE:** The internal battery of your earphones takes approximately two hours to charge when completely drained.

2. When the battery is charging, the LED indicator light will turn red. The LED indicator light will turn blue when the battery is fully charged. Unplug when charging is complete.

**NOTE:** Overcharging could reduce the life of the battery. A charged battery will lose its capacity if it is not used on a regular basis.

### Important!

To avoid a complete discharge of the battery, charge your earphones at least once every six months.

## Pairing Your Earphones with a Bluetooth Device

Your earphones can be paired with most Bluetooth devices. In order to pair your earphones with a phone, follow the steps below:

1. Press and hold the "POWER" button until your earphones turn on. The LED indicator light will start alternately flashing red and then blue repeatedly. This indicates that your earphones are in pairing mode.

2. Go to the Bluetooth Manager of your Bluetooth device.

3. Search Bluetooth devices and select your earphones (most frequently listed as "Glow on the Go") to start connecting.

4. Enter "0000" if your device asks for the PIN code.

5. Once paired, the LED indicator light will slowly blink blue every few seconds.

**Note:** If pairing is not completed after an extended period of time, the earphones will power off. If this happens, repeat the pairing steps above.

## Using Your Earphones

### Powering Your Earphones On and Off

1. Press and hold the "POWER" button for several seconds to power on your earphones. If you have already paired your earphones to your Bluetooth device, they will automatically remain paired each time you power on your earphones.

2. Press and hold the "POWER" button for several seconds to turn power off your earphones.

### Listening to Music

- Play/Pause Button: Press to play or pause a track.
- Quickly tap the "Next Track/Volume Up" button to increase the volume.
- Quickly tap the "Previous Track/Volume Down" button to decrease the volume.
- Press and hold the "Next Track/Volume Up" button to advance to the next song in a playlist.
- Press and hold the "Previous Track/Volume Down" button to go back to the previous song in a playlist.
- Switching of Light Modes: When light is off, Press for 1s simultaneously +/- buttons for the light mode where the lights will blink. Press for 1s simultaneously +/- buttons to go into the second light mode where the light will light up in a solid, non-blinking mode. Press for 1s simultaneously +/- buttons again and the light will turn off.

### Using the Phone Function

- Last Number Re-dial: Press the ANSWER button twice to re-dial the last number called.
- Answering a Call: Quickly press the ANSWER button to answer an incoming call.
- Reject an Incoming Call: Press and hold the ANSWER button to reject an incoming call.
- Ending a Call: Quickly press the ANSWER button to end a call.

## FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment . This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.