

Wireless Presentation Remote and Receiver **InFocus® PresenterRF™**
Present Better!

CONFIDENCE. CONTROL. CREDIBILITY.

Confidence and credibility are critical to successful presentations. The InFocus PresenterRF puts slide control discretely in the palm of your hand. Move through your slides with confidence. Enhance credibility by highlighting crucial points with the laser pointer. Control your presentation from the most convenient location to interact with your audience.

The InFocus Presenter RF is optimized for operating PowerPoint. The four buttons are ergonomically arranged so they are easy to use without looking. Omni-directional 2.4GHz RF technology makes the remote operate reliably without pointing it at the projector. Every PresenterRF shares a unique address with its receiver to prevent interference from other remote controls. The result: the confidence and credibility that comes from knowing every slide will advance reliably at the moment you choose and the convenience of being able to fully interact with your audience.



LASER

Highlight your key points with the integrated laser.



FORWARD

Advance slides with one touch accuracy from up to 100'/30m away.



BACK

Return to the previous slide with ease.



BLANK

When you need the audience to focus on you, hide your presentation with the press of a button. Press again and slides reappear.

InFocus is a registered trademark of InFocus Corporation. All other trademarks are used with permission or are for identification purposes only and are the property of their respective companies.
©2003 InFocus Corporation. All rights reserved.

InFocus®

REMOTE SPECIFICATIONS

- o Range: Up to 100 feet (30m)
- o Radio: Personalized Address
- o Frequency: 2.4GHz
- o Dimensions: 2" x 4" x 1" (51mm x 102mm x 25mm)
- o Weight: Less than 2.3 ounces (140g)
- o Power: 2 AAA
- o Battery Life: 6 months typical
- o Laser: Class II Laser

RECEIVER SPECIFICATIONS

- o Interface: USB
- o Dimensions: 13/16" x 3 1/2" x 1/8" (21mm x 89mm x 11mm)
- o Weight: Less than .7 ounces (60g)
- o Power: 20 mA

SYSTEM REQUIREMENTS

- o Available USB Port
- o Windows® 98, 2000, ME, XP
- o Mac OS 8.x, 9.x, X
- o PowerPoint®, KeyNote®



HW-PRESENTER-RF



7 97212 60856 7

InFocus® PresenterRF™

Present Better!

Wireless Presentation Remote and Receiver

Works with Microsoft® PowerPoint®
PC and Mac compatible
2.4GHz radio technology



www.infocus.com

Thank you for buying an InFocus PresenterRF. At InFocus we continually strive to create innovative products that are reliable, easy to use and easy to manage, right out of the box. It's all part of our mission to create better ways for people to collaborate through digital projection technology. To achieve the full benefits of ownership, we encourage you to register your product.

Translations

To obtain a Chinese translation of this manual, go to the website below.

To obtain a French translation of this manual, go to the website below.

To obtain a German translation of this manual, go to the website below.

To obtain a Italian translation of this manual, go to the website below.

To obtain a Japanese translation of this manual, go to the website below.

To obtain a Korean translation of this manual, go to the website below.

To obtain a Spanish translation of this manual, go to the website below.

www.infocus.com/service/presenterrf

Declaration of Conformity

Manufacturer: InFocus Corporation
27500 SW Parkway Ave.
Wilsonville, Oregon 97070 USA

European Office: InFocus International BV
Strawinskylaan 585, 1077 XX Amsterdam
The Netherlands

We declare under our sole responsibility that the PresenterRF conforms to the following directives and norms:

Directive 89/336/EEC, Amended by 93/68/EEC
EMI: EN 55022 (1992) Class B
EMC: EN 50082-1 (1992)
Directive 73/23/EEC, Amended by 93/68/EEC
Safety: EN 60950: 2000

January, 2004

Copyright © 2004 by InFocus Corporation



Corporate Headquarters:

27700B SW Parkway Avenue
Wilsonville, OR 97070-9215 USA
Phone: 503-685-8888
Toll Free: 800-294-6400
Fax: 503-685-8887
www.infocus.com

P/N 90-71245

FCC Certification

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a CLASS B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, can radiate radio frequency energy and if not installed and used in accordance with the instruction guide, may cause harmful interference to radio communications. However, there is no guarantee that this radio interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

Re-orient or relocate the receiving antenna.

Increase the separation between the equipment and the receiver.

Consult the dealer or an experienced Radio-TV technician for help.

Notice: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Extension cables are not recommended, if used, they must be shielded in order to comply with the emission limits.


IC Certification

The term "IC" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

FIRST USE

Install Batteries in the Remote

Remove the battery cover by placing your thumb on the 3 ridges and press down sliding the battery cover off. Insert the batteries, paying attention to the battery orientation guide inside the battery bay. Set the battery cover onto the unit with the clasp positioned in the center. Then gently snap into place.



Connect the USB Receiver

Remove the protective cap. Insert the USB receiver into any available USB port on your computer.

Certain computers will display a message stating that it has "Found New Hardware" the first time you insert your USB receiver. Click "Next" to move through the device driver installation process. PresenterRF is now ready to use.

Set Initial Channel

The first time you plug in your receiver it attempts to learn to recognize your remote. Press either the Previous <, Next > or Blank ☆ button on the remote within the first 10 minutes of plugging in the receiver. Your receiver is now trained.








Notes: The computer must be running for the receiver to operate.










If another remote is used before yours, the receiver will learn that remote. If this happens, change channels as described below.

Resolving Interference

Several other types of products share the 2.4GHz radio band with PresenterRF. Sometimes, this can cause interference. PresenterRF comes with 4 different channels to help you avoid interference. If PresenterRF is not working reliably in a particular location, try changing channels.

This is a two-step process. First change the channel on the remote, then train the receiver. The process is detailed on the next pages.

Change Channel:		
Action	LED Signal	
1. Remove and replace one battery 		
2. Hold the Previous Button down for 10 seconds 		
LED will blink the number of the current channel Channel 1 Channel 2 Channel 3 Channel 4		
3. Tap the Previous Button to increase the channel by 1. Continue tapping until you reach the desired channel Example: Channel 1 + 2 taps = Channel 3 		
LED will blink the number of the current channel		

<p>4. Tap the Next Button to secure the channel you have chosen</p>		
Train Receiver:		
Action	LED Signal	LED Signal
<p>5. Remove and replace the USB receiver</p> 		
<p>6. Hold the Next Button down for 10 seconds</p> <p>When Receiver LED stays on, release button</p> 		
<p>Receiver LED will continue to blink</p>		

InFocus®