





# User Manual

Touchpad mini wireless keyboard



Thank you for your purchasing of our product, please read user manual carefully before using.

## Button Description



## Touchpad funtions




## Keyboard Description (一)



## Keyboard Description (二)



## Function key combinations



- Fn+F1** recover the signal between the keyboard and receiver
- Fn+Space** adjusting the mice sensitivity of touch-pad
- Ctr+Alt+Del** open the task manager
- Fn+F7** full desktop screenshot function
- Fn+F8** lock the touchpad
- Fn+F9** F11
- Fn+F10** F12
- Fn+PgUp** jumping to the beginning of the letter/text
- Fn+PgDn** jumping to the end of the letter/text
- Fn+F6** open/close the backlit of the keyboard

## Notes



In line with the policy of continued development, the manufacturer reserves the right to amend the specifications without prior notification. The pictures and data in the handbook are for reference only. If there is a discrepancy, the actual product shall prevail. Since devices using 2.4G technology communicate using radio waves, your device and the other devices do not need to be in direct line-of-sight. The connection can be subject to interference from obstructions such as wall, other electronic devices.

## Overview

This is a wonderful combo 2.4GHz Mini Wireless QWERTY keyboard, TouchPad combo with USB interface Adapter.

For the better sales, manager presenter from within a 30° radius make a presentation and operate PC, wireless. Change slides and screen operations on the screen, playback words and objects just by using this wireless Mini Keyboard and Mouse with Touch Pad.

Shenzhen Sungi Technology Co., Ltd  
Phone: 86-755-61587855  
Website: www.szsjung.cn  
Add: 4F, 20th BLD, Xixiweiyuan, Gushu, Bao'an district, Shenzhen, China



Support PC, Computer, Smart TV, Internet TV Box, Android TV Box, Projector, video teaching equipment, ect.

## Connecting the receiver

Slide the receiver out from the side of keyboard, and insert to the devices with a standard USB interface. Once connected, slide the power switch to the "ON" position located on the left side of the unit to establish the connection. Note: play to switch ON, will flash lights, and then the lights out ON the keyboard, receiver connected to the keyboard, success can be normal use of the keyboard, if you find lights flash or no flash, please check: A, the distance between the receiver and the keyboard is in the range of 10 m., B, the receiver is plugged into,

## Auto sleep and wake feature

The keyboard also features an auto sleep and auto wake mode. If there is a long period of inactivity, the keyboard will automatically go into a sleep mode. During the sleep mode, the user can wake the unit up by pressing any key. The 2.4 GHz receiver and keyboard's RF indicator will continue to flash and will not power down.

## Switching off the keyboard after use

After finishing using the keyboard, push the switch to the off position. This turns off the power of the keyboard. The USB receiver should be plugged out from the PC and then inserted back in the keyboard so it is being kept safety.

## Charging the battery (Only for Configure A)

The device with built-in lithium-ion battery, please use only approved data lines and chargers. Fully charge the unit before operating for the first time. This device can be used when charging, but will extend the charging time; When the battery is low, the low-voltage light will flash to warn the user. The unit will automatically turn off if the battery has been depleted. Notes: this product has A B C three configurations can choose, Configure A: lithium battery version, this version built in rechargeable lithium battery, additional charge USB line. Configure B: install AAA 2 battery, this version does not support the charging function, Configure C: Backlit version, this version is only suitable for lithium battery configuration. The receiver must be inserted to the backlit press the FN+F6 turn on backlit press the FN+F6 turn off backlit

Backlight dormancy: 1 minute not operation, automatically shut down; Backlight reset: press any key or touch start automatically. Backlit open working current: 12 mA Backlight color: cold blue highlight Backlit normal use time: about 30 days Backlit continuous working time: about 120 hours Backlit battery capacity: 6500 mA Charging time: 4-5 hours

## Low voltage alarm

Lithium electricity: below 3.0V low voltage alarm, orange light. Dry electric: below 2.0V low voltage alarm, orange light. Alarm way: on the left side of the first light, press keys or open, flashing 3 times.

## Appendix Technical parameters Specification

- Measurements (L x W x H): 152X126.5X18.5mm; 19mm
- Weight (grams): 148g
- Operational Range: up to 25 meters
- Transmit power: +4dB Max.
- Operation voltage: 3.3V
- Operation current: < 5mA
- Charging current: < 300mA
- Sleep current: < 1mA

## Troubleshooting

Below are some basic troubleshooting scenarios for the device. Please contact support from the place of purchase if you are unable to resolve any issues with the device.

Problem	Possible issue	Solution
Unit does not respond	1. Low battery power. 2. Unit is not turned on.	1. Configure A: Charge the device for at least 15 minutes. Configure B: Recharge/insert of the AAA 2 battery. 2. Check if the switch solicited to the "ON" position.
Keyboard cannot establish a connection to the receiver	1. The receiver may not be inserted correctly.	1. Disconnect and reconnect the receiver to the USB port.
The mouse pointer moves erratically and/or unresponsive.	1. Device may not be within optimal range of the receiver. 2. Low voltage. 3. Dust or oil on the touchpad.	1. Bring the unit closer to the receiver. 2. Please recharge for Configure A or replace the battery for Configure B. 3. Clean the touchpad with a damp cloth.
The unit does not charge only for Configure A.	1. Defective battery. 2. Check connectors.	1. Contact your local dealer for replacements. 2. Verify if the device is securely connected to the charger.
Unit does not respond (light flash)	1. The receiver may not be inserted correctly. 2. Keyboard cannot connect to the receiver (or).	1. Disconnect and reconnect the receiver to the USB port. 2. Verify if the device is securely connected to the charger.

## Computer system requirements

- Windows 2000
- Windows XP
- Windows Vista, Windows CE, Windows 7
- Linux (Debian 3.1, Redhat: 9.0 Ubuntu: 8.10 Fedora: 7.0 tested)

## Maintenance

- Do not attempt to disassemble the device or replace rechargeable battery. Doing so will void the warranty.
- The battery will discharge if stored for a long period of time without usage.
- Use the specified charger. Disconnect the device after the battery has been fully charged. Overcharging the battery will shorten the life span of the battery.
- Do not expose the device in extreme heat or cold. Extreme temperatures will cause the life span of the battery to shorten.
- Use only a damp cloth with mild soap to clean the device. Solvents and other cleaning agents may cause damage to the device.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID:2ABDB-T8K