

## Remote Control:GD-60



### User Manual:

1. Short press to take pictures, the buzzer ring twice, long press to switch 3 channels, cancel the side fly, the side fly function into the left and right rotation function, the buzzer ring with three
2. Short press is the speed switch, 1 file buzzer sound, 2 files buzzer sound 2, 3 buzzer sound 3 times, in the case of throttle is not zero long press the button to enter the flip mode, buzzer Drip often ring until the side of the fly after the direction of the operation after the release of the lever
3. Boot did not on the code when the power light slow flash, 2 light off, on the code after the light, low pressure flash
4. Short press the camera, the buzzer sound 2 times, again short press to lift the camera, the buzzer sound 1, long press to switch to 4 channel mode, buzzer sound 3
5. Throttle left and right swivel joystick
6. Left and right side fly, before and after the rocker
7. Short press the boot, the buzzer sound, IC wake from the sleep, waiting for the code, long press 2 seconds off, the buzzer twice
8. Before and after the fine-tuning, about fine-tuning, click the sound of loud, often ring back 1-2S

#### FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note 2: 1.Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2. The minimum separation generally be used is at least 20 cm.