

VA-HS002



www.vava.com

NORTH AMERICA

E-mail: support@vava.com

Tel: 1-888-456-8468 (Monday-Friday: 9:00 – 17:00 PST)

Address: 46724 Lakeview Blvd, Fremont, CA 94538

EUROPE

E-mail:

support.uk@vava.com(UK)

support.de@vava.com(DE)

support.fr@vava.com(FR)

support.es@vava.com(ES)

support.it@vava.com(IT)

EU Importer: ZBT International Trading GmbH, Halstenbeker Weg 98C,
25462 Rellingen, Deutschland

ASIA PACIFIC

E-mail: support.jp@vava.com(JP)

JP Importer: 株式会社SUNVALLEY JAPAN

Address: 〒104-0032 東京都中央区八丁堀 3 丁目18-6 PMO京橋東 9 F

MANUFACTURER

Shenzhen NearbyExpress Technology Development Co.,Ltd.

Address: 333 Bulong Road, Shenzhen, China, 518129




MADE IN CHINA




VAVA Home Cam
Quick Start Guide


What's in the Box




Camera




Base Station




Ethernet Cable




Camera Power
Adapter




USB Charging Cable




Base Station
Power Adapter




Magnetic Wall
Mount




Mounting Screws
& Anchors



Desktop Mount



Stand Mount




Quick Start Guide

Product Diagram




Base Station

- ① Speaker
- ② USB Port
- ③ Reset Button
- ④ LED Indicator
- ⑤ Power Port
- ⑥ Sync Button
- ⑦ Micro SD Card Slot
- ⑧ Ethernet Port



Camera


- ① Lens
- ② Light Sensor
- ③ PIR Motion Sensor
- ④ LED Indicator
- ⑤ Microphone
- ⑥ Speaker
- ⑦ Reset Button
- ⑧ Sync Button
- ⑨ Micro USB Charging Port
- ⑩ Mount Port
- ⑪ Magnetic Mount
- ⑫ Desktop Mount
- ⑬ Stand Mount




Get Started

Connect Your Base Station


1. Insert the TF card into the base station.



2. Connect the base station to your router with the included Ethernet cable.



3. Connect the base station to a power source.




Note:

The LED indicator on the base station will keep flashing red when connecting to the internet and turn solid white once successfully connected.


Charge the Camera

Please fully charge the camera before use to ensure longer working time.



Turn on the Camera

Press the Sync Button on the camera to turn it on. The LED indicator on the camera will stay solid on for 5 seconds then turn off.



Download the APP

Before using the device, please download the "VAVA Home" app on your smartphone or tablet from the App Store or Google Play.


Please follow the instructions in the app to register / log in your account, add the base station / camera.

Mount Your Camera


Install the camera on a shelf, wall, or any flat surface with our complete mounting set.

On the wall


Fasten the mounting screws into the wall and attach the magnetic mount. When you are mounting the camera to drywall, be sure to use the plastic anchors.



On the Stand Mount



On a desktop or a shelf



Specifications

Camera

| | |
|-----------------------------------|---|
| Lens | 140°Wide Angle, f / 2.2 |
| Sensor | IMX323, 1 / 2.9 inch |
| Resolution | 1080p |
| Night View | 2 x 850nm Infrared Light, Effective Range: 8m / 26.2ft |
| Microphone | Built-In |
| Speaker | 1.5W, 8Ω |
| PIR Detection | Detection Angle 110°, Effective Range: 7m / 23.0ft |
| Battery | 2500mAh Polymer Battery, 7.68V |
| Power Consumption in Standby Mode | ≤4mW |
| Adapter Power | 5V / 1.8A |
| Internet | 2.4G Wi-Fi, Effective Range 60m / 197.0ft (empty space) |
| Weather Proof | IP66 |
| Dimensions | 80.4 x 80.4 x 80.4 mm / 3.2 x 3.2 x 3.2 in |
| Working Environment | -20°C to 50°C / -4F-122F, RH≤95% |

Base Station

| | |
|---------------------------------|--------------------------------------|
| Speaker | 2W, 8Ω |
| Micro SD Card Memory | Up to 128G |
| Internet Connection | Wired Connection |
| Effective Range | 60m / 197.0ft (empty space) |
| Max Number of Connected Cameras | 4 |
| Adapter Power | 12V / 1.5A Max |
| USB Output | 5V / 2A |
| Dimensions | 95 x 95 x 95 mm / 3.7 x 3.7 x 3.7 in |
| Working Environment | -20°C to 50°C / -4F-122F, RH≤95% |

Button Controls

Camera

| Button | Function | Operation |
|--------------|----------------------------|--|
| Sync Button | Turn on the camera | Press once |
| | Pair with the base station | Press and hold for 5 seconds to enter pairing mode with the LED indicator flashing blue slowly |
| | Turn off the camera | Press and hold for around 10 seconds |
| Reset Button | Reboot the camera | Press once to reboot the camera without losing any data |

Note: The Sync Button is not functional during firmware upgrading.

Base Station

| Button | Function | Operation |
|--------------|-----------------------------|---|
| Sync Button | Add the Base station | Press and hold the Sync and Reset Buttons at the same time until the LED indicator flashes red and white alternately to bring the base station into pairing mode. |
| Reset Button | Restore to factory settings | Press and hold for 10 seconds |

LED Indicator & Working Status

Camera

| LED Indicator | Working Status |
|---------------------------------|-----------------------|
| Off | Sleep Mode/ Power Off |
| Flashes Blue Slowly | Pairing Mode |
| Flashes Blue Quickly | Paired Successfully |
| Flashes Red Slowly | Charging |
| Solid on in Red | Fully Charged |
| Solid on in Red for 5s then off | Powering On |

Base Station

| LED Indicator | Working Status |
|--|----------------------------|
| Solid On in Red and White | Powering On |
| Solid On in White | Connected to Internet |
| Flashes Red | No Internet |
| Flashes Red and White Alternately | Pairing Mode |
| Flashes Red and White at the Same Time | Restore to Factory Setting |

Caution

- Use the included power adapters only to charge the camera and the base station within the permitted voltage range.
- Only the camera is waterproof. The base station and adapters are for indoor use only.
- Make sure the internet is functional and fast for live data feed.
- Do not use the product at temperatures higher or lower than the specified range.
- Do not use in environments with strong electromagnetic interferences or near corrosive substances.
- The warranty does not cover defects and damages caused by misuse, unauthorized dismantling, or natural hazards.
- The battery life varies according to the frequency of the triggers and the video resolution settings.
- The PIR motion sensor can only detect motions within a certain ranges and will not be activated by motions out of the range.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help