Warranty

Supersonic Inc.("Supersonic") warrants this product to the original purchaser ONLY, to be free from defects in materials and workmanship under normal use, for ninety (90) DAYS from the date of original purchase. Proof of purchase (receipt) required. Please visit http://www.supersonicinc.com/warranty for additional information.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

IQsound® INSTRUCTION MANUAL



IQ-5308DJBT
Portable BT Speaker System

Product features

- •Ultra-low distortion amplifying circuit
- Digital karaoke, treble and bass independent adjustment
- Built-in MP3 encoding supporting U disk
- Unique acoustic


appearance design

- Professional treble and bass gain controlling circuit
- Built-in battery for outdoor activities
- •Professional high-effective

loud-speaking unit

- ◆Compatible to DVD/VCD/PC and other sound sources
- Suitable for adaptor and charging
- Intelligent power switch charging circuit

CONTROL PANEL



1. POWER VOLUME CONTROL

Turn to adjust the volume lo the desired level.

2. 5V DC INPUT

USB charging cable / Adapter input 5V/1A.

3. AUX INPUT

3.5mm Stereo jack can be used Jo connect a CD player, MP3player, smart phone and other audio sources.

4. Previous Track

Skip to previous track

5. | play/ pause/ scan(TWS)

Playing the music, press it to play and pause music FM is on, press it to auto searching the FM station TWS mode, press in 3 seconds to auto searching another pairing speaker

6. Next

Skip to next track.

7. → Mode/ LED

Press to change mode(FM, Bluetooth, AUX, USB), and long press 3 seconds to control the LED light.

8. USB PORT

USB entry port.

9. MIC INPUT

6.35mm (1/4") jack input for microphone.

10. DISPLAY

it is a display to show the function for example current MODE, Bluetooth, FM, USB, AUX, etc

BLUETOOTH:

Turn on the speaker, change the mode into "Bluetooth".

Activate your Bluetooth device, find the bearby pairing list,select IQ-5308DJBT, after "Ding", connnect successfully.

TWS Function

Connection: a mobile connect with a speaker(it is a main unit) by bt connection, turn on another bt connection from second speaker(subsidiary unit), then press and hold this "SCAN/TWS" button in 3 seconds on main unit that it can connect with subsidiary unit by TWS connection.

Warning

- 1. Do not place objects on top of the device, as objects may scratch the device.
- 2. Do not expose the device to dirty or dusty environments.
- 3. Do not insert any foreign objects into the device.
- 4. Do not expose the device to strong magnetic or electrical field.
- 5. Do not use the device in the rain.
- 6. Please check with your Local Authority or retailer for proper disposal of electronic products.
- 7. Do not disassemble the device. Only a certified service technician should perform repair.
- 8. The device has apertures to disperse heat. Do not block the device may become hot and malfunction as a result.

Common simple faults and guidance for operation and repair

Common simple faults and guidance for operation and repair		
Fault phenomenon	Simple fault analysis	Troubleshooting
Failing to electrify	The power switch is not	Open power switch
	opened	
	The electricity quantity of	Use power adaptor to
	built-in battery is totally	charge the battery
	consumed	
No sound	Failing to input sound	Change signal source
	source	
	Failing to establish signal	Reconnect signal line
	line	
	Main volume is switched	Properly adjust the volume
	to minimum	knob
	U disk playing has no	Inspect U disk or audio
	sound	switch
	Faults with external signal	Change signal source
	source	
	Poor contact or damage of	Readjust or change signal
	external signal line	line

If there is still fault after the inspection above, please contact the nearest local maintenance department! The product technology of our company is upgraded continuously and we will not inform of the change of product specification and function additionally!

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter