










#### Instructions:

1. Slide the Switch button  to power on or power off the device;
2. After power on, the device default mode is Bluetooth mode, you may pair this device to your mobile phone and play the music; and you can adjust volume by the button ;
3. Short press  to play or pause the music;
4. Press "Next" button  to skip to the next song, or press "Prev" button  to go back to previous song; If there is a telephone coming in during the Bluetooth mode, short press pause button to answer the phone by speaker; Otherwise press answer button on your mobile phone to answer the phone without Bluetooth speaker.
5. Press and hold the multifunction knob to switch the modes between blue tooth mode/TF card reading/USB reading/line-in/FM.
6. During FM mode, insert the charging cable to micro USB slot as FM

antenna; Short press multifunction button to start radio auto search and storing, Press "Previous" or "Next" to select the saved FM station;  
7.If the battery is low, you can hear voice"battery is low, please charge"from this device,please use your mobile's 5V wall charger to charge the device. The charging status LED will turn on in red once the device is in charging. And the LED will turn off after fully charged.

#### Specification:

Support BT/Aux/TF/USB/FM/Clock/Phone Cradle

Bluetooth Solution: V4.2

Output Power: 1x5Watts

Driver Size: 1 x  $\Phi$ 66 mm

Frequency Response: 150HZ-20KHz

Battery Capacity: 1200mAh

Play Time: 5-6 hrs (70% Volume)

Charging Time: 4 hrs

Casing: Plastic + Fabric covering

Overall Dimension: 248\*100\*109mm

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, Pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.