



User Manual

Wi-Fi 2.4G frequency range : 2417MHz for 11n(HT20)	
Senor	
Senor	CMOS, 1/5" color
resolution ratio	640*480 (300k pixel)
focal length	3.6mm
Lens focal diameter ratio	F2.4
viewing angle	60°
minimum illumination	1.0Lux@550nm
video	
Image coding format	H.264
image resolution;	VGA (640x480) / QVGA (320x240) /QQVGA(160x120)
Maximum transmission rate of image	25fps
Light frequency	50Hz、60Hz、Indoor and outdoor adaptive
V-REV	Vertical and horizontal image flip
AWB	SUPPORTING
Wireless	
network interface;	IEEE802.11n
antenna gain	2.0dB
Working model	AP
networking protocol;	
networking protocol;	TCP/IP, DHCP, SMPT, HTTP, DDNS, UPNP
working temperature	0 - 50C° , 20% - 80%
storage temperature	-10°C ~ 60°, 0% - 90%
working voltage	3.3V ~ 5V
working current	200mA ~ 250mA
OPERATION DISTANCE:	2-3M

Camera installation procedures:




1. Insert the camera's connector wire into the interface on the main body.




2. Aiming the camera at the interface on the main body and rotating the camera in anti-clockwise direction to make it screwed.

Camera dismantling procedures:



1. Rotating the camera in the clockwise direction.



2. Then taking out the camera upward and pulling out the connector

Search and install APP "WIFI GO", switch No of airplane, the green light will be flashing in 5 seconds, and search to the "FPV_WIFI__XXXX" in mobile phone set, so light keeping when WIFI is connected,

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Radiation Exposure Statement Caution: To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby persons.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.