

User manual

Wi-Fi 2.4G frequency range : 2412-2462MHz for 11b/g/n(HT20)	
Senor	
Senor	CMOS, 1/5" color
resolution ratio	640*480 (300k pixel)
focal length	3.6mm
Lens focal diameter ratio	F2.4
viewing angle	60°
minimum illumination	1.0Lux@550nm
video	
Image coding format	H.264
image resolution;	VGA (640x480) / QVGA (320x240) /QQVGA(160x120)
Maximum transmission rate of image	25fps
Light frequency	50Hz、60Hz、Indoor and outdoor adaptive
V-REV	Vertical and horizontal image flip
AWB	SUPPORTING
Wireless	
network interface;	IEEE802.11b/g/n
antenna gain	2.0dB
Working model	AP
networking protocol;	
networking protocol;	TCP/IP, DHCP, SMPT, HTTP, DDNS, UPNP
working temperature	0 - 50C° , 20% - 80%
storage temperature	-10°C ~ 60°, 0% - 90%
working voltage	3.3V ~ 5V
working current	200mA ~ 250mA

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the

equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.