Remote Controller Manual



Arm (Away Arm)



If you press Arm key , the alarm host would make a "System Arm" sound with arm indicator on, and all the defense zones would enter into Arm status;

Stav arm



If you press Stay arm key in , the alarm host would make a "System Arm" sound with Stay arm indicator on.

Disarm



If you press Disarm key , the alarm host would make a "System Disarm" sound with Disarm indicator on, and the system would enter into Disarm status:

SOS



If you press SOS emergency key SOS, the system would enter into Alarm status despite whatever status the system would be in before.

Technical Parameter:

- 1. Working voltage: DC3.V (button battery)
- 2. Working current: ≤15mA; Static current: ≤10uA
- 3. Working frequency: 433.92 MHZ
- 4. working temperature: -10 C~+50 C
- 5. Frequency deviation: ±0.2MHZ
- 6. Transmitting power: ≥10mW
- 7. Key description: Home 4 keys (Disarm, Arm, Stay arm and SOS)
- 8. Transmitting distance: ≥80m (in open air)
- 9. Coding mode: 1527

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AIT9-PF50