User's manual

CY-WDCB7UT

V1.0



CY-WDCB7UT 1 of 12

IMPORTANT SAFETY INSTRUCTUIONS

Please read and observe all warnings and instructions given in this manual and those marked on the unit before use of the unit.

A DANGER

- Avoid direct contacts to water, moisture, any sorts of beverages, excessive heat and magnetic sources.
- Do not handle the unit in with wet hands, especially when plugging or unplugging, to avoid electric shocks.
- Do not disassemble, modify, tamper or repair the unit yourself. Refer all servicing to qualified service personnel.
- 🜟 Do not drop or expose the unit to excessive shock.

AWARNING

- Keep the device out of direct sun light, wind, highhumidity and dusts.
- Plug in USB Transmitter properly. If reversely plugged, that may cause harmful damages.
- Do not place the unit on hot area or block the ventilator of the unit to avoid overheat.
- Do not relocate the unit while in use. That may cause malfunctioning of the unit.
- ★ Use the correct power source only.
- Never place the unit or AC adaptor on a heat sensitive surface

A CAUTION

- Never allow any liquids to spill into any part of your product, and never expose the product to rain, water, seawater or moisture.
- ★ Never operate the unit during a thunderstorm.

CY-WDCB7UT 2 of 12

FCC information

FCC notice 'Declaration of Conformity Information"

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna(s).
- 2. Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4 Consult the dealer or an experienced radio/TV technician for help

FCC Conditions

This equipment has been tested and found to comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Notice "Equipment Authorization" Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


This device is authorized under Title 47 CFR 15.519 (the FCC Rules and Regulations). The operation of this device is subject to the following restriction: This UWB device shall transmit only when it is sending information to an associated receiver. This UWB device shall cease transmission within 10 seconds unless it receives an acknowledgement from the associated receiver that its transmission is being received. An acknowledgement of reception must continue to be received by the transmitting device at least every 10 seconds of operation or the UWB device must cease transmitting.

CY-WDCB7UT 3 of 12

Contents

| 1. | Package Components | 5 |
|----|--|----|
| | | |
| 2. | Computer requirements | 5 |
| | | |
| 3. | S/W installation | 6 |
| | | |
| 4. | Connecting Wireless USB dongle to USB port | 8 |
| | | |
| 5. | Cautions | 11 |
| | | |
| 6. | CY-WDCB7UT specification | 12 |

1. Package Components



Wireless Connection Dongle



User Manual

2. Computer requirements

- ❖ 1.2 GHz or higher processor (Intel® Pentium®/Celeron® family, or AMD K6®/AMD Athlon™/AMD Duron™ family, or compatible processor recommended. Intel® Core™ 2 Duo 2.0 GB or higher processor recommended for optimal video performance.)
- ❖ 512 MB memory or higher (1 GB memory or higher recommended)
- ❖ USB 2.0 port
- ❖ 50 MB of available disk space
- ❖ Microsoft® Windows® XP (32-bit edition) with SP2/SP3, or Microsoft® Windows Vista® (32-bit or 64-bit editions) with SP1 or Microsoft® Windows 7® (32-bit or 64-bit editions).

CY-WDCB7UT 5 of 12

3. S/W installation

• Put the CD to computer CD driver which is provided.




- Click the installation program in the CD
- Install Wireless USB driver. Click Next




CY-WDCB7UT 6 of 12

• If you agree the agreement, click the "I Accept".



• Click the Next after addressing the installation path.



CY-WDCB7UT 7 of 12

• Click the finish and complete the wireless manager program.



• Reboot the computer after finishing the installation.

4. Connecting Wireless USB dongle to USB port

• Plug the USB dongle to the USB port in computer.



NOTE: you can use USB extension cable if your computer is desktop PC. Be careful there is no object between USB dongle and receiver.


• New hardware device installation message is showed in the tray. Please wait until completing of the installation.

CY-WDCB7UT 8 of 12

• If new device installation is completed, click the "wireless Connection Manager" for running the program. Then you can see the connectable monitors.




(Wireless Connection Manager icon)



CY-WDCB7UT 9 of 12

• If you select and click the monitor device and it becomes Connected Monitor. If you want automatic connection, click the right button of mouse and select "Set as default".





CY-WDCB7UT 10 of 12

5. Cautions

This device uses ultra high frequency radio. Therefore if there's an object like concrete wall or furniture etc, between USB dongle and receiver device, the radio performance will be decreased much. Any obstacle objects should not be between USB dongle and receiver. The operating range is 5~10m and it can be varied according the environment.

CY-WDCB7UT 11 of 12

6. CY-WDCB7UT specification

| CY-WDCB7UT | | |
|--------------------------|---|--|
| Model Name | CY-WDCB7UT | |
| Wireless Technology | UWB(Ultra Wide Band)/IEEE 802.15.3a | |
| Data rate | 53.3~480Mbps | |
| Band Group(BG) | 1,3,6(3.1GHz~8.9GHz) | |
| | (some of BGs are available based on country regulation) | |
| PC interface | USB 2.0 | |
| Power | USB self powered | |
| Operating System Support | Microsoft Windows XP with SP2 | |
| | Microsoft Vista 32/64 | |
| | Microsoft Windows 7 | |
| Operating condition | 5 to 35°C(41 to 95 °F) / 20 to 80 % relative humidity | |
| Non-operating condition | -20 to 65°C(-4 to 149 °F)/10 to 90% relative humidity | |
| Warranty | One-year limited warranty | |

CY-WDCB7UT 12 of 12