





- This manual's images and content may differ from the product.
- Check the product box for the following items. The supplied items may vary depending on the region. (Bluetooth Keyboard, AAA Battery, User manual)

Overview



Turning the device on or off

Slide the Power switch on to turn on the device.



To turn off the device, slide the Power switch off.

Connecting the device

To use with a mobile device, you need to pair it with the device. Once pairing is complete, the device attempts to reconnect each time you turn it on. For Pairing and while in use, both devices must be placed close together.

- 1 Activate the Bluetooth feature on the mobile device, and then scan for the device.
- 2 Select the device name **Samsung Bluetooth Keyboard** from the list of available devices. If the device does not appear on the list, turn the device off and back on again, and then press and hold the Pairing button (⌘) for 3 seconds.
- 3 With the device, type the confirmation numbers displayed on the mobile device, and then press the enter key.

Disconnecting the device

To disconnect the device from a mobile device, use the following options;


- Turn the device off.
- Deactivate the Bluetooth feature on the mobile device.



To end the current connection and pair with another mobile device, press and hold the Pairing button (⌘).

Using the device

Before using the keyboard, set the language to be used on the mobile device. For details about how to set a language, refer to the mobile device's user manual.



- This device is compatible with Samsung mobile devices that have Android version 4.4 or later.
- For upgrading the mobile device's software, refer to the device's user manual.

	Keys	Functions
1		Return to the previous screen.
2		Return to the Home screen.
3		Open the list of the recent applications.
4		Open the Applications screen.
5		Open the list of options available for the current screen.
6		Adjust the brightness of the display.
7		Adjust the volume.
8		Control the media file playback.
9		- Launch Google. Fn +  : Launch S Finder.
10		- Capture a screenshot and save it. Fn +  : Display Multi Window Panel.

	Keys	Functions
11		Show or hide the on-screen keyboard.
12	Lang	Change input language.
13		Move cursor or system caret; Fn +  : Page Up Fn +  : Page Down Fn +  : Home Fn +  : End



Safety information

To prevent injury to yourself and others or damage to your device, read the safety information about your device before using the device

Do not touch the power cord with wet hands or disconnect the charger by pulling the cord

Never crush or puncture the device

Do not insert the device or supplied accessories into the eyes, ears, or mouth

Do not store your device near or in heaters, microwaves, hot cooking equipment, or high pressure containers

Do not use your device outdoor during a thunderstorm

Do not store your device in very hot or very cold areas

It is recommended to use your device at temperatures from (-)20 °C to (+)60 °C.

Do not store your device near magnetic fields

Do not use or store your device in areas with high concentrations of dust or airborne materials

Keep your device dry

Do not turn on your device if it is wet. If your is already on, turn it off (if the device will not turn off, leave as it as-is). Then, dry the device with a towel and take it to a service centre.

Do not use the device for anything other than its intended use

Any changes or modifications to your device can void your manufacturer's warranty

If your device needs servicing, take your device to a Samsung Service Centre.

Correct disposal of this product

(Waste Electrical & Electronic Equipment)



(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

This EEE is compliant with RoHS.

Correct disposal of batteries in this product

(Applicable in countries with separate collection systems)



The marking on the battery, manual or packaging indicates that the battery in this product should not be disposed of with other household waste. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66.

The battery incorporated in this product is not user replaceable. For information on its replacement, please contact your service provider. Do not attempt to remove the battery or dispose it in a fire. Do not disassemble, crush, or puncture the battery. If you intend to discard the product, the waste collection site will take the appropriate measures for the recycling and treatment of the product, including the battery.

FCC ID: A3LEJ-BT230

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Any changes or modifications (including the antennas) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

Part 15.105 (B) :

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment under FCC rules.

RF Exposure Statement (2.1091)

FCC RF Radiation Exposure Statement: This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

RF du FCC d'exposition aux radiations: Cet équipement est conforme à l'exposition de la FCC rayonnements RF limites établies pour un environnement non contrôlé. Cet appareil et son antenne ne doivent pas être co-localisés ou fonctionnant en conjonction avec une autre antenne ou transmetteur.

IC: 649E-EJBT230

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radio électrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.