

SAMSUNG

Universal user manual

S Charger Pad



CE 0678

www.samsung.com

Printed in Korea
E type. 09/2014

GH68-42455A Rev.1.0

Safety information

To prevent injury to yourself and others or damage to your device, read the safety information about your device before using the device

Samsung cannot be held responsible for any injury or property damage caused by failure to comply with the safety cautions and regulations

Do not use damaged power cords or plugs, or loose electrical sockets

Do not touch the power cord with wet hands or disconnect the charger by pulling the cord

Do not bend or damage the power cord

Do not store your device with metal objects, such as coins, keys, and necklaces

Your device may be scratched or may malfunction.

Do not use your device for a while if the device is overheated

Prolonged exposure of your skin to an overheated device may cause low temperature burn symptoms, such as red spots and pigmentation.

Do not store your device near or in heaters, microwaves, hot cooking equipment, or high pressure containers

Your device may overheat and cause a fire.

Do not drop your device or cause impacts to your device

- Store your device only on flat surfaces.
- If your device falls, it may be damaged.

Do not use the device for anything other than its intended use

Your device may malfunction.

Do not bite or suck the device or the battery

Doing so may damage the device or result in an explosion or fire.

Keep your device dry

- Humidity and liquids may damage the parts or electronic circuits in your device.
- Do not turn on your device if it is wet. If your device is already on, turn it off and remove the battery immediately (if the device will not turn off or you cannot remove the battery, leave it as-is). Then, dry the device with a towel and take it to a service centre.

Do not disassemble, modify, or repair your device


- Doing so may cause electric shock.
- Any changes or modifications to your device can void your manufacturer's warranty. If your device needs servicing, take your device to a Samsung Service Centre.

When cleaning your device, mind the following

- Wipe your device or charger with a towel or an eraser.
- Do not use chemicals or detergents. Doing so may discolour or corrode the outside the device or may result in electric shock or fire.

- *This manual's images and content may differ from the product.*
- *The content of this manual is based on EP-PN915I.*

Overview




Check the product box for the following items: Wireless Charging Pad and user manual. The items supplied with the Wireless Charging Pad and any available accessories may vary depending on the region.

Using the Wireless Charging Pad

1 Connect the Wireless Charging Pad and a charger with a charging cable, and plug the charger into an electric socket.

- When the Wireless Charging Pad is connected to the electric socket, the indicator light flashes from red to green to orange, and then turns off.




Use only Samsung-approved chargers (over 2 A). Unauthorised chargers may cause damage or the Wireless Charging Pad may malfunction.



- The charger and the charging cable are sold separately.
- To save energy, unplug the charger when not in use. The charger does not have a power switch, so you must unplug the charger from the electric socket when not in use to avoid wasting power. The charger should remain close to the electric socket and easily accessible while charging.
- The socket-outlet shall be installed near the equipment and shall be easily accessible.

2 With a Wireless Charging Cover attached, place the mobile device on the centre of the Wireless Charging Pad.



Indicator light	Device status
Red → Green → Orange	When connecting to the power outlet
Flashes orange	When not charging properly
Green	When charging properly
Flashes green	When using a charger under 2 A
Off	When in Idle mode



- The Wireless Charging Pad's indicator light flashes differently depending on its status. If the indicator light is not working properly, reconnect the charger to the Wireless Charging Pad.
- The Wireless Charging Cover is sold separately.


3 When the mobile device is fully charged, disconnect the charger from the Wireless Charging Pad.



- Check the mobile device's battery status using the charging icon displayed on the screen.
- Do not place any other object between the mobile device and the Wireless Charging Pad. The mobile device may not charge properly.
- Charging a mobile device with the Wireless Charging Pad in an area with a weak signal may cause a significant drop in reception.
- The Wireless Charging Pad is compatible with WPC certified devices.

Do not place the Wireless Charging Cover solely on the Wireless Charging Pad

Doing so may overheat the Wireless Charging Pad and cause a fire. It may also result in serious burn or device malfunction.



Correct disposal of this product

(Waste Electrical & Electronic Equipment)



(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other

household waste.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

This product is RoHS compliant.

**Samsung Electronics (UK) Ltd, Euro QA Lab.
Blackbushe Business Park. Saxony Way, Yateley,
Hampshire, GU46 6GG,
United Kingdom**



FCC ID: A3LEP-PN915IWU

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

RF Exposure Statement (2.1091)

FCC RF Radiation Exposure Statement: FCC RF Radiation Exposure Statement: This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

RF du FCC d'exposition aux radiations: Cet équipement est conforme à l'exposition de la FCC rayonnements RF limites établies pour un environnement non contrôlé. L'antenne pour ce transmetteur ne doit pas être même endroit avec d'autres émetteurs sauf conformément à la FCC procédures de produits Multi-émetteur.

Cet équipement doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur et votre corps.

IC: 649E-EPPN915IWU

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Industry Canada RF Radiation Exposure Statement

This equipment complies with Industry Canada RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

RF de l'Industrie Canada d'exposition aux radiations: Cet équipement est conforme à l'exposition de l'Industrie Canada rayonnements RF limites établies pour un environnement non contrôlé. L'antenne pour ce transmetteur ne doit pas être même endroit avec d'autres émetteurs sauf conformément à l'Industrie Canada procédures de produits Multi-émetteur.

Cet équipement doit être installé et utilisé avec une distance minimale de 20cm entre le radiateur et votre corps.