



Get to Know Your Tablet

SAMSUNG


Galaxy Tab[®] S2

Setting Up Your Phone

Welcome to Verizon Wireless. You're now part of a growing movement that's about speed, signal and strength. This guide will show you how to set up and use your phone, access special features, and find help.


Step 1. Insert the SIM Card

1. Hold the device securely.
2. Use the SIM removal tool that came with your phone to open the SIM card tray.
3. Carefully place the new SIM card into the tray with the carrier logo facing up.



Step 2. Charge the Phone

Before turning on your tablet charge it fully. Your tablet comes with an Adaptive Fast Charging charger and a USB cable. Plug the smaller end of the cable into the USB/charger port on your phone and the other end into the charger. Then plug the charger into an electrical outlet to charge the device.




WARNING! Please use only an approved charging accessory to charge your tablet. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void the warranty.


Optional: Insert the microSD Card

If you have a microSD card, slide the microSD card into the microSD card slot.


1. Hold the tablet securely.
2. Use the SIM removal tool that came with your phone to open the microSD card tray.
3. Carefully place the microSD card into the tray with the carrier logo facing up.



NOTE: The microSD card is sold separately.



NOTE: Devices and software are constantly evolving—the screen images and icons you see here are for reference only.



Using Your Tablet

Turning Your Phone On/Off

To power on your tablet:

Press and hold the **Power/Lock** key on the top of your tablet.

To power off your tablet:

1. Press and hold the **Power/Lock** key until the tablet options screen appears.
2. Tap **Power off** → **OK**.

Using Verizon Wireless Service – Activate Your Tablet

Activate your tablet to use the Internet on Verizon's super-fast 4G LTE network.

1. Make sure your SIM card is inserted and turn on your tablet.
2. Follow the onscreen instructions in the Setup Wizard to sign up for a data plan.

Initial Device Configuration

1. Select a language and tap  or tap **ACCESSIBILITY** if you are visually impaired or hard of hearing.
2. Follow the prompts to complete the setup process.

Customize

1. Tap and hold a blank space on one of the home screens and choose:
 - **Wallpapers** allows you to assign the current wallpaper for the Home screen, Lock screen, or Home and lock screens.
 - **Widgets** allows you to quickly access the Widget tab where you can then drag a selected widget to an available area on a selected screen.

NOTE: To remove a Widget from a Home screen, tap and hold the Widget and drag it to the top trash can icon to remove.

Locking/Unlocking Your Tablet

To lock the screen:

- Press the **Power/Lock** key.

To unlock the screen:

- Press the **Power/Lock** key. Then drag your finger across the screen in any direction.

Using the Touch Screen

Use touch gestures to move around the screen, open menus, select items, zoom in or out on Web pages, and more.

Swipe—Swipe by quickly sliding your finger in any direction.

Drag—Drag by touching an item and sliding it to a new position.

Double-Tap—Tap two times rapidly to zoom in or out on a web page or picture.

Multi-Touch—Pinch or spread your thumb and index finger to zoom in or out.

Connecting to Wi-Fi

1.  →  →  From the Home screen, tap **Apps** → **Settings** → **Wi-Fi**.
2. Slide the **Wi-Fi** slider to the right to turn it on.
3. Tap an available Wi-Fi network.
If the Wi-Fi network is open, you will be automatically connected. If the Wi-Fi network is secured, enter the password at the prompt to connect.

Connecting to Bluetooth® Devices

1.  →  →  From the Home screen, tap **Apps** → **Settings** → **Bluetooth**.
2. Slide the **Bluetooth** slider to the right to turn it on. When active,  appears in the status area of the screen.
3. Make sure the other device you are pairing with is in discoverable mode.

NOTE: Refer to the guide that came with the other device for details.

4. The tablet will automatically scan for nearby devices.
5. Tap a device to connect.
6. If necessary, tap **Pair**, or enter the device passkey (commonly 0000) to connect to the device. When the device is connected,  appears in the status area.

Taking Photos

1.  From the Home screen, tap **Camera**.
2. Aim your camera and use your tablet's screen to compose your shot.
3. Tap the screen to focus.
4.  Tap **Camera** icon to take the picture.

Setting Up Email

1.  →  From the Home screen, tap **Apps → Email**.
2. Choose an account to setup.
3. Enter the requested information and follow the prompts to complete.

Browsing the Web

Take the Internet with you on the go. You can reach the latest news, get the weather and follow your stocks.

-  From the Home screen, tap **Chrome**.

Google Play Store

Choose from thousands of available apps.



From the Home screen, tap **Play Store**.

Installing Apps

1.  From the Home screen, tap **Play Store** → **APPS**.
2. Tap an app you want to download and tap **Install** or the app's price.
3. Tap **Accept** after reviewing the app's permissions.

Viewing Apps

1.  From the Home screen, tap **Play Store**.
2. Tap  in the upper left corner, and then tap **My apps** to view your downloaded apps.

Uninstalling Apps

1.  From the Home screen, tap **Apps**.
2. Tap and hold the app you want to uninstall and drag it to the trash can.

Improving Accessibility

Adjust accessibility settings to assist users who have impaired vision or hearing or reduced dexterity.

1.  →  →  From the Home screen, tap **Apps** → **Settings** → **Accessibility**.
2. Tap a category and set the desired options to improve accessibility.

Using TalkBack

TalkBack provides screen reading to assist people with impaired vision.

1.  →  →  From the Home screen, tap **Apps** → **Settings** → **Accessibility** → **Vision**.
2. Tap **TalkBack**, then tap the **TalkBack** switch to turn it on.
3. Tap **Settings** at the bottom of the screen to adjust the **TalkBack** settings.

NOTE: When TalkBack is on, double-tap when you hear the item you want. (You can change to single-tap in Settings.)

Support & More

My Verizon Mobile App



Manage your account, track your usage, edit account information, pay your bill and more.

Get Help Using Your Phone



Use your Help app to get assistance at your fingertips, right from your phone.



From your computer, visit verizonwireless.com/support.

Customer Service



Call (800) 922-0204.

Follow us [@VZWSupport](https://twitter.com/VZWSupport). 

More Information



Download a User Guide from verizonwireless.com/support or call (XXX) XXX-XXXX to order a copy.

Customer Information

Your Wireless Device and Third Party Services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this wireless device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this wireless device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use, and privacy policies shall apply. Please review carefully all applicable terms and conditions and policies prior to using this wireless device and any associated application, product or service.