

- **Caution** : If you connect several hard disk, you could have wrong number.

Please choose the 0% number as the picture.

- ⑦ Press "Esc" -> choose the "No. 1 select the logic dos drive or partition" among the fdisk option items -> type "No.1" -> press "Enter"
- ⑧ Choose "No.1 basic DOS partition" among select the logic dos drive or partition --> type "No.1" --> press "Enter"
- ⑨ Just wait for the "no formation test"
- ⑩ After finishing the "no formation test" you can find the message " Will you use the whole capacity for basis DOS partition?" -> type "Y" -> "Enter"
- ⑪ Type the "needed capacity or 0%" directly and press " Enter"
- ⑫ After finishing the "no formation test" again, you can find the message "select basis Dos partition, the drive word is changed or added" then press "Esc" to return to Fdisk option.
- ⑬ Press "Esc" -> find the message " re-start the computer" -> press "Esc" again
- ⑭ If you find C:\> press " Exit" to return to Windows.
- ⑮ Separate the FHD-254 from the computer Connect the FHD-254 to USB port or IEEE 1394 port in computer again
- ⑯ The "drive word" will be created in " my computer"
- ⑰ Choose the drive -> press the right side of Mouse and do the format (M)

## 2. Windows 2000

### ■ **The way to Fdisk and Format with new hard disk (with one drive)**

- ① Install the driver before connecting the product to computer. (for USB way)
- ② Install the driver and then connect the product to the USB port or IEEE 1394 port in computer.
- ③ Click "my computer" in the screen with the right side of Mouse -> choose management.
- ④ Click "not allotted (ex. disk 1)" in disk management with the right side of Mouse and make.
- ⑤ Coming out the disk you have to check and click "Next"
- ⑥ Coming out the disk signature and finishing upgrade magician, click "Finish"

- ⑦ Click the drive of "not allotted" in disk management with the right side of Mouse.
- ⑧ Choose the "making partition" among the menu.
- ⑨ After complete the "making partition magician" click "Next"
- ⑩ Checking if the "main partition(P)" is selected in kinds of partition, click "Next"
- ⑪ Type the needed capacity at "disk space" among the partition and click Next"
- ⑫ If the drive word is allotted, click "Next"
- ⑬ Choose the kind of file system (NTFS or FAT32) among the partition format.  
And click "Next" <picture

■ **Caution** : 1. The NTFS file system will be recognized only in " Windows 2000/XP".

If you want to use it with "Windows 98/ME", please choose "FAT32" system.

2. If you designate the file system as " FAT32" way in Windows 2000/XP, the drive word in over 32GB hard disk can not be one.

If you want to make the partition as "one", make partition and format in Windows 98/ME.

And also if you want to devide over 40GB hard disk into several partition, make it with "main partition(P)"

As the "expansion partition" can not be recognized, please make it with "main partition(P)"

- ⑭ After completing the "making partition magician", click "Finish"
- ⑮ It will be format automatically

### 3. Windows XP

Click "my computer" in the screen with the right side of Mouse -> choose management. If you can not find "management" --> start --> Click "my computer" in the screen with the right side of Mouse

■ **The way to Fdisk and Format with new hard disk (with one drive)**

- ① Install the driver before connecting the product to computer. (for USB way)
- ② Install the driver and then connect the product to the USB port or IEEE 1394 port in computer.

- ③ Click "my computer" in the screen with the right side of Mouse -> choose management
- ④ Click "not allotted (ex. disk 1)" in disk management with the right side of Mouse and initialize
- ⑤ Choosing the initialized disk, click "Next"
- ⑥ Coming out "Finish changing magician and disk initialization" --> choose "Next"
- ⑦ Click the drive of "not allotted" in disk management with the right side of Mouse
- ⑧ After complete the "making partition magician" click "Next"
- ⑨ Checking if the "main partition(P)" is selected in kinds of partition, click "Next"
- ⑩ Type the needed capacity at "disk space" in partition size and click Next"
- ⑪ If the drive word is allotted, click "Next"
- ⑫ Choose the kind of file system (NTFS or FAT32) among the partition format. And click "Next"

■ **Caution** : 1. The NTFS file system will be recognized only in " Windows 2000/XP".

If you want to use it with "Windows 98/ME", please choose "FAT32" system.

2. If you designate the file system as " FAT32" way in Windows 2000/XP, the drive word in over 32GB hard disk can not be one.

If you want to make the partition as "one", make partition and format in Windows 98/ME.

And also if you want to devide over 40GB hard disk into several partition, make it with "main partition(P)"

As the "expansion partition" can not be recognized, please make it with "main partition(P)"

- ⑬ After completing the "making partition magician", click "Finish"
- ⑭ It will be format automatically

## 7. Please check when you have some troubles

### 1. Loss of data

Completing the disk slice assemble or checking the disk error with "precision", the data can bring a loss. Please avoid above operations.

### 2. Finding the message "HI-SPEED USB INSTALLATION is fixed incorrectly to HI-SPEED USB INSTALLATION herb"

It means the USB 2.0 product is connected to USB 1.1 Host Adapter on Windows XP.  
USB 2.0 product(max. 480Mbps) is connected to USB 1.1 Host Adapter and it works  
USB 1.1 speed(max. 12Mbps)

### 3. When you connect the product in your computer and if it is making a rattling sound, it means the lack of power.

Connect the offered USB power cable to the other USB port and then connect the power cable to FHD-254  
(especially for using IBM HDD (1.0A) and HDD(Tosiba 0.7A) product ,sometimes can make lack of power.. In this case, please connect the USB power cable or power adapter)

## Specification

Model	<b>FHD-254</b>	
Interface	USB 2.0 (PL)	FireWire
Data transmission speed	480Mbps(USB 2.0)	400Mbps(Firewire)
Weight	with hard (180g)	without hard (90g)
Size	127.2 x 75.6 x 15.5mm	
Power	Interface power or adapter	
OS Supported	Windows 98 SE/ME/2000/XP, Mac OS 8.6/9.x/X.x	