



# **User Manual**

## **1.FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## **2.RF Exposure Information**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.







#### WHAT ARE THE BUTTONS AND PORTS?

1. Power Button
2. USB Type-C Port (For Supply Power and Data Transfer)
3. Microphone
4. Audio Speaker
5. Sensor
6. Touch Screen Display
7. RS485
8. POE (For Ethernet and Power)

**SAFETY PRECAUTIONS:**

- Use the product only as intended.
- Use only in environments with temperatures between 5°C to 40°C (41°F to 104°F).
- Avoid dropping the unit on hard surfaces.
- Avoid exposure to liquids, moisture and direct sunlight.
- Do not attempt to disassemble, repair, or modify the product. Please contact customer service for additional questions and support.

## Installation Guide

| Step | Instructions   | Graphic  |
|------|--|--|
| 1    | Open the box and inspect all hardware to ensure damage did not occur during transport.   |  A black rectangular device is shown next to its open white packaging box. The box is open, revealing the interior compartments and the device inside. The device has a small label on its top right corner. |
| 2    | Install the holder on the wall   |  A close-up shot of a hand using a yellow power drill to install a wooden holder on a wall. The drill is positioned against the wood, and the hand is holding it steady.                                    |
| 3    | Plug the machine into an outlet that is always powered "On" and is less than 40 feet from all smarthome devices and accessories. |  The back of the device is shown, featuring a power port and a data port. The device is black with a silver-colored metal plate in the center.   |
| 4    | (Optional) Securely mount the machine to the wall if it turned on successfully.  |  The front of the device is shown, displaying the SAMI logo. The device is black with a silver-colored metal plate in the center. A small label is visible in the bottom left corner.                      |

