



OPERATING INSTRUCTIONS

BATTERY LOADING:

(FOR MAXIMUM PERFORMANCE, USE ALKALINE BATTERIES)
Remember to take out all batteries from the vehicle and transmitter after playing.

1. Do not mix old and new batteries.
2. Do not mix alkaline, standard (Carbon-Zinc), or rechargeable batteries.

HOW TO INSTALL BATTERIES IN VEHICLE

1. Push the ON/OFF switch to "OFF" position on the underside of the vehicle. (See Diagram 1)
2. Turn the latch to open the battery case cover and insert five fresh AA size alkaline batteries as indicated following the engraved (+) (-) polarity. (See Diagram 2)
3. Replace the battery case cover and turn the latch to lock it.

HOW TO INSTALL BATTERY IN TRANSMITTER

1. Remove battery cover and install 2 "AA" batteries by matching + and - poles as indicated in the battery compartment (see diagram #3)
2. Replace the battery cover.

NOTE: REMOVE BATTERY AFTER YOU HAVE FINISHED USING YOUR VEHICLE.

HOW TO PLAY

1. Build up antenna by passing the cable through the antenna tube provided and plug into the vehicle tightly. Otherwise, the vehicle will not work. (See Diagram 4)
2. Push the ON/OFF switch to the "ON" position of the vehicle. (See Diagram 1)

FORWARD RUNNING

3. Push the Driving Control Stick forward for forward running. (See Diagram 5).

REVERSE RUNNING

4. Pull the Driving Control Stick backward for reverse running. (See Diagram 6)

FRONT WHEELS STEERING ADJUSTMENT

5. If the vehicle does not run straight forward, adjust the lever for satisfactory alignment on the underside of the vehicle. (See Diagram 7)

STEERING OPERATION

6. Turn the Steering Control Stick to the left or right while pushing the Driving Stick forward at the same time, the car will turn left or right and run forward. (See Diagram 8)
7. Turn the Steering Control Stick to the left or right while pulling the Driving Stick backward at the same time, the car will turn left or right and run backward. (See Diagram 9)

STOP OPERATION

8. Release both Control Sticks, the vehicle will stop. (See Diagram 10)

PERFORMANCE TIPS:

- Don't drive in grass, sand or carpet.
- Don't go through water.
- Always use fresh alkaline batteries.
- Be sure to rest your vehicle for at least 30 minutes after every 15 minutes of operation.
- Make sure ON/OFF switch on your vehicle is OFF when not in use.
- Don't bend antenna.
- Electrical, CB interference, mobile phones, air conditioning, elevators and steel girders in building will affect the operation of your vehicle.
- Don't leave the vehicle or transmitter near sources of heat or under direct sunlight for long periods of time.
- Remove the batteries from the vehicle and transmitter when not in use.
- Non-rechargeable batteries are not to be re-charged (9V Battery).
- Different types of batteries or new and used batteries are not to be mixed.
- Rechargeable batteries are only to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Only batteries of the same or equivalent type as recommended are to be used
- The supply terminals are not to be short-circuited.
- Do not use rechargeable batteries (for 9V battery).
- Do not overcharge the rechargeable battery pack.
- ATTENTION: Battery/ Batteries should be installed by adult only.

FCC NOTE:

THE ANTENNA PROVIDED IS A UNIQUE ANTENNA. BY INSTALLATION OF UNAUTHORIZED ANTENNA TO THIS EQUIPMENT. SUCH UNAUTHORIZED INSTALLATION COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

ATTENTION PARENTS:

IT IS RECOMMENDED THAT THIS TOY AND ALL ACCESSORIES BE PERIODICALLY EXAMINED FOR POTENTIAL HAZARDS AND THAT ANY POTENTIALLY HAZARDOUS PARTS BE REPAIRED OR REPLACED.



CE 0681 !

EZTEC

EZ-TEC IS A REGISTERED TRADEMARK OWNED BY SCIENTIFIC TOYS, LTD.

© 2006 SCIENTIFIC TOYS, LTD., CHAI WAN, HONG KONG.

Visit us at www.ez-tec.com

PRINTED IN CHINA

O.I. NO.3630